06

GENERAL INFORMATION	06-5	P0558 17	06-74	Į.
Description	06-5	P1137 17	06-74	Ļ
System Function	06-7	P1138 16	06-74	Ļ
Precautions	06-8	P1139 7A	06-74	ŀ
Specifications	06-9	P1479 00	06-74	Ļ
Tools	06-9	P0111 00	06-81	l
ECM Terminal Definition	06-11	P0112 16	06-81	l
Circuit Diagram	06-13	P0113 17	06-81	l
DIAGNOSIS & TESTING	06-23	P0116 00	06-87	7
	06-23	P0117 16	06-87	7
Diagnostic Help	06-23	P0118 17	06-87	7
Intermittent DTC Troubleshooting	06-23	P0121 29	06-94	ļ
Ground Inspection	06-23 06-24	P0122 16	06-94	ļ
Throttle Self-learning Diagnostic Trouble Code (DTC)	06-24	P0123 17	06-94	ļ
Chart	06-24	P0221 29	06-94	Ļ
ECM Power Supply Circuit &	00-24	P0222 16	06-94	ļ
Ground Circuit Testing	06-33	P0223 17	06-94	ļ
P0030 13	06-40	P0130 00	06-101	l
P0031 11	06-40	P0131 16	06-101	l
P0132 12	06-40	P0132 17	06-101	
P0053 1E	06-40	P0133 00	06-101	
P0036 13	06-47	P0134 00	06-101	l
رو سامانه (مسئولي <mark>11 P0037</mark> وه	06-47	P0170 00	06-101	ı
P0038 12	06-47	P0171 00	06-101	l
P0054 1E	06-47	P0172 00	06-101	l
P0201 13	06-54	P2195 00	06-101	ı
P0202 13	06-54	P2196 00	06-101	l
P0203 13	06-54	P0136 00	06-107	7
P0204 13	06-54	P0137 16	06-107	7
P0261 11	06-54	P0138 17	06-107	7
P0262 12	06-54	P0140 00	06-107	7
P0264 11	06-54	P2270 00	06-107	7
P0265 12	06-54	P2271 00	06-107	7
P0267 11	06-54	P0606 94	06-113	3
P0268 12	06-54	P0606 92	06-113	3
P0270 11	06-54	P0606 64	06-113	3
P0271 12	06-54	P0606 61	06-113	3
P0105 28	06-61	P0606 67	06-113	3
P0106 00	06-61	P0606 96	06-113	3
P0107 11	06-61	P0606 1C	06-113	3
P0108 12	06-61	P0606 55	06-113	3
P0234 00	06-67	P0606 00	06-113	3
P0237 16	06-67	P0606 62	06-113	
P0238 17	06-67	P0606 63	06-113	3
P0556 00	06-74	P0606 48	06-113	3
P0557 16	06-74	P0606 47	06-113	3

n	\boldsymbol{c}
	n
U	U

P0606 75	06-113	P0688 91	06-188
P0606 49	06-113	P0688 92	06-188
P1100 00	06-113	P1130 00	06-193
P2122 16	06-118	P1131 17	06-193
P2123 17	06-118	P1132 16	06-193
P2127 16	06-118	P1133 13	06-193
P2128 17	06-118	P1427 12	06-193
P2138 00	06-118	P1428 11	06-193
P2138 29	06-118	P1429 13	06-193
P0300-00	06-125	P023A 00	06-198
P0301-00	06-125	P023B 00	06-198
P0302-00	06-125	P023C 00	06-198
P0303-00	06-125	P1700 00	06-198
P0304-00	06-125	P1703 00	06-198
P0322 00	06-133	P1704 00	06-198
P0327 16	06-139	P1705 00	06-198
P0327 14	06-139	P1706 00	06-198
P0327 00	06-139	P1707 00	06-198
P0328 17	06-139	P1708 00	06-198
P0328 15	06-139	P1709 00	06-198
P0328 00	06-139	P0571 29	06-205
P0341 00	06-144	P0571 1C	06-205
P0012 00	06-144	P0568 1C	06-212
P0016 22	06-144	P0568 86	06-212
P0016 21	06-144	P0568 81	06-212
در و سامانه (مسئول 29_P0016	06-144	P0601 00	06-217
P0018 22	06-151	P0604 43	06-217
P0018 21	06-151	P0605 43	06-217
ال تعميركاران خودر 29 P0018	06-151	P1614 00	06-219
P0346 00	06-151	P1615 00	06-219
P0420 00	06-158	P1616 00	06-219
P0444 13	06-160	P1617 00	06-219
P0458 16	06-160	P1618 00	06-219
P0459 17	06-160	P1619 00	06-219
P0480 13	06-167	U0001 88	06-224
P0691 11	06-167	U0101 87	06-224
P0692 12	06-167	U0129 87	06-224
P0481 13	06-167	U0140 00	06-224
P0693 11	06-167	U0214 87	06-224
P0694 12	06-167	U0140 87	06-224
P0560 00	06-173	U0155 87	06-224
P0562 16	06-173	U0121 87	06-224
P0563 17	06-173	P000A 00	06-229
P1101 00	06-173	P000A 77	06-229
P0645 13	06-178	P0010 13	06-229
P0646 11	06-178	P2088 11	06-229
P0647 12	06-178	P2089 12	06-229
P0627 13	06-183	P000B 00	06-236
P0628 11	06-183	P000B 77	06-236
PU020 11	00 100	1 000B 11	
P0629 12	06-183	P0013 13	06-236

P0015 00		06-236	Description	06-284
P2090 11		06-236	Operation	06-284
P2091 12		06-236	Removal	06-284
P0033 13		06-242	Installation	06-284
P0034 11		06-242	Oxygen Sensor	06-285
P0035 12		06-242	Description	06-285
P2261 00		06-242	Operation	06-285
P0234 00		06-248	Upstream Oxygen Sensor	06-285
P0243 13		06-248	Downstream Oxygen Sensor	06-285
P0245 11		06-248	Removal & Installation - Upstream	00 200
P0246 12		06-248	Oxygen Sensor	06-285
Engine Problen	n Symptom	00 2-10	Removal & Installation - Downstream	
Diagnosis	i Cymptom	06-255	Oxygen Sensor	06-285
Diagnostic He	n	06-255	Camshaft Position Sensor	06-286
Problem Symp	•	06-255	Description	06-286
	ot crank or cranks	00 200	Operation	06-286
slowly while sta		06-257	Removal	06-286
-	normally but cannot		Installation	06-286
•	Illy while starting	06-259	Engine Speed Sensor	06-287
	t with hot engine	06-261	Description	06-287
	t with cold engine	06-263	Operation	06-287
	s normal, but it is		Removal	06-287
difficult to start		06-265	Installation	06-287
	ormally, but idles		Boost Pressure/Temperature	00-207
roughly at anyt		06-267	Sensor	06-288
Engine starts n	ormally, but idles		Description	06-288
roughly during	warming up	06-269	Operation	06-288
_	ormally, but idles		Removal	06-288
roughly after w		06-271	Installation	06-288
	ormally, but idles		Ignition Coil	06-289
	s with partial load	06-273	Description	06-289
(for example, A	•	06-273	Operation	06-289
speed is too high	ormally, but idle	06-274	Removal & Installation	06-289
•	s too low or engine	00-214	Electronic Accelerator Pedal	00-203
stalls when acc	•	06-275	Sensor	06-290
	when accelerating	06-277	Description	06-290
Lack of power a	•		Operation	06-290
•	hen accelerating	06-279	Removal & Installation	06-290
-	_	00 000	Electric Fuel Pump	06-291
ON-VEHICLE SI		06-282	Description	06-291
VVT Control Va	lve	06-282	Operation	06-291
Description		06-282	Removal & Installation	06-291
Operation		06-282	Fuel Injector	06-292
Removal		06-282	Description	06-292
Installation		06-282	Operation	06-292
Coolant Tempe	rature Sensor	06-283	Removal & Installation	06-292
Description		06-283	Canister Solenoid Valve	06-292 06-292
Operation		06-283		
Removal		06-283	Description	06-292
Installation		06-283	Operation	06-292
Knock Sensor		06-284	Removal & Installation	06-292

Engine Control Module (ECM)	06-293	Removal	06-293
Description	06-293	Installation	06-293
Operation	06-293		

06



GENERAL INFORMATION


Description

Engine of M1A model adopts Bosch ME1788 engine management system. This system mainly consists of Engine Control Module (ECM), sensors and actuators, which controls intake air amount, injection volume and ignition timing, etc. when engine is operating.

In the engine management system, sensors are used as the input part to measure various physical signals (temperature and pressure, etc.), and converts them into corresponding electrical signals; the function of ECM is to receive the input signals from sensors and perform calculation according to set procedure, producing corresponding control signals and outputting them to power drive circuit. The power drive circuit drives each actuator to perform various actions, thus making the engine run according to the preset program.

Also, the trouble diagnosis system of ECM monitors each component and control function in this system. Once detecting and confirming a fault, it will store the trouble code. When detecting that fault has been eliminated, it will return to use normal value.

Basic Components of Engine Management System



1 - Engine Control Module (ECM)	2 - Intake Pressure/Temperature Sensor
3 - Electronic Throttle	4 - Camshaft Position Sensor
5 - Coolant Temperature Sensor	6 - Crankshaft Position Sensor
7 - Oxygen Sensor	8 - Electronic Accelerator Pedal
9 - Knock Sensor	10 - Ignition Coil
11 - Fuel Injector	12 - Electric Fuel Pump
13 - VVT Control Valve	14 - Canister Solenoid Valve
15 - Electrical Water Pump	16 - Turbocharger Control Valve
17 - Boost Actuator	18 - Boost Pressure Sensor





System Function

· Calculate air flow

ECM calculates air flow entering the cylinder by signals from intake pressure/temperature sensor, and then adjusts injection volume to make air-fuel ratio meet the requirements of various operating conditions.

Measure crankshaft position and engine speed

ECM determines the crankshaft position and engine speed according to signals from crankshaft position sensor, and accurately controls the engine ignition and injection timing.

• Determine operating sequence of cylinders

ECM recognizes the top dead center of cylinder 1 by camshaft position sensor, so as to determine the operating sequence of cylinders.

Fuel control

There are two modes of fuel control: closed-loop fuel control and open-loop fuel control. Closed-loop fuel control can accurately regulate the air-fuel ratio of engine, thus effectively controlling emissions. Open-loop fuel control is applied when engine is starting or warming up and when oxygen sensor is malfunctioning.

Ignition control

Ignition control system of this engine adopts individual control.

Knock control

When a knocking is detected by knock sensor, system will calculate the ignition advance angle that needs to be delayed or advanced according to current operating conditions and knock intensity and adjust the ignition angle, thus avoiding or reducing knocking.

Emission control

Three-way catalytic converter can convert engine exhaust gas into harmless gas and discharge it into atmosphere. When engine temperature becomes normal after warming up, ECM will activate closed-loop fuel control to correct the air-fuel ratio, thus realizing the optimum conversion efficiency of three-way catalytic converter.

Three-way catalytic converter protection

Engine management system has the function to protect three-way catalytic converter. ECM estimates the three-way catalytic converter temperature according to engine operating conditions. When it is estimated that exhaust temperature will exceed the converter's maximum permissible temperature for a long time, ECM will automatically activate the protection function of three-way catalytic converter to keep the temperature normal.

System voltage protection

When system voltage becomes extremely high due to charging system malfunction, engine management system will activate the protection program to limit engine speed, thus avoiding damage to ECM and battery.

Precautions

General service requirements

- Only digital multimeter can be used to perform inspection for engine management system.
- Use genuine components to perform service work, otherwise appropriate engine management system operation cannot be guaranteed.
- Only use unleaded gasoline during servicing.
- Please observe normative service and diagnostic flowchart to perform service work.
- Never disassemble components of engine management system during servicing.
- When holding electronic elements (ECM and sensor etc.) during servicing, take extra care not to drop them on the ground.
- Set up a consciousness of environmental protection and dispose of the waste effectively that is produced during servicing.

Precautions during servicing

- 1. Do not causally remove any engine management system component or its connector from its installation position to prevent damaging accidentally, or foreign matter, such as moisture, oil from entering connectors, which will affect the normal operation of engine management system.
- 2. Be sure to turn ignition switch to OFF when disconnecting and connecting connectors. Otherwise electronic elements may be damaged.
- 3. When simulating hot operating condition of malfunction and performing other service work that may cause temperature to rise, never allow temperature of ECM to exceed 80°C.
- 4. As the supplying pressure of fuel system is high (approximately 400 kPa), all fuel pipes are high pressure resistant pipe. Fuel pressure in fuel lines is still high even when engine is not running. Therefore, be careful not to casually remove fuel pipes during servicing; when it is necessary to service fuel system, discharge pressure in the fuel system before removing fuel pipes. The way to discharge pressure is as follows:
- Remove fuel pump relay, start engine and idle it until the engine stops running by itself. Then try to start
 engine 2 3 times to ensure fuel pressure is discharged completely. Removal of fuel pipes and
 replacement of fuel filter should be performed in a well-ventilated area by professional service men.
 - 5. Do not energize electric fuel pump when removing it from fuel tank to prevent electric sparks, which will cause a fire.
 - 6. Running test for fuel pump is prohibited when it is empty or in water; otherwise it will shorten the service life. Never connect the positive and negative of fuel pump in reverse.
 - 7. When checking ignition system, only perform spark jump test when it is necessary and duration should be shortened as much as possible. Do not open throttle during test; otherwise a large amount of unburned gasoline will enter the exhaust pipe, causing damage to the three-way catalytic converter.
 - 8. Do not connect battery with its polarity reversed to prevent damage to electronic elements. This system adopts negative ground.
 - 9. Never remove battery cable when engine is running.
 - 10. The positive, negative battery cables and ECM must be removed before performing welding on vehicle.
 - 11. Do not puncture wire outer coat to detect electric signals input and output by components.


Specifications

Torque Specifications

Description	Torque (N·m)
Coolant Temperature Sensor Fixing Bolt	14 ± 1
Intake Pressure/Temperature Sensor Fixing Bolt	6 ± 1
Knock Sensor Fixing Bolt	20 ± 5
Engine Speed Sensor Fixing Bolt	8 ± 2
Camshaft Position Sensor Fixing Bolt	8 ± 1
VVT Control Valve Fixing Bolt	8 ± 2
ECM Fixing Bolt	7 ± 1

Tools

Special Tool



Digital Multimeter	RCH0000002
Cylinder Pressure Gauge	RCH0000044
Fuel Pressure Gauge	RCH0000048
هیتال خودرو سامانه (مسئولیت محدود) انه دیجیتال تعمیرکاران خودرو در ایرار Oscilloscope	RCH0000061

ECM Terminal Definition


ECM Connector

Terminal No.	Description	Terminal No.	Description
1	CAN Bus 1 High	57	-
2	-	58	-
3	-	59	Electronic Accelerator Pedal Sensor 2 Ground
4	-	60	-
5	Main Relay	61	-
6	Clutch Switch	62	Boost Pressure Sensor Temperature Signal
7	Electronic Accelerator Pedal Sensor 1 Ground	63	ECM Ground 2
8	-	64	ECM Ground 1
9	Constant Speed Cruise Signal	65	Exhaust Emission Valve
10	A/C High/Low Pressure Switch Signal	66	-
11		67	Injector in Cylinder 2
12	Brake Vacuum Sensor Signal	68	Injector in Cylinder 1
13 ولىت محد	• • • • • • • • • • • • • • • • • • •	69	Variable Camshaft Timing Valve (Exhaust)
14	-	70	ERCV Valve
درو 15 ایران	UBR Noncontinuous Power Supply	اولیاح سام	Variable Camshaft Timing Valve (Intake)
16	UBR Noncontinuous Power Supply	72	Injector in Cylinder 3
17	CAN Bus 1 Low	73	Upstream Oxygen Sensor Heater
18	-	74	Injector in Cylinder 4
19	5 V Power Supply 1	75	Throttle Actuator (+)
20	UBD Continuous Power Supply	76	Ignition Coil 4
21	Downstream Oxygen Sensor	77	Throttle Position Sensor 1
22	-	78	Throttle Position Sensor 2
23	Brake Switch	79	-
24	A/C Compressor Medium Pressure Switch	80	Oxygen Sensor Ground
25	Brake Light Switch	81	-
26	-	82	-
27	-	83	-
28	A/C Switch	84	Engine Speed Sensor Ground
	-	85	Intake Pressure Sensor (-)
29	-	00	Intako i robbaro beriber ()


Terminal No.	Description	Terminal No.	Description
31	High Speed Fan Control	87	Throttle Actuator (-)
32	Anti-theft Input	88	Ignition Coil 2
33	-	89	Knock Sensor B
34	-	90	Knock Sensor A
35	Ignition Switch	91	Intake Pressure Sensor
36	5 V Power Supply of Electronic Accelerator Pedal Sensor 2	92	PWM Control
37	5 V Power Supply of Electronic Accelerator Pedal Sensor 1	93	Camshaft Position Sensor 1
38	-	94	TEV Carbon Canister Valve
39	-	95	Intake Camshaft Position Sensor Ground
40	-	96	Engine Speed Sensor Signal
41	Fuel Pump Relay	97	-
42	A/C Compressor Relay	98	Camshaft Position Sensor (+5 V)
43	Downstream Oxygen Sensor Ground	99	Ignition Coil 3
44	Bottom Clutch Switch	100	Ignition Coil 1
45	Electronic Accelerator Pedal Sensor 1	101	Engine Coolant Temperature Sensor
46	Boost Pressure Sensor	102	-
47	Analog Ground	103	- 0
48	Downstream Oxygen Sensor Heater	104	Upstream Oxygen Sensor
JUL 49 9JO	انه دیجیتال تعمیرکاران خو	105-9	Exhaust Camshaft Position Sensor
50	-	106	Electric Water Pump Signal
51	-	107	5 V Power Supply of Throttle
52	-	108	Engine Speed Sensor Power Supply
53	-	109	5 V Power Supply of Intake Manifold
54	Electric Vacuum Pump	110	-
55	-	111	ECM Ground 4
56	Low Speed Fan Control	112	ECM Ground 3

Circuit Diagram


Engine Management System (Page 1 of 10)




Engine Management System (Page 2 of 10)




Engine Management System (Page 3 of 10)




Engine Management System (Page 4 of 10)




Engine Management System (Page 5 of 10)




Engine Management System (Page 6 of 10)




Engine Management System (Page 7 of 10)




Engine Management System (Page 8 of 10)



Engine Management System (Page 9 of 10)



Engine Management System (Page 10 of 10)



DIAGNOSIS & TESTING

Diagnostic Help

- 1. Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC), and make it communicate with vehicle electronic module through data network.
- 2. Confirm that malfunction is current, and carry out diagnostic test and repair procedures.
- 3. If DTC cannot be deleted, malfunction is current.
- 4. Only use a digital multimeter to measure voltage of electronic system.
- 5. Refer to any Technical Bulletin that may apply to malfunction.
- 6. Visually check the related wire harness.
- 7. Check and clean all Engine Control Module (ECM) ground points related to current DTC.
- 8. If multiple trouble codes were set, use circuit diagrams and look for any common ground circuit or power supply circuit applied to DTC.

Intermittent DTC Troubleshooting

If malfunction is intermittent, perform the following:

- · Check if connectors are loose.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Monitor X-431 3G diagnostic tester (the latest software) data that is related to this circuit.
- Wiggle related wire harness and connector and observe if signal in related circuit is interrupted.
- If possible, try to duplicate the conditions under which DTC was set.
- Look for data that has changed or DTC to reset during wiggle test.
- Look for broken, bent, protruded or corroded terminals.
- Inspect sensors and mounting areas for damage, foreign matter, etc. that will cause incorrect signals.
- Use data recorder and/or oscilloscope to help diagnose intermittent malfunctions.
- Remove Engine Control Module (ECM) from malfunctioning vehicle and install it to a new vehicle to perform a test. If DTC cannot be cleared, ECM is malfunctioning. If DTC can be cleared, reinstall ECM to original vehicle.

Ground Inspection

Ground points are very important to the proper operation of circuits. Ground points are often exposed to moisture, dirt or other corrosive areas. Corrosion (rust) can increase resistance which will change the way in which a circuit works.

Electrical control circuits are very sensitive to proper grounding. A loose or corroded ground point can seriously affect control circuit. Check ground points as follows:

- 1. Remove ground bolt or nut.
- 2. Check all contact surfaces for tarnish, dirt and rust, etc.
- 3. Clean as necessary to ensure that contacting is in good condition.
- Reinstall ground bolt or nut securely.
- 5. Check if add-on accessories interfere with ground circuit.
- 6. If several wire harnesses are crimped into one ground terminal, check for proper crimps. Make sure that all wires are clean, securely fastened and good contacted without crimping any excessive insulation coat.

Throttle Self-learning

Perform throttle self-learning in the following conditions:

- Battery is removed and negative battery cable is disconnected.
- · ECM is replaced.
- ECM is disconnected and reconnected.
- Throttle is replaced or cleaned.

Throttle self-learning conditions:

- Engine intake temperature > 5°C
- 100.5°C > Engine coolant temperature > 5°C
- Engine speed ≤ 250 rpm
- Vehicle speed = 0 km/h
- Battery voltage > 10 V
- Accelerator pedal opening angle < 14.9%

Throttle self-learning procedures:

Turn ignition switch to ON and then turn to OFF after waiting for 15 seconds. After self-learning is completed, start vehicle and check for proper operation.

Diagnostic Trouble Code (DTC) Chart

P000A 00	Camshaft Control Slow Response (Inlet)
P000A 77	Camshaft Control Target Error (Inlet)
P000B 00	Camshaft Control Slow Response (Outlet)
P000B 77	Camshaft Control Target Error (Outlet)
P0010 13	Control Circuit of Camshaft Control Valve (Inlet)
P0012 00	Inlet Camshaft not in Locking Position During Start
P0013 13	Control Circuit of Camshaft Control Valve (Outlet)
P0015 00	Outlet Camshaft not in Locking Position During Start
P0016 29	Npl Error for Alignment Between Camshaft (Inlet) and Crankshaft
P0016 22	Retard Error for Alignment Between Camshaft (Inlet) and Crankshaft
P0016 21	Advance Error for Alignment Between Camshaft (Inlet) and Crankshaft
P0018 29	Npl Error for Alignment Between Camshaft (Outlet) and Crankshaft
P0018 22	Retard Error for Alignment Between Camshaft (Outlet) and Crankshaft
P0018 21	Advance Error for Alignment Between Camshaft (Outlet) and Crankshaft
P0030 13	O2 Sensor Heater Control Circuit Open (Upstream of the Catalyzer)
P0031 11	O2 Sensor Heater Control Circuit Low (Upstream of the Catalyzer)
P0032 12	O2 Sensor Heater Control Circuit High (Upstream of the Catalyzer)
P0033 13	Dump Valve Control Circuit Open
P0034 11	Dump Valve Control Circuit Low
P0035 12	Dump Valve Control Circuit High
P0036 13	O2 Sensor Heater Control Circuit Open (Downstream of the Catalyzer)
P0037 11	O2 Sensor Heater Control Circuit Low (Downstream of the Catalyzer)
P0038 12	O2 Sensor Heater Control Circuit High (Downstream of the Catalyzer)

P0053 1E	O2 Sensor Heater Resistance Too Large (Upstream of the Catalyzer)
P0054 1E	O2 Sensor Heater Resistance Too Large (Downstream of the Catalyzer)
P0105 28	Manifold Absolut Pressure Circuit No Change
P0106 00	Manifold Abs. Pressure Performance Non-plausible
P0107 11	Manifold Abs. Pressure Low Input
P0108 12	Manifold Abs. Pressure High Input
P0111 00	Intake Air Temp. Circ. Performance Non-plausible
P0112 16	Intake Air Temp. Circ. Low Input
P0113 17	Intake Air Temp. Circ. High Input
P0116 00	Engine Coolant Temp. Circ. Performance Non-plausible
P0117 16	Engine Coolant Temp. Circ. Low Input
P0118 17	Engine Coolant Temp. Circ. High Input
P0121 29	Throttle Pos. Sensor 1 Circ. Performance Non-plausible
P0122 16	Throttle Pos. Sensor 1 Circ. Low Input
P0123 17	Throttle Pos. Sensor 1 Circ. High Input
P0130 00	O2 Sensor Circ. Malfunction (Upstream of the Catalyzer)
P0131 16	O2 Sensor Circ. Low Voltage (Upstream of the Catalyzer)
P0132 17	O2 Sensor Circ. High Voltage (Upstream of the Catalyzer)
P0133 00	O2 Sensor Circ. Slow Response (Upstream of the Catalyzer)
P0134 00	O2 Sensor Circ. No Activity Detected (Upstream of the Catalyzer)
P0136 00	O2 Sensor Circ. Malfunction (Downstream of the Catalyzer)
P0137 16	O2 Sensor Circ. Low Voltage (Downstream of the Catalyzer)
P0138 17	O2 Sensor Circ. High Voltage (Downstream of the Catalyzer)
P0140 00	O2 Sensor Circ. No Activity Detected (Downstream of the Catalyzer)
P0170 00	Fuel Trim, Malfunction
P0171 00	Fuel Trim, System Too Lean
P0172 00	Fuel Trim, System Too Rich
P0201 13	Cylinder 1 - Injector Circuit Error
P0202 13	Cylinder 2 - Injector Circuit Error
P0203 13	Cylinder 3 - Injector Circuit Error
P0204 13	Cylinder 4 - Injector Circuit Error
P0219 00	Engine Overspeed Condition
P0221 29	Throttle Position Sensor 2 Performance Non-plausible
P0222 16	Throttle Position Sensor 2 Performance Low Input
P0223 17	Throttle Position Sensor 2 Performance High Input
P0234 00	Turbu/Super Charger Overboost Condition
P0237 16	Turbocharger Boost Sensor (A) Circ. Low Input
P0238 17	Turbocharger Boost Sensor (A) Circ. High Input

P0243 13 Turbo/Super Charger Wastegate Solonoid Open P0245 11 Turbo/Super Charger Wasteg. Solonoid Low P0246 12 Turbo/Sup. Charger Wasteg. Solonoid High P0261 11 Cylinder 1 - Injector Circuit Low P0262 12 Cylinder 1 - Injector Circuit High P0264 11 Cylinder 2 - Injector Circuit Low P0265 12 Cylinder 2 - Injector Circuit High P0267 11 Cylinder 3 - Injector Circuit Low P0268 12 Cylinder 3 - Injector Circuit High P0270 11 Cylinder 4 - Injector Circuit Low P0271 12 Cylinder 4 - Injector Circuit High P0299 00 Turbo/Super Charger Underboost	
P0246 12 Turbo/Sup. Charger Wasteg. Solonoid High P0261 11 Cylinder 1 - Injector Circuit Low P0262 12 Cylinder 1 - Injector Circuit High P0264 11 Cylinder 2 - Injector Circuit Low P0265 12 Cylinder 2 - Injector Circuit High P0267 11 Cylinder 3 - Injector Circuit Low P0268 12 Cylinder 3 - Injector Circuit High P0270 11 Cylinder 4 - Injector Circuit Low P0271 12 Cylinder 4 - Injector Circuit High P0299 00 Turbo/Super Charger Underboost	
P0261 11 Cylinder 1 - Injector Circuit Low P0262 12 Cylinder 1 - Injector Circuit High P0264 11 Cylinder 2 - Injector Circuit Low P0265 12 Cylinder 2 - Injector Circuit High P0267 11 Cylinder 3 - Injector Circuit Low P0268 12 Cylinder 3 - Injector Circuit High P0270 11 Cylinder 4 - Injector Circuit Low P0271 12 Cylinder 4 - Injector Circuit High P0299 00 Turbo/Super Charger Underboost	
P0262 12 Cylinder 1 - Injector Circuit High P0264 11 Cylinder 2 - Injector Circuit Low P0265 12 Cylinder 2 - Injector Circuit High P0267 11 Cylinder 3 - Injector Circuit Low P0268 12 Cylinder 3 - Injector Circuit High P0270 11 Cylinder 4 - Injector Circuit Low P0271 12 Cylinder 4 - Injector Circuit High P0299 00 Turbo/Super Charger Underboost	
P0264 11 Cylinder 2 - Injector Circuit Low P0265 12 Cylinder 2 - Injector Circuit High P0267 11 Cylinder 3 - Injector Circuit Low P0268 12 Cylinder 3 - Injector Circuit High P0270 11 Cylinder 4 - Injector Circuit Low P0271 12 Cylinder 4 - Injector Circuit High P0299 00 Turbo/Super Charger Underboost	
P0265 12 Cylinder 2 - Injector Circuit High P0267 11 Cylinder 3 - Injector Circuit Low P0268 12 Cylinder 3 - Injector Circuit High P0270 11 Cylinder 4 - Injector Circuit Low P0271 12 Cylinder 4 - Injector Circuit High P0299 00 Turbo/Super Charger Underboost	
P0267 11 Cylinder 3 - Injector Circuit Low P0268 12 Cylinder 3 - Injector Circuit High P0270 11 Cylinder 4 - Injector Circuit Low P0271 12 Cylinder 4 - Injector Circuit High P0299 00 Turbo/Super Charger Underboost	
P0268 12 Cylinder 3 - Injector Circuit High P0270 11 Cylinder 4 - Injector Circuit Low P0271 12 Cylinder 4 - Injector Circuit High P0299 00 Turbo/Super Charger Underboost	
P0270 11 Cylinder 4 - Injector Circuit Low P0271 12 Cylinder 4 - Injector Circuit High P0299 00 Turbo/Super Charger Underboost	
P0271 12 Cylinder 4 - Injector Circuit High P0299 00 Turbo/Super Charger Underboost	
P0299 00 Turbo/Super Charger Underboost	
P0300 21 Random/Multiple Cylinder Misfire Detected (Over Emission Limit)	
P0300 22 Random/Multiple Cylinder Misfire Detected (Harmful to Catalyst)	
P0300 29 Random/Multiple Cylinder Misfire Detected (During First Statistic Cycle)	
P0301 21 Cylinder 1 Misfire Detected (Over Emission Limit)	
P0301 22 Cylinder 1 Misfire Detected (Harmful to Catalyst)	
P0301 29 Cylinder 1 Misfire Detected (During First Statistic Cycle)	
P0302 21 Cylinder 2 Misfire Detected (Over Emission Limit)	
P0302 22 Cylinder 2 Misfire Detected (Harmful to Catalyst)	
P0302 29 Cylinder 2 Misfire Detected (During First Statistic Cycle)	
P0303 21 Cylinder 3 Misfire Detected (Over Emission Limit)	
P0303 22 Cylinder 3 Misfire Detected (Harmful to Catalyst)	
P0303 29 Cylinder 3 Misfire (During First Statistic Cycle)	
P0304 21 Cylinder 4 Misfire Detected (Over Emission Limit)	
P0304 22 Cylinder 4 Misfire Detected (Harmful to Catalyst)	
P0304 29 Cylinder 4 Misfire Detected (During First Statistic Cycle)	
P0318 00 Rough Road Sensor Signal Circuit	
P0322 00 EPM - Crankshaft Signal Fault	
P0327 16 Knock Sensor 1 Circ. Low Input	
P0327 14 Knock Sensor 1 Circuit Low	
P0327 00 Knock Sensor 1 Circuit Low	
P0328 17 Knock Sensor 1 Circ. High Input	
P0328 15 Knock Sensor 1 Circuit High	
P0328 00 Knock Sensor 1 Circuit High	
P0341 00 EPM - Camshaft Signal Fault	
P0346 00 EPM - Camshaft 2 Signal Fault	
P0420 00 Catalyst Conversion Insufficient	

P0444 13	Evaporativ Emiss. System Purge Control Valve Circuit Open	
P0458 16	Evaporative Emission System Purge Control Valve Circuit Low	
P0459 17	Evaporative Emission System Purge Control Valve Circuit High	
P0480 13	Cooling Fan 1 Control Circuit Error	
P0481 13	Cooling Fan 2 Control Circuit Error	
P0501 00	Vehicle Speed Sensor Signal Fault	
P0506 00	Idle Control System RPM Lower than Expected	
P0507 00	Idle Control System RPM Higher than Expected	
P0532 16	A/C Refrigerant Pressure Sensor Circuit Low	
P0533 17	A/C Refrigerant Pressure Sensor Circuit High	
P0537 16	A/C Evaporator Temperature Sensor Circuit Low	
P0538 17	A/C Evaporator Temperature Sensor Circuit High	
P0556 00	Brake Booster Pressure Sensor Circuit Performance Non-plausible	
P0557 16	Brake Booster Pressure Sensor Circuit Low	
P0558 17	Brake Booster Pressure Sensor Circuit High	
P0560 00	Non-plausible Error of Battery Voltage	
P0562 16	System Voltage Low	
P0563 17	System Voltage High	
P0568 1C	Cruise Control Set Signal Non-plausible	
P0568 86	Cruise Control Set Signal Stuck	
P0568 81	Cruise Control Set Signal Error	
P0571 29	Brake Signal Synchronization Error	
P0571 1C	Brake Light Signal Circuit Error	
P0601 00	Safety Monitoring Function Error (ECU EEPROM Error)	
P0604 43	Internal Contr. Module RAM Error	
P0605 43	Internal Contr. Module ROM Error	
P0606 00	Safety Monitoring Fuel Cutoff Error	
P0606 1C	Throttle Signal, Wiring Harness or ECU Error	
P0606 28	Safety Monitoring Function Error (CAN Sending Monitoring Error)	
P0606 42	Safety Monitoring Function Error (ECU EEPROM Error)	
P0606 47	Monitoring Module Feedback Error	
P0606 48	Monitoring Fault Reaction Error	
P0606 49	Monitoring Module Inquiry Error	
P0606 55	Variant Coding Monitoring Error	
P0606 61	Ignition Angle Signal, Wiring Harness or ECU Error	
P0606 62	Pedal Signal Unplausibility Error in Level 2	
P0606 63	Safety Monitoring Function Error (SSM System Monitoring Error)	
P0606 64	Load Signal, Wiring Harness or ECU Error	

P0606 67	ECU Fault Reaction Monitoring Error
P0606 75	Shut Off Path Test Error
P0606 92	Engine Speed Monitoring Error in Level 2
P0606 94	Torque Monitoring Error in Level 2
P0606 96	AD Convertor Monitoring Error
P0615 13	Starter Relay Circuit Open
P0616 11	Starter Relay Circuit Low
P0617 12	Starter Relay Circuit High
P0627 13	Fuel Pump Control Circuit Open
P0628 11	Fuel Pump Control Circuit Low
P0629 12	Fuel Pump Control Circuit High
P0645 13	AC Clutch Relais Circuit Open
P0646 11	A/C Clutch Relay Control Circuit Low
P0647 12	A/C Clutch Relay Control Circuit High
P0650 13	Malfunction Indicator Lamp (MIL) Control Circuit/Open
P0650 11	Malfunction Indicator Lamp (MIL) Control Circuit Low
P0650 12	Malfunction Indicator Lamp (MIL) Control Circuit High
P0688 91	Power Relay Sense Circuit Non-plausible Error
P0688 92	Power Relay Sense Circuit Signal Error
P0691 11	Fan 1 Control Circuit Low
P0692 12	Fan 1 Control Circuit High
P0693 11	Fan 2 Control Circuit Low
P0694 12	Fan 2 Control Circuit High
P0700 00	Transmission Control System (MIL Request)
P0704 00	Clutch Switch Input Circuit Non-plausible
P083F 00	Bottom Clutch Switch 'A'/'B' Correlation
P2088 11	Control Circuit Low of Camshaft Control Valve (Inlet)
P2089 12	Control Circuit High of Camshaft Control Valve (Inlet)
P2090 11	Control Circuit Low of Camshaft Control Valve (Outlet)
P2091 12	Control Circuit High of Camshaft Control Valve (Outlet)
P2106 92	Throttle Power Stage Non-plausible Error
P2106 12	Throttle Power Stage Max Error
P2106 13	Throttle Power Stage Signal Error
P2106 29	Load Monitoring Error
P2106 19	Throttle Power Stage Min Error
P2122 16	Pedal Pos. Sensor 1 Circ. Low Input
P2123 17	Pedal Pos. Sensor 1 Circ. High Input
P2127 16	Pedal Pos. Sensor 2 Circ. Low Input
	ı

P2128 17	Pedal Pos. Sensor 2 Circ. High Input	
P2138 00	Pedal Movement Check Error	
P2138 29	Pedal Pos. Sensor 1/2 Unplausible	
P2177 00	System Too Lean Off Idle	
P2178 00	System Too Rich Off Idle	
P2187 00	System Too Lean at Idle	
P2188 00	System Too Rich at Idle	
P2195 00	O2 Sensor Signal Stuck Lean (Upstream of the Catalyzer)	
P2196 00	O2 Sensor Signal Stuck Rich (Upstream of the Catalyzer)	
P2261 00	Dump Valve - Mechanical Error	
P2270 00	O2 Sensor Signal Stuck Lean (Downstream of the Catalyzer)	
P2271 00	O2 Sensor Signal Stuck Rich (Downstream of the Catalyzer)	
P2600 13	Diagnosis of Electrical Water Pump Control Circ. Open	
P2602 11	Diagnosis of Electrical Water Pump Control Circ. Low	
P2603 12	Diagnosis of Electrical Water Pump Control Circ. High	
P3046 13	Starter Relay Open Defect	
P3050 00	Starter Relay 2 Closed Stick Defect	
P3052 00	Starter Relay 1 Closed Stick Defect	
P3054 00	Engine Blocked/Starter Not Engaged	
P3055 11	Starter State Line S_kl50r Short to Ground	
P3056 12	Starter State Line S_kl50r Short to UB	
P3088 93	Starter Damaged or Wire Dropped	
U0001 88	Error Busoff on CAN-bus	
U0101 87	Lost Communication with TCM	
U0129 87	Lost Communication with Brake System Control Module	
U0121 87	Lost Communication with ABS	
U0140 00	Lost Communication with Body Control Module (Immo)	
U0140 87	Lost Communication with Body Control Module (BCM)	
U0155 87	Lost Communication with Instrument Panel Cluster (IPC) Control Module	
U0214 87	Lost Communication with Passive Entry Passive Start (PEPS)	
P1011 01	Diagnosis of Electrical Water Pump Control Circ. Error	
P1009 7A	Leakage Detection Upstream the Throttle Valve	
P1100 00	Engine Torque Control Adaption at Limit	
P1101 00	System Voltage Can Not Fulfill Throttle Self Learning Condition	
P1102 00	Throttle Limphome Position Self Learning Error	
P1102 29	Throttle Lower Mechanic Stop Re-learning Error	
P1103 00	Throttle Lower Mechanic Stop First Learning Error	
P1104 00	Throttle Lower Mechanic Stop First Learning Error	

P1106 00 T		
F 1100 00 1	Throttle Position Deviation Error	
P1106 21 T	Throttle PID Adjustment Min Error	
P1106 22 T	Throttle PID Adjustment Max Error	
P1111 00 R	Return Spring Check Max Error	
P1122 77 T	orque Limitation When Throttle-valve Error Happen	
P1130 00 D	Diagnosis of Brake Booster Pump Malfunction	
P1131 17 D	Diagnosis of Brake Booster Pump Control Circuit High	
P1132 16	Diagnosis of Brake Booster Pump Control Circuit Low	
P1133 13	Diagnosis of Brake Booster Pump Control Circ. Open	
P1137 17	Diagnosis of Pressure Sensor in Brake Booster Pump Circuit High	
P1138 16	Diagnosis of Pressure Sensor in Brake Booster Pump Circuit Low	
P1139 7A D	Diagnosis of Pressure Sensor in Brake Booster Pump Leakage Detection	
P1427 12 D	Diagnosis of Brake Booster Pump Control Circ. High	
P1428 11 D	Diagnosis of Brake Booster Pump Control Circ. Low	
P1429 13 D	Diagnosis of Brake Booster Pump Control Circ. Open	
P1479 00 N	Non-plausible Error for Brake Booster Diagnosis	
P1500 00 C	Checksum Error of LIN Message from EBS	
P1501 00 F	raming Error of LIN Message from EBS	
P1502 00	Reponse Reception Time Out Error of LIN Message from EBS	
P1503 00 R	Read Back Time Out Error of LIN Message from EBS	
P1512 92 E	EBS or Battery Error	
P1513 00 B	Battery has been Changed and Long Time No Tester Confirmation	
P1520 00 F	Framing Error of LIN Message from AGS	
P1521 00 C	Checksum Error of LIN Message from AGS	
P1522 00 R	Reponse Reception Time Out Error of LIN Message from AGS	
P1523 00 R	Read Back Time Out Error of LIN Message from AGS	
P1530 00 C	Checksum Error of LIN Message from Generator	
P1531 00 F	Framing Error of LIN Message from Generator	
P1532 00 R	Reponse Reception Time Out Error of LIN Message from Generator	
P1533 00 R	Read Back Time Out Error of LIN Message from Generator	
P1541 00 C	Communication Error of Generator	
P1542 00 N	Mechanical Status Error of Generator	
P1543 00 E	Electrical Status Error of Generator	
P1600 00 S	S/S Main Switch Stick Error	
P1610 00 Ir	Immo Secret Key and Security Code Not Programmed	
P1611 00 Ir	mmo Wrong Security Code Received	
P1612 00 Ir	mmo Challenge Service Not Received	

P1614 00	Immo Transferred Transponder Response was Corrupted	
P1615 00	ECM Status Unknown	
P1616 00	Authentication Not OK	
P1617 00	No Response from SIM During Challenge Period	
P1618 00	Fail to Write EOL Confidtional Data into EEProm	
P1619 00	ECM Not Programed (Virgin State)	
P1651 13	Service Vehicle Soon (SVS) Control Circuit	
P1651 11	Service Vehicle Soon (SVS) Control Circuit Low	
P1651 12	Service Vehicle Soon (SVS) Control Circuit High	
P1701 00	Power Train State Signal Wire Open	
P1702 00	Bottom Clutch Switch Error	
P0016-76	Crankshaft Position-Camshaft (inlet) Installation Error	
P0016-78	Crankshaft Position-Camshaft (Inlet) Position Error	
P0017-76	Crankshaft Position-Camshaft (Outlet) Installation Error	
P0017-78	Crankshaft Position-Camshaft (Outlet) Position Error	
P0096-00	Air Temperature Sensor (After Throttle Valve) Circuit Performance Non-plausible	
P0097-16	Air Temperature Sensor (After Throttle Valve) Circuit Low	
P0098-17	Air Temperature Sensor (After Throttle Valve) Circuit High	
P0300-00	Misfire Detected	
P0301-00	Misfire Detected on Cylinder 1	
P0302-00	Misfire Detected on Cylinder 2	
P0303-00	Misfire Detected on Cylinder 3	
P0304-00	Misfire Detected on Cylinder 4	
P0321-00	Crankshaft Signal Disturbance	
P0342-00	Camshaft Position Sensor (Inlet) Circuit Low	
P0343-00	Camshaft Position Sensor (Inlet) Circuit High	
P0366-00	Camshaft Position Sensor (Outlet) Circuit Performance Non-plausible	
P0367-00	Camshaft Position Sensor (Outlet) Circuit Low	
P0368-00	Camshaft Position Sensor (Outlet) Circuit High	
P0600-00	MSC/COM-Errors of the TLE8888	
P0606-97	Function Monitoring: Fault of ECU ADC - Test Voltage	
P0606-17	Reported OverVoltage of VDD5	
P0606-16	Reported UnderVoltage of VDD5	
P0606-91	Diagnostic Fault Check to Report WDA Active Due to Overvoltage Detection	
P0606-45	Visibility of Software Resets in DSM	
P130A-00	Cylinder Selective Fuel Cutoff Active Due to Catalyst Damaging Misfire	
P1386-00	Diagnostic Fault Check Knock Control Signal Evaluation	
P023A 00	Charge Air Cooler Coolant Pump Control Circuit	

P023B 00	Charge Air Cooler Coolant Pump Control Circuit Low	
P023C 00	Charge Air Cooler Coolant Pump Control Circuit High	
P0458 11	Evaporative Emission System Purge Control Valve Circuit Low	
P0459 12	Evaporative Emission System Purge Control Valve Circuit High	
P0606 47	Monitoring Module Feedback Error	
P1700 00	Charge Air Cooler Coolant Pump Dry Run	
P1703 00	Charge Air Cooler Coolant Pump Over Voltage	
P1704 00	Charge Air Cooler Coolant Pump Over Current	
P1705 00	Charge Air Cooler Coolant Pump Over Temperature	
P1706 00	Charge Air Cooler Coolant Pump Stall	
P1707 00	Charge Air Cooler Coolant Pump Under Voltage	
P1708 00	Charge Air Cooler Coolant Pump Feedback Signal Error Circ. High	
P1709 00	Charge Air Cooler Coolant Pump Feedback Signal Error Circ. Low	









ECM Power Supply Circuit & Ground Circuit Testing

Power Supply Circuit



Ground Circuit



Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.


- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using diagnostic tester, select Read Datastream.
- If datastream is not detected, malfunction indicated by datastream is current. Go to diagnosis procedure Step 1.
- If datastream is detected, malfunction indicated by datastream is intermittent (See page 06-23).

Diagnosis Procedure

1 Check ECM power supply circuit

- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector B-011.
- c. Check voltage between terminal of ECM connector B-011 and body ground.

Multimeter Connection	Condition	Specified Condition
B-011 (20) - Body ground	Always	11 to 14 V
OK Go to	step 4	103.111211



NG

2 Check ECM fuse

- a. Unplug ECM fuse EF37 (10 A) from engine compartment fuse and relay box.
- b. Check resistance of fuse.

Standard resistance: less than 1 Ω

NG Replace ECM fuse

OK

3 Check wire harness and connector (ECM - engine compartment fuse and relay box)


- a. Disconnect the engine compartment fuse and relay box connector B-007.
- b. Check wire harness between connector terminals on wire harness side.

Check for Open

Multimeter Connection	Specified Condition
B-007 (B4) - B-011 (20)	Continuity

Check for Short

Multimeter Connection	Specified Condition
B-007 (B4) or B-011 (20) - Body ground	No continuity
B-007 (B4) or B-011 (20) - Battery positive	No continuity





Repair or replace wire harness or connector



Repair or replace engine compartment fuse and relay box or wire harness (engine compartment fuse and relay box - battery)


4 Check main relay circuit voltage

- a. Remove the main relay from engine compartment fuse and relay box.
- b. Check voltage between terminals of main relay and body ground.

Multimeter Connection	Condition	Specified Condition
Main relay terminals 85 and 87 (engine compartment fuse and relay box side) - Body ground	Always	11 to 14 V

NG

Repair or replace wire harness or connector (main relay - battery)






- 5 Check main relay and fuse EF30
- a. Check if fuse EF30 is normal.
- b. Check for continuity between terminals of main relay.

Multimeter Connection	Specified Condition	
Terminal 87 - Terminal 30	No continuity	
Terminal 87 - Terminal 30	Continuity (Battery voltage is applied between terminals 85 and 86)	

NG

Replace fuse or main relay






- 6 Check wire harness and connector (ECM engine compartment fuse and relay box)
- a. Disconnect the engine compartment fuse and relay box connector B-007.
- b. Check wire harness between connector terminals.

Check for Open

Multimeter Connection	Specified Condition
B-011 (15, 16) - B-007 (B7)	Continuity

Check for Short

Multimeter Connection	Specified Condition
B-011 (15, 16) or B-007 (B7) - Body ground	No continuity
B-011 (15, 16) or B-007 (B7) - Battery positive	No continuity




Check for Open

Multimeter Connection	Specified Condition
B-008 (F16) - B-011 (5)	Continuity

Check for Short

Multimeter Connection	Specified Condition
B-008 (F16) or B-011 (5) - Body ground	No continuity
B-008 (F16) or B-011 (5) - Battery positive	No continuity








7 Check ECM power supply circuit (ignition switch voltage)

- a. Turn ignition switch to ON.
- b. Check voltage between terminals of ECM connector.

Multimeter Connection	Condition	Specified Condition
B-011 (35) - B-011 (63, 64)	Ignition switch ON	11 to 14 V

ОК

Replace ECM



NG

- 8 Check ECM fuse
- a. Unplug fuse RF1 (10 A) from instrument panel fuse box.
- b. Check resistance of fuse.

Standard resistance: less than 1 Ω

NG

Replace ECM fuse



9 Check wire harness and connector (ECM - instrument panel fuse box and body ground)

- a. Disconnect the instrument panel fuse box connector I-030.
- b. Check wire harness between connector terminals on wire harness side.

Check for Open

Multimeter Connection	Specified Condition
B-011 (35) - I-030 (RF12)	Continuity

Check for Short


Multimeter Connection	Specified Condition
B-011 (35) or I-030 (RF12) - Body ground	No continuity
B-011 (35) or I-030 (RF12) - Battery positive	No continuity


- c. Disconnect the ground point B-017.
- d. Check the ECM ground point (See page 06-23).
- e. Check the ECM ground wire harness.

Check for Open

Multimeter Connection	Specified Condition
B-011 (63, 64) - B-017	Continuity

NG Repair or replace wire harness or connector






DTC	P0030 13	O2 Sensor Heater Control Circuit Open (Upstream of the Catalyzer)	
DTC	P0031 11	O2 Sensor Heater Control Circuit Low (Upstream of the Catalyzer)	
DTC	P0132 12	O2 Sensor Heater Control Circuit High (Upstream of the Catalyzer)	
DTC	P0053 1E	O2 Sensor Heater Resistance Too Large (Upstream of the Catalyzer)	







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0030 13	O2 Sensor Heater Control Circuit Open (Upstream of the Catalyzer)		
P0031 11	O2 Sensor Heater Control Circuit Low (Upstream of the Catalyzer)	Ignition switch ON	Upstream Oxygen SensorWire harness or connector
P0132 12	O2 Sensor Heater Control Circuit High (Upstream of the Catalyzer)	Engine running	FuseECM
P0053 1E	O2 Sensor Heater Resistance Too Large (Upstream of the Catalyzer)		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
 - If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
 - If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

• When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check upstream oxygen sensor connector
- a. Disconnect the upstream oxygen sensor connector E-055 (arrow).
- b. Check the upstream oxygen sensor connector.

NG

Repair or replace connector






- 3 Check upstream oxygen sensor heater power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between terminal D of upstream oxygen sensor connector E-055 and body ground.

Multime Connect	Condition	Specified Condition
E-055 (D) - ground	nition switch ON	11 to 14 V

OK Go to step 5



NG

4 Check upstream oxygen sensor power supply circuit

- a. Turn ignition switch to OFF.
- b. Check the fuse EF32 and main relay.
- c. Disconnect the engine compartment fuse and relay box connector E-017.
- d. Check wire harness between upstream oxygen sensor connector terminal and engine compartment fuse and relay box connector terminal.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-017 (A5) - E- 055 (D)	Always	Continuity


Check for Short

Multimeter Connection	Condition	Specified Condition
E-055 (D) or E- 017 (A5) - Body ground	Always	No continuity
E-055 (D) or E- 017 (A5) - Battery positive	Always	No continuity

NG

Replace fuse, main relay, wire harness or connector (upstream oxygen sensor - engine compartment fuse and relay box)





5 Check upstream oxygen sensor heater control circuit

- a. Disconnect the ECM connector E-034.
- b. Check wire harness between upstream oxygen sensor connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-034 (73) - E- 055 (C)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-034 (73) or E- 055 (C) - Body ground	Always	No continuity
E-034 (73) or E- 055 (C) - Battery positive	Always	No continuity

NG


Repair or replace wire harness or connector (upstream oxygen sensor - ECM)





- 6 Check upstream oxygen sensor heater
- a. Measure resistance of upstream oxygen sensor.

Multimeter Connection	Condition	Specified Condition
Terminal C - Terminal D	20°C	7 to 11 Ω
Terminal A - Terminal C	Always	
Terminal A - Terminal D		No continuity
Terminal B - Terminal C		140 Continuity
Terminal B - Terminal D		



NG

Replace upstream oxygen sensor



- 7 Check appearance of upstream oxygen sensor
- a. Remove the upstream oxygen sensor.
- b. Check upstream oxygen sensor for following problems.
 - Moisture enters internal of sensor, temperature changes greatly or probe is broken.
 - Oxygen sensor is "poisoned" (Pb, S, Br and Si etc.).

NG

Replace upstream oxygen sensor



8 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0030 13, P0031 11, P0032 12 or P0053 1E still exists.

NG

Replace ECM




System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

DTC	P0036 13	O2 Sensor Heater Control Circuit Open (Downstream of the Catalyzer)
DTC	P0037 11	O2 Sensor Heater Control Circuit Low (Downstream of the Catalyzer)
DTC	P0038 12	O2 Sensor Heater Control Circuit High (Downstream of the Catalyzer)
DTC	P0054 1E	O2 Sensor Heater Resistance Too Large (Downstream of the Catalyzer)







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0036 13	O2 Sensor Heater Control Circuit Open (Downstream of the Catalyzer)		
P0037 11	O2 Sensor Heater Control Circuit Low (Downstream of the Catalyzer)		Downstream Oxygen SensorWire harness or connector
P0038 12	O2 Sensor Heater Control Circuit High (Downstream of the Catalyzer)	Engine running	FuseECM
P0054 1E	O2 Sensor Heater Resistance Too Large (Downstream of the Catalyzer)		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
 - If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
 - If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

• When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point B-017 (See page 06-23).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check downstream oxygen sensor connector
- a. Disconnect the downstream oxygen sensor connector (arrow).
- b. Check the downstream oxygen sensor connector

NG

Repair or replace connector





- 3 Check downstream oxygen sensor heater power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between terminal D of downstream oxygen sensor connector B-062 and body ground.

Multimeter Connection	Condition	Specified Condition
B-002 (D) - Body ground	Ignition switch ON	11 to 14 V

NG

Replace wire harness or connector (downstream oxygen sensor - ECM)



OK

4 Check downstream oxygen sensor power supply circuit

- a. Turn ignition switch to OFF.
- b. Check the fuse EF36 and main relay.
- c. Disconnect the engine compartment fuse and relay box connector B-007.
- d. Check wire harness between downstream oxygen sensor connector terminal and engine compartment fuse and relay box connector terminal.

Check for Open


Multimeter Connection	Condition	Specified Condition
B-062 (D) - B-007 (B8)	Always	Continuity

Check for Short

	Multimeter Connection	Condition	Specified Condition
	B-062 (D) or B- 007 (B8) - Body ground	Always	No continuity
9	B-062 (D) or B- 007 (B8) - Battery positive	Always	No continuity

NG >

Replace fuse, main relay, wire harness or connector (downstream oxygen sensor - engine compartment fuse and relay box)





5 Check downstream oxygen sensor heater control circuit


a. Check wire harness between downstream oxygen sensor connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
B-062 (C) - B-011 (48)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
B-062 (C) or B- 011 (48) - Body ground	Always	No continuity
B-062 (C) or B- 011 (48) - Battery positive	Always	No continuity



NG

Repair or replace wire harness or connector (downstream oxygen sensor - ECM)




اولين سامانه ديجيتال تعميركاران خودرودراب

6 Check downstream oxygen sensor heater

a. Measure resistance of downstream oxygen sensor.

Multimeter Connection	Condition	Specified Condition
Terminal C - Terminal D	20°C	7 to 11 Ω
Terminal A - Terminal C	Always	No continuity
Terminal A - Terminal D		
Terminal B - Terminal C		
Terminal B - Terminal D		



NG

Replace downstream oxygen sensor



- 7 Check appearance of downstream oxygen sensor
- a. Remove the downstream oxygen sensor.
- b. Check downstream oxygen sensor for following problems.
 - Moisture enters internal of sensor, temperature changes greatly or probe is broken.
 - Oxygen sensor is "poisoned" (Pb, S, Br and Si etc.).

NG

Replace downstream oxygen sensor



- 8 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0036 13, P0037 11, P0038 12 or P0054 1E still exists.

NG

Replace ECM




System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

DTC	P0201 13	Cylinder 1 - Injector Circuit Error
DTC	P0202 13	Cylinder 2 - Injector Circuit Error
DTC	P0203 13	Cylinder 3 - Injector Circuit Error
DTC	P0204 13	Cylinder 4 - Injector Circuit Error
DTC	P0261 11	Cylinder 1 - Injector Circuit Low
DTC	P0262 12	Cylinder 1 - Injector Circuit High
DTC	P0264 11	Cylinder 2 - Injector Circuit Low
DTC	P0265 12	Cylinder 2 - Injector Circuit High
DTC	P0267 11	Cylinder 3 - Injector Circuit Low
DTC	P0268 12	Cylinder 3 - Injector Circuit High
DTC	P0270 11	Cylinder 4 - Injector Circuit Low
DTC	P0271 12	Cylinder 4 - Injector Circuit High

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0201 13	Cylinder 1 - Injector Circuit Error		
P0202 13	Cylinder 2 - Injector Circuit Error		
P0203 13	Cylinder 3 - Injector Circuit Error		
P0204 13	Cylinder 4 - Injector Circuit Error		
P0261 11	Cylinder 1 - Injector Circuit Low		
P0262 12	Cylinder 1 - Injector Circuit High	Ignition switch ON	Fuel injector Wire harness or connector
P0264 11	Cylinder 2 - Injector Circuit Low	Engine running	ECM
P0265 12	Cylinder 2 - Injector Circuit High		
P0267 11	Cylinder 3 - Injector Circuit Low		
P0268 12	Cylinder 3 - Injector Circuit High	ـ پجيا	
P0270 11	Cylinder 4 - Injector Circuit Low	کت دیجیتال خود	شر
P0271 12	Cylinder 4 - Injector Circuit High	بين سامانه ديجيت	

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG)

Repair or replace ground wire harness or ground point


OK

- 2 Check injector connector
- a. Turn ignition switch to OFF.
- b. Separately disconnect injector connectors (arrow) in cylinders 1, 2, 3, 4.
- c. Check terminals of injector connectors.

NG

Repair or replace connector

، سامانه دیجیتال تعمیرکاران خودرو در ایران



OK


3 Check injector power supply voltage

- a. Separately disconnect injector connectors in cylinders 1, 2, 3, 4.
- b. Turn ignition switch to ON.
- c. Check voltage between injector connector terminals in cylinders 1, 2, 3, 4 and body ground.

Multimeter Connection	Condition	Specified Condition
E-040 (1), E-041 (1), E-042 (1), E- 044 (1) - Body ground	Ignition switch ON	11 to 14 V

NG)

Go to step 5





4 Check injector power supply circuit


- a. Turn ignition switch to OFF.
- b. Check fuse EF33 and main relay.
- c. Disconnect the engine compartment fuse and relay box connector E-017.
- d. Check wire harness between connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-040 (1), E-041 (1), E-042 (1), E- 044 (1) - E-017 (A9)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-040 (1), E-041 (1), E-042 (1), E- 044 (1) or E-017 (A9) - Body ground	Always	No continuity



Multimeter Connection	Condition	Specified Condition
E-040 (1), E-041 1), E-042 (1), E- 044 (1) or E-017 (A9) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (injector- engine compartment fuse and relay box)

OK

5 Check injector control circuit

a. Disconnect the ECM connector E-034.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-044 (2) - E-034 (68)		
E-042 (2) - E-034 (67) E-041 (2) - E-034 (72)	Always 9)	Continuity
E-040 (2) - E-034 (74)	ل تعميركاران	سامانه ديجيتا

Check for Short

Multimeter Connection	Condition	Specified Condition
E-044 (2), E-042 (2), E-041 (2), E- 040 (2) - Body ground or power supply	Always	No continuity
E-044 (2), E-042 (2), E-041 (2), E- 040 (2) - Body ground or power supply	Always	No continuity

NG

Repair or replace wire harness or connector (injector- ECM)



ОК

- 6 Check injector
- a. Check resistance of injector (12 \pm 1 Ω).

NG Replace injector

ОК


- 7 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0201 13, P0202 13, P0203 13, P0204 13, P0261 11, P0262 12, P0264 11, P0265 12, P0267 11, P0268 12, P0270 11 or P0271 12 still exists.



DTC	P0105 28	Manifold Absolut Pressure Circuit No Change
DTC	P0106 00	Manifold Abs. Pressure Performance Non-plausible
DTC	P0107 11	Manifold Abs. Pressure Low Input
DTC	P0108 12	Manifold Abs. Pressure High Input







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0105 28	Manifold Absolut Pressure Circuit No Change		
P0106 00	Manifold Abs. Pressure Performance Non-plausible	Ignition switch ON Engine running	Intake pressure sensorWire harness or connector
P0107 11	Manifold Abs. Pressure Low Input		• ECM
P0108 12	Manifold Abs. Pressure High Input		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).




Repair or replace ground wire harness or ground point

OK

- 2 Check intake pressure sensor connector
- a. Disconnect the intake pressure sensor connector E-043 (arrow).
- b. Check the intake pressure sensor connector.

NG


Repair or replace connector





- 3 Check intake pressure sensor signal voltage
- a. Connect the intake pressure sensor connector E-043.
- b. Turn ignition switch to ON and start engine.
- c. Using a multimeter, measure voltage between terminal 1 of connector E-043 and body ground.

Multimeter Connection	Condition	Specified Condition
سئوليت محد	ldling	Voltage is about 1.3 V (value changes with
E-043 (1) - Body	ل تعميركاران	model) Maximum
ground	Accelerator pedal depressed rapidly	instantaneous voltage is about 4 V (value changes with model)



NG

Go to step 8

ОК

4 Check intake pressure sensor power supply voltage

- a. Disconnect the intake pressure/temperature sensor connector E-043.
- b. Check voltage between connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-043 (2) - Body ground	Ignition switch ON	5 V

ок >

Go to step 6



NG

5 Check intake pressure sensor signal circuit

- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector E-034.
- c. Check wire harness between connector terminals.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-034 (91) - E- 043 (1)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-034 (91) - E- 043 (1) - Body ground	Always	No continuity
E-034 (91) - E- 043 (1) - Battery positive	Always	No continuity

NG

Replace wire harness or connector (intake pressure sensor - ECM)



ОК

6 Check intake pressure sensor power supply circuit


a. Check wire harness between intake pressure sensor connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-034 (109) - E- 043 (2)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-034 (109) or E- 043 (2) - Body ground	Always	No continuity
E-034 (109) or E- 043 (2) - Battery positive	Always	No continuity



NG

Repair or replace wire harness or connector (intake pressure sensor - ECM)

شرکت دیجیتال خودرو سامانه (مسئولیت مح

ОК

7 Check intake pressure sensor

- a. Remove the intake pressure sensor.
- b. Check sensor connection part for debris and damage.

NG Clean or replace intake pressure sensor

OK

8 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0105 28, P0106 00, P0107 11 or P0108 12 still exists.

NG Replace ECM


ОК

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0234 00	Turbu/Super Charger Overboost Condition
DTC	P0237 16	Turbocharger Boost Sensor (A) Circ. Low Input
DTC	P0238 17	Turbocharger Boost Sensor (A) Circ. High Input







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0234 00	Turbu/Super Charger Overboost Condition		
P0237 16	Turbocharger Boost Sensor (A) Circ. Low Input	Ignition switch ON Engine running	 Boost pressure/temperature sensor Wire harness or connector ECM
P0238 17	Turbocharger Boost Sensor (A) Circ. High Input		LOW

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

اولین سامانه دیجیتال تعمیر Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check boost pressure sensor connector
- a. Disconnect the boost pressure/temperature sensor connector E-046 (arrow).
- b. Check the boost pressure/temperature sensor connector.

NG]


Repair or replace connector





- 3 Check boost pressure sensor signal voltage
- a. Connect the boost pressure/temperature sensor connector E-046.
- b. Turn ignition switch to ON and start engine.
- c. Using a multimeter, measure voltage between terminal 1 of connector E-046 and body ground.

Multimeter Connection	Condition	Specified Condition
E-046 (1) - Body ground	ارو ساماده رصا ال تعمیرکاران	Voltage is about 1.3 V (value changes with model)
	Accelerator pedal depressed rapidly	Maximum instantaneous voltage is about 4 V (value changes with model)



ок

Go to step 8

NG


4 Check boost pressure sensor power supply voltage

- a. Disconnect the boost pressure/temperature sensor connector E-046.
- b. Check voltage between connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-046 (2) - Body ground	Ignition switch ON	5 V

ок

Go to step 6





5 Check boost pressure sensor signal circuit

- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector B-011.
- c. Check wire harness between connector terminals.

Check for Open


J J J - JJ - J - J		11 1 11
Multimeter Connection	Condition	Specified Condition
B-011 (46) - B- 008 (F19) - E-035 (E10) - E-046 (4)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
B-011 (46) or E- 046 (4) - Body ground	Always	No continuity
B-011 (46) or E- 046 (4) - Battery positive	Always	No continuity

NG

Replace wire harness or connector (boost pressure/temperature sensor - ECM)





6 Check boost pressure sensor power supply voltage

 a. Check wire harness between boost pressure/ temperature sensor connector terminal and ECM connector terminal.

Check for Open


Multimeter Connection	Condition	Specified Condition
B-011 (19) - B- 008 (F18) - E-035 (E11) - E-046 (3)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
B-011 (19) or E- 046 (3) - Body ground	Always	No continuity
B-011 (19) or E- 046 (3) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (boost pressure/temperature sensor - ECM)



ОК

7 Check boost pressure/temperature sensor

- a. Remove the boost pressure/temperature sensor.
- b. Check sensor connection part for debris and damage.

NG Clean or replace boost pressure/ temperature sensor

ОК

8 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0234 00, P0237 16 or P0238 17 still exists.

NG Replace ECM



System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.






DTC	P0556 00	Brake Booster Pressure Sensor Circuit Performance Non-plausible	
DTC	P0557 16	Brake Booster Pressure Sensor Circuit Low	
DTC	P0558 17	Brake Booster Pressure Sensor Circuit High	
DTC	P1137 17	Diagnosis of Pressure Sensor in Brake Booster Pump Circuit High	
	ı		
DTC	P1138 16	Diagnosis of Pressure Sensor in Brake Booster Pump Circuit Low	
DTC	P1139 7A	Diagnosis of Pressure Sensor in Brake Booster Pump Leakage Detection	
		1	
DTC	P1479 00	Non-plausible Error for Brake Booster Diagnosis	



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران





DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0556 00	Brake Booster Pressure Sensor Circuit Performance Non-plausible		
P0557 16	Brake Booster Pressure Sensor Circuit Low		
P0558 17	Brake Booster Pressure Sensor Circuit High		
P1137 17	Diagnosis of Pressure Sensor in Brake Booster Pump Circuit High	Ignition switch ON Engine running	Vacuum pressure sensorWire harness or connectorECM
P1138 16	Diagnosis of Pressure Sensor in Brake Booster Pump Circuit Low		
P1139 7A	Diagnosis of Pressure Sensor in Brake Booster Pump Leakage Detection	تيجية	
P1479 00	Non-plausible Error for Brake Booster Diagnosis	کت دیجیتال خود	شر

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

• When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

1 Check ECM ground point

a. Turn ignition switch to OFF.

b. Check the ECM ground point B-019 (See page 06-23).

NG

Repair or replace ground wire harness or ground point

OK

- 2 Check vacuum pressure sensor connector
- a. Disconnect the vacuum pressure sensor connector B-056.
- b. Check the vacuum pressure sensor connector.

NG

Repair or replace connector


ОК

- 3 Check vacuum pressure sensor signal voltage
- a. Connect the vacuum pressure sensor connector B-056.
- b. Turn ignition switch to ON and start engine.
- c. Using a multimeter, measure voltage between terminal 1 of connector B-056 and body ground.

Multimeter Connection	Condition	Specified Condition
B-056 (1) - Body	When vacuum degree is maximum (70)	Voltage is about 1.3 V (value changes with model)
ground	When vacuum degree is minimum (0)	Voltage is about 4 V (value changes with model)

ок

Go to step 8



NG


4 Check vacuum pressure sensor power supply voltage

- a. Disconnect the vacuum pressure sensor connector B-056.
- b. Check voltage between connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
B-056 (3) - Body ground	Ignition switch ON	5 V

ок >

Go to step 6



NG

5 Check vacuum pressure sensor signal circuit

- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector B-011.
- c. Check wire harness between connector terminals.

Check for Open


		11 1 11
Multimeter Connection	Condition	Specified Condition
B-011 (12) - B- 056 (1)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
B-011 (12) or B- 056 (1) - Body ground	Always	No continuity
B-011 (12) or B- 056 (1) - Battery positive	Always	No continuity

NG >

Replace wire harness or connector (vacuum pressure sensor - ECM)



OK

6 Check vacuum pressure sensor power supply circuit


a. Check wire harness between vacuum pressure sensor connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
B-011 (19) - B- 056 (3)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
B-011 (19) or B- 056 (3) - Body ground	Always	No continuity
B-011 (19) or B- 056 (3) - Battery positive	Always	No continuity



NG

Repair or replace wire harness or connector (vacuum pressure/temperature sensor - ECM)

OK

اولين سامانه ديجيتال تعميركاران خودرودرابرا

- 7 Check vacuum pressure sensor
- a. Remove the vacuum pressure sensor.
- b. Check sensor connection part for debris and damage.

NG Clean or replace vacuum pressure sensor

ОК

- 8 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0556 00, P0557 16, P0558 17, P1137 17, P1138 16, P1139 7A or P1479 00 still exists.

NG Replace ECM



System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.






DTC	P0111 00	Intake Air Temp. Circ. Performance Non-plausible
DTC	P0112 16	Intake Air Temp. Circ. Low Input
DTC	P0113 17	Intake Air Temp. Circ. High Input







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0111 00	Intake Air Temp. Circ. Performance Non- plausible	Leavities and the ON	Intake pressure/temperature sensor
P0112 16	Intake Air Temp. Circ. Low Input	Ignition switch ON Engine running	Wire harness or connectorECM
P0113 17	Intake Air Temp. Circ. High Input		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

1 Check ECM ground point

- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG >

Repair or replace ground wire harness or ground point


OK

2 Check intake pressure/temperature sensor connector

- a. Disconnect the intake pressure/temperature sensor connector E-043 (arrow).
- b. Check the intake pressure/temperature sensor connector.

NG

Repair or replace connector






3 Check intake pressure/temperature sensor signal voltage

- a. Connect the intake pressure/temperature sensor connector E-043.
- b. Turn ignition switch to ON and start engine.
- Using a multimeter, measure voltage between terminal 2
 of connector E-043 and body ground.

Multimeter Connection	Condition	Specified Condition
E-046 (2) - Body ground	Ignition switch ON	5 V
	. 1 1 / 1	



Go to step 5



NG

4 Check intake pressure/temperature sensor signal circuit


- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector B-011.
- c. Check wire harness between connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-043 (2) - E-034 (109)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-043 (2) or E- 034 (109) - Body ground	Always	No continuity
E-043 (2) or E- 034 (109) - Battery positive	Always	No continuity



NG

Replace wire harness or connector (intake pressure/temperature sensor - ECM)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




- 5 Check intake pressure/temperature sensor ground circuit
- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector B-011.
- c. Check wire harness between connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-034 (85) - E- 043 (4)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-034 (85) or E- 043 (4) - Body ground	Always	No continuity



Multimeter Connection	Condition	Specified Condition
E-034 (85) or E- 043 (4) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (intake pressure/temperature sensor - ECM)

ОК

- 6 Check intake pressure/temperature sensor
- a. Remove the intake pressure/temperature sensor.
- b. Check resistance of intake pressure/temperature sensor.

Check for Open

Multimeter Connection	Condition	Specified Condition
Terminal 3 - Terminal 4	Always	2.5 kΩ ± 5% (at 20°C)

NG

Replace intake pressure/temperature sensor

ОК

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

- 7 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0111 00, P0112 16 or P0113 17 still exists.

NG Replace ECM


OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0116 00	Engine Coolant Temp. Circ. Performance Non-plausible
DTC	P0117 16	Engine Coolant Temp. Circ. Low Input
DTC	P0118 17	Engine Coolant Temp. Circ. High Input







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0116 00	Engine Coolant Temp. Circ. Performance Non-plausible	lancition quitale ON	Engine coolant temperature sensor
P0117 16	Engine Coolant Temp. Circ. Low Input	Ignition switch ON Engine running	Wire harness or connectorECM
P0118 17	Engine Coolant Temp. Circ. High Input		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

1 Check ECM ground point

- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check engine coolant temperature sensor connector
- a. Disconnect the engine coolant temperature sensor connector E-061 (arrow).
- b. Check the engine coolant temperature sensor connector.

NG)

Repair or replace connector






- 3 Check engine coolant temperature sensor power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between engine coolant temperature sensor terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-061 (2) - Body ground	Ignition switch ON	5 V

OK Go to step 5



NG

4 Check engine coolant temperature sensor power supply circuit

- a. Disconnect the engine coolant temperature sensor connector E-061.
- b. Check voltage between connector terminal and body ground.
- c. Check wire harness between engine coolant temperature sensor connector terminal and ECM connector terminal.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-061 (2) - E-034 (101)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-061 (2) or E- 034 (101) - Body ground	Always	No continuity
E-061 (2) or E- 034 (101) - Battery positive	Always	No continuity

NG

Replace wire harness or connector (engine coolant temperature sensor - ECM)





5 Check engine coolant temperature sensor ground circuit


a. Check wire harness between engine coolant temperature sensor connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-061 (1) - E-034 (85)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-061 (1) or E- 034 (85) - Body ground	Always	No continuity
E-061 (1) or E- 034 (85) - Battery positive	Always	No continuity



NG

Repair or replace wire harness or connector (engine coolant temperature sensor - ECM)




اولين سامانه ديجيتال بتعميركاران خودرودراير

- 6 Check engine coolant temperature sensor
- a. Remove the engine coolant temperature sensor.
- b. Check resistance of engine coolant temperature sensor.

Check for Open

Multimeter Connection	Specified Condition	
Terminal 1 - Terminal 2	Always Resistance is $2.5 \text{ k}\Omega \pm 5\%$ at normal temperature (20°C), $300 \Omega - 400 \Omega$ in boiled water (80°C) (value changes with boiled water temperature)	





Replace engine coolant temperature sensor

ОК

7 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0116 00, P0117 16 or P0118 17 still exists.

NG >

Replace ECM

ОК

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.




اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC	P0121 29	Throttle Pos. Sensor 1 Circ. Performance Non-plausible
DTC	P0122 16	Throttle Pos. Sensor 1 Circ. Low Input
DTC	P0123 17	Throttle Pos. Sensor 1 Circ. High Input
DTC	P0221 29	Throttle Position Sensor 2 Performance Non-plausible
DTC	P0222 16	Throttle Position Sensor 2 Performance Low Input
DTC	P0223 17	Throttle Position Sensor 2 Performance High Input







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0121 29	Throttle Pos. Sensor 1 Circ. Performance Non-plausible		
P0122 16	Throttle Pos. Sensor 1 Circ. Low Input		
P0123 17	Throttle Pos. Sensor 1 Circ. High Input	 Ignition switch ON Engine running Throttle position sensor 1 Throttle position sensor 2 Wire harness or connector ECM 	'
P0221 29	Throttle Position Sensor 2 Performance Non-plausible		Wire harness or connector
P0222 16	Throttle Position Sensor 2 Performance Low Input		
P0223 17	Throttle Position Sensor 2 Performance High Input		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
 - Start engine and warm it up to normal operating temperature, and then select Read Code.
 - If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
 - If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

• When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check electronic throttle position sensor connector
- a. Disconnect the electronic throttle position sensor connector E-048 (arrow).
- b. Check the electronic throttle connector.

NG


Repair or replace connector





- 3 Check throttle position sensor signal voltage
- a. Turn ignition switch to ON.
- b. Connect the electronic throttle position sensor connector E-048.
- c. Using diagnostic tester, check signal voltage of throttle position sensor.

Multimeter Connection	Condition	Specified Condition
E-048 (6) - Body ground	Ignition switch ON, idling	0.74 V
	Ignition switch ON, throttle fully opened	4.24 V
E-048 (5) - Body	Ignition switch ON, idling	4.24 V
ground	Ignition switch ON, throttle fully opened	0.36 V



NG

Go to step 8

ОК

4 Check throttle position sensor power supply voltage

- a. Turn ignition switch to OFF.
- b. Disconnect the electronic throttle position sensor connector E-048.
- Turn ignition switch to ON and check voltage between electronic throttle position sensor connector terminal and body ground.

Voltage Inspection

Multimeter Connection	Condition	Specified Condition
E-048 (3) - Body ground	Ignition switch ON	5 V

NG

Go to step 6





5 Check throttle position sensor power supply circuit and ground circuit

- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector E-034.
- c. Check wire harness between electronic throttle position sensor connector terminal and ECM connector terminal.

Check for Open


Multimeter Connection		Condition	Specified Condition
	E-048 (3) - E-034 (107) or E-048 (2) - E-034 (86)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-048 (3), E-034 (107) - Body ground or battery positive	Always	No continuity
E-048 (2), E-034 (86) - Body ground or battery positive	Aiways	No continuity

NG >

Replace wire harness or connector (electronic throttle - ECM)





6 Check throttle position sensor signal circuit

a. Check wire harness between electronic throttle position sensor connector terminal and ECM connector terminal.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-048 (6) - E-034 (77)	Always	Continuity
E-048 (5) - E-034 (78)	7 iiway 5	Continuity

Check for Short

NG

Multimeter Connection	Condition	Specified Condition
E-048 (6), E-034 (77) - Body ground or battery positive	الاذ	لحيا
E-048 (5), E-034 (78) - Body ground or battery positive	Always رو سامانه (می	No continuity

Repair or replace wire harness or connector (electronic throttle - ECM)




OK

7 Check electronic throttle

- a. Check electronic throttle for carbon deposits and foreign matter accumulation inside.
- b. Check if electronic throttle valve body is stuck.
- c. Check resistance of electronic throttle.

Throttle Inspection

Multimeter Connection	Condition	Specified Condition
Terminal 5 - Terminal 3	Throttle turned	Resistance between terminals 5 and 3 increases as throttle valve opens
Terminal 6 - Terminal 3		Resistance between terminals 6 and 3 decreases as throttle valve opens
Terminal 5 - Terminal 3 and Terminal 6 - Terminal 3	On same position of valve at normal temperature	Sum of resistance in two groups is $1.9 \text{ k}\Omega \pm 0.2 \text{ k}\Omega$



NG

Clean or replace electronic throttle assembly, and go to next step

OK

8 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0121 29, P0122 16, P0123 17, P0221 29, P0222 16 or P0223 17 still exists.

NG Replace ECM


ОК

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0130 00	O2 Sensor Circ. Malfunction (Upstream of the Catalyzer)
DTC	P0131 16	O2 Sensor Circ. Low Voltage (Upstream of the Catalyzer)
DTC	P0132 17	O2 Sensor Circ. High Voltage (Upstream of the Catalyzer)
DTC	P0133 00	O2 Sensor Circ. Slow Response (Upstream of the Catalyzer)
DTC	P0134 00	O2 Sensor Circ. No Activity Detected (Upstream of the Catalyzer)
DTC	P0170 00	Fuel Trim, Malfunction
DTC	P0171 00	Fuel Trim, System Too Lean
DTC	P0172 00	Fuel Trim, System Too Rich
DTC	P2195 00	O2 Sensor Signal Stuck Lean (Upstream of the Catalyzer)
DTC	P2196 00	O2 Sensor Signal Stuck Rich (Upstream of the Catalyzer)

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0130 00	O2 Sensor Circ. Malfunction (Upstream of the Catalyzer)		
P0131 16	O2 Sensor Circ. Low Voltage (Upstream of the Catalyzer)		
P0132 17	O2 Sensor Circ. High Voltage (Upstream of the Catalyzer)		
P0133 00	O2 Sensor Circ. Slow Response (Upstream of the Catalyzer)		
P0134 00	O2 Sensor Circ. No Activity Detected (Upstream of the Catalyzer)	Ignition switch ON Engine running	Upstream oxygen sensorWire harness or connectorECM
P0170 00	Fuel Trim, Malfunction		
P0171 00	Fuel Trim, System Too Lean		
P0172 00	Fuel Trim, System Too Rich	ـ پجيا	
P2195 00	O2 Sensor Signal Stuck Lean (Upstream of the Catalyzer)	کت دیجیتال خود	شر
P2196 00	O2 Sensor Signal Stuck Rich (Upstream of the Catalyzer)	ین سامانه دیجیت	gl O-O

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).



 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG)

Repair or replace ground wire harness or ground point


OK

- 2 Check upstream oxygen sensor connector
- a. Disconnect the upstream oxygen sensor connector E-055 (arrow).
- b. Check the upstream oxygen sensor connector.

NG

Repair or replace connector

، سامانه دیجیتال تعمیرکاران خودرو در ایران



ОК


3 Check upstream oxygen sensor signal

- a. Connect the upstream oxygen sensor connector E-055.
- b. Turn ignition switch to ON, start engine and idle it for about 3 minutes.
- c. Using a multimeter, measure voltage between terminals A and B of connector E-055.

Multimeter Connection	Condition	Specified Condition
E-055 (A) - E-055 (B)	Engine running	Fluctuates rapidly between 0.1 and 0.9 V (when operating temperature is 350°C)

NG

Go to step 4





4 Check upstream oxygen sensor signal circuit


- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector E-034.
 - c. Disconnect the upstream oxygen sensor connector E-055.
 - d. Check wire harness between upstream oxygen sensor connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition	
E-055 (B) - E-034 (104) or E-055 (A) - E-034 (80)	Always	Continuity	

Check for Short

Multimeter Connection	Condition	Specified Condition
E-055 (B), E-034 (104) - Body ground or battery positive	Always	No continuity
E-055 (A), E-034 (80) - Body ground or battery positive	Aiways	No continuity



NG Replace wire harness or connector (upstream oxygen sensor - ECM)

ОК

- 5 Check upstream oxygen sensor
- a. Remove the upstream oxygen sensor.
- b. Check upstream oxygen sensor for following problems.
 - Moisture enters internal of sensor, temperature changes greatly or probe is broken.
 - Oxygen sensor is "poisoned" (Pb, S, Br and Si etc.).

NG)

Replace upstream oxygen sensor



- 6 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0130 00, P0131 16, P0132 17, P0133 00, P0134 00, P2177 00, P2178 00, P2187 00, P2188 00, P2195 00 or P2196 00 still exists.

NG)

Replace ECM

OK

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.


DTC	P0136 00	O2 Sensor Circ. Malfunction (Downstream of the Catalyzer)
DTC	P0137 16	O2 Sensor Circ. Low Voltage (Downstream of the Catalyzer)
DTC	P0138 17	O2 Sensor Circ. High Voltage (Downstream of the Catalyzer)
DTC	P0140 00	O2 Sensor Circ. No Activity Detected (Downstream of the Catalyzer)
DTC	P2270 00	O2 Sensor Signal Stuck Lean (Downstream of the Catalyzer)
DTC	P2271 00	O2 Sensor Signal Stuck Rich (Downstream of the Catalyzer)



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران





DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0136 00	O2 Sensor Circ. Malfunction (Downstream of the Catalyzer)		
P0137 16	O2 Sensor Circ. Low Voltage (Downstream of the Catalyzer)		
P0138 17	O2 Sensor Circ. High Voltage (Downstream of the Catalyzer)		Downstream oxygen sensor
P0140 00	O2 Sensor Circ. No Activity Detected (Downstream of the Catalyzer)	Ignition switch ON Engine running	Wire harness or connectorECM
P2270 00	O2 Sensor Signal Stuck Lean (Downstream of the Catalyzer)		
P2271 00	O2 Sensor Signal Stuck Rich (Downstream of the Catalyzer)	: پچين	

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point B-017 (See page 06-23).

NG >


Repair or replace ground wire harness or ground point



- 2 Check downstream oxygen sensor connector
- a. Disconnect the downstream oxygen sensor connector B-062 (arrow).
- b. Check the downstream oxygen sensor connector.

NG

Repair or replace connector






- 3 Check downstream oxygen sensor signal
- a. Connect the downstream oxygen sensor connector B-062.
- b. Turn ignition switch to ON, start engine and idle it for about 3 minutes.
- c. Use diagnostic tester to check downstream oxygen sensor signal voltage, or use multimeter to measure voltage between terminals B and A of connector B-062.

Multimeter Connection	Condition	Specified Condition
B-062 (A) - B-062 (B)	Engine running	Fluctuates slightly at about 0.45 V

NG

Go to step 4



ОК

Check downstream oxygen sensor signal circuit

- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector B-011.
- c. Disconnect the downstream oxygen sensor connector B-
- d. Check wire harness between downstream oxygen sensor connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
B-062 (B) - B-011 (21) or B-062 (A) - B-011 (43)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
B-062 (B), B-011 (21) - Body ground or battery positive	Always	No continuity
B-062 (A), B-011 (43) - Body ground or battery	رو سامانه (می	ديجيتال خود
positive		

NG

Replace wire harness or connector (downstream oxygen sensor - ECM)



5 Check downstream oxygen sensor

- a. Remove the downstream oxygen sensor.
- b. Check downstream oxygen sensor for following problems.
 - Moisture enters internal of sensor, temperature changes greatly or probe is broken.
 - Oxygen sensor is "poisoned" (Pb, S, Br and Si etc.).


NG

Replace downstream oxygen sensor



6 **Check for DTCs**

a. Using X-431 3G diagnostic tester, read ECM DTCs.



- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0136 00, P0137 16, P0138 17, P0140 00, P2270 00 or P2271 00 still exists.

NG

Replace ECM




System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.





DTC	P0606 94	Torque Monitoring Error in Level 2	
DTC	P0606 92	Engine Speed Monitoring Error in Level 2	
DTC	P0606 64	Load Signal, Wiring Harness or ECU Error	
DTC	P0606 61	Ignition Angle Signal, Wiring Harness or ECU Error	
DTC	P0606 67	ECU Fault Reaction Monitoring Error	
DTC	P0606 96	AD Convertor Monitoring Error	
DTC	P0606 1C	Throttle Signal, Wiring Harness or ECU Error	
DTC	P0606 55	Variant Coding Monitoring Error	
DTC	P0606 00	Safety Monitoring Fuel Cutoff Error	
DTC	P0606 62	Pedal Signal Unplausibility Error in Level 2	
DTC	P0606 63	Safety Monitoring Function Error (SSM System Monitoring Error)	
DTC	P0606 48	Monitoring Fault Reaction Error	
DTC	P0606 47	Monitoring Module Feedback Error	
DTC	P0606 75	Shut Off Path Test Error	
DTC	P0606 49	Monitoring Module Inquiry Error	
DTC	P1100 00	Engine Torque Control Adaption at Limit	



DTC	DTC Definition	DTC Detection Condition	Possible Cause	
P0606 94	Torque Monitoring Error in Level 2			
P0606 92	Engine Speed Monitoring Error in Level 2			
P0606 64	Load Signal, Wiring Harness or ECU Error			
P0606 61	Ignition Angle Signal, Wiring Harness or ECU Error			
P0606 67	ECU Fault Reaction Monitoring Error			
P0606 96	AD Convertor Monitoring Error			
P0606 1C	Throttle Signal, Wiring Harness or ECU Error	Ignition switch ON Engine running		
P0606 55	Variant Coding Mon <mark>i</mark> toring Error		Throttle Low battery voltage	
P0606 00	Safety Monitoring Fuel Cutoff Error		Throttle mechanical malfunction Wire harness or connector	
P0606 62	Pedal Signal Unplausibility Error in Level 2		شرکت دیجیتال خود روا	
P0606 63	Safety Monitoring Function Error (SSM System Monitoring Error)			gl O
P0606 48	Monitoring Fault Reaction Error			
P0606 47	Monitoring Module Feedback Error			
P0606 75	Shut Off Path Test Error			
P0606 49	Monitoring Module Inquiry Error			
P1100 00	Engine Torque Control Adaption at Limit			

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.

- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

• When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check electronic throttle position sensor connector
- a. Disconnect the electronic throttle position sensor connector E-048 (arrow).
- b. Check the electronic throttle connector.

NG

Repair or replace connector



ОК

- 3 Clear DTCs
- a. Use X-431 3G diagnostic tester to clear ECM DTCs.
- b. Start engine and depress accelerator pedal for several times in neutral condition.
- c. Using X-431 3G diagnostic tester, read ECM DTCs.
- d. Check if DTC P0606 94, P0606 92, P0606 64, P0606 61, P0606 67, P0606 96, P0606 1C, P0606 55, P0606 00, P0606 62, P0606 63, P0606 48, P0606 47, P0606 75, P0606 49 or P1100 00 still exists.

NG Replace ECM

OK

- 4 Perform electronic throttle self-learning procedures
- a. Perform the electronic throttle self-learning procedures (See page 06-24).



System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.




اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC	P2122 16	Pedal Pos. Sensor 1 Circ. Low Input
DTC	P2123 17	Pedal Pos. Sensor 1 Circ. High Input
DTC	P2127 16	Pedal Pos. Sensor 2 Circ. Low Input
DTC	P2128 17	Pedal Pos. Sensor 2 Circ. High Input
DTC	P2138 00	Pedal Movement Check Error
DTC	P2138 29	Pedal Pos. Sensor 1/2 Unplausible







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P2122 16	Pedal Pos. Sensor 1 Circ. Low Input		
P2123 17	Pedal Pos. Sensor 1 Circ. High Input		
P2127 16	Pedal Pos. Sensor 2 Circ. Low Input	Ignition switch ON Engine running	Accelerator pedal position sensorWire harness or connector
P2128 17	Pedal Pos. Sensor 2 Circ. High Input		• ECM
P2138 00	Pedal Movement Check Error		
P2138 29	Pedal Pos. Sensor 1/2 Unplausible		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point B-017 (See page 06-23).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check electronic accelerator pedal connector
- a. Disconnect the electronic accelerator pedal connector B-002 (arror).
- b. Check the electronic accelerator pedal connector.

NG

Repair or replace connector






- 3 Check electronic accelerator pedal voltage
- a. Turn ignition switch to ON.
- b. Connect the electronic accelerator pedal sensor connector B-002.
- c. Check electronic accelerator pedal sensor signal voltage and ground.

Multimeter Connection	Condition	Specified Condition
B-002 (3, 6) - Body ground	رو سامانه زمیا	5 V
B-002 (2, 5) - Body ground	Ignition switch ON	سامانین پیتا

NG

Repair or replace related wire harness




ок

4 Check electronic accelerator pedal circuit

- a. Turn ignition switch to OFF.
- b. Disconnect electronic accelerator pedal sensor connector B-002 and ECM connector B-011.
- c. Check wire harness between connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
B-002 (6) - B-011 (37)		
B-002 (5) - B-011 (7)	Always	Continuity
B-002 (3) - B-011 (36)	Always	Continuity
B-002 (2) - B-011 (59)		



Check for Short

	Multimeter Connection	Condition	Specified Condition
C	B-002 (6, 5, 3, 2) or B-011 (37, 7, 36, 59) - Body	رو سامانه (می	ديجيتال خود
	ground B-002 (6, 5, 3, 2) or B-011 (37, 7,	Always	No continuity
	36, 59) - Battery positive		

NG


Repair or replace related wire harness (electronic accelerator pedal - ECM)



5 Check electronic accelerator pedal sensor signal circuit

- a. Connect the electronic accelerator pedal sensor connector.
- b. Turn ignition switch to ON.
- c. Using a multimeter, measure voltage between terminals 4, 1 of connector B-002 and body ground.

Multimeter Connection	Condition	Specified Condition
B-002 (4) - Body	Accelerator pedal not depressed	0.72 V
ground	Accelerator pedal fully depressed	3.95 V
B-002 (1) - Body	Accelerator pedal not depressed	0.36 V
ground	Accelerator pedal fully depressed	1.97 V



Check for Open

	Multimeter Connection	Condition	Specified Condition
C	B-002 (4) - B-011 (45)	Always	Continuity
-	B-002 (1) - B-011 (30)	Aiways	Continuity
	(30)	ا ، تعمیر کاران	سامانه ديجيتا

Check for Short

Multimeter Connection	Condition	Specified Condition
B-002 (4, 1) or B- 011 (45, 30) - Body ground	Always	No continuity
B-002 (4, 1) or B- 011 (45, 30) - Battery positive		

NG

Replace wire harness or connector (electronic accelerator pedal - ECM)



- 6 Replace electronic accelerator pedal and recheck DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".

c. Check if DTC P2122 16, P2123 17, P2127 16, P2128 17, P2138 00 or P2138 29 still exists.

NG Replace ECM

ОК

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.






DTC P0301-00 Misfire Detected on Cylinder 1 DTC P0302-00 Misfire Detected on Cylinder 2	DTC	P0300-00	Misfire Detected
DTC P0302-00 Misfire Detected on Cylinder 2	DTC	P0301-00	Misfire Detected on Cylinder 1
	DTC	P0302-00	Misfire Detected on Cylinder 2
DTC P0303-00 Misfire Detected on Cylinder 3	DTC	P0303-00	Misfire Detected on Cylinder 3
DTC P0304-00 Misfire Detected on Cylinder 4			·







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0300-00	Misfire Detected	Ignition switch ON Engine running	Ignition coilWire harness or connectorEngine mechanical
P0301-00	Misfire Detected on Cylinder 1		
P0302-00	Misfire Detected on Cylinder 2		
P0303-00	Misfire Detected on Cylinder 3		• ECM
P0304-00	Misfire Detected on Cylinder 4		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- · Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point B-037 (See page 06-23).

NG

Repair or replace ground wire harness or ground point

ок

- 2 Check for DTCs related to injector in corresponding cylinder
- a. Connect diagnostic tester, and check for DTCs related to injector in corresponding cylinder.

NG


Repair DTCs related to injector in corresponding cylinder (See page 06-54)



- 3 Check ignition coil connector
- a. Turn ignition switch to OFF.
- b. Disconnect the ignition coil connectors (arrow).
- c. Check the ignition coil connectors.

NG)

Repair or replace connector





- 4 Check compression of misfiring cylinder
- a. Measure compression of misfiring cylinder (See page 07-20).

NG

Check engine to confirm cause of low compression

ОК

Check injectors, valve clearance, intake system and fuel pressure, etc. of misfiring cylinder


- 5 Check ignition coil
- a. Check resistance of ignition coil primary winding with an oscilloscope.
- b. Check resistance of ignition coil secondary winding.

Secondary Ignition Coil Inspection

Multimeter Connection	Condition	Specified Condition
Terminal 2 - Terminal 3	At normal temperature (25°C ± 5°C)	0.5 Ω - 0.64 Ω



Replace ignition coil in corresponding cylinder





- 6 Check ignition coil
- a. Turn ignition switch to ON.
- b. Remove the ignition coil.
- c. Visually check ignition coil for cracks or bumps.

NG

Replace ignition coil




7 Check ignition coil power supply circuit

- a. Turn ignition switch to OFF.
- b. Check the fuse EF31 and main relay.
- c. Check wire harness between ignition coil connector terminal and engine compartment fuse and relay box connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-030 (1) - E-017 (A8)	.رو سامانه (می	ديجيتال خود
E-032 (1) - E-017 (A8) E-033 (1) - E-017	Always	Continuity
(A8)		
E-031 (1) - E-017 (A8)		



Check for Short

Multimeter Connection	Condition	Specified Condition
E-030 (1), E-032 (1), E-033 (1), E- 031 (1) or E-017 (A8) - Body ground	Always	No continuity
E-030 (1), E-032 (1), E-033 (1), E- 031 (1) or E-017 (A8) - Battery positive	Always	NO continuity

NG

Replace wire harness or connector (ignition coil- engine compartment fuse and relay box)


ОК

8 Check ignition coil control circuit

- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector E-034.
- c. Check wire harness between ignition coil connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-030 (2) - E-034 (100)		
E-032 (2) - E-034 (99)	Always	Continuity
E-033 (2) - E-034 (76)	Always	Continuity
E-031 (2) - E-034 (88)	مرسامانه (مر	در درتال خور



Check for Short

Multimeter Connection	Condition	Specified Condition
E-030 (2), E-032 (2), E-033 (2), E- 031 (2) or E-034 (100, 99, 76, 88) - Body ground	Always	No continuity
E-030 (2), E-032 (2), E-033 (2), E- 031 (2) or E-034 (100, 99, 76, 88)- Battery positive	Always	No continuity

NG]

Repair or replace wire harness or connector (ignition coil - ECM)

ОК

9 Check ignition coil ground circuit

- a. Turn ignition switch to OFF.
- b. Check the E-045 ground point.
- c. Check wire harness between ignition coil connector terminal and E-045 ground point.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-030 (3) - E-045	Always	Continuity
E-032 (3) - E-045		
E-033 (3) - E-045		
E-031 (3) - E-045		

Check for Short

Multimeter Connection	Condition	Specified Condition
E-030 (3), E-032 (3), E-033 (3), E- 031 (3) or E-045 - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (ignition coil - E-045 ground point)

ОК

10 Check spark plug

- a. Turn ignition switch to ON.
- b. Remove the spark plug.
- c. Check spark plug for electric leakage, air leakage and clearance.

NG Replace spark plug

ОК

11 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0300-00、 P0301-00、 P0302-00、 P0303-00 or P0304-00 still exists.


NG Replace ECM



System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0322 00	EPM - Crankshaft Signal Fault	Ignition switch ON Engine running	Speed sensorWire harness or connectorECM

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

• When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG

Repair or replace ground wire harness or ground point



- 2 Check engine speed sensor signal waveform
- a. Turn ignition switch to ON, start engine and observe signal waveform of engine speed sensor with an oscilloscope.

OK]

Go to step 9



RM1A065675

NG

- 3 Check engine speed sensor connector
- a. Turn ignition switch to OFF.
- b. Disconnect the engine speed sensor connector E-058.
- c. Check the engine speed sensor connector.

NG

Repair or replace engine speed sensor connector

OK

- 4 Check installation of engine speed sensor
- a. Remove the engine speed sensor.
- b. Check and clean engine speed sensor and installation area, and check for damage, foreign matter or excessive movement, etc. that cause signal incorrectness.

NG >

Clean or replace engine speed sensor

OK

- 5 Check engine speed sensor power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between terminal 1 of engine speed sensor connector E-058 and body ground.
 Voltage Inspection

Multimeter Connection	Condition	Specified Condition
E-058 (1) - Body ground	Ignition switch ON	5 V

NG)

Go to step 6

OK

6 Check engine speed sensor circuit


- a. Turn ignition switch to OFF.
- b. Disconnect the engine speed sensor connector E-058.
- c. Check wire harness between engine speed sensor connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-034 (108) - E- 058 (1)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-034 (108) or E- 058 (1) - Body ground	Always	No continuity
E-034 (108) or E- 058 (1) - Battery positive	Always	No continuity



NG

Repair or replace wire harness or connector (engine speed sensor - ECM)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Replace ECM

- 7 Check engine speed sensor ground circuit
- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector E-034.
- c. Check wire harness between engine speed sensor connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-034 (84) - E- 058 (3)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-034 (84) or E- 058 (3) - Body ground	Always	No continuity
E-034 (84) or E- 058 (3) - Battery positive	Aiways	140 continuity

NG

Repair or replace wire harness or connector (engine speed sensor - ECM)

OK

Replace ECM

- 8 Check engine speed sensor signal circuit
- a. Disconnect the ECM connector E-034.
- b. Check wire harness between engine speed sensor connector terminal and ECM connector terminal.

دىحىتال خودرو سامانه (مستولى خودرو


Multimeter Connection	Condition	Specified Condition
E-058 (2) - E-034	Always	Continuity
(96)	Aiways	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-058 (2) or E- 034 (96)- Body ground	Always	No continuity
E-058 (2) or E- 034 (96)- Battery positive	Always	No continuity

NG

Replace wire harness or connector (engine speed sensor - ECM)



OK

9 Check flywheel ring gear

a. Turn crankshaft, and check crankshaft and flywheel ring gear for damage or foreign matter, etc. that cause signal incorrectness.

NG

Clear off debris and clean flywheel gear ring. Replace flywheel if necessary

OK

10 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0322 00 still exists.

NG Repla

Replace ECM

ОК

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

DTC	P0327 16	Knock Sensor 1 Circ. Low Input
DTC	P0327 14	Knock Sensor 1 Circuit Low
DTC	P0327 00	Knock Sensor 1 Circuit Low
DTC	D0220 47	Knock Sensor 1 Circ. High Input
סום ן	PU320 17	Knock Sensor i Circ. riigii iliput
DTC		Knock Sensor 1 Circuit High







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0327 16	Knock Sensor 1 Circ. Low Input		
P0327 14	Knock Sensor 1 Circuit Low		
P0327 00	Knock Sensor 1 Circuit Low	Ignition switch ON Engine running • Knock sensor • Wire harness or connector • ECM	
P0328 17	Knock Sensor 1 Circ. High Input		
P0328 15	Knock Sensor 1 Circuit High		
P0328 00	Knock Sensor 1 Circuit High		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check knock sensor connector
- a. Disconnect the knock sensor connector E-050 (arrow).
- b. Check the knock sensor connector.

NG)

Repair or replace wire harness connector





- 3 Check knock sensor signal circuit
- a. Disconnect the ECM wire harness connector E-034.
- b. Check wire harness between terminals of connector E-034 and connector E-050.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-034 (90) - E- 050 (1)	رو سامانه (می Always	Continuity
E-034 (89) - E- 050 (2)	ل تعمیرکاران	سامانه دیجیتا

Check for Short

Multimeter Connection	Condition	Specified Condition
E-034 (90, 89) or E-050 (1, 2) - Body ground	Always	No continuity
E-034 (90, 89) or E-050 (1, 2) - Battery positive	Always	No continuity



Replace wire harness or connector (knock sensor- ECM)



ОК

- 4 Check installation of knock sensor
- a. Remove the knock sensor.

b. Check installation area of knock sensor, and check for damage, foreign matter or excessive movement, etc. that cause signal incorrectness.

NG Clean installation area or replace knock sensor

ОК

- 5 Check resistance of knock sensor
- a. Check resistance between terminals 1 and 2 of knock sensor.

HINT:

OK: Resistance should be more than 1 M Ω (at normal temperature).

NG Replace knock sensor

OK

- 6 Check knock sensor signal
- a. Install the knock sensor.
- b. Slightly strike around knock sensor with a rubber hammer, and measure if voltage is generated between 2 terminals of knock sensor with multimeter (mV) at the same time.

NG Replace knock sensor

OK

ولین سامانه دیجیتال تعمیرکاران خودر و در ایران

7 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0327 16, P0327 16, P0327 14, P0327 00, P0328 17, P0328 15, P0328 00 still exists.

NG Replace ECM


OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0341 00	EPM - Camshaft Signal Fault
DTC	P0012 00	Inlet Camshaft not in Locking Position During Start
DTC	P0016 22	Retard Error for Alignment Between Camshaft (Inlet) and Crankshaft
DTC	P0016 21	Advance Error for Alignment Between Camshaft (Inlet) and Crankshaft
DTC	P0016 29	Npl Error for Alignment Between Camshaft (Inlet) and Crankshaft







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0341 00	EPM - Camshaft Signal Fault		
P0012 00	Inlet Camshaft not in Locking Position During Start		
P0016 22	Retard Error for Alignment Between Camshaft (Inlet) and Crankshaft	Ignition switch ON Engine running	 Camshaft position sensor Wrong camshaft position sensor installation position Engine mechanical malfunction
P0016 21	Advance Error for Alignment Between Camshaft (Inlet) and Crankshaft		Wire harness or connectorECM
P0016 29	Npl Error for Alignment Between Camshaft (Inlet) and Crankshaft		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

• When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG Repair

Repair or replace ground wire harness or ground point


OK

2 Check intake camshaft position sensor signal waveform

 a. Turn ignition switch to ON, start engine and observe signal waveform of intake camshaft position sensor with an oscilloscope.

NG]

Go to step 10



RM1A065720




3 Check intake camshaft position sensor connector

- a. Turn ignition switch to OFF.
- b. Disconnect the intake camshaft position sensor connector E-047 (arrow).
- c. Check the intake camshaft position sensor connector.

NG

Repair or replace intake camshaft position sensor connector



دیجیتال خودرو سامانه (مسئولیت محدود




اولین سامانه دیدیتال تعمیرکاران خودرو در ایرار

- 4 Check intake camshaft position sensor power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between terminal 3 of intake camshaft position sensor connector E-047 and body ground.

Multimeter Connection	Condition	Specified Condition
E-047 (3) - Body ground	Ignition switch ON	5 V

NG

Go to step 6



OK _

5 Check intake camshaft position sensor power supply circuit


- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector E-034.
- c. Check wire harness between intake camshaft position sensor connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-047 (3) - E-034 (98)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-047 (3) or E- 034 (98) - Body ground	Always	No continuity
E-047 (3) or E- 034 (98) - Battery positive	Always	No continuity



NG

Repair or replace wire harness or connector (intake camshaft position sensor - ECM)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران




6 Check intake camshaft position sensor ground circuit

- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector E-034.
- c. Check wire harness between intake camshaft position sensor connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-047 (1) - E-034 (95)	Always	Continuity



Check for Short

Multimeter Connection	Condition	Specified Condition
E-047 (1) or E- 034 (95) - Body ground	Always	No continuity
E-047 (1) or E- 034 (95) - Battery positive	Always	140 Continuity

NG

Repair or replace wire harness or connector (intake camshaft position sensor - ECM)

ОК

7 Check intake camshaft position sensor signal circuit

a. Check wire harness between intake camshaft position sensor connector terminal and ECM connector terminal.

Check for Open


Multimeter Connection	Condition	Specified Condition	
E-047 (2) - E-034 (93)	Always	Continuity	

Check for Short

Multimeter Connection	Condition	Specified Condition
E-047 (2) or E- 034 (93) - Body ground	Always	No continuity
E-047 (2) or E- 034 (93) - Battery positive	Always	No continuity

NG


Replace wire harness or connector (intake camshaft position sensor - ECM)



OK


8 Check installation of intake camshaft position sensor

- a. Remove the intake camshaft position sensor.
- b. Check and clean intake camshaft position sensor and installation area, and check for damage, foreign matter or excessive movement, etc. that cause signal incorrectness.




OK

- 9 Check intake camshaft ring gear
- a. Check intake camshaft ring gear for damage or foreign matter (such as debris) that cause signal incorrectness.





- 10 Install a normal intake camshaft position sensor and observe signal waveform
- a. Install a normal intake camshaft position sensor.
- b. Connect the intake camshaft position sensor connector.
- c. Turn ignition switch to ON, start engine and observe signal waveform of intake camshaft position sensor with an oscilloscope.



OK

- ولین سامانه دیجیتال تعمیر Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0341 00, P0012 00, P0016 22, P0016 21 or P0016 29 still exists.




OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0018 22	Retard Error for Alignment Between Camshaft (Outlet) and Crankshaft
DTC	P0018 21	Advance Error for Alignment Between Camshaft (Outlet) and Crankshaft
DTC	P0018 29	Npl Error for Alignment Between Camshaft (Outlet) and Crankshaft
DTC	P0346 00	EPM - Camshaft2 Signal Fault







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0018 22	Retard Error for Alignment Between Camshaft (Outlet) and Crankshaft		
P0018 21	Advance Error for Alignment Between Camshaft (Outlet) and Crankshaft	Ignition switch ON Engine running	 Camshaft position sensor Wrong camshaft position sensor installation position Engine mechanical malfunction
P0018 29	Npl Error for Alignment Between Camshaft (Outlet) and Crankshaft		Wire harness or connectorECM
P0346 00	EPM - Camshaft2 Signal Fault		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG Repair or


Repair or replace ground wire harness or ground point

OK

- 2 Check exhaust camshaft position sensor signal waveform
- a. Turn ignition switch to ON, start engine and observe signal waveform of exhaust camshaft position sensor with an oscilloscope.

NG

Go to step 10




RM1A065720



- 3 Check exhaust camshaft position sensor connector
- a. Turn ignition switch to OFF.
- b. Disconnect the exhaust camshaft position sensor connector E-054 (arrow).
- c. Check the exhaust camshaft position sensor connector.

NG

Repair or replace exhaust camshaft position sensor connector



، دیجینال خودرو سامانه (مسئولیت محدو




اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

- 4 Check exhaust camshaft position sensor power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between terminal 3 of exhaust camshaft position sensor connector E-054 and body ground.

Multimeter Connection	Condition	Specified Condition
E-054 (3) - Body ground	Ignition switch ON	5 V

NG

Go to step 6



ОК

5 Check exhaust camshaft position sensor power supply circuit

- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector E-034.
- c. Check wire harness between exhaust camshaft position sensor connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-054 (3) - E-034 (98)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition	
E-054 (3) or E- 034 (98) - Body ground	Always	No continuity	
E-054 (3) or E- 034 (98) - Battery positive	Always	No continuity	

NG

Repair or replace wire harness or connector (exhaust camshaft position sensor - ECM)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران




6 Check exhaust camshaft position sensor ground circuit

- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector E-034.
- c. Check wire harness between exhaust camshaft position sensor connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-054 (1) - E-034 (95)	Always	Continuity



Check for Short

Multimeter Connection	Condition	Specified Condition	
E-054 (1) or E- 034 (95) - Body ground	Always	No continuity	
E-054 (1) or E- 034 (95) - Battery positive	Always	NO continuity	

NG

Repair or replace wire harness or connector (exhaust camshaft position sensor - ECM)

ОК

7 Check exhaust camshaft position sensor signal circuit

a. Check wire harness between exhaust camshaft position sensor connector terminal and ECM connector terminal.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-054 (2) - E-034 (105)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition	
E-054 (2) or E- 034 (105) - Body ground	Always	No continuity	
E-054 (2) or E- 034 (105) - Battery positive	Aiways	No continuity	

NG

Replace wire harness or connector (exhaust camshaft position sensor - ECM)



OK

8 Check installation of exhaust camshaft position sensor

- a. Remove the exhaust camshaft position sensor.
- b. Check and clean exhaust camshaft position sensor and installation area, and check for damage, foreign matter or excessive movement, etc. that cause signal incorrectness.

NG Clean installation area or replace exhaust camshaft position sensor

ОК

- 9 Check exhaust camshaft ring gear
- a. Check exhaust camshaft ring gear for damage or foreign matter (such as debris) that cause signal incorrectness.

NG Remove debris and clean exhaust camshaft ring gear or replace camshaft



- 10 Install a normal exhaust camshaft position sensor and observe signal waveform
- a. Install a normal exhaust camshaft position sensor.
- b. Connect the exhaust camshaft position sensor connector.
- c. Turn ignition switch to ON, start engine and observe signal waveform of exhaust camshaft position sensor with an oscilloscope.

NG Replace exhaust camshaft position sensor

OK

11 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0346 00, P0018 22, P0018 21 or P0018 29 still exists.

NG Replace ECM

ОК

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0420 00	Catalyst Conversion Insufficient

DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0420 00	Catalyst Conversion Insufficient	Ignition switch ON Engine running	 Three-way catalytic converter Leakage in exhaust system Upstream oxygen sensor Downstream oxygen sensor ECM

DTC Confirmation Procedure


Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- · Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

Diagnosis Procedure

- 1 Check for any other DTCs output (in addition to DTC P0420 00)
- a. Connect X-431 3G diagnostic tester to Data Link Connector (DLC).
- b. Turn ignition switch to ON, start engine and warm it up to normal operating temperature, and then select Read Code.

Display (DTC Output)	Proceed to
Other DTCs	А
P0420 00	В





- 2 Read datastream
- a. Using diagnostic tester, select Read Datastream.
- b. Check the datastream below.

Item	OK (Idling)		If NG, proceed to
Upstream Oxygen Sensor Voltage	Fluctuates rapidly betwee and 0.9 V	า 0.1	Α

Item			OK (Idling)	If NG, proceed to
Downstream Voltage	Oxygen	Sensor	Fluctuates slightly at about 0.45 V	В
Average Inject	ion Pulse W	/idth	Approximately 2.15 ms	С

A Replace upstream oxygen sensor

C Check injector, fuel pressure and other

causes for abnormal injection pulse width

В

- 3 Check exhaust system
- a. Turn ignition switch to ON and start engine.
- b. Check exhaust system for leakage.

NG Repair or replace related exhaust system components

OK

4 Check downstream oxygen sensor

NG Replace downstream oxygen sensor

ولین سامانه دیجیتال تعمیرکاران حودرو در ایرار

OK

Replace three-way catalytic converter, and go to step 5

- 5 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0420 00 still exists.

NG Replace ECM


OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0444 13	Evaporativ E Open	miss. Syst	em Purge	e Contro	ol Valve	Circuit
DTC	P0458 16	Evaporative Circuit Low	Emission	System	Purge	Control	Valve
DTC	P0459 17	Evaporative Circuit High	Emission	System	Purge	Control	Valve







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0444 13	Evaporativ Emiss. System Purge Control Valve Circuit Open		
P0458 16	Evaporative Emission System Purge Control Valve Circuit Low	Ignition switch ON Engine running	Canister solenoid valveWire harness or connectorECM
P0459 17	Evaporative Emission System Purge Control Valve Circuit High		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG)


Repair or replace ground wire harness or ground point

OK

- 2 Check canister solenoid valve connector
- a. Turn ignition switch to OFF.
- b. Disconnect the canister solenoid valve connector E-060 (arrow).
- c. Check the canister solenoid valve connector.

NG

Repair or replace connector






- 3 Check canister solenoid valve power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between canister solenoid valve connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-060 (1) - Body ground	Ignition switch ON	12 to 14 V

NG

Go to step 5



ок

4 Check canister solenoid valve power supply circuit

- a. Turn ignition switch to OFF.
- b. Check fuse EF34 and main relay.
- c. Disconnect the engine compartment fuse and relay box connector E-017.
- d. Check wire harness between canister solenoid valve connector terminal and engine compartment fuse and relay box connector terminal.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-017 (A10) - E- 060 (1)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-017 (A10) or E- 060 (1) - Body ground		
E-017 (A10) or E- 060 (1) - Battery	Always	No continuity
positive	ر و سامانه (می	ديحيتال خود

NG

Repair or replace wire harness or connector (canister solenoid valve - engine compartment fuse and relay box)





5 Check canister solenoid valve control circuit

- a. Disconnect the ECM connector E-034.
- b. Check wire harness between canister solenoid valve connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-034 (94) - E- 060 (2)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-034 (94) or E- 060 (2) - Body ground	Always	No continuity
E-034 (94) or E- 060 (2) - Battery positive	Aiways	140 Continuity

Ω + 0 0 E-060 E-060 E-060 RM1A065860

NG

Repair or replace wire harness or connector (canister solenoid valve - ECM)

- 6 Check canister solenoid valve
- a. Check resistance of canister solenoid valve.

Multimeter Connection	Specified Condition
Terminal 1 - Terminal 2	26 ± 4 Ω (at 20°C)

b. With battery voltage applied between terminals 1 and 2, valve should open when air is sucked into the valve; with battery voltage not applied, valve should close when air is sucked into the valve.

NG

Replace canister solenoid valve

ОК

- 7 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0444 13, P0458 16 or P0459 17 still exists.

NG Replace ECM

OK


System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.











DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0480 13	Cooling Fan 1 Control Circuit Error		
P0691 11	Fan 1 Control Circuit Low		
P0692 12	Fan 1 Control Circuit High	Ignition switch ON Engine running Output Output Description Output	- Wile Harriese serificator
P0481 13	Cooling Fan 2 Control Circuit Error		
P0693 11	Fan 2 Control Circuit Low		
P0694 12	Fan 2 Control Circuit High		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG

Repair or replace ground wire harness or ground point


OK

2 Check cooling fan control relay

- a. Turn ignition switch to OFF.
- b. Remove low speed fan relay and high speed fan relay from engine compartment fuse and relay box.
- c. Check the fan relay.

Multimeter Connection	Condition	Specified Condition
Terminal 87 - Terminal 30	Always	No continuity
Terminal 87 - Terminal 30	Continuity (When battery voltage is applied between terminal 85 and terminal 86)	Continuity

Repair or replace relay NG



OK


3 Check cooling fan control relay circuit voltage

a. Check voltage of cooling fan control relay connector 292 terminals.

	Multimeter Connection	Condition	Specified Condition
	Relay (86, 30) - Body ground	Ignition switch ON	11 to 14 V

NG

Repair or replace engine compartment fuse and relay box



OK

4 Check cooling fan high speed control circuit


- a. Disconnect the ECM connector B-011.
- b. Check wire harness between high speed fan control relay connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
B-011 (31) - B- 019 (G24)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
B-011 (31) or B- 019 (G24) - Body ground	Always	No continuity
B-011 (31) or B- 019 (G24) - Battery positive	Always	No continuity



NG

Repair or replace wire harness



5 Check cooling fan low speed control circuit


- a. Disconnect the ECM connector B-011.
- b. Check wire harness between low speed fan control relay connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
B-011 (56) - B- 019 (G30)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
B-011 (56) or B- 019 (G30) - Body ground	Always	No continuity
B-011 (56) or B- 019 (G30) - Battery positive	riways	



NG]

Repair or replace wire harness

ок

- 6 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0480 13, P0481 13, P0691 11, P0692 12, P0693 11 or P0694 12 still exists.

NG >

Replace ECM

ОК

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

حيجيتاك خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC	P0560 00	Non-plausible Error of Battery Voltage		
DTC	P0562 16	System Voltage Low		
DTC	P0563 17	System Voltage High		
DTC	P1101 00	System Voltage Can Not Fulfill Throttle Self Learning Condition		







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0560 00	Non-plausible Error of Battery Voltage		• Fuse
P0562 16	System Voltage Low	Ignition switch ON	Wire harness or connector
P1101 00	System Voltage Can Not Fulfill Throttle Self Learning Condition	Engine running	BatteryBattery terminalECM
P0563 17	System Voltage High		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check battery voltage
- a. Check if battery voltage is normal.

NG Recharge or replace battery

ОК

- 2 Check battery terminal
- a. Check if battery terminal is loose or corroded.

NG Tighten or replace battery terminal

ОК

- 3 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground points B-017, E-037 (See page 06-23).

NG Repair or replace ground wire harness or ground point

ОК

- 4 Check ECM connector
- a. Disconnect the ECM connector B-011.
- b. Check the ECM connector

NG Repair or replace ECM connector


ОК

- 5 Check ECM power supply voltage
- a. Check voltage between terminals 35, 20 of ECM connector B-011 and body ground.

Voltage Inspection

Multimeter Connection	Condition	Specified Condition
B-011 (35, 20) - Body ground	Always	11 to 14 V

NG Go to step 8



ОК

- 6 Check ECM fuse
- a. Unplug ECM fuses EF37 (10 A), EF30 (15A) from engine compartment fuse and relay box.
- b. Check resistance of fuse.

Standard resistance: less than 1 Ω

NG Replace ECM fuse

ОК


7 Check wire harness and connector (ECM - engine compartment fuse and relay box)

Check for Open

Multimeter Connection	Condition	Specified Condition
B-011 (35) - I-030 (RF12) or B-011 (20) - B-007 (B4)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
B-011 (35, 20) or I-030 (RF12), B- 007 (B4) - Body ground	Always	No continuity
B-011 (35, 20) or I-030 (RF12), B- 007 (B4) - Battery positive	Always	No continuity



NG Repair or replace wire harness or connector

ОК

8 Check ignition switch (See page 15-14).

NG

Repair ignition switch

ОК

- 9 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0560 00, P0562 16, P0563 17 or P1101 00 still exists.

NG Replace ECM


ОК

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0645 13	AC Clutch Relais Circuit Open		
DTC	P0646 11	A/C Clutch Relay Control Circuit Low		
DTC	P0647 12	A/C Clutch Relay Control Circuit High		







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0645 13	AC Clutch Relais Circuit Open		A/C compressor relay
P0646 11	A/C Clutch Relay Control Circuit Low	Ignition switch ON Engine running	Wire harness or connectorBattery
P0647 12	A/C Clutch Relay Control Circuit High		• ECM

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- · Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point E-037 (See page 06-23).

NG Repair or replace ground wire harness or ground point

ОК

2 Check A/C compressor relay control circuit

- a. Disconnect the engine compartment fuse and relay box connector B-008.
- b. Disconnect the ECM connector B-011.
- c. Check wire harness between ECM connector terminal and engine compartment fuse and relay box connector terminal.

Check for Open


Multimeter Connection	Condition	Specified Condition
B-008 (F7) - B- 011 (42)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
B-018 (F7) or B- 011 (42) - Body ground	Always	No continuity
B-008 (F7) or B- 011 (42) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (ECM- engine compartment fuse and relay box)






- 3 Check A/C compressor relay and fuse
- a. Turn ignition switch to ON.
- b. Check the fuse EF28 (10A).
- c. Check voltage between engine compartment fuse and relay box connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-017 (A4) - Body ground	Always	12 to 14 V

NG)

Replace engine compartment fuse and relay box



ОК

- 4 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0645 13, P0646 11 or P0647 12 still exists.

NG


Replace ECM



DTC	P0627 13	Fuel Pump Control Circuit Open
DTC	P0628 11	Fuel Pump Control Circuit Low
DTC	P0629 12	Fuel Pump Control Circuit High







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0627 13	Fuel Pump Control Circuit Open		Fuel pump relay
P0628 11	Fuel Pump Control Circuit Low	Ignition switch ON Engine running	Wire harness or connectorBattery
P0629 12	Fuel Pump Control Circuit High		• ECM

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point E-037 (See page 06-23).

NG Repair or replace ground wire harness or ground point

OK


2 Check fuel pump relay

- a. Unplug fuel pump relay from engine compartment fuse and relay box.
- b. Check the fuel pump relay terminals.

Multimeter Connection	Condition	Specified Condition
Terminal 3 - Terminal 5	Always	No continuity
Terminal 3 - Terminal 5	Continuity (When battery voltage is applied between terminal 1 and terminal 2)	Continuity

NG

Replace fuel pump relay





3 Check fuel pump relay control circuit


- a. Disconnect the engine compartment fuse and relay box connector B-008.
- b. Disconnect the ECM connector B-011.
- c. Check wire harness between ECM connector terminal and engine compartment fuse and relay box connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
B-008 (F8) - B- 011 (41)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
B-008 (F8) or B- 011 (41) - Body ground	Always	No continuity
B-008 (F8) or B- 011 (41) - Battery positive	Always	No continuity



NG

Repair or replace wire harness or connector (ECM- engine compartment fuse and relay box)

ОК


4 Check fuel pump relay power supply circuit

- a. Turn ignition switch to ON.
- b. Disconnect the fuel pump relay.
- c. Check voltage between terminals 1 and 5 of fuel pump relay and body ground.

Multimeter Connection	Condition	Specified Condition
Fuel pump relay (1, 5) - Body ground	Always	12 to 14 V

NG

Replace engine compartment fuse and relay box



ОК

5 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0627 13, P0628 11 or P0629 12 still exists.


NG Replace ECM

ОК

DTC	P0688 91	Power Relay Sense Circuit Non-plausible Error
DTC	P0688 92	Power Relay Sense Circuit Signal Error







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0688 91	Power Relay Sense Circuit Non-plausible Error	Ignition switch ON Engine running	Main relay Wire harness or connector
P0688 92	Power Relay Sense Circuit Signal Error	Engine running	BatteryECM

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

شرکت دیجیتال خودر و سامان Diagnosis Procedure

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point B-017 (See page 06-23).

NG

Repair or replace ground wire harness or ground point

OK


2 Check main relay

- a. Unplug main relay and fuse EF29 (15A) from engine compartment fuse and relay box.
- b. Check resistance of fuse.

Standard resistance: less than 1 Ω

c. Check terminals of main relay.

Multimeter Connection	Condition	Specified Condition
Terminal 87 - Terminal 30	Always	No continuity
Terminal 87 - Terminal 30	Continuity (When battery voltage is applied between terminal 85 and terminal 86)	Continuity



NG

Replace main relay and fuse



3 Check main relay circuit


- a. Disconnect engine compartment fuse and relay box connectors B-007 and B-008.
- b. Disconnect the ECM connector B-011.
- c. Check wire harness between ECM connector terminal and engine compartment fuse and relay box connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
B-008 (F16) - B- 011 (5)	Always	Continuity
B-007 (B7) - B- 011 (15, 16)	7 iiway 3	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
B-008 (F16), B- 007 (B7) or B-011 (5, 15, 16) - Body ground	Always	No continuity



Multimeter Connection	Condition	Specified Condition
B-008 (F16), B- 007 (B7) or B-011 (5, 15, 16) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (ECM- engine compartment fuse and relay box)

ОК


4 Check main relay power supply circuit

- a. Turn ignition switch to ON.
- b. Disconnect the main relay.
- c. Check voltage between terminals 2 and 3 of main relay and body ground.

Multimeter Connection	Condition	Specified Condition
Main relay (85, 87) - Body ground	Always	12 to 14 V

NG

Replace engine compartment fuse and relay box



ОК

5 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0688 91 or P0688 92 still exists.


NG Replace ECM

OK

DTC	P1130 00	Diagnosis of Brake Booster Pump Malfunction
DTC	P1131 17	Diagnosis of Brake Booster Pump Control Circuit High
DTC	P1132 16	Diagnosis of Brake Booster Pump Control Circuit Low
DTC	P1133 13	Diagnosis of Brake Booster Pump Control Circ. Open
DTC	P1427 12	Diagnosis of Brake Booster Pump Control Circ. High
DTC	P1428 11	Diagnosis of Brake Booster Pump Control Circ. Low
DTC	P1429 13	Diagnosis of Brake Booster Pump Control Circ. Open







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P1130 00	Diagnosis of Brake Booster Pump Malfunction		
P1131 17	Diagnosis of Brake Booster Pump Control Circuit High		
P1132 16	Diagnosis of Brake Booster Pump Control Circuit Low		Brake vacuum booster pump relay
P1133 13	Diagnosis of Brake Booster Pump Control Circ. Open	Ignition switch ON Engine running	Wire harness or connector Battery
P1427 12	Diagnosis of Brake Booster Pump Control Circ. High		• ECM
P1428 11	Diagnosis of Brake Booster Pump Control Circ. Low		
P1429 13	Diagnosis of Brake Booster Pump Control Circ. Open	الحيا	

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

• When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point B-017 (See page 06-23).

NG >

Repair or replace ground wire harness or ground point




2 Check brake vacuum booster pump relay

- a. Unplug brake vacuum booster pump relay and fuse EF10 (15A) from engine compartment fuse and relay box.
- b. Check resistance of fuse.

Standard resistance: less than 1 Ω

c. Check terminals of brake vacuum booster pump relay.

Multimeter Connection	Condition	Specified Condition
Terminal 3 - Terminal 5	Always	No continuity
Terminal 3 - Terminal 5	Continuity (When battery voltage is applied between terminal 1 and terminal 2)	Continuity



NG

Replace brake vacuum booster pump relay and fuse



3 Check brake vacuum booster pump relay control circuit


- Disconnect the engine compartment fuse and relay box connector B-019.
- b. Disconnect the ECM connector B-011.
- c. Check wire harness between ECM connector terminal and engine compartment fuse and relay box connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
B-019 (G13) - B- 011 (54)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
B-019 (G13) or B- 011 (54) - Body ground	Always	No continuity



Multimeter Connection	Condition	Specified Condition
B-019 (G13) or B- 011 (54) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (ECM- engine compartment fuse and relay box)




4 Check brake vacuum booster pump relay power supply circuit

- a. Turn ignition switch to ON.
- b. Disconnect the brake vacuum booster pump relay.
- c. Check voltage between terminals 86, 30 of brake vacuum booster pump relay and body ground.

Multimeter Connection	Condition	Specified Condition
Brake vacuum booster pump relay (1, 2) - Body	Always	12 to 14 V
ground	ب میں اوالہ (م	المنال من



Replace engine compartment fuse and relay box



ОК

5 Check for DTCs


- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P1130 00, P1131 17, P1132 16, P1133 13, P1427 12, P1428 11 or P1429 13 still exists.

NG Replace ECM



DTC	P023A 00	Charge Air Cooler Coolant Pump Control Circuit
DTC	P023B 00	Charge Air Cooler Coolant Pump Control Circuit Low
DTC	P023C 00	Charge Air Cooler Coolant Pump Control Circuit High
DTC	P1700 00	Charge Air Cooler Coolant Pump Dry Run
DTC	P1703 00	Charge Air Cooler Coolant Pump Over Voltage
DTC	P1704 00	Charge Air Cooler Coolant Pump Over Current
DTC	P1705 00	Charge Air Cooler Coolant Pump Over Temperature
DTC	P1706 00	Charge Air Cooler Coolant Pump Stall
DTC	P1707 00	Charge Air Cooler Coolant Pump Under Voltage
DTC	P1708 00	Charge Air Cooler Coolant Pump Feedback Signal Error Circ.High
DTC	P1709 00	Charge Air Cooler Coolant Pump Feedback Signal Error Circ.Low

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC	DTC Definition	DTC Detection Condition	Possible Cause
P023A 00	Charge Air Cooler Coolant Pump Control Circuit		
P023B 00	Charge Air Cooler Coolant Pump Control Circuit Low		
P023C 00	Charge Air Cooler Coolant Pump Control Circuit High		
P1700 00	Charge Air Cooler Coolant Pump Dry Run		
P1703 00	Charge Air Cooler Coolant Pump Over Voltage		
P1704 00	Charge Air Cooler Coolant Pump Over Current	Ignition switch ON Engine running	Electric water pumpWire harness or connectorBattery
P1705 00	Charge Air Cooler Coolant Pump Over Temperature		• ECM
P1706 00	Charge Air Cooler Coolant Pump Stall		
P1707 00	Charge Air Cooler Coolant Pump Under Voltage	کت دیجیتال خود	شر
P1708 00	Charge Air Cooler Coolant Pump Feedback Signal Error Circ. High	ین سامانه دیجیت	91
P1709 00	Charge Air Cooler Coolant Pump Feedback Signal Error Circ. Low		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).



 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point E-037 (See page 06-23).

NG

Repair or replace ground wire harness or ground point

OK

- 2 Check electric water pump connector
- a. Turn ignition switch to OFF.
- b. Disconnect the electric water pump connector E-051.
- c. Check the electric water pump connector.

NG

Repair or replace electric water pump connector

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران


ОК

- 3 Check electric water pump power supply
- a. Turn ignition switch to OFF.
- b. Unplug the electric water pump connector E-051.
- c. Turn ignition switch to ON.
- d. Check voltage between electric water pump connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-051 (1) - Body ground	Always	12 to 14 V

NG)

Go to step 6



ОК

- 4 Check electric water pump fuse
- a. Unplug fuse EF034 (15A) from engine compartment fuse and relay box.
- b. Check resistance of fuse.

Standard resistance: less than 1 Ω

NG]

Replace fuse

OK

5 Check electric water pump power supply circuit

- a. Turn ignition switch to OFF.
- b. Disconnect the engine compartment fuse and relay box connector E-017.
- c. Check wire harness between electric water pump connector terminal and engine compartment fuse and relay box connector terminal.

Check for Open


Multimeter Connection	Condition	Specified Condition	
E-051 (1) - E-017 (A10)	Always	Continuity	

Check for Short

Multimeter Connection	Condition	Specified Condition
E-051 (1) or E- 017 (A10) - Body ground	Always	No continuity
E-051 (1) or E- 017 (A10) - Battery positive	Always	NO Continuity



Repair or replace wire harness or connector (electric water pump - engine compartment fuse and relay box)



OK

6 Check electric water pump ground circuit

a. Check wire harness between electric water pump connector terminal and ground point.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-051 (4) - E-045	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-051 (4) - Power supply	Always	No continuity

NG

Repair or replace wire harness or connector (electric water pump - ground point E-045)





7 Check electric water pump relay control circuit

- a. Disconnect the electric water pump connector E-051.
- b. Disconnect the ECM connector E-034.
- c. Check wire harness between ECM connector terminal and electric water pump connector terminal.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-034 (92) - E- 051 (2)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-034 (92) or E- 051 (2) - Body ground	Always	No continuity
E-034 (92) or E- 051 (2) - Battery positive	Always	No continuity

NG >

Repair or replace wire harness or connector (ECM- electric water pump)





8 Check electric water pump signal feedback circuit


- a. Disconnect the electric water pump connector E-051.
- b. Disconnect the ECM connector E-034.
- c. Check wire harness between ECM connector terminal and electric water pump connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-034 (106) - E- 051 (3)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-034 (106) or E- 051 (3) - Body ground	Always	No continuity
E-034 (106) or E- 051 (3) - Battery positive	Always	No continuity





Repair or replace wire harness or connector (ECM- electric water pump)



Replace electric water pump

9 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P023A 00, P023B 00, P023C 00, P1700 00, P1703 00, P1704 00, P1705 00, P1706 00, P1707 00, P1708 00 or P1709 00 still exists.


NG Replace ECM



DTC	P0571 29	Brake Signal Synchronization Error
DTC	P0571 1C	Brake Light Signal Circuit Error







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0571 29	Brake Signal Synchronization Error	Ignition switch ON	FuseBrake switch
P0571 1C	Brake Light Signal Circuit Error	Ignition switch ON	Wire harness or connectorECM

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point B-017 (See page 06-23).

NG)

Repair or replace ground wire harness or ground point

OK

2 Check fuse

- a. Remove fuses EF21 (10A) and EF03 (15A) from engine compartment fuse and relay box.
- b. Check if fuses EF21 and EF03 are normal and measure the resistance.

Standard resistance: less than 1 Ω

NG


Replace fuse

OK

- 3 Check brake light switch connector
- a. Disconnect the brake light switch connector B-004 (arrow).
- b. Check the brake light switch connector.

NG


Repair or replace connector





- 4 Check brake light switch
- a. Remove the brake light switch.
- b. Check the brake light switch.

Multimeter Connection	Condition	Specified Condition	
Terminal 1 - Terminal 3	Brake pedal depressed (switch	Continuity	
Terminal 4 - Terminal 2	pin released)	No continuity	
Terminal 1 - Terminal 3	Brake pedal released (switch pin pushed)	inal 3 Brake pedal No continu	No continuity
Terminal 4 - Terminal 2		Continuity	



NG

Replace brake light switch

ок


5 Check brake light switch power supply voltage

- a. Turn ignition switch to OFF and check voltage between terminal 1 of brake light switch connector and body ground.
- b. Turn ignition switch to ON and check voltage between terminal 2 of brake light switch connector and body ground.

Multimeter Connection	Condition	Specified Condition
B-004 (1) - Body ground	Ignition switch OFF	11 to 14 V
B-004 (2) - Body ground	Ignition switch ON	11 to 14 V

NG

Go to step 7





6 Check brake light switch power supply circuit


- a. Turn ignition switch to OFF.
- b. Disconnect brake light switch connector and engine compartment fuse and relay box connector.
- c. Check wire harness between brake light switch connector terminal and engine compartment fuse and relay box connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
B-004 (1) - B-018 (D2)	Always	Continuity
B-004 (2) - B-018 (D7)	Aiways	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
B-004 (1, 2) or B- 018 (D2, D7) - Body ground	Always	No continuity
B-004 (1, 2) or B- 018 (D2, D7) - Battery positive	Always	No continuity



NG

Repair or replace wire harness or connector (brake light switch - engine compartment fuse and relay box)

ОК

7 Check circuit between brake light switch and ECU

- a. Turn ignition switch to OFF.
- b. Disconnect brake light switch connector and ECM connector.
- c. Check wire harness between brake light switch connector terminal and ECM connector terminal.

Check for Open


Multimeter Connection	Condition	Specified Condition
B-004 (3) - B-011 (25)	Always	Continuity
B-004 (4) - B-011 (23)	Always	Continuity

Check for Short

Multimeter Connection	Condition 9	Specified Condition
B-004 (3, 4) or B- 011 (23, 25) - Body ground	ل تعميركاران	سامانه ديجيتا
B-004 (3, 4) or B- 011 (23, 25) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (brake light switch - ECM)



ОК

8 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0571 29 or P0571 1C still exists.

NG

Replace ECM








DTC	P0568 1C	Cruise Control Set Signal Non-plausible
DTC	P0568 86	Cruise Control Set Signal Stuck
DTC P0568 81 Cruise Control Set Signal Error		







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0568 1C	Cruise Control Set Signal Non-plausible		Cruise switch
P0568 86	Cruise Control Set Signal Stuck	Ignition switch ON	Wire harness or connector ECM
P0568 81	Cruise Control Set Signal Error		LOW

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point E-037 (See page 06-23).

NG Repair or replace ground wire harness or ground point

ОК

- 2 Check cruise switch connector
- a. Disconnect the cruise switch connector I-030 (arrow).
- b. Check the cruise switch connector.

NG Repair or replace connector

ОК

(1-030)

(B-011)

- 3 Check cruise switch
- a. Remove the cruise switch.
- b. Check the cruise switch (See page 35-8).

Replace cruise switch



4 Check circuit between cruise switch and ECU

- a. Turn ignition switch to OFF.
- b. Disconnect cruise switch connector and ECM connector.
- c. Check wire harness between cruise switch connector terminal and ECM connector terminal.

Check for Open

Multimeter Connection	Condition	Specified Condition
I-030 (3) - B-011 (9) I-030 (4) - B-011 (47)	Always	Continuity

H H 00
ways Continuity

Multimeter Connection	Condition	Specified Condition
I-030 (3, 4) or B- 011 (9, 47) - Body ground	Always	No continuity
I-030 (3, 4) or B- 011 (9, 47) - Battery positive	Always	NO Continuity

NG

Repair or replace wire harness or connector (cruises witch - ECM)



RM1A066760

5 **Check for DTCs**

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0568 1C, P0568 86 or P0568 81 still exists.

NG Replace ECM







DTC	P0601 00	Safety Monitoring Function Error (ECU EEPROM Error)	
DTC	P0604 43	Internal Contr. Module RAM Error	
DTC	P0605 43	Internal Contr. Module ROM Error	

DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0601 00	Safety Monitoring Function Error (ECU EEPROM Error)		Wire harness or connector
P0604 43	Internal Contr. Module RAM Error	Ignition switch ON	ECM
P0605 43	Internal Contr. Module ROM Error		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
 - If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG Repair or replace ground wire harness or ground point

OK

2 Check ECM connector

a. Disconnect the ECM connectors E-034 and B-011.

b. Check if connectors are normal.

NG

Repair or replace connector

OK

3 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0601 00, P0604 43 or P0605 43 still exists.

NG Replace ECM


OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

ديجيتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC	P1614 00	Immo Transferred Transponder Response was Corrupted	
DTC	P1615 00	ECM Status Unknown	
DTC	P1616 00	Authentication Not OK	
DTC	P1617 00	No Response from SIM During Challenge Period	
DTC	P1618 00	Fail to Write EOL Confidtional Data into EEProm	
DTC	P1619 00	ECM Not Programed (Virgin State)	







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P1614 00	Immo Transferred Transponder Response was Corrupted		
P1615 00	ECM Status Unknown		
P1616 00	Authentication Not OK		Anti-theft module
P1617 00	No Response from SIM During Challenge Period	Ignition switch ON	ECM Wire harness or connector
P1618 00	Fail to Write EOL Confidtional Data into EEProm		
P1619 00	ECM Not Programed (Virgin State)		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
 - If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM power supply and ground
- a. Check ECM power supply and ground.


Multimeter Connection	Condition	Specified Condition
B-011 (20, 35) - Body ground	Ignition switch ON	11 to 14 V
B-011 (63, 64) - Body ground	ignition switch ON	0 V

NG

Repair or replace connector



ت دیجیتال خودرو سامانه (مسئولیت محدود



ولین سامانه دیجیتال تعمیرکاران خودرو در ایرار

2 Rematch anti-theft system

- a. Turn ignition switch to OFF.
- b. Check if information in anti-theft module can be read.

NG Replace anti-theft module with a new one and perform match

ок

OK

3 Read SK code in ECM

NG Reprogram ECM

ОК

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P1614 00, P1615 00, P1616 00, P1617 00, P1618 00 or P1619 00 still exists.

NG Replace ECM

OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

WWW.DIGITALKHODRO.COM


DTC	U0001 88	Error Busoff on CAN-bus	
DTC	U0101 87	Lost Communication with TCM	
DTC	U0129 87	Lost Communication with Brake System Control Module	
DTC	U0140 00	Lost Communication with Body Control Module (Immo)	
DTC	U0214 87	Lost Communication with Passive Entry Passive Start (PEPS)	
DTC	U0140 87	Lost Communication with Body Control Module (BCM)	
DTC	U0155 87	Lost Communication with Instrument Panel Cluster (IPC) Control Module	
DTC	U0121 87	Lost Communication with ABS	



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران





DTC	DTC Definition	DTC Detection Condition	Possible Cause
U0001 88	Error Busoff on CAN- bus		
U0101 87	Lost Communication with TCM		
U0129 87	Lost Communication with Brake System Control Module		
U0121 87	Lost Communication with ABS		CANUS
U0140 00	Lost Communication with Body Control Module (Immo)	Ignition switch ON Engine running	 CAN line or connector Shielded wire TCU, ABC, BCM, PEPS, SAM, IPC,
U0140 87	Lost Communication with Body Control Module (BCM)		HCU, CCU, ECM
U0155 87	Lost Communication with Instrument Panel Cluster (IPC) Control Module		
U0214 87	Lost Communication with Passive Entry Passive Start (PEPS)	- ثحتا	

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

• When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

1 Check ECM ground point

- a. Turn ignition switch to OFF.
- b. Check the ECM ground point E-037 (See page 06-23).

NG

Repair or replace ground wire harness or ground point

OK

- 2 Check CAN bus connector
- a. Turn ignition switch to OFF.
- b. Disconnect the ECM connector B-011.
- c. Check if connector is normal.

NG)

Repair or replace connector



3 Check CAN line

- a. Turn ignition switch to OFF and disconnect negative battery cable.
- b. Use a multimeter to measure data link connector I-008.

Resistance Inspection

Multimeter Connection	Condition	Specified Condition
I-008 (6) - I-008 (14)	Always	60 Ω
I-008 (3) - I-008 (11)	Always	60 Ω




Connect negative battery cable, turn ignition switch to ON and measure voltage between CAN line connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
I-008 (3) or I-008 (6) - Body ground	Always	2.6 V
I-008 (11) or I-008 (14) - Battery positive	Always	2.4 V



Repair or replace CAN line



OK

- 4 Check connections between TCU, ABC, BCM, PEPS, IPC modules and CAN
- a. Turn ignition switch to OFF.
- b. Disconnect the TCU, ABC, BCM, PEPS and IPC connectors.
- c. Check if connectors are normal.

NG

Repair or replace connector and wire harness

OK

- 5 Check TCU, ABC, BCM, PEPS and IPC modules
- a. Turn ignition switch to ON.
- b. Use X-431 3G diagnostic tester to diagnose if each module operates normally.

NG >

Replace corresponding faulty module

OK

- 6 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC U0001 88, U0101 87, U0104 87, U0129 87, U0121 87, U0140 00, U0140 87 or U0155 87 still exists.

NG

Replace ECM




System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P000A 00	Camshaft Control Slow Response (Inlet)
DTC	P000A 77	Camshaft Control Target Error (Inlet)
DTC	P0010 13	Control Circuit of Camshaft Control Valve (Inlet)
DTC	P2088 11	Control Circuit Low of Camshaft Control Valve (Inlet)
DTC	P2089 12	Control Circuit High of Camshaft Control Valve (Inlet)







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P000A 00	Camshaft Control Slow Response (Inlet)		
P000A 77	Camshaft Control Target Error (Inlet)		
P0010 13	Control Circuit of Camshaft Control Valve (Inlet)	Ignition switch ON Engine running	VVT control valveWire harness or connector
P2088 11	Control Circuit Low of Camshaft Control Valve (Inlet)	g g	• ECM
P2089 12	Control Circuit High of Camshaft Control Valve (Inlet)		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- · Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point E-037 (See page 06-23).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check intake VVT control valve connector
- a. Turn ignition switch to OFF.
- b. Disconnect the intake VVT control valve connector E-054 (arrow).
- c. Check the intake VVT control valve connector.

NG

Repair or replace connector






- 3 Check intake VVT control valve power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-054 (1) - Body ground	Ignition switch ON	11 to 14 V

NG

Go to step 5



OK

4 Check intake VVT control valve power supply circuit and fuse EF20 (15A)

- a. Turn ignition switch to OFF.
- b. Check if fuse EF34 (15A) is normal.
- c. Disconnect the engine compartment fuse and relay box connector E-017.
- d. Check wire harness between connector terminals.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-054 (1) - E-017 (A10)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-054 (1) or E- 017 (A10) - Body ground	Always	No continuity
E-054 (1) or E- 017 (A10) - Battery positive		No continuity

NG

Repair or replace wire harness or connector (intake VVT control valve - engine compartment fuse and relay box)






5 Check intake VVT control valve control circuit

- a. Disconnect the ECM connector E-034.
- b. Check wire harness between connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-054 (2) - E-034 (69)	Always	Continuity



Check for Short

Multimeter Connection	Condition	Specified Condition
E-054 (2) or E- 034 (69) - Body ground	Always	No continuity
E-054 (2) or E- 034 (69) - Battery positive	Always	140 Continuity

NG

Repair or replace wire harness or connector (intake VVT control valve - ECM)

ОК

6 Check intake VVT control valve


- a. Remove the intake VVT control valve.
- b. Check the intake VVT control valve.

Multimeter Connection	Condition	Specified Condition
Terminal 1 - Terminal 2	Always	ديجيΩ 8ل خود

c. When battery voltage is applied between terminals 1 and 2, control valve should move quickly.

NG

Replace intake VVT control valve



ОК

7 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P000A 00, P000A 77, P0010 13, P2088 11 or P2089 12 still exists.



Replace ECM



System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.






DTC	P000B 00	Camshaft Control Slow Response (Outlet)
DTC	P000B 77	Camshaft Control Target Error (Outlet)
DTC	P0013 13	Control Circuit of Camshaft Control Valve (Outlet)
DTC	P0015 00	Outlet Camshaft not in Locking Position During Start
DTC	P2090 11	Control Circuit Low of Camshaft Control Valve (Outlet)
DTC	P2091 12	Control Circuit High of Camshaft Control Valve (Outlet)







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P000B 00	Camshaft Control Slow Response (Outlet)		
P000B 77	Camshaft Control Target Error (Outlet)		
P0013 13	Control Circuit of Camshaft Control Valve (Outlet)		VVT control valve
P0015 00	Outlet Camshaft not in Locking Position During Start	Ignition switch ON Engine running	Wire harness or connectorECM
P2090 11	Control Circuit Low of Camshaft Control Valve (Outlet)		
P2091 12	Control Circuit High of Camshaft Control Valve (Outlet)		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
 - Start engine and warm it up to normal operating temperature, and then select Read Code.
 - If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
 - If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

• When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point E-037 (See page 06-23).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check exhaust VVT control valve connector
- a. Turn ignition switch to OFF.
- b. Disconnect the exhaust VVT control valve connector E-056 (arrow).
- c. Check the exhaust VVT control valve connector.

NG

Repair or replace connector






- 3 Check exhaust VVT control valve power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-056 (1) - Body ground	Ignition switch ON	11 to 14 V

OK Go to step 5



NG

4 Check exhaust VVT control valve power supply circuit and fuse EF04 (15A)

- a. Turn ignition switch to OFF.
- b. Check if fuse EF34 (15A) is normal.
- c. Disconnect the engine compartment fuse and relay box connector E-017.
- d. Check wire harness between connector terminals.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-056 (1) - E-017 (A10)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-056 (1) or E- 017 (A10) - Body ground	Always	No continuity
E-056 (1) or E- 017 (A10) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (exhaust VVT control valve - engine compartment fuse and relay box)






5 Check exhaust VVT control valve control circuit

- a. Disconnect the ECM connector E-034.
- b. Check wire harness between connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-056 (2) - E-034 (71)	Always	Continuity



Check for Short

Multimeter Connection	Condition	Specified Condition
E-056 (2) or E- 034 (71) - Body ground	Always	No continuity
E-056 (2) or E- 034 (71) - Battery positive	nways	140 Continuity

NG

Repair or replace wire harness or connector (exhaust VVT control valve - ECM)

OK

- 6 Check exhaust VVT control valve
- a. Remove the exhaust VVT control valve.
- b. Check the exhaust VVT control valve.

Multimeter Connection	Condition	Specified Condition
Terminal 1 - Terminal 2	Always	ديجي ۵ ال خود

c. When battery voltage is applied between terminals 1 and 2, control valve should move quickly.

NG

Replace exhaust VVT control valve

OK

7 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P000B 00, P000B 77, P0013 13, P0015 00, P2090 11 or P2091 12 still exists.

NG Replace ECM


ОК

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0033 13	Dump Valve Control Circuit Open
DTC	P0034 11	Dump Valve Control Circuit Low
DTC	P0035 12	Dump Valve Control Circuit High
DTC	P2261 00	Dump Valve - Mechanical Error







DTC	DTC Definition	DTC Detection Condition	Possible Cause	
P0033 13	Dump Valve Control Circuit Open			
P0034 11	Dump Valve Control Circuit Low	Ignition switch ON	ERCV relief valveWire harness or connector	
P0035 12	Dump Valve Control Circuit High	Engine running	• ECM	
P2261 00	Dump Valve - Mechanical Error			

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point E-037 (See page 06-23).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check ERCV relief valve connector
- a. Turn ignition switch to OFF.
- b. Disconnect the ERCV relief valve connector E-060 (arrow).
- c. Check the ERCV relief valve connector.

NG

Repair or replace connector






- 3 Check ERCV relief valve power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-060 (1) - Body ground	Ignition switch ON	11 to 14 V





NG

4 Check ERCV relief valve power supply circuit and fuse EF34 (15A)

- a. Turn ignition switch to OFF.
- b. Check if fuse EF34 (15A) is normal.
- c. Disconnect the engine compartment fuse and relay box connector E-017.
- d. Check wire harness between connector terminals.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-060 (1) - E-017 (A10)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-060 (1) or E- 017 (A10) - Body ground	Always	No continuity
E-060 (1) or E- 017 (A10) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (ERCV relief valve - engine compartment fuse and relay box)






5 Check ERCV relief valve control circuit

- a. Disconnect the ECM connector E-034.
- b. Check wire harness between connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-060 (2) - E-034 (70)	Always	Continuity



Check for Short

Multimeter Connection	Condition	Specified Condition
E-060 (2) or E- 034 (70) - Body ground	Always	No continuity
E-060 (2) or E- 034 (70) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (ERCV relief valve - ECM)

OK

- 6 Check ERCV relief valve
- a. Remove the ERCV relief valve.
- b. Check the ERCV relief valve.

	Multimeter Connection	Condition	Specified Condition
-	Terminal 1 - Terminal 2	Always	13 Ω

c. When battery voltage is applied between terminals 1 and2, ERCV relief valve should move quickly.

NG

Replace ERCV relief valve



- 7 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0033 13, P0034 11, P0035 12 or P2261 00 still exists.

NG Replace ECM


ОК

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0234 00	Turbu/Super Charger Overboost Condition	
DTC	P0243 13	Turbo/Super Charger Wastegate Solonoid Open	
DTC	P0245 11	Turbo/Super Charger Wasteg. Solonoid Low	
DTC	P0246 12	Turbo/Sup. Charger Wasteg. Solonoid High	







DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0234 00	Turbu/Super Charger Overboost Condition		
P0243 13	Turbo/Super Charger Wastegate Solonoid Open	Ignition switch ON Engine running • Exhaust gas control valve • Wire harness or connector	
P0245 11	Turbo/Super Charger Wasteg. Solonoid Low		• ECM
P0246 12	Turbo/Sup. Charger Wasteg. Solonoid High		

DTC Confirmation Procedure

Confirm that battery voltage is between 11 V and 14 V before performing following procedures.

- Turn ignition switch to OFF.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-23).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایرار

Diagnosis Procedure

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point E-037 (See page 06-23).

NG >


Repair or replace ground wire harness or ground point

OK

- 2 Check exhaust gas control valve connector
- a. Turn ignition switch to OFF.
- b. Disconnect the exhaust gas control valve connector E-059 (arrow).
- c. Check the exhaust gas control valve connector.

NG

Repair or replace connector






- 3 Check exhaust gas control valve power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-059 (2) - Body ground	Ignition switch ON	11 to 14 V

NG

Go to step 5



ОК

4 Check exhaust gas control valve power supply circuit and fuse EF34 (15A)

- a. Turn ignition switch to OFF.
- b. Check if fuse EF34 (15A) is normal.
- c. Disconnect the engine compartment fuse and relay box connector E-017.
- d. Check wire harness between connector terminals.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-059 (2) - E-017 (A10)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-059 (2) or E- 055 (A10) - Body ground	Always	No continuity
E-059 (2) or E- 055 (A10) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (exhaust gas control valve - engine compartment fuse and relay box)






5 Check exhaust gas control valve control circuit

- a. Disconnect the ECM connector E-034.
- b. Check wire harness between connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-059 (1) - E-034 (65)	Always	Continuity



Check for Short

Multimeter Connection	Condition	Specified Condition
E-059 (1) or E- 034 (65) - Body ground	Always	No continuity
E-059 (1) or E- 034 (65) - Battery positive	nways	140 Continuity

NG

Repair or replace wire harness or connector (exhaust gas control valve - ECM)

OK

- 6 Check exhaust gas control valve
- a. Remove the exhaust gas control valve.
- b. Check the exhaust gas control valve.

Multimeter Connection	Condition	Specified Condition
Terminal 1 - Terminal 2	Always	ديد Ω 23 خود

c. When battery voltage is applied between terminals 1 and 2, control valve should move quickly.

NG


Replace exhaust gas control valve

ОК

- 7 Check exhaust gas control valve line
- a. Check exhaust gas control valve line for blockage, air leakage, crush or damage.

NG

Reinstall or replace exhaust gas control valve line



OK

8 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTCs.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0234 00, P0243 13, P0245 11 or P0246 12 still exists.

NG

Replace ECM

OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Engine Problem Symptom Diagnosis

Perform primary inspection first before performing malfunction diagnosis procedures:

- Confirm that engine malfunction indicator operates normally.
- 2. Using diagnostic tester, check that no error messages are recorded.
- 3. Confirm that malfunction complained by customer is present, and confirm the condition under which malfunction occurs.

Then, perform appearance inspection:

- 1. Check fuel line for leakage.
- 2. Check if vacuum line is broken or twisted, and if connection is correct.
- 3. Check intake line for blockage, air leakage, crush or damage.
- 4. Check if high-voltage cable of ignition system is broken or deteriorated, and if ignition sequence is correct.
- 5. Check if wire harness ground points are clean and secure.
- 6. Check each sensor or actuator connector for looseness or poor contact.

HINT:

If above conditions exist, repair the trouble areas first. Otherwise it will affect the repair work for following trouble diagnosis.


Diagnostic Help

- 1. Confirm that there are no trouble records for engine.
- Confirm that complained trouble symptoms are present.
- 3. There are no abnormal conditions after performing inspection according to above procedures.
- 4. During servicing, do not ignore vehicle maintenance condition, cylinder pressure, mechanical ignition timing and fuel condition, etc. that can affect the system.
- Replace ECM, and perform a test. If trouble symptom can be eliminated, trouble area is in ECM; if trouble symptom still exists, reuse the original ECM and repeat procedures to perform service again.

Problem Symptoms Table

Symptom	Suspected Area	See page
	Battery	
	Starter motor	
Engine deep not event on events aloudy	Wire harness or ignition switch	
Engine does not crank or cranks slowly while starting	Starter relay	06-257
Willie Starting	ECM, TCM	
	Gear switch (CVT)	
	Engine mechanical	
	No fuel in tank	
	Fuel pump	
	Fuel injector	
Engine cranks normally but cannot start	Engine speed sensor	06-259
successfully while starting	Ignition coil	00-259
	Engine immobilizer	
	ECM	
	Engine mechanical	

Symptom	Suspected Area	See page
	Water in fuel	
	Fuel pump	
	Coolant temperature sensor	
Difficult to start with hot ongine	Engine speed sensor	06.264
Difficult to start with hot engine	Ignition coil	06-261
	Camshaft position sensor	
	Fuel injector	
	Engine mechanical	
Engine starts normally, but idles roughly or	A/C system	
stalls with partial load (for example, A/C is ON)	Fuel injector	06-273
	Throttle	
Engine starts normally, but idle speed is too	Vacuum pipe	00.074
high	Coolant temperature sensor	06-274
	Ignition timing	
	Water in fuel	
	Intake pressure/temperature sensor	
	Intake pipe	
Engine speed is too low or engine stalls	Exhaust pipe	06-275
when accelerating	Ignition timing	00-275
	Throttle position sensor	
1.6 \	Fuel injector	
خودرو سامانه (مسئولیت محد	Spark plug	
	Water in fuel	
عیتال تعمیرکاران خودرو در ایران	Intake pressure/temperature sensor	
75 7 35 7 C7 7 C	Intake pipe	
Slow response when accelerating	Exhaust pipe	06-277
Join response when accelerating	Ignition timing	00-211
	Throttle position sensor	
	Fuel injector	
	Spark plug	





Go to Diagnostic Help





Engine cranks normally but cannot start successfully while starting

1 Check fuel pressure

a. Using a fuel pressure gauge, check the fuel pressure (See page 08-11). Standard Fuel Pressure

Condition	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key Lock	400

NG

Repair or replace fuel system

OK

- 2 Using diagnostic tester, observe if any speed signal is output
- a. Connect diagnostic tester, start engine and select Read Datastream.
- b. Observe if any speed signal is output.

NG

Check and repair crankshaft position sensor wire harness

OK

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

3 Check ignition system

- a. Remove ignition coil and spark plug of one cylinder, and ground the spark plug housing. Start engine, and check if spark is generated.
- · OK: Spark is generated

NG

Check and repair ignition system

OK

- 4 Check pressure of cylinder
- a. Measure compression of misfiring cylinder (See page 07-20).

NG

Check engine to confirm cause of low compression

OK


5 Check ECM power supply and ground

- a. Disconnect the ECM connector B-011.
- b. Turn ignition switch to ON and check ECM connector terminals.

Multimeter Connection	Condition	Specified Condition
B-011 (35, 20)	Ignition switch ON	11 to 14 V
B-011 (63, 64)	Igrittori switch ON	0 V

NG >

Repair or replace related wire harness



ОК

Go to Diagnostic Help

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Difficult to start with hot engine

1 Check fuel pressure

a. Using a fuel pressure gauge, check the fuel pressure (See page 08-11). Standard Fuel Pressure

Condition	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key Lock	400

NG Repair or replace fuel system

OK

- 2 Check ignition system
- a. Remove ignition coil and spark plug of one cylinder, and ground the spark plug housing. Start engine, and check if spark is generated.
- OK: Spark is generated

NG Check and repair ignition system

OK

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Disconnect coolant temperature sensor connector, start engine and observe if engine starts successfully at this time

NG >

Check and repair circuit or replace sensor

ОК

- 4 Check pressure of cylinder
- a. Measure compression of misfiring cylinder (See page 07-20).

NG Check engine to confirm cause of low compression

OK

- 5 Check fuel condition
- a. Observe if trouble occurs just after fuel is filled.

NG Replace fuel

OK

Go to Diagnostic Help



Difficult to start with cold engine

1 Check fuel pressure

a. Using a fuel pressure gauge, check the fuel pressure (See page 08-11). Standard Fuel Pressure

Condition	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key Lock	400

NG

Repair or replace fuel system

OK

2 Check ignition system

- a. Remove ignition coil and spark plug of one cylinder, and ground the spark plug housing. Start engine, and check if spark is generated.
- OK: Spark is generated

NG

Check and repair ignition system

OK

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Disconnect coolant temperature sensor connector, start engine and observe if engine starts successfully at this time

NG

Check and repair circuit or replace sensor

OK

4 Depress accelerator pedal slightly, and observe if it is easy to start

NG


Clean or replace throttle valve


ОК

5 Check injector for leakage or blockage

NG

Clean or replace injector





		ОК
6	Depress accelerator pedal slightly, and observe if it is easy to start	
NG	Clean throttle	
		ОК
7	Check injector for leakage or blockage	
NG	Clean or replace injector	
		ОК
8	Check fuel condition	
a. Obse	rve if trouble occurs just after fuel is filled.	
NG	Replace fuel	ОК
9	Check pressure of cylinder	
a. Meas	Check engine to confirm cause of low compression	
10	Check engine ignition sequence and ignition timing	
a. Chec	k if engine ignition sequence and ignition timing are as specified.	
NG	Check and repair ignition timing	
		ОК
Go to E	Diagnostic Help	

Engi	ne starts normally, but idles roughly at anytime	
1	Check air filter for blockage, and intake pipe for air leakage	
NG	Check and repair intake system	
		ОК
2	Check if throttle is stuck	
NG	Repair or replace throttle	
		ОК
3	Check spark plug	
a. Che	ck spark plug of each cylinder, and observe if type and gap are as specified.	
NG	Replace spark plug	
		OK
محد	شرکت دیجیتال خودرو سامانه (مسئولیت	
4	Check throttle for carbon deposits	
NG	Clean throttle	
		ОК
5	Check injector for leakage or blockage	
NG	Clean or replace injector	
		ОК
6	Check fuel condition	
a. Obs	erve if trouble occurs just after fuel is filled.	
NG	Replace fuel	
		ОК

7 Check pressure of cylinder

a. Measure compression of misfiring cylinder (See page 07-20).

NG

Check engine to confirm cause of low compression

OK

8 Check engine ignition sequence and ignition timing

a. Check if engine ignition sequence and ignition timing are as specified.

NG

Check and repair ignition timing

OK

Go to Diagnostic Help



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Engi	ne starts normally, but idles roughly during warming up	
4		
1	Check air filter for blockage, and intake pipe for air leakage	
NG	Check and repair intake system	
		ОК
2	Check spark plug	
a Che	ck spark plug of each cylinder, and observe if type and gap are as specified.	
NG	Replace spark plug	
	Tropidos opam piag	
		ОК
3	Check throttle for carbon deposits	
NG	Clean throttle	
		OK
محدو	Unplug coolant temperature sensor connector, start engine and observe if	engine idles
4	normally during warming up	
NG	Check and repair circuit or replace sensor	
		ОК
	<u> </u>	
5	Check injector for leakage or blockage	
NG	Clean or replace injector	
		01/
		ОК
6	Check fuel condition	
a. Obse	erve if trouble occurs just after fuel is filled.	
NG	Replace fuel	
		ОК

7 Check pressure of cylinder

a. Measure compression of misfiring cylinder (See page 07-20).

NG

Check engine to confirm cause of low compression

OK

Go to Diagnostic Help





Engine s	tarts normally, but idles roughly after warming up
1 Ch	eck air filter for blockage, and intake pipe for air leakage
NG	Check and repair intake system
	ОК
2 Ch	eck spark plug
a. Check spa	ark plug of each cylinder, and observe if type and gap are as specified.
NG	Replace spark plug
	ОК
	plug coolant temperature sensor connector, start engine and observe if engine idles mally during warming up
NG	Check and repair circuit or replace sensor
	ОК
	شرکت دیجیتال خودرو سامانه (مسئول
4 Ch	eck injector for leakage or blockage
NG	Clean or replace injector
	ОК
5 Ch	eck fuel condition
a. Observe i	f trouble occurs just after fuel is filled.
NG	Replace fuel
	ОК
6 Ch	eck pressure of cylinder
a. Measure	compression of misfiring cylinder (See page 07-20).
NG	Check engine to confirm cause of low compression



Go to Diagnostic Help





4	Ta	
1	Check throttle for carbon deposits	
NG	Clean throttle	
		ОК
2	Observe if engine output increases when A/Cis turned on. In other words, observe if engine output increases when A/Cis turned on. In other words, observe if engine output increases when A/Cis turned on. In other words, observe if engine output increases when A/Cis turned on. In other words, observe if engine output increases when A/Cis turned on. In other words, observe if engine output increases when A/Cis turned on. In other words, observe if engine output increases when A/Cis turned on. In other words, observe if engine output increases when A/Cis turned on. In other words, observe if engine output increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on. In other words, observe its engine of increases when A/Cis turned on the A/Cis turned	
NG	Go to step 5	
		ОК
3	Check if A/C compressor pump resistance increases	
NG	Check and repair or replace A/C system	
	شرکت دیجیتال خودرو سامانه (مسئولیت	ОК
4	Observe if engine speed increases when A/Cis turned on	
NG	Replace ECM	
		ОК
5	Check injector for leakage or blockage	
NG	Clean or replace injector	
		ОК

Engine starts normally, but idle speed is too high
1 Check if accelerator pedal is stuck
NG Adjust or replace accelerator pedal
ОК
2 Check intake system and connected vacuum pipe for air leakage
NG Check and repair intake system
ОК
3 Check throttle for carbon deposits
NG Clean or replace throttle valve
Disconnect coolant temperature sensor connector, start engine and observe if engine idle is normal
NG Check and repair circuit or replace sensor
ОК
5 Check engine ignition timing
NG Check and repair ignition timing
ОК
Go to Diagnostic Help

Engine speed is too low or engine stalls when accelerating 1 Check air filter for blockage, and intake pipe for air leakage Check and repair intake system NG OK 2 Check fuel pressure a. Using a fuel pressure gauge, check the fuel pressure (See page 08-11). Standard Fuel Pressure Condition Fuel System Pressure (kPa) Key ON 400 400 Engine Idling Key Lock 400 Repair or replace fuel system OK 3 Check spark plug a. Check spark plug of each cylinder, and observe if type and gap are as specified. Replace spark plug OK 4 Check throttle for carbon deposits Clean throttle NG OK 5 Check intake pressure/temperature sensor, throttle position sensor and circuit Check and repair circuit or replace sensor NG OK

6	Check injector for leakage or blockage	
NG	Clean or replace injector	
		ОК
7	Check fuel condition	
a. Obse	erve if trouble occurs just after fuel is filled.	
NG	Replace fuel	
		ОК
8	Check engine ignition sequence and ignition timing	
. Chec	k if engine ignition sequence and ignition timing are as specified.	
NG	Check and repair ignition timing	
T	ه _ دیجیتال خود	ОК
9	Check exhaust system	
. Chec	k exhaust system for leakage or blockage.	
NG	Repair or replace related exhaust system components	
		ОК
Go to E	Diagnostic Help	

Slow response when accelerating			
		pones mon describing	
1	Ch	eck air filter for blockage, and intake pi	pe for air leakage
		<u> </u>	
NG	>	Check and repair intake system	
			ОК
2	Ch	eck fuel pressure	
a. Using	g a fu	iel pressure gauge, check the fuel pressur	re (See page 08-11).
	_	el Pressure	
		Condition	Fuel System Pressure (kPa)
		Key ON	400
		Engine Idling	400
		Key Lock	400
NG	>	Repair or replace fuel system	
			ОК
محد	بت	عیتال خودرو سامانه (مسئول	شرکت دید
3	Ch	eck spark plug	
a. Chec	k sp	ark plug of each cylinder, and observe if ty	pe and gap are as specified.
NG	>	Replace spark plug	
_			
			OK
4	Ch	eck throttle for carbon deposits	
NG	>	Clean throttle	
			ОК
			UK UK
5	Ch	eck intake pressure/temperature senso	r, throttle position sensor and circuit
		·	
NG	>	Check and repair circuit or replace se	nsor
			ОК

6	Check injector for leakage or blockage	
NG	Clean or replace injector	
		ОК
7	Check fuel condition	
a. Obse	erve if trouble occurs just after fuel is filled.	
NG	Replace fuel	
		ОК
8	Check engine ignition sequence and ignition timing	
. Chec	k if engine ignition sequence and ignition timing are as specified.	
NG	Check and repair ignition timing	
T	ه _ دیجیتال خود	ОК
9	Check exhaust system	
. Chec	k exhaust system for leakage or blockage.	
NG	Repair or replace related exhaust system components	
		ОК
Go to E	Diagnostic Help	

Lack of power and poor performance when accelerating

1 Check if malfunctions that clutch slipping, low tire inflation pressure, brake dragging, incorrect tire size, and incorrect four-wheel alignment are present

NG

Check and repair faulty components

ОК

2 Check air filter for blockage, and intake pipe for air leakage

NG

Check and repair intake system

OK

3 Check fuel pressure

a. Using a fuel pressure gauge, check the fuel pressure (See page 08-11).

Standard Fuel Pressure

Condition	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key Lock	400

NG

Repair or replace fuel system

ОК

4 Check spark plug

a. Check spark plug of each cylinder, and observe if type and gap are as specified.

NG

Replace spark plug


OK

5 Check ignition system

- a. Remove ignition coil and spark plug of one cylinder, and ground the spark plug housing. Start engine, and check if spark is generated.
- · OK: Spark is generated

NG >

Check and repair ignition system





Go to Diagnostic Help





ON-VEHICLE SERVICE

VVT Control Valve

Description

There are two VVT control valves, which are located on front end of intake and exhaust camshafts.


Operation

ECM controls VVT control valves depending on engine conditions, changes the flowing direction of oil in phasers to advance or retard camshaft, thus changing the timing of intake valve and exhaust valve.

Removal

- 1. Turn off all electrical equipment and the ignition switch.
- 2. Disconnect the negative battery cable.
- 3. Remove the engine trim cover.
- 4. Remove the VVT control valve (take intake VVT as an example).
 - a. Disconnect intake VVT control valve connector (arrow), and then remove intake VVT control valve fixing bolt (1).

(Tightening torque: 8 ± 2 N·m)



ولين سامانه ديجيتال تعمير كاران خو Installation

Installation is in the reverse order of removal.

Coolant Temperature Sensor

Description

Coolant temperature sensor is a negative temperature coefficient sensor, which is installed into the mounting hole in thermostat holder.

Operation

Coolant temperature sensor provides an input signal for Engine Control Module (ECM). As temperature increases, the resistance of sensor decreases. As coolant temperature changes, the resistance of coolant temperature sensor varies accordingly, resulting in a change in voltage of coolant temperature sensor signal circuit. ECM uses this input signal to control air-fuel mixture, ignition timing, A/C compressor and radiator fan on/off timing.


Removal

- 1. Turn off all electrical equipment and the ignition switch.
- 2. Disconnect the negative battery cable.

⚠ WARNING

- Always make sure engine is cold before operating cooling system. Never open expansion tank cap or remove drain cock plug, when engine is operating or cooling system overheats. The overheated engine coolant and steam with high-pressure may flow out and cause serious personal injury.
- Remove the engine trim cover.
- Disconnect coolant temperature sensor connector and remove coolant temperature sensor (arrow).

(Tightening torque: 14 ± 1 N⋅m)



Installation

Installation is in the reverse order of removal.

CAUTION

- Perform sealing with anaerobic seal gum.
- Confirm that sensor is tightened fully during installation.
- After installing engine coolant temperature sensor, check coolant level.

Knock Sensor

Description

Knock sensor is installed on cylinder block, and used to detect engine vibration caused by detonation.

Operation


Sensitive element of knock sensor is a piezoelectric ceramic. Vibration of engine cylinder block is transferred to the piezoelectric ceramic through a mass block in sensor. Due to pressure generated by vibration of mass block, the piezoelectric ceramic generates a voltage at both electrode faces, and converts the vibration signal to an AC voltage signal to output it. As intensity of vibration increases, knock sensor output voltage increases accordingly.

Because frequency of vibration signal caused by engine knocking is far more than that of normal engine vibration signal, Engine Control Module (ECM) can distinguish between knock or non-knock signals by processing these signals from knock sensor.

Removal

- 1. Turn off all electrical equipment and the ignition switch.
- 2. Disconnect the negative battery cable.
- 3. Disconnect knock sensor connector (arrow) and remove knock sensor fixing bolt (1).

(Tightening torque: 20 ± 5 N·m)



Installation is in the reverse order of removal.

CAUTION

- Never allow any kinds of gasket and washer between sensor and engine block. Only the metal part of sensor can contact with engine block directly.
- DO NOT apply lubricant, grease or seal gum when installing knock sensor. Keep engine block clean and dry, and never allow any foreign matter (such as oil) on the installation area of knock sensor.
- · Never tap knock sensor when installing it.

Oxygen Sensor

Description

Oxygen sensors consist of upstream oxygen sensor and downstream oxygen sensor. Oxygen sensors continually monitor the oxygen concentration in exhaust gas.

Operation


Oxygen sensors monitor oxygen content and convert it into voltage. The sensor generates low voltage when oxygen content is high, and high voltage when oxygen content is low. Therefore, sensor acts as controlling injection volume by closed-loop.

Oxygen sensor is equipped with a heating element that keeps sensor at proper operating temperature under all operating conditions.

Upstream Oxygen Sensor


Input signal from heated upstream oxygen sensor informs Engine Control Module (ECM) of the oxygen content in exhaust gas. Based on this input signal, Engine Control Module (ECM) adjusts air-fuel ratio finely by adjusting injector pulse width.





Downstream Oxygen Sensor

Heated downstream oxygen sensor signal is used to detect the catalytic converter deterioration. As converter deteriorates, signal from downstream oxygen sensor begins to match upstream oxygen sensor signal except for a slight delay. By comparing the signal from heated upstream oxygen sensor to the signal from downstream oxygen sensor, Engine Control Module (ECM) calculates the efficiency of catalytic converter.



Removal & Installation - Upstream Oxygen Sensor

(See page 09-13).

Removal & Installation - Downstream Oxygen Sensor

(See page 09-15).

Camshaft Position Sensor

Description

Camshaft position sensor is installed on cylinder head behind camshaft.


Operation

Camshaft position sensor is a Hall type sensor, and a phaser is installed on camshaft. When phaser is in high teeth, applicable circuit output is high level; when phaser is in missing teeth, applicable circuit output is low level. As a result, crankshaft phase information is provided to Engine Control Module (ECM), so that the compression top dead center and exhaust top dead center of crankshaft can be distinguished.

Removal

- 1. Turn off all electrical equipment and the ignition switch.
- 2. Disconnect the negative battery cable.
- 3. Remove the engine trim cover.
- 4. Remove the camshaft position sensor (take intake side as an example).
 - a. Disconnect camshaft position sensor connector (arrow), and then remove camshaft position sensor fixing bolt.

(Tightening torque: 8 ± 1 N·m)



Installation

Installation is in the reverse order of removal.

CAUTION

• Sensor should be pressed into mounting hole. Never use tools (such as a hammer) to strike sensor into mounting hole forcibly.

Engine Speed Sensor

Description

Engine speed sensor is installed on clutch case, against flywheel teeth. It is used to detect the speed and position of crankshaft.

Operation

Engine speed sensor is a magnetoelectric sensor. When crankshaft rotates, it drives flywheel to rotate. The flywheel teeth will change the strength of sensor magnetic field, and change of magnetic flux causes change of sensor output signal voltage which is sent to Engine Control Module (ECM). And the output signal can indicate the speed and position of crankshaft.

Removal

- 1. Turn off all electrical equipment and the ignition switch.
- 2. Disconnect the negative battery cable.
- 3. Remove the engine trim cover.
- 4. Remove the engine speed sensor.
 - a. Disconnect engine speed sensor connector, and remove engine speed sensor fixing bolt. (Tightening torque: 8 ± 2 N·m)

Installation

Installation is in the reverse order of removal.

CAUTION

· Press in engine speed sensor rather than tapping when installing it.

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Boost Pressure/Temperature Sensor

Description

Boost pressure/temperature sensor integrates with the boost pressure sensor and intake temperature sensor, which is installed on the boost intercooler.

Operation

Boost pressure sensing element consists of a piece of silicon chip, which will deform mechanically as the intercooler pressure changes. The piezoresistor in sensor will also deform, thus changing the resistance. Voltage signal linearly related to the pressure is generated after processing by signal circuit of the silicon chip. Intake temperature sensor is a negative temperature coefficient thermostat, whose resistance changes with the intake temperature. This sensor sends the voltage generated by intake temperature change to Engine Control Module (ECM), thus monitoring the change of intake temperature.

Removal

- 1. Turn off all electrical equipment and the ignition switch.
- 2. Disconnect the negative battery cable.
- 3. Remove the engine trim cover.
- 4. Disconnect the boost pressure/temperature sensor connector (arrow).



5. Remove boost pressure/temperature sensor fixing bolt, and remove boost pressure/temperature sensor. (Tightening torque: 6 ± 1 N·m)

Installation

Installation is in the reverse order of removal.

CAUTION

- Remove foreign matter on sensor before installation.
- Apply grease to O-ring before installation to prevent it from being damaged during installation.


Ignition Coil

Description

Ignition coil converts low voltage of primary winding into high voltage of secondary winding, and discharges spark plug electrode to produce sparks which will ignite the combustible air-fuel mixture in cylinder.

Operation

Ignition coil consists of primary winding, secondary winding, iron core and housing etc. The primary and secondary windings form an induced circuit. An instant induced voltage generated by turning primary circuit switch on and off, and an instant high voltage generated by secondary circuit will cause spark plugs to discharge, thus igniting the combustible air-fuel mixture. Primary winding will recharge when its ground channel is engaged through an Engine Control Module (ECM) signal. Once Engine Control Module (ECM) cuts off the control signal to primary winding circuit, it will stop charging and a high voltage will be induced in the secondary winding.



Removal & Installation

(See page 14-8). (See page 14-8).

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Electronic Accelerator Pedal Sensor

Description

Accelerator pedal is installed to cowl of the body, and accelerator pedal sensor is located inside the accelerator pedal.

Operation

Accelerator pedal sensor outputs the electrical signal which varies linearly depending on the pedal travel to ECM, in order to detect position of the accelerator pedal.

ECM adjusts opening angle of the electronic throttle according to this signal and other information to meet the intake requirements under different operating conditions.

Removal & Installation

(See page 10-33).





Electric Fuel Pump

Description

Electric fuel pump consists of DC motor, vane pump and end cover (integrated with check valve, pressure regulator and anti-electromagnetic interference element) etc. Pump and motor are installed coaxially, and sealed in the same housing. Fuel is filled around the pump and motor in the housing and used for heat dissipation and lubrication.

Operation

Battery supplies power to electric fuel pump via electric fuel pump relay, which can turn on electric fuel pump circuit only when starting and engine running. When engine stops running because of an accident, fuel pump stops running automatically. The maximum pressure at electric fuel pump outlet is adjusted by pressure regulator to keep the whole fuel system pressure at 400 kPa.

Removal & Installation

(See page 08-15).





Fuel Injector

Description

Fuel injector is located on the cylinder head near to one end of intake valve, and nozzle end is located directly above the intake port.

Operation

Engine Control Module (ECM) sends electric pulse to injector coil, forming magnetic field force. When magnetic field force increases enough to overcome the resultant force from return spring pressure, needle valve gravity and friction force, needle valve begins to rise up and injector starts to inject fuel. Pressure of return spring forces the needle valve to close again when injection pulse stops.

Removal & Installation

(See page 08-26).

Canister Solenoid Valve

Description


Canister solenoid valve opens when power is on, and closes when power is off.

Operation

Canister solenoid valve consists of solenoid coil, magnet armature and valve, etc. Air volume through canister solenoid valve is related to electric pulse duty ratio output from ECU and pressure difference between canister solenoid valve inlet and outlet. When there is no electric pulse, canister solenoid valve closes.

، دیجیتال خودرو سامانه (مسئولیت محدود)

ن سامانه دیجیتال تعمیرکاران خودرو در ایران



Removal & Installation

(See page 09-9).

Engine Control Module (ECM)

Description

Engine Control Module (ECM), mounted on the left side rail wheel housing assembly in engine compartment, can be removed only as a unit for replacement.


Operation

Engine Control Module (ECM) is a pre-programmed microprocessor digital computer, which is used to adjust ignition timing, air-fuel ratio, emission control, speed control, A/C compressor and idle speed etc. Engine Control Module (ECM) enables the program to suit ever-changing operation conditions.

Removal

- 1. Turn off all electrical equipment and the ignition switch.
- 2. Disconnect the negative battery cable.
- 3. Remove the Engine Control Module (ECM).
 - a. Remove 4 ECM fixing bolts.
 - b. Disconnect ECM connectors (arrow), and remove ECM.

(Tightening torque: 7 ± 1 N·m)



Installation

Installation is in the reverse order of removal.

CAUTION

- Pay attention to static electricity protection when installing.
- Take care to protect connector terminals.
- To prevent water droplets from accumulating on connector joint, face it down.



