

STEERING COLUMN

GENERAL INFORMATION	41-3	Inspection	41-9
Description	41-3	Installation	41-9
Specifications	41-5	Combination Switch Cover	41-11
Tools	41-5	Removal	41-11
DIAGNOSIS & TESTING	41-6	Inspection	41-12
Problem Symptoms Table	41-6	Installation	41-12
Steering Wheel Free Play Inspection	41-7	Steering Column with	
Steering Wheel Centering/ Returnability Inspection	41-7	Intermediate Shaft Assembly	41-13
ON-VEHICLE SERVICE	41-8	Removal	41-13
Steering Wheel Assembly	41-8	Disassembly	41-15
Removal	41-8	Inspection	41-15
		Assembly	41-15
		Installation	41-16

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

41


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



GENERAL INFORMATION

Description

Hydraulic Steering Column




RT15400010

41

1 - Driver Airbag	2 - Steering Wheel Assembly Fixing Nut
3 - Steering Wheel Assembly	4 - Spiral Cable
5 - Combination Switch Upper Cover	6 - Wiper Switch
7 - Combination Light Switch	8 - Combination Switch Lower Cover
9 - Steering Column with Intermediate Shaft Assembly	

41 - STEERING COLUMN

Electronic Power Steering Column



1 - Driver Airbag	2 - Steering Wheel Assembly Fixing Nut
3 - Steering Wheel Assembly	4 - Spiral Cable
5 - Combination Switch Upper Cover	6 - Wiper Switch
7 - Combination Light Switch	8 - Combination Switch Lower Cover
9 - Steering Column with Intermediate Shaft Assembly	

Specifications

Torque Specifications


Description	Tightening torque (N·m)
Steering Wheel Assembly Fixing Nut	35 ± 3
Combination Switch Cover Fixing Screw	2 ± 0.5
Steering Column Assembly Upper Bracket Fixing Bolt	25 ± 3
Steering Column Assembly Lower Bracket Fixing Bolt	25 ± 3
Coupling Bolt Between Steering Column with Intermediate Shaft Assembly (Hydraulic Assist) and Steering Gear Input Shaft	25 ± 3
Coupling Bolt Between Steering Column with Intermediate Shaft Assembly (Electronic Power) and Steering Gear Input Shaft	1st step: 15 ± 1 N·m; 2nd step: $125^\circ \pm 5^\circ$

Data Specifications


Description	Standard Value
Steering Wheel Free Play (Rotation Angle)	$\leq 15^\circ$
Steering Wheel Centering/Returnability (Rotation Angle)	$> 70^\circ$

Tools

Special Tool

Steering Wheel Remover	 RCH0000014
------------------------	---

General Tool

Electric Drill	 RCH0000013
----------------	--

DIAGNOSIS & TESTING

Problem Symptoms Table

HINT:

Use symptoms table below to help determine cause of problem. Check each suspected area in sequence. Repair or adjust faulty components, or replace as necessary.


Steering System

Symptom	Suspected Area	See page
Steering wheel assembly cannot lock or unlock	Electric steering column lock	41-15
	Engine switch	25-13
Steering wheel assembly has no free play or free play is too large	Front axle hub bearing (seriously worn)	35-14
	Intermediate shaft with universal joint assembly (seriously worn)	41-13
	Ball pin assembly (worn or loosen)	42-19
	Steering tie rod assembly	42-20
	Steering gear assembly (improper engagement gap of rack and pinion)	42-22
Hard steering	Front tire (improperly inflated or unevenly worn)	37-8
	Front wheel alignment (incorrect)	36-47
	Front sub frame welding assembly	35-16
	Intermediate shaft with universal joint assembly (insufficiently lubricated)	41-13
	Ball pin assembly (insufficiently lubricated)	42-19
	Steering tie rod assembly	42-20
	Steering column assembly	41-13
	Steering gear assembly	42-22
	Front tire (improperly inflated or unevenly worn)	37-8
	Front wheel alignment (incorrect)	36-47
Poor returnability	Front suspension	36-11
	Ball pin assembly (loosen, insufficiently lubricated)	42-19
	Steering tie rod assembly	42-20
	Intermediate shaft with universal joint assembly (loosen, insufficiently lubricated)	41-13
	Steering column assembly (stuck)	41-13
	Steering gear assembly (stuck)	42-22
	Front tire (improperly inflated or unevenly worn)	37-8
	Front wheel alignment (incorrect)	36-47

Symptom	Suspected Area	See page
Knocking (or clunking) sound occurs when turning steering wheel while steering system is in operation	Intermediate shaft with universal joint assembly	41-13
	Control arm ball pin	36-21
	Control arm	36-19
	Front strut upper connecting plate assembly (w/insulator)	36-14
	Steering gear assembly	42-22
Friction sound occurs when steering wheel is turned during low speed driving	Steering column assembly	41-13
	Front strut upper connecting plate assembly (w/insulator)	-
Steering wheel vibrates and noise occurs when steering wheel is turned with vehicle stopped	Steering column assembly	41-13
	Front strut upper connecting plate assembly (w/insulator)	-

Steering Wheel Free Play Inspection

1. Position front wheels straight ahead when engine is idling (hydraulic system is operating).
2. Slightly turn steering wheel to left and right, and check steering wheel free play when wheels start to rotate.
Standard value of free play (rotation angle): $a \leq 15^\circ$.




41

3. If measured value exceeds standard value, check steering system.

Steering Wheel Centering/Returnability Inspection

Steering wheel centering/returnability inspection should be performed during road test.

1. Perform slow turn and sharp turn tests.
Check for deviation of steering wheel steering force required during left/right turn and centering/returnability.
2. When vehicle speed is between 20 and 30 km/h, turn steering wheel either to left or right by 90° and keep it for 1 or 2 seconds, and then release steering wheel. If steering wheel turns back more than 70° , it is determined that steering wheel centering/returnability is in good condition.



3. If steering wheel returning angle is not as specified, check tire pressure, steering system and suspension system.

ON-VEHICLE SERVICE

Steering Wheel Assembly

Removal

CAUTION


- Be sure to read precautions for SRS airbag before removing steering wheel (See page 45-88).

1. Set steering wheel to straight-ahead position.
2. Turn off all electrical equipment and the engine switch.
3. Disconnect the negative battery cable.

CAUTION


- Wait at least 90 seconds after disconnecting the negative battery cable to prevent airbag and belt pretensioner from being activated.

4. Remove the driver airbag assembly (See page 45-88).
5. Remove the steering wheel assembly.
 - a. Disconnect the steering wheel quick button connector (arrow).




- b. Secure steering wheel assembly, and put matchmarks on steering wheel assembly and steering column assembly, then remove steering wheel assembly fixing nut (arrow).

(Tightening torque: 30 ± 3 N·m)



41 - STEERING COLUMN

- c. As shown in illustration, install steering wheel remover, and then tighten it with a wrench to loosen steering wheel assembly from steering column assembly.



- d. Remove the steering wheel assembly.

CAUTION

- Be careful when removing steering wheel assembly to prevent damage to airbag connector and horn connector on spiral cable.

Inspection

- Check steering wheel assembly body for damage or deformation. Replace steering wheel assembly if necessary.
- Check spline in steering wheel assembly for damage. Replace steering wheel assembly if necessary.

Installation


CAUTION

- Check that front wheels are in straight-ahead position before installing steering wheel assembly.

- Adjust spiral cable to correct position (arrow).

HINT:

Fully turn spiral cable inner circle clockwise when realigning the center, and then turn it counterclockwise to align with ►◄ while yellow ball occurs in clear vertical window. Failure to follow these instructions may affect normal operation of airbag system and cause injury to driver.



- Pass airbag connector and horn connector through hole of steering wheel assembly, and connect steering wheel quick button connector. Then align matchmarks on steering wheel assembly and steering column assembly to install steering wheel assembly.
- Other installation procedures are in the reverse order of removal.

41 - STEERING COLUMN

 CAUTION

- Tighten steering wheel assembly fixing nut to specified torque.
- Install each connector in place.
- After repairing, check that airbag system operates normally.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

41


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران





Combination Switch Cover

Removal


1. Set steering wheel to straight-ahead position.
2. Turn off all electrical equipment and the engine switch.
3. Remove the combination switch cover.
 - a. Remove lower fixing screw (arrow) from combination switch cover.
(Tightening torque: $2 \pm 0.5 \text{ N}\cdot\text{m}$)



- b. Disengage coupling clip between upper cover and lower cover, and then separate upper cover and lower cover to remove lower cover.



- c. Separate 5 clips (arrow) between upper cover and steering column dust gasket, and then remove upper cover.



CAUTION

- Operate carefully to prevent damage to components during removal.

41 - STEERING COLUMN

Inspection

1. Check combination switch upper and lower covers for damage or deformation. Replace upper and lower covers if necessary.
2. Check if upper and lower cover clips are normal. Replace upper and lower covers if necessary.

Installation

1. Loosen steering wheel adjusting handle, and adjust steering column assembly to uppermost position, then tighten adjusting handle to uppermost position.
2. Insert steering column lower cover from lower side at an angle, and then install adjusting handle into cover hole.
3. After adjusting lower cover, install upper cover and fix upper and lower cover clips in place, then install self-tapping screws.

CAUTION

- Tighten self-tapping screws in place.
- Operate carefully to prevent damage to components during installation.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

41

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




Steering Column with Intermediate Shaft Assembly

Removal


HINT:

Use same removal procedures for mechanical steering column and electric steering column. Removal procedures listed below are for electric steering column.

1. Set steering wheel to straight-ahead position.
2. Turn off all electrical equipment and the engine switch.
3. Disconnect the negative battery cable.
4. Remove the airbag (See page 45-88).
5. Remove the steering wheel assembly (See page 41-8).
6. Remove the combination switch cover (See page 41-11).
7. Remove the spiral cable (See page 45-91).
8. Remove the combination switch assembly.
 - a. Disconnect combination switch connector (1) and wiper switch connector (2).




- b. Loosen combination switch clamp, pull combination switch and wiper switch outward and remove combination switch.



9. Remove the lower left protector assembly (See page 60-14).
10. Remove the steering column with intermediate shaft assembly.
 - a. Remove coupling bolt (arrow) between steering column with intermediate shaft assembly and steering gear input shaft.


(Tightening torque for hydraulic assist: $30 \pm 3 \text{ N}\cdot\text{m}$)

(Tightening torque for electronic power: 1st step: $15 \pm 1 \text{ N}\cdot\text{m}$; 2nd step: $125^\circ \pm 5^\circ$)




41 - STEERING COLUMN


- b. Disconnect the electronic steering column lock connector (arrow) (for MT model).




- c. Remove 2 connectors (arrow) from EPS controller (w/ electronic power steering).



- d. Remove 2 fixing bolts (arrow) from steering column upper bracket.
(Tightening torque: 25 ± 3 N·m)



- e. Remove 1 fixing bolt (arrow) from steering column lower bracket.
(Tightening torque: 25 ± 3 N·m)





- f. Remove the steering column with intermediate shaft assembly.

 CAUTION

- DO NOT touch interior ornaments when removing steering column with intermediate shaft assembly to avoid scratching interior ornaments.

Disassembly

1. Remove the electronic steering column lock.
 - a. Using an electric drill (1), drill a hole on anti-theft bolt (arrow) of electronic steering column lock.
 - b. Using a screw remover, remove anti-theft bolt of electronic steering column lock.




Inspection

1. Check steering column assembly for wear, cracks or deformation. As welding or correction is not allowed, replace steering column assembly if necessary.
2. Check steering column bearing for looseness, wear or sticking. Replace steering column assembly if necessary.

Assembly

1. Install the electronic steering column lock.
 - a. Install electronic steering column lock to steering column assembly with new electronic steering column lock anti-theft bolt (arrow), and then tighten bolt until head is disengaged.



41 - STEERING COLUMN

Installation

Installation is in the reverse order of removal.

CAUTION

- Before installing steering column assembly, slide spline at lower part of steering column assembly onto intermediate shaft upper universal joint first.
- Tighten each fixing nut, bolt and screw in place.
- Install each connector in place.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

41

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



HYDRAULIC ASSIST STEERING

GENERAL INFORMATION	42-3	Power Steering Pump Assembly	42-17
Description	42-3	Removal	42-17
Operation	42-4	Disassembly	42-17
Specifications	42-5	Inspection	42-18
Tool	42-5	Assembly	42-18
		Installation	42-18
DIAGNOSIS & TESTING	42-6	Ball Pin Assembly	42-19
Problem Symptoms Table	42-6	Removal	42-19
Steering Fluid Draining	42-7	Inspection	42-19
Steering Fluid Adding	42-8	Installation	42-19
Bleeding Procedures	42-9	Steering Tie Rod Assembly	42-20
ON-VEHICLE SERVICE	42-10	Removal	42-20
Steering Fluid Reservoir Assembly	42-10	Inspection	42-20
Removal	42-10	Installation	42-21
Inspection	42-10	Steering Gear Assembly	42-22
Installation	42-10	Removal	42-22
Steering Fluid Pipe	42-12	Inspection	42-23
Removal	42-12	Installation	42-23
Inspection	42-15	Steering Gear Clearance Adjustment	42-24
Installation	42-15		

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



دیجیتال خودرو


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران 42



GENERAL INFORMATION

Description



RT15410010

42 - HYDRAULIC ASSIST STEERING

1 - Ball Pin Locking Nut	2 - Right Steering Tie Rod Ball Pin
3 - Elastic Clamp	4 - Right Steering Tie Rod Boot
5 - Clamping Ring	6 - Right Steering Tie Rod Assembly
7 - Steering Gear Heat Insulation Cover	8 - Steering Gear Assembly
9 - Left Steering Tie Rod Assembly	10 - Left Steering Tie Rod Boot
11 - Steering Tie Rod Adjustment Nut	12 - Left Steering Tie Rod Ball Pin
13 - Fluid Return Pipe 1	14 - Fluid Return Pipe 2
15 - Steering Fluid Reservoir Cap	16 - Steering Fluid Reservoir
17 - Steering Fluid Reservoir Bracket	18 - Fluid Suction Pipe
19 - Hollow Bolt	20 - Power Steering Pump Assembly
21 - Idler Pulley	22 - Power Steering Pump Bracket
23 - High Pressure Fluid Pipe	24 - Cooling Pipe

Hydraulic assist steering system consists of power steering pump assembly, steering gear assembly, steering fluid pipe and steering fluid reservoir assembly, etc. This system can reduce the steering effort when driver operates steering wheel, thus improving operation convenience and driving safety.

Steering Gear Assembly

Steering gear assembly is rack & pinion type, which is characterized by simple and compact construction and high steering sensitivity. The piston-rod is integrated with rack, and there is a boot at the connection between steering tie rod assembly and rack. The length of steering tie rod can be adjusted properly to match with the toe-in. Tie rod ball pin assembly and steering knuckle are connected and tightened by locking nut.

Power Steering Pump Assembly

Power steering pump assembly is connected with steering gear assembly through high pressure fluid pipe, and connected with steering fluid reservoir assembly through fluid suction pipe. Never operate the power steering pump assembly without fluid. Try to avoid turning the steering wheel to limit position for more than 5 seconds during use.

Steering Fluid Pipe

Steering fluid pipe is used to deliver power steering fluid. Steering fluid pipes are divided into steel pipe, hose and hybrid type according to the length and operating features of each component. Ferrule connection is adopted between steel pipe and hose of high pressure fluid pipe assembly. The Joint bolt and O-ring are used between steel pipe and component, and the hose and clamp are used between hose and component. And all these provide reliable sealing.

Steering Fluid Reservoir Assembly

Main functions of steering fluid reservoir assembly are to store and supply fluid to the steering fluid pump and system.

Operation

Steering gear assembly converts the circular motion of steering wheel into the linear motion of rack by engaging pinion and rack inside the steering gear assembly. Power steering pump assembly delivers fluid into steering gear assembly to drive pistons to move toward the direction made by driver. Piston transmits force to steering knuckle by steering tie rod assembly, thus reducing the steering effort needed when driver turns steering wheel. If steering assist is ineffective, more steering effort is needed.


Specifications

Torque Specifications

Description	Torque (N·m)
Steering Gear Heat Insulation Cover Fixing Bolt	9 ± 1
High Pressure Fluid Pipe Bracket Bolt 1	9 ± 1
High Pressure Fluid Pipe Bracket Bolt 2	9 ± 1
Clamping Bolt Between High Pressure Fluid Pipe and Steering Gear Assembly	30 ± 3
Clamping Bolt Between Fluid Return Pipe and Steering Gear Assembly	30 ± 3
Fluid Return Pipe Bracket Bolt 1	9 ± 1
Fluid Return Pipe Bracket Nut 2	7 ± 1
Fluid Return Pipe Bracket Bolt 3	7 ± 1
Fluid Return Pipe Bracket Nut 4	7 ± 1
High Pressure Fluid Pipe Joint Hollow Bolt	40 ± 3
Cooling Pipe Bracket Nut 1	7 ± 1
Cooling Pipe Bracket Nut 2	7 ± 1
Mounting Bolt Between Steering Gear and Sub Frame	120 ± 10
Steering Tie Rod Locking Nut	45 ± 5
Power Steering Pump Bracket Fixing Bolt	25 ± 3
Coupling Bolt Between Power Steering Pump Assembly and Steering Pump Bracket	25 ± 3
Locking Nut Between Ball Pin Assembly and Steering Knuckle Assembly	45 ± 5
Mounting Bolt Between Steering Gear Assembly and Front Sub Frame Welding Assembly	120 ± 10
Steering Tie Rod Adjustment Nut	55 ± 5

Tool

Special Tool

Ball Pin Separator	
--------------------	---

DIAGNOSIS & TESTING

Problem Symptoms Table

HINT:

Use the table below to help determine the cause of problem symptoms. Check each suspected area in sequence. Repair or replace the faulty components, or adjust as necessary.


Symptom	Suspected Area	See page
Stuck or sticking occurs when steering in some position	Steering fluid (insufficient or dirty)	42-8
	Steering tie rod boot (damaged or worn)	42-20
	Steering tie rod assembly (rust)	42-20
	Steering gear assembly	42-22
	Accessory drive belt (loose)	09-19
Steering wheel is not centered or centered improperly	Tire (unevenly worn, deformed) or wheel (out of balance)	37-8
	Front wheel alignment (wrong)	36-47
	Ball pin assembly (worn or loose)	42-19
	Steering tie rod assembly (worn or loose)	42-20
	Intermediate shaft (twisted and deformed) or universal joint (worn, loose or insufficiently lubricated)	41-13
	Front sub frame welding assembly	35-16
	Steering knuckle	35-9
	Steering gear assembly (incorrect clearance)	42-22
Steering shudders	Tire (unevenly worn, deformed) or wheel (out of balance)	37-8
	Front wheel alignment (wrong)	36-47
	Ball pin assembly (worn or loose)	42-19
	Brake disc and lining (deformed)	39-25
	Intermediate shaft (twisted and deformed) or universal joint (worn, loose or insufficiently lubricated)	41-13
	Front sub frame welding assembly	35-16
	Steering knuckle assembly	35-9
	Steering gear assembly (incorrect clearance)	42-22

42 - HYDRAULIC ASSIST STEERING

Symptom	Suspected Area	See page
Steering wheel turns heavily or steering effort is uneven	Tire (improperly inflated)	37-8
	Front wheel alignment (wrong)	36-47
	Steering fluid (insufficient)	42-8
	Fluid pipe (leakage or blocking)	42-12
	Ball pin assembly (worn or loose)	42-19
	Steering tie rod assembly (worn or loose)	42-20
	Front suspension	36-11
	Accessory drive belt (loose or damaged)	09-19
	Power steering pump assembly	42-17
	Steering gear assembly (incorrect clearance)	42-22
Abnormal noises from steering system	Steering fluid (insufficient, air or dirty)	42-8
	Steering system fluid pressure fluctuates abnormally	-
	Ball pin assembly (worn or loose)	42-19
	Steering tie rod assembly (worn or loose)	42-20
	Steering gear assembly (incorrect clearance)	42-22
	Power steering pump assembly	42-17

Steering Fluid Draining

1. Set steering wheel to straight-ahead position.
2. Turn off all the electrical equipment and engine switch.
3. Disconnect the negative battery cable.
4. Turn engine switch to OFF.
5. Open the steering fluid reservoir cap.
6. Remove the engine lower protector assembly.
7. Remove the fluid suction pipe clamp (arrow) on the power steering pump assembly side.



8. Place a fluid container under the fluid suction pipe, and disconnect the fluid suction pipe joint to collect steering fluid flowing from the fluid suction pipe.
9. Turn the steering wheel left and right to the limit positions, and repeat the operation several times to drain steering fluid in steering system.

42 - HYDRAULIC ASSIST STEERING

 WARNING

- If steering fluid sprays on your skin, immediately wash it off with water.
- It is harmful to your skin, if contacting with power steering fluid for a long time.
- Steering wheel should not be in the limit position for more than 5 seconds.

 ENVIRONMENTAL PROTECTION

- Wasted power steering fluid should be handled according to local environmental regulations.

Steering Fluid Adding

The proper steering fluid level is between "MAX" and "MIN" marks. It affects power steering system performance directly whether fluid level of the fluid reservoir is proper. If fluid level drops below "MIN" mark, it is necessary to add steering fluid.

 CAUTION

- DO NOT apply foaming or expired steering fluid to vehicle. Otherwise it may damage the power steering pump assembly.

1. Open the steering fluid reservoir cap, and add steering fluid to reservoir until the level reaches "MAX" mark.
2. Start engine and run it at idle to drive the power steering pump assembly, thus filling whole steering system with steering fluid.
3. Observe fluid level of fluid reservoir while engine is running. If fluid level drops below "MIN" mark, add steering fluid to a proper level in time to prevent fluid level from dropping excessively and avoid air entering power steering pump assembly.
4. If bubbles occur in steering fluid reservoir, perform bleeding procedures. Check that level is between "MAX" and "MIN" marks when there are no bubbles in fluid reservoir and fluid level does not change any longer.

 WARNING

- If steering fluid sprays on your skin, immediately wash it off with water.
- It is harmful to your skin, if contacting with power steering fluid for a long time.

Bleeding Procedures

It is necessary to perform the bleeding procedures when bubbles occur in steering fluid reservoir assembly and fluid has emulsified or there is excessive noise in power steering pump assembly.

Bleeding procedures are as follows:

1. Open the steering fluid reservoir cap.
2. Raise vehicle with a lifter (with front wheels off ground).
3. Start engine (idling) and turn steering wheel left and right to the limit positions (do not stay at the limit positions more than 2 seconds). Repeat several times to fully bleed air in system from the reservoir. Observe the fluid level of fluid reservoir during bleeding. If fluid level drops below "MIN" mark, add steering fluid to proper level in time.
4. After repeatedly turning the steering wheel to the limit positions several times, center the steering wheel, run engine at idle for 3 or 5 minutes and observe whether there are still bubbles in fluid reservoir. If there are still bubbles, perform above procedures again until no bubbles are bled. If there are still problems, perform steering system inspection.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



ON-VEHICLE SERVICE

⚠ WARNING

- Be sure to wear necessary safety equipment to prevent accidents when servicing.
- When removing and installing high temperature components and surrounding components, wait and operate until they drops to normal temperature to avoid being burned.
- Prevent skin and eyes from contacting with steering fluid.


👁 CAUTION

- After disconnecting steering line, seal it immediately to prevent foreign matter from entering.
- Never run power steering pump assembly when the steering fluid is insufficient.
- Steering wheel should not be in limit positions for more than 5 seconds.
- Never start engine with hose loosened or disconnected.
- Never allow hose to contact with high temperature exhaust pipe.

Steering Fluid Reservoir Assembly

Removal

1. Drain the steering fluid (See page 42-7).
2. Remove the steering fluid reservoir assembly.
 - a. Remove the fluid suction pipe clamp (1) on steering fluid reservoir, and disconnect the connection between fluid suction pipe assembly and steering fluid reservoir assembly.
 - b. Remove the fluid return pipe clamp (2) on steering fluid reservoir, and disconnect the connection between fluid return pipe assembly and steering fluid reservoir assembly.



👁 CAUTION

- Using a plug, clog the disconnected pipe to prevent foreign matter from entering.

- c. Pull the steering fluid reservoir assembly upward to remove it from the steering pump bracket.

Inspection

1. Check steering fluid reservoir assembly for breakage or deformation. Replace fluid reservoir if necessary.
2. Check if there is contamination in steering fluid reservoir assembly. Clean or replace if necessary.

Installation

Installation is in the reverse order of removal.

 CAUTION

- Install fluid suction pipe clamp and fluid return pipe clamp in place.
- Never tap or hit the fluid reservoir.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Steering Fluid Pipe


Removal




ENVIRONMENTAL PROTECTION

- Collect residual steering fluid in the line with a container when disconnecting the line.


1. Drain the steering fluid (See page 42-7).
2. Remove the front bumper (See page 63-6).
3. Remove the fluid suction pipe.
 - a. Remove the fluid suction pipe clamp (arrow) on steering fluid reservoir, and disconnect the connection between fluid suction pipe and steering fluid reservoir assembly.



- b. Remove the fluid suction pipe clamp (arrow) on the power steering pump assembly side.



- c. Loosen the plastic pipe clamp from the front vertical board of body.




- d. Remove the fluid suction pipe.


42 - HYDRAULIC ASSIST STEERING

4. Remove the high pressure fluid pipe.


- a. Remove the high pressure fluid pipe joint hollow bolt (arrow) from the power steering pump assembly.
(Tightening torque: 40 ± 3 N·m)



- b. Remove the high pressure fluid pipe clamping bolt from the steering gear assembly.
(Tightening torque: 30 ± 3 N·m)




- c. Remove the high pressure fluid pipe bracket bolt 1 (arrow).
(Tightening torque: 9 ± 1 N·m)




- d. Remove the high pressure fluid pipe bracket bolt
e. Remove the high pressure fluid pipe.

42 - HYDRAULIC ASSIST STEERING


5. Remove the fluid return pipe.
- a. Remove the fluid return pipe clamping bolt from the steering gear assembly.
(Tightening torque: 30 ± 3 N·m)




- b. Remove the fluid return pipe bracket bolt 1 (arrow).
(Tightening torque: 9 ± 1 N·m)



- c. Loosen the fluid return pipe 1 clamp and disconnect the fluid return pipe joint.




- d. Remove the fluid return pipe bracket nut 2 (arrow).
(Tightening torque: 7 ± 1 N·m)




42 - HYDRAULIC ASSIST STEERING


- e. Remove the fluid return pipe bracket bolt 3 (arrow).
(Tightening torque: 7 ± 1 N·m)



- f. Remove the fluid return pipe bracket nut 4 (arrow).
(Tightening torque: 7 ± 1 N·m)



- g. Remove the fixing bolt (arrow) and remove the guide pipe.
(Tightening torque: 7 ± 1 N·m)



- h. Remove the fluid return pipe 2 carefully.

6. Remove the cooling pipe.

- Remove 3 plastic clamps from the right radiator deflector, and remove the right radiator deflector.
- Remove the cooling pipe bracket nut.
- Move away the clamp between cooling pipe and fluid return pipe, and disconnect the connection between cooling pipe and fluid return pipe.
- Remove the cooling pipe bracket nut.
- Remove the cooling pipe carefully.

Inspection

- Check steering fluid pipe for cracks, wear or blockage. Replace steering fluid pipe assembly if necessary.
- Check steering fluid pipe joint and O-ring for deformation or damage. Replace steering fluid pipe assembly if necessary.
- Check if steering fluid pipe bracket is normal. Replace if necessary.

Installation

Installation is in the reverse order of removal.

42 - HYDRAULIC ASSIST STEERING

 CAUTION

- Never tap or squeeze steering fluid pipe.
- Tighten fixing nut to the specified torque.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

42 اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Power Steering Pump Assembly


Removal



ENVIRONMENTAL PROTECTION

- Collect steering fluid flowing from the line with a container when disconnecting the line.


1. Drain steering fluid (See page 42-7).
2. Remove the accessory drive belt (See page 09-19).
3. Remove the power steering pump with bracket assembly.
 - a. Remove the high pressure fluid pipe joint hollow bolt (1).
(Tightening torque: $45 \pm 5 \text{ N}\cdot\text{m}$)
 - b. Loosen the elastic clamp (2), and disconnect the connection between fluid suction pipe and power steering pump assembly.



CAUTION

- Using a plug, clog the disconnected steering system line to prevent foreign matter from entering.


- c. Remove 3 fixing bolts (1), (2) and (3) from the steering pump bracket and the fixing bolt (arrow) from the idler pulley.
(Tightening torque for steering pump bracket fixing bolt: $25 \pm 3 \text{ N}\cdot\text{m}$)
(Tightening torque for idler pulley fixing bolt: $50 \pm 5 \text{ N}\cdot\text{m}$)



42


Disassembly

1. Separate the power steering pump assembly and steering pump bracket.
 - a. Remove the coupling bolt (arrow) between power steering pump assembly and pulley side of steering pump bracket.
(Tightening torque: $25 \pm 3 \text{ N}\cdot\text{m}$)



42 - HYDRAULIC ASSIST STEERING

- b. Remove 2 coupling bolts (arrow) between power steering pump assembly and the other side of steering pump bracket.
(Tightening torque: 25 ± 3 N·m)



Inspection

1. Check power steering pump assembly for blockage or damage, and power steering pump bearing for looseness and abnormal noise. Replace the power steering pump assembly if necessary.
2. Check if power steering pump pulley is normal. Replace the power steering pump assembly if necessary.
3. Check if steering pump bracket is normal. Replace the steering pump bracket if necessary.

Assembly

Assembly is in the reverse order of disassembly.

CAUTION

- Tighten the bolts to the specified torque.
- DO NOT tap or hit power steering pump assembly.

Installation

Installation is in the reverse order of removal.

CAUTION

- Tighten the fixing bolts to the specified torque.
- DO NOT tap or hit power steering pump assembly.

Ball Pin Assembly

Removal

HINT:

- Use the same procedures for the right side and left side.
 - Procedures listed below are for the left side.
1. Remove the front wheel ([See page 37-7](#)).
 2. Remove the ball pin assembly.
 - a. Remove the locking nut between left steering tie rod assembly ball pin and front left steering knuckle assembly.
 - b. Install the ball pin separator, and tighten the ball pin separator bolt with a wrench to separate the steering tie rod ball pin and steering knuckle assembly
 - c. Loosen the steering tie rod adjustment nut, and turn the ball pin assembly counterclockwise to remove it.

HINT:

When removing the ball pin assembly, record the revolutions during removal to make the front wheel toe-in closer to the setting value after installation.

Inspection

Check ball pin assembly for looseness and insufficient lubrication and bush rubber for damage. Replace the ball pin assembly if necessary.

Installation

Installation is in the reverse order of removal.

CAUTION


- After installation, it is necessary to perform wheel alignment procedure ([See page 36-47](#)).

Steering Tie Rod Assembly

Removal

HINT:

- Use the same procedures for the right side and left side.
 - Procedures listed below are for the left side.
1. Remove the battery (See page 27-7).
 2. Remove the battery tray (See page 27-9).
 3. Remove the front wheel (See page 37-7).
 4. Remove the ball pin assembly (See page 43-22).
 5. Remove the steering tie rod assembly.
 - a. Remove the steering tie rod boot clamp (2).
 - b. Remove the steering tie rod boot clamping ring (1) and remove the steering tie rod boot.




CAUTION

- Operate carefully to prevent damaging the boot.
- It is necessary to replace with new clamping ring when reinstalling steering tie rod boot.

42

- c. Using a wrench, remove the steering tie rod ball pin (arrow).



Inspection

1. Check steering tie rod boot for damage, and clamp for normality. Replace the steering tie rod boot and clamp if necessary to prevent water and micro dust from entering and causing parts failure prematurely.
2. Check steering tie rod assembly for deformation or wear, and ball for insufficient lubrication. Replace steering tie rod assembly or add grease if necessary.

Installation

Installation is in the reverse order of removal.

CAUTION

- It is necessary to apply thread seal gum to the ball pin.
- It is necessary to fit the steering tie rod ball pin face and rack face closely.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Steering Gear Assembly

WARNING


- Be sure to wear necessary safety equipment to prevent accidents when servicing.
- When removing and installing high temperature components and surrounding components, wait and operate them until they drop to the normal temperature to avoid being burned.
- Prevent skin and eyes from contacting with steering fluid when removing the steering system.

CAUTION

- After disconnecting steering system line, seal it immediately to prevent foreign matter from entering.
- Never run power steering pump assembly when steering fluid is insufficient.
- Steering wheel should not be in limit positions for more than 5 seconds.
- Never start engine with hose loosened or disconnected.
- Never allow hose to contact with high temperature exhaust manifold or catalyst.

Removal

1. Set steering wheel to straight-ahead position.
2. Turn off all the electrical equipment and engine switch.
3. Disconnect the negative battery cable.
4. Drain the steering fluid (See page 42-7).
5. Remove the front wheel (See page 37-7).
6. Remove the coupling bolt between steering column with intermediate shaft assembly and input shaft of steering gear.
(Tightening torque: $30 \pm 3 \text{ N}\cdot\text{m}$)



7. Separate the ball pin assembly and steering knuckle.

HINT:


- Use the same procedures for the right side and left side.
- Procedures listed below are for the left side.
 - a. Remove the locking nut between left steering tie rod assembly ball pin and front left steering knuckle assembly.
 - b. Install the ball pin separator, and tighten the ball pin separator bolt with a wrench to separate the steering tie rod ball pin and steering knuckle assembly.
- 8. Remove the steering gear with tie rod assembly.

42 - HYDRAULIC ASSIST STEERING

- a. Remove the high pressure fluid pipe clamping bolt (1) and fluid return pipe clamping bolt (2) from the steering gear assembly, and disconnect the connections between fluid return pipe, high pressure fluid pipe and steering gear assembly.

(Tightening torque for fluid return pipe clamping bolt: $30 \pm 3 \text{ N}\cdot\text{m}$)

(Tightening torque for high pressure fluid pipe clamping bolt: $30 \pm 3 \text{ N}\cdot\text{m}$)




- b. Remove the high pressure fluid pipe bracket bolt 1 and fluid return pipe bracket bolt 2 from the steering gear assembly.

(Tightening torque for the high pressure fluid pipe bracket bolt: $9 \pm 1 \text{ N}\cdot\text{m}$)

(Tightening torque for the fluid return pipe bracket bolt: $9 \pm 1 \text{ N}\cdot\text{m}$)

- c. Remove 2 mounting bolts between steering gear and sub frame.



- d. Slowly remove the steering gear with tie rod assembly.

Inspection

1. Check steering gear assembly housing for damage or deformation, and rack and pinion for sticking. Replace the steering gear assembly if necessary.
2. Check if steering tie rod boot, clamp and clamping ring are normal. Replace if necessary to prevent water and micro dust from entering and causing parts failure prematurely.
3. Check steering tie rod assembly and ball pin assembly for serious wear. Replace the steering tie rod assembly or ball pin assembly if necessary.

Installation

Installation is in the reverse order of removal.


CAUTION

- After installing the steering gear assembly, perform front wheel alignment procedure (See page 36-47).

42 - HYDRAULIC ASSIST STEERING

Steering Gear Clearance Adjustment

1. Set wheels to straight-ahead position.
2. Loosen the adjustment bolt locking nut (arrow).



3. Turn steering wheel left and right. If sound is heard from steering gear assembly, adjust the adjustment bolt until no clattering noise is heard when turning the steering wheel.
4. Tighten the adjustment bolt for more 1/8 turn (approximately 45°).
5. Perform road test.
6. If steering mechanism cannot return to central position, unscrew the bolt by 15°.
7. Perform road test.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

42 اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



ELECTRONIC POWER STEERING

GENERAL INFORMATION	43-3	C1211-1C	43-16
Description	43-3	C1200-44	43-16
Operation	43-4	C1201-44	43-16
Specifications	43-4	C1202-49	43-16
Tools	43-4	C1203-00	43-16
Circuit Diagram	43-6	C1204-48	43-16
EPS Controller Pin Definition	43-7	C1205-45	43-16
		C1206-07	43-16
DIAGNOSIS & TESTING	43-8	C1218-4B	43-16
Diagnostic Help	43-8	C1219-4B	43-16
Intermittent DTC Troubleshooting	43-8	C121A-49	43-16
Ground Inspection	43-8	C121B-46	43-16
Diagnostic Trouble Code (DTC) Chart	43-9	C1209-49	43-16
C1208-49	43-11	C121C-00	43-16
C1212-1C	43-11	C122D-48	43-16
C1213-1C	43-11	C120C-07	43-17
C1214-17	43-11		
C1215-1C	43-11	ON-VEHICLE SERVICE	43-22
C1216-1C	43-11	Ball Pin Assembly	43-22
C1217-16	43-11	Removal	43-22
C1207-49	43-16	Inspection	43-22
C120A-49	43-16	Installation	43-22
C120B-49	43-16	Steering Gear Assembly	43-23
C120D-00	43-16	Removal	43-23
C120E-00	43-16	Inspection	43-24
C120F-00	43-16	Installation	43-24
C1210-49	43-16	Steering Gear Clearance Adjustment	43-25

دیجیتال خودرو


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



GENERAL INFORMATION

Description



1 - Right Steering Tie Rod Ball Pin	2 - Tie Rod Ball Pin Locking Nut
3 - Tie Rod Dust Boot Clamp	4 - Right Steering Tie Rod Dust Boot
5 - Clamp	6 - Right Steering Tie Rod Assembly
7 - Steering Gear Assembly	8 - Left Steering Tie Rod Assembly
9 - Left Steering Tie Rod Dust Boot	10 - Left Steering Tie Rod Ball Pin
11 - Steering Gear Heat Insulator	

The vehicle adopts electronic power steering system, which can reduce the workload when driver operates the steering wheel, thus improving operation convenience and driving safety.

43 - ELECTRONIC POWER STEERING

Operation

The circular motion of steering wheel is converted into linear motion of rack by engaging rack and pinion inside steering gear. The rack can push and pull the tie rod by lateral motion, thus changing the direction of front wheel.

EPS controller controls the rotating direction of steering motor and assisting current level based on torque sensor signals to finish the steering assist. When vehicle is not turning, EPS controller does not send command to steering motor controller, and steering motor does not operate. Electronic power steering can easily provide different assist effects according to vehicle speed with steering motor, thus ensuring the steering convenience when vehicle is turning at low speed, and the stability and reliability when vehicle is turning at high speed.



Specifications

Torque Specification

Description	Torque (N·m)
Coupling Nut Between Steering Tie Rod and Steering Knuckle	45 ± 5
Coupling Bolt Between Steering Gear Input Shaft and Steering Column with Intermediate Shaft Assembly	15 ± 1
Steering Gear Fixing Bolt	180 ± 18


Tools

Special Tools

43	Ball Pin Separator	 RCH0000024
	Diagnostic Tester	 RCH0000001

General Tool

Digital Multimeter



RCH0000002

دیجیتال خودرو


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




43 - ELECTRONIC POWER STEERING

Circuit Diagram



43



ET15420010

EPS Controller Pin Definition


1. EPS terminal

Vehicle supply: controller supply connector (connector A)

Pin	Definition
A1	Power supply positive
A2	Power supply negative

Vehicle signal: controller signal connector (connector B)

Pin	Definition
B1	Ignition switch signal
B3	-
B5	-
B2	CAN1-H
B4	CAN1-L
B6	-
B7	-
B8	-
B9	-
B10	-



DIAGNOSIS & TESTING

Diagnostic Help

1. Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC), and make it communicate with vehicle electronic module by the data network.
2. Confirm that malfunction exists, and perform the diagnosis tests and service procedures.
3. If Diagnostic Trouble Codes (DTC) cannot be cleared, it indicates that there is a current malfunction.
4. Only digital multimeter can be used when measuring the voltage of electronic system.
5. Refer to any Technical Bulletin applied to the malfunction.
6. Visually check the related wire harness.
7. Check and clean Electronic Power Steering controller (EPS controller) ground related to the latest DTC.
8. If numerous trouble codes are set, refer to circuit diagram and look for any common ground circuit or power supply circuit applied to the DTC.

Intermittent DTC Troubleshooting

If it is an intermittent problem, perform the following procedures:

1. Check connector for looseness.
2. Check wire harness for wear, piercing, pinch or partial break.
3. Observe the diagnostic tester data related to this circuit.
4. Wiggle related wire harness and connector and observe if signal is interrupt in the related circuit.
5. Try to duplicate conditions under which the DTC is set.
6. Check for data that has changed or the DTC that has been reset during wiggle test.
7. Check if terminals are broken, bent, protruded out or corroded.
8. Check sensor and mounting area for any condition that would result in an incorrect signal, such as damage, foreign matter.
9. A data recorder and/or oscilloscope can be helpful in diagnosing the intermittent malfunction.

43

Ground Inspection

Groundings are often exposed to moisture, dirt or other corrosive areas. Corrosion (rust) may form additional resistance. This additional resistance will change the way in which a circuit works. A loose or corroded ground can drastically affect the electronically controlled circuit. Perform the following operations:

1. Remove ground bolt or nut.
2. Check all the contact surfaces for tarnish, dirt, rust, etc.
3. Clean as necessary to ensure that contacting is in a good condition.
4. Reinstall bolt or nut securely.
5. Check for accessories which may interfere with the ground circuit.
6. If several wires are crimped into one ground terminal, check for proper crimps. Make sure that all the wire harnesses are clean, securely fastened and good contacted without crimping any excessive insulation coat.

Diagnostic Trouble Code (DTC) Chart

Failure Type Byte (Hex)	Description
11	Circuit short to ground
13	Circuit open
12	Circuit short to battery
14	Circuit short to ground or open
15	Circuit short to battery or open
16	Circuit voltage below threshold
17	Circuit voltage above threshold
1A	Circuit resistance below threshold
1B	Circuit resistance above threshold
1F	Circuit intermittent
47	Watchdog/safety μ C failure
48	Supervision software failure
71	Actuator stuck
79	Mechanical linkage failure
86	Signal invalid
87	Missing message
91	Parametric
92	Performance or incorrect operation
95	Incorrect assembly
96	Component Internal failures

43

C1200-44	Data Flash Operation Error
C1201-44	Data Flash Verify Error
C1202-49	ECU Hardware Error
C1203-00	ECU Reset Error
C1204-48	ECU SW Monitoring Error
C1205-45	Flash Code Verify Error
C1206-07	High Friction
C1207-49	Index Sensor Error
C1208-49	Output Stage Error
C1209-49	Phase Current Error
C120A-49	Rotor Position Sensor Error
C120B-49	Rotor Position Sensor Slave Channel Error
C120C-07	Steering Oscillation
C120D-00	Steering Angle Implausible

43 - ELECTRONIC POWER STEERING

C120E-00	Steering Angle No Initialization
C120F-00	Steering Angle Sensor not Calibrated
C1210-49	Steering Angle Sensor Self Test Error
C1211-1C	Supply Voltage Abnormal during Initialization
C1212-1C	Supply Voltage Uncritical Too High Warning
C1213-1C	Supply Voltage Uncritical Too High
C1214-17	Supply Voltage Critical Too High
C1215-1C	Supply Voltage Uncritical Too Low Warning
C1216-1C	Supply Voltage Uncritical Too Low
C1217-16	Supply Voltage Critical Too Low
C1218-4B	Over Temperature Reduction
C1219-4B	Temperature Out of Range
C121A-49	Torque Sensor Error
C121B-46	XCP Flash Data Changed
U0100-87	Lost Communication With EMS
U0129-87	Lost Communication With BSM
U0140-87	Lost Communication With BCM
U0401-81	Invalid Data Received From EMS
U0418-81	Invalid Data Received From BSM
U0422-81	Invalid Data Received From BCM
C121C-00	Software Configuration Invalid
C122D-48	ECU SW Information Error

DTC	C1208-49	Output Stage Error
DTC	C1212-1C	Supply Voltage Uncritical Too High Warning
DTC	C1213-1C	Supply Voltage Uncritical Too High
DTC	C1214-17	Supply Voltage Critical Too High
DTC	C1215-1C	Supply Voltage Uncritical Too Low Warning
DTC	C1216-1C	Supply Voltage Uncritical Too Low
DTC	C1217-16	Supply Voltage Critical Too Low


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



43 - ELECTRONIC POWER STEERING



43



ET15420020

43 - ELECTRONIC POWER STEERING

DTC	DTC Definition	DTC Detection Condition	Possible Cause
C1208-49	Output Stage Error	Engine switch OFF Engine not running	• Circuit voltage below threshold • Circuit voltage above threshold • Internal fault in component
C1212-1C	Supply Voltage Uncritical Too High Warning		
C1213-1C	Supply Voltage Uncritical Too High		
C1214-17	Supply Voltage Critical Too High		
C1215-1C	Supply Voltage Uncritical Too Low Warning		
C1216-1C	Supply Voltage Uncritical Too Low		
C1217-16	Supply Voltage Critical Too Low		

 CAUTION

- When performing circuit diagnosis and test, always refer to circuit diagram for the specific circuit and the component information.

1 Check battery voltage

- Connect negative battery cable, and turn engine switch to ON to run the engine normally.
- Using voltage band of multimeter, check the battery voltage.

Specified Condition

Multimeter Connection	Condition	Specified Condition
Battery (+) - Battery (-)	Engine switch ON	12 V - 13.8 V

NG**Check battery charging system****OK****Go to next step****NEXT****2 Check fuse**

- Turn engine switch to OFF.

43 - ELECTRONIC POWER STEERING

b. Using voltage band of multimeter, check if fuses EF48 (80A), RF03 (10A) are good.

NG

Replace fuse

OK

Go to next step

NEXT

3

Check ground

a. Turn engine switch to OFF.

b. Disconnect negative battery cable and check ground point of EPS (See page 43-8).

NG

Repair or replace the ground point

OK

Go to next step

NEXT

4

Check wire harness connector

a. Turn engine switch to OFF.


b. Disconnect electronic power steering module connectors B-065, I-005, EPS power connector B-073, instrument panel fuse and relay box connector I-048.

c. Using ohm band of multimeter, check for continuity between B-065 (A1) and B-073 (R4), and continuity between I-005 (B1) and I-048 (11).

Check for Open

43

Multimeter Connection	Condition	Specified Condition
B-065 (A1) - B-073 (R4)	Engine switch OFF	Continuity
I-005 (B1) - I-048 (11)	Engine switch OFF	Continuity



43 - ELECTRONIC POWER STEERING

- d. Using ohm band of multimeter, check for continuity between B-065 (A1) and B-073 (R4), and continuity between I-005 (B1) and I-048 (11).


Check for Short

Multimeter Connection	Condition	Specified Condition
B-065 (A1) - Ground	Engine switch OFF	No continuity
I-005 (B1) - Ground	Engine switch OFF	No continuity

- e. Using ohm band of multimeter, check for continuity between B-065 (A1) and battery (+), and continuity between I-005 (B1) and battery (+).

Check for Short

Multimeter Connection	Condition	Specified Condition
B-065 (A1) - Battery (+)	Engine switch OFF	No continuity
I-005 (B1) - Battery (+)	Engine switch OFF	No continuity



NG**Repair or replace control circuit wire harness and connector****OK****Replace EPS module assembly**

43 - ELECTRONIC POWER STEERING


DTC	C1207-49	Index Sensor Error
DTC	C120A-49	Rotor Position Sensor Error
DTC	C120B-49	Rotor Position Sensor Slave Channel Error
DTC	C120D-00	Steering Angle Implausible
DTC	C120E-00	Steering Angle No Initialization
DTC	C120F-00	Steering Angle Sensor not Calibrated
DTC	C1210-49	Steering Angle Sensor Self Test Error
DTC	C1211-1C	Supply Voltage Abnormal during Initialization
DTC	C1200-44	Data Flash Operation Error
DTC	C1201-44	Data Flash Verify Error
DTC	C1202-49	ECU Hardware Error
DTC	C1203-00	ECU Reset Error
DTC	C1204-48	ECU SW Monitoring Error
DTC	C1205-45	Flash Code Verify Error
DTC	C1206-07	High Friction
DTC	C1218-4B	Over Temperature Reduction
DTC	C1219-4B	Temperature Out of Range
DTC	C121A-49	Torque Sensor Error
DTC	C121B-46	XCP Flash Data Changed
DTC	C1209-49	Phase Current Error
DTC	C121C-00	Software Configuration Invalid
DTC	C122D-48	ECU SW Information Error

43 - ELECTRONIC POWER STEERING

DTC	C120C-07	Steering Oscillation
-----	----------	----------------------



(I-003)
B



(I-005)
B

ET15420030

43 - ELECTRONIC POWER STEERING

DTC	DTC Definition	DTC Detection Condition	Possible Cause
C1207-49	Index Sensor Error	Engine switch OFF Engine not running	• Ground • Wire harness connector • CAN network system fault • Module failure
C120A-49	Rotor Position Sensor Error		
C120B-49	Rotor Position Sensor Slave Channel Error		
C120D-00	Steering Angle Implausible		
C120E-00	Steering Angle No Initialization		
C120F-00	Steering Angle Sensor not Calibrated		
C1210-49	Steering Angle Sensor Self Test Error		
C1211-1C	Supply Voltage Abnormal during Initialization		
C1200-44	Data Flash Operation Error		
C1201-44	Data Flash Verify Error		
C1202-49	ECU Hardware Error		
C1203-00	ECU Reset Error		
C1204-48	ECU SW Monitoring Error		
C1205-45	Flash Code Verify Error		
C1206-07	High Friction		
C1218-4B	Over Temperature Reduction		
C1219-4B	Temperature Out of Range		
C121A-49	Torque Sensor Error		
C121B-46	XCP Flash Data Changed		
C1209-49	Phase Current Error		
C121C-00	Software Configuration Invalid		
C122D-48	ECU SW Information Error		
C120C-07	Steering Oscillation		

CAUTION

- When performing circuit diagnosis and test, always refer to circuit diagram for the specific circuit and the component information.

1 Check battery voltage

- Connect negative battery cable, and turn engine switch to ON to run the engine normally.
- Using voltage band of multimeter, check the battery voltage.

Specified Condition

Multimeter Connection	Condition	Specified Condition
Battery (+) - Battery (-)	Engine switch ON	12 V - 13.8 V

NG

Check battery charging system

OK

Go to next step

NEXT

2 Check ground

- Turn engine switch to OFF.
- Disconnect negative battery cable and check ground point of EPS ([See page 43-8](#)).

NG

Repair or replace the ground point

OK

Go to next step

NEXT

3 Check wire harness connector


- Turn engine switch to OFF.
- Disconnect steering angle sensor connector I-003 and instrument panel fuse and relay box connector I-048.

43 - ELECTRONIC POWER STEERING

- c. Using ohm band of multimeter, check for continuity between I-003 (3) and I-048 (11).

Check for Open


Multimeter Connection	Condition	Specified Condition
I-003 (3) - I-048 (11)	Engine switch OFF	Continuity



- d. Using ohm band of multimeter, check for continuity between I-003 (3) and ground.

Check for Short

Multimeter Connection	Condition	Specified Condition
I-003 (3) - Ground	Engine switch OFF	No continuity



- e. Using ohm band of multimeter, check for continuity between I-003 (3) and battery (+).

Check for Short

Multimeter Connection	Condition	Specified Condition
I-003 (3) - Battery (+)	Engine switch OFF	No continuity

43

NG

Repair or replace control circuit wire harness and connector

OK

Go to next step

NEXT

43 - ELECTRONIC POWER STEERING

4

Check CAN network

- Disconnect negative battery cable, and turn engine switch to OFF.
- Disconnect steering angle sensor connector I-003 and electronic power steering module connector I-005.
- Using a multimeter, check for continuity between I-003 (1) and I-005 (B4), and continuity between I-003 (2) and I-005 (B2).

Specified Condition


Multimeter Connection	Condition	Specified Condition
I-003 (1) - I-005 (B4)	Engine switch OFF	Continuity
I-003 (2) - I-005 (B2)	Engine switch OFF	Continuity

NG

Replace CAN network wire harness

OK

Go to next step



RT15420160

NEXT

5

Check module assembly

- Disconnect steering angle sensor connector I-003 and electronic power steering module connector I-005.
- Using ohm band of multimeter, check for continuity between I-003 (1) and I-003 (2), and continuity between I-005 (B4) and I-005 (B2).

Specified Condition


Multimeter Connection	Condition	Specified Condition
I-003 (1) - I-003 (2)	Engine switch OFF	120 Ω
I-003 (2) - I-005 (B2)	Engine switch OFF	120 Ω

NG

Replace steering angle sensor assembly or electronic power steering module

OK

End



RT15420170

43


ON-VEHICLE SERVICE

Ball Pin Assembly


Removal

HINT:

- Use same procedures for right and left sides.
 - Procedures listed below are for left side.
1. Set steering wheel to straight-ahead position.
 2. Turn off all electrical equipment and the ignition switch.
 3. Disconnect the negative battery cable.
 4. Remove the front left wheel ([See page 37-7](#)).
 5. Remove the ball pin assembly.
 - a. Remove locking nut (arrow) between left steering tie rod ball pin assembly and front left steering knuckle assembly.
(Tightening torque: $45 \pm 5 \text{ N}\cdot\text{m}$)



- b. Install ball pin separator (1), and separate steering tie rod ball pin from steering knuckle assembly.



- c. Remove the ball pin assembly.

Inspection

1. Check tie rod ball pin for looseness. Replace ball pin assembly if necessary.
2. Check tie rod ball pin bush rubber for damage. Replace ball pin assembly if necessary.

Installation

Installation is in the reverse order of removal.

CAUTION

- After installing tie rod ball pin assembly, it is necessary to perform wheel alignment procedure ([See page 36-47](#)).


Steering Gear Assembly

Removal


1. Set front wheels to straight-ahead position.
2. Turn off all electrical equipment and the ignition switch.
3. Disconnect the negative battery cable.
4. Remove the front left and right wheels (See page 37-7).
5. Remove the tie rod ball pin.

- a. Remove locking nut (arrow) between left steering tie rod assembly ball pin and front left steering knuckle assembly.

(Tightening torque: 45 ± 5 N·m)




- b. Install ball pin separator (1), and separate steering tie rod ball pin from steering knuckle assembly.




6. Remove coupling bolt between steering column with intermediate shaft assembly and steering gear input shaft.

- a. Turn over carpet below driver seat in direction of arrow.




- b. Using a screwdriver wrapped with protective tape, remove steering column lower universal joint boot from two studs.



43 - ELECTRONIC POWER STEERING


- c. Remove coupling bolt (arrow) between steering column with intermediate shaft assembly and steering gear input shaft.

(Tightening torque: 15 ± 1 N·m)



7. Remove 2 fixing bolts from left and right brackets on steering gear.

(Tightening torque: 180 ± 18 N·m)



8. Remove the steering gear assembly.

Inspection

1. Check steering gear boot for damage and clamp for looseness. Replace them if necessary. Or water and dust may enter easily, causing parts failure prematurely.
2. Check steering gear for damage. Replace steering gear assembly if necessary.

Installation

Installation is in the reverse order of removal.

HINT:

43


- It is necessary to assemble coupling bolt between steering column lower universal joint and steering gear input shaft reliably when installing.

CAUTION

- After installing steering gear assembly, perform front wheel alignment procedure (See page 36-47).

Steering Gear Clearance Adjustment

1. Set wheels to straight-ahead position.
2. Turn steering wheel to right and left sides.
3. If a sound is heard from steering gear, adjust the adjustment bolt (arrow) until no hitting noise is heard when turning steering wheel.



4. Retighten adjustment bolt by 1/8 turn (about 45°).
5. Perform the road test.
6. If steering mechanism cannot return to center position, loosen adjustment bolt for 15°.
7. Perform the road test.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



- MEMO -

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

