### 06

# SQRD4G15B ENGINE MANAGEMENT SYSTEM

GENERAL INFORMATION	06-3	P0121-14	06-74
Description	06-3	P0221-12	06-74
System Function	06-4	P0221-14	06-74
Precautions	06-5	P0130-23	06-81
Specifications	06-6	P0130-24	06-81
Tools	06-6	P0133-62	06-81
ECM Terminal Definition	06-8	P0136-23	06-87
Circuit Diagram	06-10	P0136-24	06-87
-	00.40	P0139-62	06-87
DIAGNOSIS & TESTING	06-19	P1654-62	06-93
Diagnostic Help	06-19	P1655-94	06-93
Intermittent DTC Troubleshooting	06-19	P1656-94	06-93
Ground Inspection	06-19	P1657-77	06-93
Throttle Self-learning	06-20	P1658-77	06-93
Flywheel Self-learning	06-20	P1659-92	06-93
Operations for Replacing New ECM	06-20	P1660-77	06-93
Diagnostic Trouble Code (DTC) Chart	06-21	P0120-12	06-99
ECM Power Supply Circuit & Ground		P0120-14	06-99
Circuit Testing	06-26	P0220-12	06-99
P0135-12	06-34	P0220-14	06-99
تودر و سامانه (مسئه <b>۱</b> - <b>P0135</b> م	06-34	P0351-12	06-105
P0132-12	06-34	P0351-14	06-105
P0053-1E	06-34	P0335-62	06-111
يتال تعميركاران حر12-90138 ا	06-41	P0325-12	06-116
P0141-12	06-41	P1652-12	06-116
P0141-14	06-41	P1652-11	06-116
P0054-1E	06-41	P1652-49	www.digitalkho6-116
P0201-11	06-48	P1652-64	06-116
P0201-12	06-48	P0340-11	06-121
P0201-13	06-48	P0340-11	06-121 06-121
P0105-12	06-54	P0340-15 P0340-62	
P0105-14	06-54		06-121
P0106-26	06-54	P0016-76	06-121
P0106-27	06-54	P0420-62	06-128
P0101-62	06-54	P0443-11	06-130
P1663-62	06-54	P0443-12	06-130
P0110-11	06-61	P0443-13	06-130
P0110-15	06-61	P0481-13	06-136
P0110-3A	06-61	P0480-13	06-136
P0111-62	06-61	P0480-11	06-136
P0115-11	06-67	P0480-12	06-136
P0115-15	06-67	P0481-11	06-136
P0115-3A	06-67	P0481-12	06-136
P0116-62	06-67	P0560-16	06-144
P0121-12	06-74	P0560-17	06-144
		P0645-13	06-150

06

P0645-11	06-150	Installation	06-235
P0645-12	06-150	Oxygen Sensor	06-236
P0504-13	06-156	Description	06-236
P0504-62	06-156	Operation	06-236
P0504-67	06-156	Upstream Oxygen Sensor	06-236
P0504-86	06-156	Downstream Oxygen Sensor	06-236
P0604-62	06-163	Removal & Installation -	
P0605-41	06-163	Upstream Oxygen Sensor	06-236
P0605-49	06-163	Removal & Installation -	
P1610-51	06-165	Downstream Oxygen Sensor	06-236
P1616-81	06-165	Camshaft Position Sensor	06-237
P1617-87	06-165	Description	06-237
P1618-87	06-165	Operation	06-237
P1614-86	06-165	Removal	06-237
U0129-87	06-170	Installation	06-237
U0101-87	06-173	Engine Speed Sensor	06-238
P0403-11	06-176	Description	06-238
P0403-12	06-176	Operation	06-238
P0403-13	06-176	Removal	06-238
P0403-61	06-176	Installation	06-238
P0409-12	06-183	Intake Pressure/Temperature Sensor	06-239
P0409-14	06-183	Description	06-239
P1600-11	06-189	Operation	06-239
P1600-12	06-189	Removal	06-239
P1600-13	06-189	Installation	06-239
ودرو سامانه (مسئة 90010-11	06-195	Ignition Coil	06-240
P0010-12	06-195	Description	06-240
P0010-13	06-195	Operation Operation	06-240
P0010-14	06-195	Removal & Installation	06-240
P0704-23	06-201	Electronic Accelerator Pedal Sensor	06-241
P0704-24	06-201	Description	06-241
Engine Problem Symptom Diagnosis	06-206	Operation WWW.Clerk	06-241
Diagnostic Help	06-206	Removal & Installation	06-241
Problem Symptoms Table	06-206	Electric Fuel Pump	06-242
		Description	06-242
ON-VEHICLE SERVICE	06-233	Operation	06-242
VVT Control Valve	06-233	Removal & Installation	06-242
Description	06-233	Fuel Injector	06-243
Operation	06-233	Description	06-243
Removal	06-233	Operation	06-243
Installation	06-233	Removal & Installation	06-243
Coolant Temperature Sensor	06-234	Canister Solenoid Valve	06-244
Description	06-234	Description	06-244
Operation	06-234	Operation	06-244
Removal	06-234	Removal & Installation	06-244
Installation	06-234	Engine Control Module (ECM)	06-245
Knock Sensor	06-235	Description	06-245
Description	06-235	Operation	06-245
Operation			
Removal	06-235 06-235	Removal	06-245



### **GENERAL INFORMATION**


### **Description**

Engine of A13T model adopts Marelli engine management system. This system mainly consists of Engine Control Module (ECM), sensors and actuators, which controls intake air amount, injection volume and ignition timing, etc. when engine is operating.

In the engine management system, sensors are used as the input part to measure various physical signals (temperature and pressure, etc.), and converts them into corresponding electrical signals; the function of ECM is to receive the input signals from sensors and perform calculation according to set procedure, producing corresponding control signals and outputting them to power drive circuit. The power drive circuit drives each actuator to perform various actions, thus making the engine run according to the preset program.

Also, the trouble diagnosis system of ECM monitors each component and control function in this system. Once detecting and confirming a fault, it will store the trouble code and recall "Limp Home" function. When detecting that fault has been eliminated, it will return to use normal value.

### **Basic Components of Engine Management System**



06

1 - Engine Control Unit	2 - Speed Sensor
3 - Intake Pressure/Temperature Sensor	4 - Electronic Throttle Body
5 - Injector	6 - Ignition Coil
7 - Coolant Temperature Sensor	8 - Camshaft Position Sensor
9 - Throttle Position Sensor	10 - Electronic Accelerator Pedal
11 - Oil Rail	12 - Knock Sensor
13 - Canister Solenoid Valve	14 - Canister
15 - Fuel Tank Cap	16 - Fuel Tank
17 - Fuel Seal Cover	18 - Fuel Pump
19 - Upstream Oxygen Sensor	20 - Precatalytic Converter
21 - Downstream Oxygen Sensor	22 - Air Filter
23 - EGR Valve	24 - OBD Diagnostic Interface
25 - Brake Switch	26 - A/C Compressor Relay
27 - A/C Compressor	28 - Battery
29 - Instrument Cluster Fuel Level Indictor	30 - Warning Light
31 - Engine Tachometer	32 - Fuse
33 - VVT Driver	34 - Ignition Switch

### System Function

06

شرکت دیدیتال خودر و سامانه Calculate air flow 🔍

ECM calculates air flow entering the cylinder by signals from intake pressure/temperature sensor, and then adjusts injection volume to make air-fuel ratio meet the requirements of various operating conditions.

Measure crankshaft position and engine speed

00

ECM determines the crankshaft position and engine speed according to signals from crankshaft position sensor, and accurately controls the engine ignition and injection timing.

• Determine operating sequence of cylinders

ECM recognizes the top dead center of No.1 cylinder by camshaft position sensor, so as to determine the operating sequence of cylinders.

Fuel control

There are two modes of fuel control: closed-loop fuel control and open-loop fuel control. Closed-loop fuel control can accurately regulate the air-fuel ratio of engine, thus effectively controlling emissions. Open-loop fuel control is applied when engine is starting or warming up and when oxygen sensor is malfunctioning.

Ignition control

Ignition control system of this engine adopts group control.

Knock control

When a knocking is detected by knock sensor, system will calculate the ignition advance angle that needs to be delayed or advanced according to current operating conditions and knock intensity and adjust the ignition angle, thus avoiding or reducing knocking.

Emission control

Three-way catalytic converter can convert engine exhaust gas into harmless gas and discharge it into atmosphere. When engine temperature becomes normal after warming up, ECM will activate closed-loop fuel control to correct the air-fuel ratio, thus realizing the optimum conversion efficiency of three-way catalytic converter.



- Three-way catalytic converter protection
  - Engine management system has the function to protect three-way catalytic converter. ECM estimates the three-way catalytic converter temperature according to engine operating conditions. When it is estimated that exhaust temperature will exceed the converter's maximum permissible temperature for a long time, ECM will automatically activate the protection function of three-way catalytic converter to keep the temperature normal.
- · System voltage protection

When system voltage becomes extremely high due to charging system malfunction, engine management system will activate the protection program to limit engine speed, thus avoiding damage to ECM and battery.

### **Precautions**

### General service requirements

- Only digital multimeter can be used to perform inspection for engine management system.
- Use genuine components to perform service work, otherwise appropriate engine management system operation cannot be guaranteed.
- Only use unleaded gasoline during servicing.
- Please observe normative service and diagnostic flowchart to perform service work.
- Never disassemble components of engine management system during servicing.
- When holding electronic elements (ECM and sensor etc.) during servicing, take extra care not to drop them on the ground.
- Set up a consciousness of environmental protection and dispose of the waste effectively that is produced during servicing.

### Precautions during servicing

- Do not causally remove any engine management system component or its connector from its installation
  position to prevent damaging accidentally, or foreign matter, such as moisture, oil from entering
  connectors, which will affect the normal operation of engine management system.
  - 2. Be sure to turn ignition switch off when disconnecting and connecting connectors. Otherwise electronic elements may be damaged.
  - 3. When simulating hot operating condition of malfunction and performing other service work that may cause temperature to rise, never allow ECM temperature to exceed 80°C.
  - 4. As the supplying pressure of fuel system is high (approximately 400 kPa), all fuel pipes are high pressure resistant pipe. Fuel pressure in fuel lines is still high even when engine is not running. Therefore, be careful not to casually remove fuel pipes during servicing; when it is necessary to service fuel system, discharge pressure in the fuel system before removing fuel pipes. The way to discharge pressure is as follows:
    - Remove fuel pump relay, start engine and idle it until the engine stops running by itself. Then try to start engine 2 3 times to ensure fuel pressure is discharged completely. Removal of fuel pipes and replacement of fuel filter should be performed in a well-ventilated area by professional service men.
  - 5. Do not energize electric fuel pump when removing it from fuel tank to prevent electric sparks, which will cause a fire.
  - 6. Running test for fuel pump is prohibited when it is empty or in water; otherwise it will shorten the service life. Never connect the positive and negative of fuel pump in reverse.
  - 7. When checking ignition system, only perform spark jump test when it is necessary and duration should be shortened as much as possible. Do not open throttle during test; otherwise a large amount of unburned gasoline will enter the exhaust pipe, causing damage to the three-way catalytic converter.
  - 8. Do not connect battery with its polarity reversed to prevent damage to electronic elements. This system adopts negative ground.
  - 9. Never remove battery cable when engine is running.
  - 10. The positive, negative battery cables and ECM must be removed before performing welding on vehicle.



06

11. Do not puncture wire outer coat to detect electric signals input and output by components.

### **Specifications**

### **Torque Specifications**

Description	Torque (N·m)
Coolant Temperature Sensor	14 ± 1
Intake Pressure/Temperature Sensor Fixing Bolt	6 ± 1
Knock Sensor Fixing Bolt	20 ± 5
Engine Speed Sensor Fixing Bolt	8 ± 2
Camshaft Position Sensor Fixing Bolt	8 ± 1
VVT Control Valve Fixing Bolt	8 ± 2
ECM Fixing Bolt	7 ± 1

### **Tools**

06

### **Special Tool**



### **General Tools**

62 99 92 92	www.digitalkhodro.co
X-431 3G Fuel Injector Cleaning Analyzer	RCH0000062
Ignition Timing Light	RCH0000016

	Digital Multimeter	RCH0000002	
	Cylinder Pressure Gauge	RCH0000044	06
<b>وا</b> حدود)	Fuel Pressure Gauge	RCH0000048	
يران 021 6	انه دیجیتال تعمیرکاران خودرو در Oscilloscope 2 99 92 92	RCH0000061	.com

### **ECM Terminal Definition**

### **ECM Connector A**

Terminal No.	Definition	Terminal No.	Definition
A1	Electronic Accelerator Pedal 2 Sensor	A29	Cruise Switch Ground
A2	-	A30	Electronic Accelerator Pedal 2 Power
A3	Cruise Switch Signal	A31	-
A4	A/C Middle Pressure Switch	A32	-
A5	Brake Switch 2	A33	-
A6	A/C Switch	A34	Thermostat
A7	Starter Relay Control	A35	-
A8	-	A36	-
A9	-	A37	-
A10	-	A38	Sensor Ground
A11	CAN1-H	A39	Sensor Ground
A12		A40	Electronic Accelerator Pedal 1 Ground
A13	Electronic Accelerator Pedal 1 Sensor	A41	
A14		A42	Main Relay Coil
A15		A43	Low-speed Fan
A16	Clutch Pedal Switch	A44	A/C Compressor Relay
A17	Brake Switch 1	A45	Fuel Pump Relay
A18	92	A46	High-speed Fan
A19	-	A47	-
A20	-	A48	-
A21	Ground	A49	Upstream Oxygen Sensor Heating
A22	Ignition Switch (ON)	A50	Downstream Oxygen Sensor Heating
A23	CAN1-L	A51	-
A24	-	A52	Ground 1
A25	Ignition Switch (Start)	A53	Ground 2
A26	Upstream Oxygen Sensor	A54	Battery Power Supply
A27	Downstream Oxygen Sensor	A55	Noncontinuous Power Supply
A28	Electronic Accelerator Pedal 2 Ground	A56	Noncontinuous Power Supply

06




### 06

### **ECM Connector B**


Terminal No.	Definition	Terminal No.	Definition
B1	-	B29	EGR Sensor Power
B2	-	B30	Throttle Position Sensor (+)
В3	Power Steering Pump	B31	Throttle Position Sensor (-)
B4	Coolant Temperature Sensor Ground	B32	EGR Sensor Ground
B5	Knock Sensor (+)	B33	Sensor Ground
B6	Throttle Position Sensor 2	B34	-
B7	Intake Temperature Sensor Signal	B35	Injector 3
B8	EGR Sensor Signal	B36	Injector 1
B9	-	B37	-
B10	-	B38	Variable Camshaft Timing
B11	-	B39	Ignition Coil Drive
B12	Engine Speed Sensor	B40	Engine Speed Sensor (+)
B13	Camshaft Position Sensor	B41	Camshaft Position Sensor (+)
B14	-	B42	
B15	A/C High/Low Pressure Switch	B43	
B16	Camshaft Position Sensor (-)	B44	-
B179	Knock Sensor (-)	B45	-
B18	Throttle Position Sensor 1	B46	
B19	Intake Pressure Sensor Signal	B47	Injector 4
B20	-	B48	Injector 2
B21	Coolant Temperature Sensor Signal	B49	
B22	32	B50	Alternator
B23	-	B51	Throttle Actuator (-)
B24	Engine Speed Sensor (-)	B52	Throttle Actuator (+)
B25	-	B53	Ignition Coil 4
B26	EGR Valve Control	B54	Ignition Coil 3
B27	-	B55	Ignition Coil 2
B28	Intake Pressure Sensor Power	B56	Ignition Coil 1

### **Circuit Diagram**


### **Engine Management System (Page 1 of 9)**




### **Engine Management System (Page 2 of 9)**




### **Engine Management System (Page 3 of 9)**



### **Engine Management System (Page 4 of 10)**




### **Engine Management System (Page 5 of 9)**






### **Engine Management System (Page 6 of 9)**




06–15

### **Engine Management System (Page 7 of 9)**



### **Engine Management System (Page 8 of 9)**






06-17

EA13T060080

### **Engine Management System (Page 9 of 9)**





EA13T060090

(E-001)

### **DIAGNOSIS & TESTING**

### **Diagnostic Help**

- 1. Connect X-431 3G Diagnostic tester (the latest software) to Data Link Connector (DLC), and make it communicate with vehicle electronic module through data network.
- 2. Confirm that malfunction is current, and carry out diagnostic test and repair procedures.
- 3. If DTC cannot be deleted, the malfunction is current.
- 4. Only use a digital multimeter to measure voltage of electronic system.
- 5. Refer to any Technical Bulletin that may apply to the malfunction.
- 6. Visually check the related wire harness.
- 7. Check and clean all Engine Control Module (ECM) ground points related to current DTC.
- 8. If multiple trouble codes were set, refer to circuit diagrams to look for any common ground circuit or power supply circuit applied to DTC.

06

### **Intermittent DTC Troubleshooting**

If malfunction is intermittent, perform the following:

- · Check if connectors are loose.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Monitor X-431 3G diagnostic tester (the latest software) data that is related to this circuit.
- Wiggle related wire harnesses and connectors and observe if related circuit signal is interrupted.
- If possible, try to duplicate the conditions under which DTC was set.
- Look for data that has changed or DTC to reset during wiggle test.
- Look for broken, bent, protruded or corroded terminals.
- Inspect sensors and mounting areas for damage, foreign matter, etc. that will cause incorrect signals.
- Use data recorder and/or oscilloscope to help diagnose intermittent malfunctions.
- Remove the Engine Control Module (ECM) from malfunctioning vehicle and install it to a new vehicle to perform a test. If DTC cannot be cleared, ECM is malfunctioning. If DTC can be cleared, reinstall ECM to original vehicle.

### **Ground Inspection**

Ground points are very important to the proper operation of circuits. Ground points are often exposed to moisture, dirt or other corrosive areas. Corrosion (rust) can increase resistance which will change the way in which a circuit works.

Electrical control circuits are very sensitive to proper grounding. A loose or corroded ground point can seriously affect control circuit. Check ground points as follows:

- 1. Remove ground bolt or nut.
- 2. Check all contact surfaces for tarnish, dirt and rust, etc.
- 3. Clean as necessary to ensure that contacting is in good condition.
- Reinstall ground bolt or nut securely.
- 5. Check if add-on accessories interfere with ground circuit.
- 6. If several wire harnesses are crimped into one ground terminal, check if they are installed correctly. Make sure that all wires are clean, securely fastened and good contacted without crimping any excessive insulation coat.

### Throttle Self-learning

Perform throttle self-learning in the following conditions:

- Battery is removed and negative battery cable is disconnected.
- ECM is replaced.
- ECM is disconnected and reconnected.
- Throttle is replaced or cleaned.

Throttle self-learning conditions:

- 100.5°C > coolant temperature > 80°C
- Engine speed not more than 250 rpm
- Vehicle speed = 0 km/h
- Battery voltage 9 V ~ 15.2 V

Throttle self-learning procedures:

Start engine for 3 times to finish self-learning. Then start vehicle and observe if it operates normally.

### Flywheel Self-learning

Perform throttle self-learning in the following conditions:

- Battery is removed and negative battery cable is disconnected.
- ECM is replaced.

06

ECM is disconnected and reconnected.

Flywheel self-learning conditions:

- 100.5°C > coolant temperature > 80°C
- Vehicle speed = 0 km/h
- Battery voltage 9 V ~ 15.2 V

شرکت دیجیتال خودرو ب Flywheel self-learning procedure:

Depress accelerator pedal continuously and rapidly to 4500 rpm for 3 times.

### Operations for Replacing New ECM

- 1. Engine immobilizer match (if equipped).
- 2. Clutch switch position learning for MT model (unlearning starter not opearte). Method: Fully depress clutch pedal, then release it, which can allow ECM receive a complete clutch switch
  - 3. Brake switch position learning for AT model (unlearning starter not opearte). Method: Fully depress brake pedal, then release it, which can allow ECU receive a complete brake switch signal.
  - 4. Throttle self-learning.
  - 5. Flywheel self-learning.



## 06

### **Diagnostic Trouble Code (DTC) Chart**

P0009-62	VVT Parking Position Signal Compare Failure
P0010-11	VVT Driver Circuit Short to Ground
P0010-12	VVT Driver Circuit Short to Battery
P0010-13	VVT Driver Circuit Open
P0010-14	VVT Driver Circuit Short to Ground or Open
P0011-61	VVT Error Position Signal Calculation Failure
P0012-65	EVELVVT - Variator Speed Diagnosis Signal Has Too Few Transitions/Events
P0012-66	EVELVVT - Variator Speed Diagnosis Signal Has Too Many Transitions/Events
P0016-76	Crankshaft Position - Camshaft Position Correlation Bank 1 Sensor A
P0053-1E	Upstream Lambda Sonde Resistor (Functional Test) Circuit Resistance Out of Range
P0054-1E	Downstream Lambda Sonde Resistor (Functional Test) Circuit Resistance Out of Range
P0101-62	Air Intake Manifold Signal Compare Failure
P0105-12	Intake Manifold Pressure Sensor (Electric) Circuit Short to Battery
P0105-14	Intake Manifold Pressure Sensor (Electric) Circuit Short to Ground or Open
P0106-26	Air Pressure Sensor (Functional) Signal Rate of Change Below Threshold
P0106-27	Air Pressure Sensor (Functional) Signal Rate of Change Above Threshold
P0110-110)	Air Temperature Sensor Circuit Short to Ground
P0110-15	Air Temperature Sensor Circuit Short to Battery or Open
P0110-3A	Air Temperature Sensor Signal Has Too Many Pulses
P0111-62	Air Temperature Sensor (Functional) Signal Compare Failure
P0115-11	Water temperature sensor Circuit Short to Ground
P0115-15	Water Temperature Sensor Circuit Short to Battery or Open
P0115-3A	Water Temperature Sensor Signal Has Too Many Pulses
P0116-62	Water Temperature Sensor (Functional) Signal Compare Failure
P0120-12	Pedal Ootentiometer 1 Circuit Short to Battery
P0120-14	Pedal Potentiometer 1 Circuit Short to Ground or Open
P0121-12	Throttle Potentiometer 1 Circuit Short to Battery
P0121-14	Throttle Potentiometer 1 Circuit Short to Ground or Open
P0130-24	Functional Test Lambda Sensor 1 Signal Stuck High
P0132-12	Electric Test Lambda Sensor 1 Circuit Short to Battery
P0133-62	First Probe Diagnosis Signal Compare Failure
P0135-12	Lambda Sensor1 Heater Driver Circuit Short to Battery
P0135-14	Lambda Sensor1 Heater Driver Circuit Short to Ground or Open
P0136-23	Functional Test Lambda Sensor 2 Signal Stuck Low
P0136-24	Functional Test Lambda Sensor 2 Signal Stuck High

#### 06 - SQRD4G15B ENGINE MANAGEMENT SYSTEM

P0139-62	DO2V Signal Compare Failure
P0141-12	Lambda Sensor2 Heater Driver Circuit Short to Battery
P0141-14	Lambda Sensor2 Heater Driver Circuit Short to Ground or Open
P0170-25	Frequency Diagnosis Signal Shape/Waveform Failure
P0171-62	DFSL - Lean Diagnosis Signal Compare Failure
P0171-64	DFSL - Lean Diagnosis Signal Plausibility Failure
P0171-67	DFSL - Lean Diagnosis Signal Incorrect After Event
P0172-62	Rich Diagnosis Signal Compare Failure
P0172-64	Rich Diagnosis Signal Plausibility Failure
P0172-67	Rich Diagnosis Signal Incorrect After Event
P0201-11	Injector 1 Driver Circuit Short to Ground
P0201-12	Injector 1 Driver Circuit Short to Battery
P0201-13	Injector 1 Driver Circuit Open
P0202-11	Injector 2 Driver Circuit Short to Ground
P0202-12	Injector 2 Driver Circuit Short to Battery
P0202-13	Injector 2 Driver Circuit Open
P0203-11	Injector 3 Driver Circuit Short to Ground
P0203-12	Injector 3 Driver Circuit Short to Battery
P0203-13	Injector 3 Driver Circuit Open
P0204-11	Injector 4 Driver Circuit Short to Ground
P0204-12	Injector 4 Driver Circuit Short to Battery
P0204-13	Injector 4 Driver Circuit Open
P0219-68	OSP-Engine Over Speed Event Information
P0220-12	Pedal Ootentiometer 2 Circuit Short to Battery
P0220-14	Pedal Potentiometer 2 Circuit Short to Ground or Open
P0230-11	Relay High Side Circuit Short to Ground
P0230-15	Relay High Side Circuit Short to Battery or Open
P0230-12	Relay High Side Circuit Short to Battery
P0230-13	Relay High Side Circuit Open
P023D-26	AIRC-Aircomponent Signal Rate of Change Below Threshold
P023D-27	AIRC-Aircomponent Signal Rate of Change Above Threshold
P0300-92	DM10 - 1000 Turn Misfire Diagnosis Performance or Incorrect Operation
P0300-98	DM20 - 200 Turn Misfire Diagnosis Component or System Over Temperature
P0301-92	DM11 - 1000 Turn Misfire Diagnosis Performance or Incorrect Operation
P0301-98	DM21 - 200 Turn Misfire Diagnosis Component or System Over Temperature
P0302-92	DM12 - 1000 Turn Misfire Diagnosis Performance or Incorrect Operation
	DMOO COO Turn Minfre Discussio Common at an Custom Curry Towns and the
P0302-98	DM22 - 200 Turn Misfire Diagnosis Component or System Over Temperature

06



P0303-98	DM23 - 200 Turn Misfire Diagnosis Component or System Over Temperature
P0304-92	DM14 - 1000 Turn Misfire Diagnosis Performance or Incorrect Operation
P0304-98	DM24 - 200 Turn Misfire Diagnosis Component or System Over Temperature
P0325-12	Knock Sensor (Engine-Run) Circuit Short to Battery
P0335-62	Engine Speed Sensor Signal Compare Failure
P0340-11	Cam-shaft Sensor Circuit Short to Ground
P0340-15	Cam-shaft Sensor Circuit Short to Battery or Open
P0340-62	Cam-shaft Sensor Signal Compare Failure
P0351-12	Ignition 1 Driver Circuit Short to Battery
P0351-14	Ignition 1 Driver Circuit Short to Ground or Open
P0352-12	Ignition 2 Driver Circuit Short to Battery
P0352-14	Ignition 2 Driver Circuit Short to Ground or Open
P0353-12	Ignition 3 Driver Circuit Short to Battery
P0353-14	Ignition 3 Driver Circuit Short to Ground or Open
P0354-12	Ignition 4 Driver Circuit Short to Battery
P0354-14	Ignition 4 Driver Circuit Short to Ground or Open
P0403-11	EGR Control Circuit Short to Ground
P0403-12	EGR Control Circuit Short to Battery
P0403-13	EGR Control Circuit Open
P0403-61	EGR Control Circuit Signal Calculation Failure
P0409-12	EGR Sensor Circuit Short to Battery
P0409-14	EGR Sensor Circuit Short to Ground or Open
P0420-62	Catalizer Diagnosis Signal Compare Failure
P0441-72	DNPG Actuator Stuck Open
P0443-11	Canister Purge Driver Circuit Short to Ground
P0443-12	Canister Purge Driver Circuit Short to Battery
P0443-13	Canister Purge Driver Circuit Open
P0480-11	Cooling Fan Driver 1 (Low) Circuit Short to Ground
P0480-12	Cooling Fan Driver 1 (Low) Circuit Short to Battery
P0480-13	Cooling Fan Driver 1 (Low) Circuit Open
P0481-11	Cooling Fan Driver 2 (High) Circuit Short to Ground
P0481-12	Cooling Fan Driver 2 (High) Circuit Short to Battery
P0481-13	Cooling Fan Driver 2 (High) Circuit Open
P0500-64	VEV-Vehicle Speed Sensor Signal Plausibility Failure
P0500-68	VEV-Vehicle Speed Sensor Event Information
P0504-13	Brake Signal Circuit Open
P0504-62	Brake Signal Compare Failure
P0504-67	Brake Signal Incorrect After Event

#### 06 - SQRD4G15B ENGINE MANAGEMENT SYSTEM

	P0504-86	Brake Signal Invalid	
	P0560-16	ECU Power Supply Circuit Voltage Below Threshold	
	P0560-17	ECU Power Supply Circuit Voltage Above Threshold	
	P0576-62	CCANOM-Cruise Control Disabled for High Deceleration Signal Compare Failure	
	P0579-62	CRCAN-Cruise Control Disabled for High Acceleration Signal Compare Failure	
	P0601-44	EEPROM Memory Data Memory Failure	
	P0604-62	RAM Memory Signal Compare Failure	
	P0605-41	ROM (EPROM) Memory General Checksum Failure	
	P0605-49	ROM (EPROM) Memory Internal Electronic Failure	
	P0606-47	E.C.U. (Microprocessor) Watchdog/Safety uC Failure	
	P0606-92	E.C.U. (Microprocessor) Performance or Incorrect Operation	
	P060B-49	A/D Converter Internal Electronic Failure	
	P060C-62	SAFSE-Stop Engine for Safety Signal Compare Failure	
r	P0615-11	Starter Relay Circuit Short to Ground	
	P0615-15	Starter Relay Circuit Short to Battery or Open	
	P0638-11	DC Motor Command Circuit Short to Ground	
F	P0638-12	DC Motor Command Circuit Short to Battery	
ı	P0638-13	DC Motor Command Circuit Open	
	P0638-61	DC Motor Command Signal Calculation Failure	
2.0	P0641-49	SSPLY - Sensor Supply 1 Internal Electronic Failure	
Ī	P0645-11	Air Conditioner 1 (Relay I/O) Circuit Short to Ground	
	P0645-12	Air Conditioner 1 (Relay I/O) Circuit Short to Battery	
	P0645-13	Air Conditioner 1 (Relay I/O) Circuit Open	
	P0651-49	SSPLY - Sensor Supply 2 Internal Electronic Failure	
) 2	P0657-16	Main Relay Circuit Voltage Below Threshold	.com
	P0657-17	Main Relay Circuit Voltage Above Threshold	
	P0685-11	Fuel Pump Relay Driver Circuit Short to Ground	
	P0685-12	Fuel Pump Relay Driver Circuit Short to Battery	
	P0685-13	Fuel Pump Relay Driver Circuit Open	
	P0697-49	Sensor Supply 3 Internal Electronic Failure	
	P0700-62	Engine Stop Request by Selespeed Signal Compare Failure	
	P0704-23	Clutch Switch Signal Stuck Low	
r	P0704-24	Clutch Switch Signal Stuck High	
r	P1300-55	Flywheel Self Learning Not Configured	
	P1430-11	A/C Defrost Temperature Diagnosis Circuit Short to Ground	
	P1430-15	A/C Defrost Temperature Diagnosis Circuit Short to Battery or Open	
	P1430-3A	A/C Defrost Temperature Diagnosis Signal Has Too Many Pulses	
	P1600-11	Thermostat Circuit Short to Ground	
ш			


06



P1600-12	Thermostat Circuit Short to Battery	
P1600-13	Thermostat Circuit Open	
P1601-23	CC_BUTTON Cruise Control Button Signal Stuck Low	
P1610-51	Immo Secret Key and Security Code Not Programmed Not Programmed	
P1614-86	Immo Transferred Transponder Authentication is Failed Signal Invalid	
P1616-81	IMMO Authentication Fail Invalid Serial Data Received	
P1617-87	IMMO Authentication Message not Received Missing Message	
P1618-87	Fail to Write EOL Immobilizer Data into EEProm Missing Message	
P1619-51	ECM Not Programmed (Virgin State) Not Programmed	
P1666-54	EGR Selflearning Mechanical Fault Missing Calibration	
P1652-12	Knock Sensor; Key on Diagnosis Circuit Short to Battery	06
P1652-11	Knock Sensor; Key on Diagnosis Circuit Short to Ground	00
P1652-49	Knock Sensor; Key on Diagnosis Internal Electronic Failure	
P1652-64	Knock Sensor; Key on Diagnosis Signal Plausibility Failure	
P1653-62	Pedal Potentiometer Congruence Signal Compare Failure	
P1654-62	Throttle Potentiometer Congruence Signal Compare Failure	
P1655-94	Self Learning Throttle bat Unexpected Operation	
P1656-94	Self Learning Throttle slc Unexpected Operation	
P1657-77	Self Learning Throttle Ihp Commanded Position not Reachable	
P1658-77	Self Learning Throttle trc Commanded Position not Reachable	
P1659-92	Self Learning Throttle mtc Performance or Incorrect Operation	
P1660-77	Self Learning Throttle tro Commanded Position not Reachable	
P1661-61	Throttle Control Error Position Signal Calculation Failure	
P1663-62	Low Air Manifold Pressure (Functional) Signal Compare Failure	
P1667-16	Puntual ECS Fdbk Current Fault Circuit Voltage Below Threshold	.com
P1667-17	Puntual ECS Fdbk Current Fault Circuit Voltage Above Threshold	
P2227-62	Plausibility MAP at Key On Signal Compare Failure	
P2244-92	O2 Sensor Reference Voltage Performance (Bank 1 Sensor 1) Performance or Incorrect Operation	
P2299-62	Gas & Brake Pedal Coherence Signal Compare Failure	


### **ECM Power Supply Circuit & Ground Circuit Testing**

### **Power Supply Circuit**





### **Ground Circuit**



#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using diagnostic tester, select Read Datastream.
- If datastream is not detected, malfunction indicated by datastream is current. Go to diagnosis procedure -Step 1.
- If datastream is detected, malfunction indicated by datastream is intermittent (See page 06-19).


#### **Diagnosis Procedure**

### Check ECM power supply circuit

- a. Turn ignition switch to LOCK.
  - b. Disconnect the ECM connector E-041.
  - c. Check voltage between terminal of ECM connector E-041 and body ground.

Multimeter Connection	Condition	Specified Condition
E-041 (A54) - Body ground	Always	11 to 14 V

Go to step 4 OK.



NG

#### **Check ECM fuse**

- a. Unplug ECM fuse EF26 (10A) from engine compartment fuse and relay box.
- b. Check resistance of fuse.

Standard resistance: less than 1  $\Omega$ 

Replace ECM fuse

OK

### 3 Check wire harness and connector (ECM - engine compartment fuse and relay box)

- a. Disconnect the engine compartment fuse and relay box connector E-067.
- b. Check wire harness between connector terminals on wire harness side.

#### **Check for Open**


Multimeter Connection	Specified Condition
E-041 (A54) - E-067 (75)	Continuity

#### **Check for Short**

Multimeter Connection	Specified Condition
E-041 (A54) or E-067 (75) - Body ground	No continuity
E-041 (A54) or E-067 (75) - Battery positive	No continuity

NG Repair or replace wire harness or connector

خودرو سامانه (مس



ок

Repair or replace engine compartment fuse and relay box or wire harness (engine compartment fuse and relay box - battery)


### 4 Check main relay circuit voltage

- a. Remove main relay from engine compartment fuse and relay box.
- b. Check voltage between terminals of main relay and body ground.

Multimeter Connection	Condition	Specified Condition
Main relay terminals 85 and 30 (engine compartment fuse and relay box side) - Body ground	Always	11 to 14 V

NG

Repair or replace wire harness or connector (mainrelay - battery)








- 5 Check main relay and fuse EF30
- a. Check if fuse EF30 is normal.
- b. Check for continuity between terminals of main relay.

Multimeter Connection	Specified Condition
Terminal 30 - Terminal 87	No continuity
Terminal 30 - Terminal 87	Continuity (battery voltage is applied between terminals 85 and 86)

NG

06

Replace fuse or main relay



ОК


- 6 Check wire harness and connector (ECM engine compartment fuse and relay box)
- a. Check wire harness between connector terminals.
- b. Disconnect the engine compartment fuse and relay box connector E-067.

#### **Check for Open**

	0.00.00.00	
)	Multimeter Connection	Specified Condition
	E-041 (A55,A56) - E-067 (115)	Continuity

#### **Check for Short**

Multimeter Connection	Specified Condition
E-041 (A55,A56) or E-067 (115) - Body ground	No continuity
E-041 (A55,A56) or E-067 (115) - Battery positive	No continuity



#### **Check for Open**


Multimeter Connection	Specified Condition
E-041 (A42) - E-067 (20)	Continuity

#### **Check for Short**

Multimeter Connection	Specified Condition
E-041 (A42) or E-067 (20) - Body ground	No continuity
E-041 (A42) or E-067 (20) - Battery positive	No continuity

NG

Repair or replace wire harness or connector



OK


Check ECM power supply circuit (ignition switch voltage)

- a. Turn ignition switch to ON.
- b. Check voltage between terminals of ECM connector.

Multimeter Connection	Condition	Specified Condition
E-041 (A22) - E- 041 (A52,A53)	Ignition switch ON	11 to 14 V

ок

Replace ECM



NG

- 8 Check ECM fuse
- a. Unplug fuse FE07(15A) from instrument panel fuse box.
- b. Check resistance of fuse.

Standard resistance: less than 1  $\Omega$ 

NG

Replace ECM fuse





### 9 Check wire harness and connector (ECM - instrument panel fuse box and body ground)

- a. Disconnect the engine compartment fuse and relay box connector E-067.
- b. Check wire harness between connector terminals on wire harness side.

#### **Check for Open**

Multimeter Connection	Specified Condition
E-041 (A22) - E-067 (39)	Continuity

#### **Check for Short**

06


Multimeter Connection	Specified Condition
E-041 (A22) or E-067 (39) - Body ground	No continuity
E-041 (A22) or E-067 (39) - Battery positive	No continuity


- c. Disconnect the ground point E-043.
- d. Check the ECM ground point (See page 06-19).
  - e. Check the ECM ground wire harness.

#### **Check for Open**

1.02		88 9 89
	Multimeter Connection	Specified Condition
2	E-041 (A52, A35) - E-043	Continuity

NG Repair or replace wire harness or connector





ОК

10 Check the ignition switch assembly (See page 15-12).

NG Replace ignition switch assembly



Repair or replace engine compartment fuse and relay box or wire harness

06






121 62 99 92 92

www.digitalkhodro.com

DTC	P0135-12	Lambda Sensor1 Heater Driver Circuit Short to Battery	
1 DTC 1 P0135-14 I		Lambda Sensor1 Heater Driver Circuit Short to Ground or Open	
DTC	P0132-12 Electric Test Lambda Sensor 1 Circuit Short to Battery		
DTC	P0053-1E	Upstream Lambda Sonde Resistor (Functional Test) Circuit Resistance Out of Range	


06





021 62 99 92 92

www.digitalkhodro.com



DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0135-12	Lambda Sensor1 Heater Driver Circuit Short to Battery	Ignition switch ON Engine running	
P0135-14	Lambda Sensor1 Heater Driver Circuit Short to Ground or Open		<ul><li>Upstream oxygen sensor</li><li>Wire harness or connector</li></ul>
P0132-12	Electric Test Lambda Sensor 1 Circuit Short to Battery		• Fuse • ECM
P0053-1E	Upstream Lambda Sonde Resistor (Functional Test) Circuit Resistance Out of Range		

### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

#### **CAUTION**

06

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG Repair or replace ground wire harness or ground point


OK



- 2 Check upstream oxygen sensor connector
- a. Disconnect the upstream oxygen sensor connector E-037.
- b. Check the upstream oxygen sensor connector.

NG )

Repair or replace connector





06


- 3 Check upstream oxygen sensor heater power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between terminal 4 of upstream oxygen sensor connector E-037 and body ground.

Multimeter Connection	Condition	Specified Condition
E-037 (4) - Body ground	Ignition switch ON	11 - 14 V

ОК

Go to step 5

021 62 99 92 92





### 4 Check upstream oxygen sensor power supply circuit

- a. Turn ignition switch to LOCK.
- b. Check fuse EF13 and main relay.
- c. Disconnect the engine compartment fuse and relay box connector E-067.
- d. Check wire harness between upstream oxygen sensor connector terminal and engine compartment fuse and relay box connector terminal.

#### **Check for Open**

06

ĺ	Multimeter Connection	Condition	Specified Condition
	E-037 (4) - E-067 (45)	Always	Continuity


#### **Check for Short**

	Multimeter Connection	Condition	Specified Condition
	E-037 (4) or E- 067 (45) - Body ground	Always	No continuity
1/	E-037 (4) or E- 067 (45) - Battery positive	Always 9 J	No continuity

NG

Replace fuse, main relay, wire harness or connector(upstream oxygen sensor - engine compartment fuse and relay box)

021 62 99 92 92







### 5 Check upstream oxygen sensor heater control circuit

- a. Disconnect the ECM connector E-041.
- b. Check wire harness between upstream oxygen sensor connector terminal and ECM connector terminal.

#### **Check for Open**


Multimeter Connection	Condition	Specified Condition
E-037 (3) - E-041 (A49)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-037 (3) or E- 041 (A49) - Body ground	Always	No continuity
E-037 (3) or E- 041 (A49) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (upstream oxygen sensor - ECM)



06

ولين سامانه ديجيتال تعمير كاران خ

# 6 Check upstream oxygen sensor heater

a. Measure resistance of upstream oxygen sensor.

Multimeter Connection	Condition	Specified Condition
Terminal C - Terminal D	20°C	7 - 11 Ω
Terminal A - Terminal C	Always	
Terminal A - Terminal D		No continuity
Terminal B - Terminal C		140 Continuity
Terminal B - Terminal D		

RA13T060150

NG >

Replace upstream oxygen sensor



OK

ОК

- 7 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0135-14, P0135-12, P0132-12 or P0053-1E still exists.

NG

Replace ECM

OK

06

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران


021 62 99 92 92

DTC	P0138-12	Electric Test Lambda sensor 2 Circuit Short to Battery
DTC	P0141-12	Lambda Sensor2 Heater Driver Circuit Short to Battery
DTC	P0141-14	Lambda Sensor2 Heater Driver Circuit Short to Ground or Open
DTC	P0054-1E	Downstream Lambda Sonde Resistor (Functional Test) Circuit Resistance Out of Range





021 62 99 92 92



DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0138-12	Electric Test Lambda sensor 2 Circuit Short to Battery	<ul> <li>Downstream oxygen sensor</li> <li>Wire harness or connector</li> <li>Fuse</li> <li>ECM</li> </ul>	
P0141-12	Lambda Sensor2 Heater Driver Circuit Short to Battery		Downstream oxygen sensor
P0141-14	Lambda Sensor2 Heater Driver Circuit Short to Ground or Open		• Fuse
P0054-1E	Downstream Lambda Sonde Resistor (Functional Test) Circuit Resistance Out of Range		

### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### **CAUTION**

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG )

Repair or replace ground wire harness or ground point

OK




### 2 Check downstream oxygen sensor connector

- a. Disconnect the downstream oxygen sensor connector.
- b. Check the downstream oxygen sensor connector.

NG

Repair or replace connector



ОК

06


### 3 Check downstream oxygen sensor signal

- a. Connect the downstream oxygen sensor connector E-038.
- b. Turn ignition switch to ON, start engine and idle it for about 3 minutes.
- c. Use diagnostic tester to check downstream oxygen sensor signal voltage, or use multimeter to measure voltage between terminals 2 and 1 of connector E-038.

ميائمانيم	) dilalman	110111.00
Multimeter Connection	Condition	Specified Condition
E-038 (2) - E-038 (1)	Engine running	Fluctuates slightly at about 0.45 V

ок

Go to step 8



NG


### Check downstream oxygen sensor signal circuit

- a. Connect the downstream oxygen sensor connector E-
- b. Turn ignition switch to LOCK.
- c. Disconnect the ECM connector E-041.
- d. Check wire harness between downstream oxygen sensor connector terminal and ECM connector terminal.


#### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-038 (1) - E-041 (A39)	Always	Continuity
E-038 (2) - E-041 (A27)	Always	Continuity

#### **Check for Short**



Go to step 8



06



### 5 Check downstream oxygen sensor heater power supply voltage


- a. Turn ignition switch to ON.
- b. Check voltage between terminal 4 of downstream oxygen sensor connector E-062 and body ground.

Multimeter Connection	Condition	Specified Condition
E-038 (4) - Body ground	Ignition switch ON	11 - 14 V

NG )

06

Replace wire harness or connector (downstream oxygen sensor - ECM)



ОК

### 6 Check downstream oxygen sensor heater control circuit

0.0

- a. Check wire harness between downstream oxygen sensor connector terminal and ECM connector terminal.
  - b. Check for Open


Multimeter Connection	Condition	Specified Condition
E-038 (3) - E-041 (A50)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-038 (3) or E- 041 (A50) - Body ground	Always	No continuity
E-038 (3) or E- 041 (A50) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (downstream oxygen sensor - ECM)



OK



- 7 Visually check downstream oxygen sensor
- a. Remove the downstream oxygen sensor.
- b. Check downstream oxygen sensor for following problems.
  - Moisture enters internal of sensor, temperature changes greatly or probe is broken.
  - Oxygen sensor is "poisoned" (Pb, S, Br and Si etc.).

NG

Replace downstream oxygen sensor

OK

8 Check for DTCs

06

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0138-12, P0141-12, P0141-14 or P0054-1E still exists.

6.8

NG )

Replace ECM



System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

021 62 99 92 92


DTC	P0201-11	Injector 1 Driver Circuit Short to Ground
DTC	P0201-12	Injector 1 Driver Circuit Short to Battery
DTC	P0201-13	Injector 1 Driver Circuit Open





021 62 99 92 92





DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0201-11	Injector 1 Driver Circuit Short to Ground		Fuel injector
P0201-12	Injector 1 Driver Circuit Short to Battery	Ignition switch ON Engine running	Wire harness or connector     ECM
P0201-13	Injector 1 Driver Circuit Open		2 LOW

#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
  - Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
  - Start engine and warm it up to normal operating temperature, and then select Read Code.
  - If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
  - If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### **CAUTION**

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG

Repair or replace ground wire harness or ground point

www.digitalkhodro.com


OK

### 2 Check injector connector of cylinder 1

- a. Disconnect injector connector E-024 of cylinder 1.
- b. Turn ignition switch to ON.
- c. Check voltage between injector connector terminal of cylinder 1 and body ground.

NG

Repair or replace connector






### 3 Check injector power supply voltage of cylinder1

- a. Disconnect injector connector E-002 of cylinder 1.
- b. Turn ignition switch to ON.
- c. Check voltage between injector connector terminal of cylinder 1 and body ground.

Multimeter Connection	Condition	Specified Condition
E-024 (1) - Body ground	Ignition switch ON	11 - 14 V

ок

Go to step 5



06

NG

# 4 Check injector power supply circuit of cylinder1


- a. Turn ignition switch to LOCK.
- b. Check fuse EF38 and main relay.
- c. Disconnect the engine compartment fuse and relay box connector E-067.
- d. Check wire harness between connector terminals.

#### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-024 (1) - E-067 (116)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-024 (1) or E- 067 (116) - Body ground	Always	No continuity
E-024 (1) or E- 067 (116) - Battery positive	Always	No continuity



NG

06

Repair or replace wire harness or connector (injector- engine compartment fuse and relay box)

OK

### 5 Check injector control circuit of cylinder1


a. Disconnect the ECM connector E-001.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-024 (2) - E-001 (B36)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-024 (2) or E- 001 (B36) - Body ground	Always	No continuity
E-024 (2) or E- 001 (B36) - Body ground	Always 9 J	No continuity



NG

Repair or replace wire harness or connector (injector- ECM)

62 99 92 92

www.digitallhokrd.

6 Check injector

a. Check resistance of injector.

NG Replace injector

ОК

## 7 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0201-11, P0201-12 or P0201-13 still exist.

NG Replace ECM



System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

06





121 62 99 92 92


	DTC	P0105-12	Intake Manifold Pressure Sensor (Electric) Circuit Shortto Battery		
	DTC	P0105-14	Intake Manifold Pressure Sensor (Electric) Circuit Shortto Ground or Open		
	DTC	P0106-26	Air Pressure Sensor (Functional) Signal Rate of Change BelowThreshold		
	DTC	P0106-27	Air Pressure Sensor (Functional) Signal Rate of Change AboveThreshold		
06	DTC	P0101-62	Air Intake Manifold Signal Compare Failure		
	DTC	P1663-62	Low Air Manifold Pressure (Functional) Signal Compare Failure		



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

021 62 99 92 92



DTC	DTC Definition	DTC Detection Condition	Possible Cause	
P0105-12	Intake Manifold Pressure Sensor (Electric) Circuit Short to Battery			
P0105-14	Intake Manifold Pressure Sensor (Electric) Circuit Short to Ground or Open			
P0106-26	Air Pressure Sensor (Functional) Signal Rate of Change Below Threshold	Ignition switch ON	<ul><li>Intake pressure sensor</li><li>Wire harness or connector</li></ul>	
P0106-27	Air Pressure Sensor (Functional) Signal Rate of Change Above Threshold		• ECM	
P1663-62	Low Air Manifold Pressure (Functional) Signal Compare Failure			
P0101-62	Air Intake Manifold Signal Compare Failure			

#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
  - Start engine and warm it up to normal operating temperature, and then select Read Code.
  - If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
  - If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### **CAUTION**

06

• When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

# 1 Check ECM ground point

- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG

Repair or replace ground wire harness or ground point


OK

### 2 Check intake pressure/temperature sensor connector

- a. Disconnect the intake pressure/temperature sensor connector E-025.
- b. Check the intake pressure/temperature sensor connector.

NG )

Repair or replace connector



ОК

### 3 Check intake pressure sensor signal voltage


**|| || 00** 

- a. Connect the intake pressure/temperature sensor connector E-025.
- b. Turn ignition switch to ON and start engine.
  - c. Using a multimeter, measure voltage between terminal 4 of connector E-025 and body ground.

Multimeter Connection	Condition	Specified Condition
2 99 92 92	Idle	Voltage is about 1.3 V (value changes with model)
E-025 (4) - Body ground	Rapidly depress accelerator pedal	Maximum instantaneous voltage is about 4 V (value changes with model)

ок

Go to step 8



NG


### 4 Check intake pressure sensor power supply voltage

- a. Disconnect the intake pressure/temperature sensor connector E-025.
- b. Check voltage between connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-025 (3) - Body ground	Ignition switch ON	5 V

ок

Go to step 6



NG

### 5 Check intake pressure sensor power supply circuit

00

- a. Turn ignition switch to LOCK.
- b. Disconnect the ECM connector E-001.
- c. Check wire harness between connector terminals.

# Check for Open Contact Check Check for Open Contact Check for Open Contact Check for Open Contact Check for Open Contact Check for Open Chec


Multimeter Connection	Condition	Specified Condition
E-025 (3) - E-001 (B28)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-025 (3) or E- 001 (B28) - Body ground	Always	No continuity
E-025 (3) or E- 001 (B28) - Battery positive	Always	No continuity

NG

Replace wire harness or connector (intake pressure/temperature sensor - ECM)







a. Check wire harness between intake temperature sensor connector terminal and ECM connector terminal.

#### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-025 (4) - E-001 (B19)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-025 (4) or E- 001 (B19) - Body ground	Always	No continuity
E-025 (4) or E- 001 (B19) - Battery positive	Always	No continuity

E-001 RA13T060290

Repair or replace wire harness or connector (intake pressure/temperature sensor - ECM)

OK

- Check intake pressure sensor
- a. Remove the intake pressure/temperature sensor.
- b. Check sensor connection part for debris or damage.

Clean or replace intake pressure/ temperature sensor

OK

- 8 **Check for DTCs**
- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0101-62, P0105-12, P0105-14, P1663-62, P0106-26 or P0106-27 still exists.

NG

Replace ECM

06



System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

06






021 62 99 92 92

DTC	P0110-11	Air Temperature Sensor Circuit Short to Ground
DTC	P0110-15	Air Temperature Sensor Circuit Short to Battery or Open
DTC	P0110-3A	Air Temperature Sensor Signal Has Too Many Pulses
DTC	P0111-62	Air Temperature Sensor (Functional) Signal Compare Failure





121 62 99 92 92





DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0110-11	Air Temperature Sensor Circuit Short to Ground		
P0110-15	Air Temperature Sensor Circuit Short to Battery or Open	Ignition switch ON	Intake temperature sensor
P0110-3A	Air Temperature Sensor Signal Has Too Many Pulses	Engine running	<ul><li>Wire harness or connector</li><li>ECM</li></ul>
P0111-62	Air Temperature Sensor (Functional) Signal Compare Failure		

#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

#### **CAUTION**

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

#### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG

Repair or replace ground wire harness or ground point


OK

### 2 Check intake pressure/temperature sensor connector

- a. Disconnect the intake pressure/temperature sensor connector E-025.
- b. Check the intake pressure/temperature sensor connector.

NG

Repair or replace connector



06



### 3 Check intake temperature sensor signal voltage


- a. Connect the intake pressure/temperature sensor connector E-025.
- b. Turn ignition switch to ON and start engine.
- c. Using a multimeter, measure voltage between terminal 4 of connector E-025 and body ground.

Multimeter Connection	Condition	Specified Condition
E-025 (4) - Body ground	Ignition switch ON	5 V

ок

Go to step 5

021 62 99 92 92



NG

## 4 Check intake temperature sensor signal circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect the ECM connector E-018.
- c. Check wire harness between connector terminal and ECM connector terminal.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-025 (2) - E-001 (B7)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-025 (2) or E- 001 (B7) - Body ground	Always	No continuity
E-025 (2) or E- 001 (B7) - Battery positive	Always	No continuity

NG

Replace wire harness or connector (intake pressure/temperature sensor - ECM)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



06

### 5 Check intake temperature sensor ground circuit


a. Check wire harness between connector terminals.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-025 (1) - E-001 (B33)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-025 (1) or E- 001 (B33) - Body ground	Always	No continuity
E-025 (1) or E- 001 (B33) - Battery positive	Always	No continuity





NG

Repair or replace wire harness or connector (intake pressure/temperature sensor - ECM)

OK

- 6 Check intake temperature sensor
- a. Remove the intake pressure/temperature sensor.
- b. Check resistance of intake temperature sensor.

#### **Check for Open**

06

Multimeter Connection	Condition	Specified Condition
Terminal 1 - Terminal 2	Always	2.5 kΩ ± 5% (20°C)

NG

Replace intake pressure/temperature sensor

00

OK

- 7 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0110-11, P0110-15, P0110-3A or P0111-62 exists.

NG

Replace ECM

italkhodro.co


System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0115-11	Water temperature sensor Circuit Short to Ground
DTC	P0115-15	Water Temperature Sensor Circuit Short to Battery or Open
DTC	P0115-3A	Water Temperature Sensor Signal Has Too Many Pulses
DTC	P0116-62	Water Temperature Sensor (Functional) Signal Compare Failure





021 62 99 92 92





DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0115-11	Water temperature sensor Circuit Short to Ground		
P0115-15	Water Temperature Sensor Circuit Short to Battery or Open	Ignition switch ON	Engine coolant temperature sensor
P0115-3A	Water Temperature Sensor Signal Has Too Many Pulses	Engine running	<ul><li>Wire harness or connector</li><li>ECM</li></ul>
P0116-62	Water Temperature Sensor (Functional) Signal Compare Failure		

#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

#### **CAUTION**

اولین سامانه د بجیتال تعمیرکاران خودرو در

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

1 Check ECM ground point

- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG

Repair or replace ground wire harness or ground point

OK




### 2 Check engine coolant temperature sensor connector

- a. Disconnect the engine coolant temperature sensor connector E-006.
- b. Check engine coolant temperature sensor connector

NG

Repair or replace connector



06



### 3 Check engine coolant temperature sensor power supply voltage


- a. Turn ignition switch to ON.
- b. Check voltage between engine coolant temperature sensor terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-006 (2) - Body ground	Ignition switch ON	ديجي <sup>5</sup> ل خو

ок

Go to step 5

021 62 99 92 92



NG

### Check engine coolant temperature sensor power supply circuit

- a. Disconnect the engine coolant temperature sensor connector E-025.
- b. Check voltage between connector terminal and body ground.
- c. Check wire harness between engine coolant temperature sensor connector terminal and ECM connector terminal.

#### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-006 (2) - E-001 (B4)	Always	Continuity


#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-006 (2) or E- 001 (B4) - Body ground	Always	No continuity
E-006 (2) or E- 001 (B4) - Battery positive	Always ) در و سامانه	No continuity

or

Replace wire harness NG connector(engine coolant temperature sensor - ECM)

www.digitall



### 5 Check engine coolant temperature sensor ground circuit

a. Check wire harness between engine coolant temperature sensor connector terminal and ECM connector terminal.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-006 (1) - E-001 (B21)	Always	Continuity


#### **Check for Short**

06

Multimeter Connection	Condition	Specified Condition	
E-006 (1) or E- 001 (B21) - Body ground	Always	No continuity	
E-006 (1) or E- 001 (B21) - Battery positive	Always	No continuity	

NG

Repair or replace wire harness or connector (engine coolant temperature sensor - ECM)



ОК

# اولین سامانه دیجیتال تعمیرکاران خودرو د


- 6 Check engine coolant temperature sensor
- a. Remove the engine coolant temperature sensor.
  - b. Check resistance of engine coolant temperature sensor.

#### **Check for Open**

Multimeter Connection	Specified Condition	
Terminal 1 - Terminal 2	Always  Resistance is $2.5 \text{ k}\Omega \pm 5\%$ at normal temperature ( $20^{\circ}\text{C}$ ) and $300 - 400 \Omega$ in boiled water (value changes with boiled water temperature)	



Replace engine coolant temperature sensor



ОК



### 7 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0115-11, P0115-15, P0115-3A or P0116-62 still exists.

NG

Replace ECM

ОК


System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

06



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



021 62 99 92 92


DTC	P0121-12	Throttle Potentiometer 1 Circuit Short to Battery	
DTC	P0121-14	Pedal Potentiometer 1 Circuit Short to Ground or Open	
DTC	P0221-12	Throttle Potentiometer 2 Circuit Short to Battery	
DTC	P0221-14	Pedal Potentiometer 2 Circuit Short to Ground or Open	

06





021 62 99 92 92



#### 06 - SQRD4G15B ENGINE MANAGEMENT SYSTEM

DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0121-12	Throttle Potentiometer 1 Circuit Short to Battery		
P0121-14	Pedal Potentiometer 1 Circuit Short to Ground or Open	Ignition switch ON	<ul><li>Throttle position sensor 1</li><li>Throttle position sensor 2</li></ul>
P0221-12	Throttle Potentiometer 2 Circuit Short to Battery	Engine running	<ul><li>Wire harness or connector</li><li>ECM</li></ul>
P0221-14	Pedal Potentiometer 2 Circuit Short to Ground or Open		

06

#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- II III 00 Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

#### CAUTION

When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

# **Diagnosis Procedure**

- 1 **Check ECM ground point**
- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG

Repair or replace ground wire harness or ground point

OK




### 2 Check electronic throttle connector

- a. Disconnect the electronic throttle connector E-008.
- b. Check the electronic throttle connector.

NG )

Repair or replace connector





06


### 3 Check throttle position sensor 1 signal voltage

- a. Turn ignition switch to ON.
- b. Connect the electronic throttle connector E-008.
- c. Using diagnostic tester, check signal voltage of throttle position sensor 1.

Multimeter Connection	Condition	Specified Condition
Accelerator pedal released	Ignition switch ON	0.78 V
Accelerator pedal depressed		ساما 4.22 V

ок

Go to step 8



NG

### 4 Check throttle position sensor power supply voltage

- a. Turn ignition switch to LOCK.
- b. Disconnect the electronic throttle connector E-008.
- c. Turn ignition switch to ON and check voltage between electronic throttle connector terminal and body ground.


#### **Voltage Inspection**

Multimeter Connection	Condition	Specified Condition
E-008 (6) - Body ground	Ignition switch ON	5 V

ок

06

Go to step 6



NG

### 5 Check throttle position sensor power supply circuit

00

- a. Turn ignition switch to LOCK.
- b. Disconnect the ECM connector E-001.
- c. Check wire harness between electronic throttle connector terminal and ECM connector terminal.

#### **Check for Open**


Multimeter Connection	Condition	Specified Condition
E-008 (6) - E-001 (B31)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-008 (6) or E- 001 (B31) - Body ground	Always	No continuity
E-008 (6) or E- 001 (B31) - Battery positive	Always	No continuity

NG

Replace wire harness or connector (electronic throttle - ECM)





### 6 Check throttle position sensor 1 signal circuit and ground circuit

a. Check wire harness between electronic throttle connector terminal and ECM connector terminal.

#### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-008 (4) - E-001 (B6)	Always	Continuity
E-008 (2) - E-001 (B30)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-008 (4), E-018 (B6), E-008 (2) or E-001 (B30) - Body ground	Always	No continuity
E-008 (4), E-018 (B6), E-008 (2) or E-001 (B30) - Battery positive	Always 93	No continuity

NG Repair or replace wire harness or connector (electronic throttle - ECM)

06

www.digitalk




## 21 62 99 92 92

### 7 Check electronic throttle

- a. Check electronic throttle for carbon deposits and foreign matter accumulation inside.
- b. Check if electronic throttle valve body is stuck.
- c. Check resistance of electronic throttle.

#### **Throttle Inspection**

Multimeter Connection	Condition	Specified Condition
Terminal 3 - Terminal 2	Normal temperature	1.067 kΩ



#### 06 - SQRD4G15B ENGINE MANAGEMENT SYSTEM

Multimeter Connection	Condition	Specified Condition
Terminal 6 - Terminal 2	Throttle turned	Resistance increases as throttle valve opens
Terminal 6 - Terminal 3	Throttle turned	Resistance decreases as throttle valve opens

NG

Clean or replace electronic throttle assembly, and go to next step

06

ОК

- 8 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTC.

شرکت دیجیتال خودر و سامانه (مسئولیت محدود)

- b. Refer to "DTC Confirmation Procedure".
- Check if DTC P0120-12, P0120-14, P0121-12 or P0121-14 still exists.



Replace ECM

OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

021 62 99 92 92


DTC	P0130-23	Functional Test Lambda Sensor 1 Signal Stuck Low
DTC	P0130-24	Functional Test Lambda Sensor 1 Signal Stuck High
DTC	P0133-62	First Probe Diagnosis Signal Compare Failure

06





021 62 99 92 92



DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0130-23	Functional Test Lambda Sensor 1 Signal Stuck Low		
P0130-24	Functional Test Lambda Sensor 1 Signal Stuck High	Ignition switch ON Engine running	<ul><li>Upstream oxygen sensor</li><li>Wire harness or connector</li><li>ECM</li></ul>
P0133-62	First Probe Diagnosis Signal Compare Failure		

#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- · Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

#### **CAUTION**

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

## ولین سامانه دیجیتال تعمیرکاران خودرو در ا

### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG >

Repair or replace ground wire harness or ground point

OK


06

### 2 Check upstream oxygen sensor connector

- a. Disconnect the upstream oxygen sensor connector E-037.
- b. Check the upstream oxygen sensor connector.

NG

Repair or replace connector



06




### 3 Check upstream oxygen sensor signal

- a. Connect the upstream oxygen sensor connector E-037.
- b. Turn ignition switch to ON, start engine and idle it for about 3 minutes.
- c. Using a multimeter, measure voltage between terminals 2 and 1 of connector E-037.

Multimeter Connection	Condition	Specified Condition
E-037 (2) - E-037 (1)	Engine running	Fluctuates fast between 0.1 and 0.9 V (when operating temperature is 350°C)

OK

Go to step 8



NG



### 4 Check upstream oxygen sensor signal circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect the ECM connector E-001.
- c. Disconnect the upstream oxygen sensor connector E-037.
- d. Check wire harness between upstream oxygen sensor connector terminal and ECM connector terminal.

#### **Check for Open**


Multimeter Connection	Condition	Specified Condition
E-037 (2) - E-041 (A26)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-037 (2) or E- 041 (A26) - Body ground	Always	No continuity
E-037 (2) or E- 041 (A26) - Battery positive	Always	No continuity

NG

Replace wire harness or connector (upstream oxygen sensor - ECM)



06



## 021 62 99 92 92

### Check upstream oxygen sensor ground circuit


a. Check wire harness between upstream oxygen sensor connector terminal and ECM connector terminal.

#### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-037 (1) - E-041 (A38)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-037 (1) or E- 041 (A38) - Body ground	Always	No continuity



www.digitalk



#### 06 - SQRD4G15B ENGINE MANAGEMENT SYSTEM

Multimeter Connection	Condition	Specified Condition
E-037 (1) or E- 041 (A38) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (upstream oxygen sensor - ECM)

ОК

06

- 6 Check upstream oxygen sensor
- a. Remove the upstream oxygen sensor.
- b. Check upstream oxygen sensor for following problems.
  - Moisture enters internal of sensor, temperature changes greatly or probe is broken.
  - Oxygen sensor is "poisoned" (Pb, S, Br and Si etc.).

NG

Replace upstream oxygen sensor

00

OK

7 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0130-23, P0130-24 or P0133-62 still exists.

21 62 NG

Replace ECM

www.digitalkhodro.com

OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.


DTC	P0136-23	Functional Test Lambda Sensor 2 Signal Stuck Low
DTC	P0136-24	Functional Test Lambda Sensor 2 Signal Stuck High
DTC	P0139-62	DO2V Signal Compare Failure

06





021 62 99 92 92



DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0136-23	Functional Test Lambda Sensor 2 Signal Stuck Low		Downstream oxygen sensor
P0136-24	Functional Test Lambda Sensor 2 Signal Stuck High	Ignition switch ON Engine running	Wire harness or connector     ECM
P0139-62	DO2V Signal Compare Failure		

#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

#### **CAUTION**

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

## ولين سامانه ديجيتال تعميا

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG Repair or replace ground wire harness or ground point

OK


06

### 2 Check downstream oxygen sensor connector

- a. Disconnect the downstream oxygen sensor connector E-038.
- b. Check the downstream oxygen sensor connector.

NG

Repair or replace connector



06




### 3 Check downstream oxygen sensor signal

- a. Connect the downstream oxygen sensor connector E-038.
- b. Turn ignition switch to ON, start engine and idle it for about 3 minutes.
- c. Use diagnostic tester to check downstream oxygen sensor signal voltage, or use multimeter to measure voltage between terminals 2 and 1 of connector E-062.

مسئوليت،	) dilaluary	11011.00
Multimeter Connection	Condition	Specified Condition
E-038 (2) - E-038 (1)	Engine running	Fluctuates slightly at about 0.45 V

ок

Go to step 8



NG

### 4 Check downstream oxygen sensor signal circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect the ECM connector E-041.
- Disconnect the downstream oxygen sensor connector E-038.
- d. Check wire harness between downstream oxygen sensor connector terminal and ECM connector terminal.

#### **Check for Open**


Multimeter Connection	Condition	Specified Condition
E-038 (2) - E-041 (A27)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-038 (2) or E- 041 (A27) - Body ground	Always	No continuity
E-038 (2) or E- 041 (A27) - Battery positive	Always	No continuity

NG

Replace wire harness or connector (downstream oxygen sensor - ECM)



06



## 021 62 99 92 92

### Check downstream oxygen sensor ground circuit


 a. Check wire harness between downstream oxygen sensor connector terminal and ECM connector terminal.

#### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-038 (1) - E-041 (A39)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-038 (1) or E- 041 (A39) - Body ground	Always	No continuity



www.digitalk

#### 06 - SQRD4G15B ENGINE MANAGEMENT SYSTEM

Multimeter Connection	Condition	Specified Condition
E-038 (1) or E- 041 (A39) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (downstream oxygen sensor - ECM)

ОК

06

- 6 Check downstream oxygen sensor
- a. Remove the downstream oxygen sensor.
- b. Check downstream oxygen sensor for following problems.
  - Moisture enters internal of sensor, temperature changes greatly or probe is broken.

00

• Oxygen sensor is "poisoned" (Pb, S, Br and Si etc.).

NG

Replace downstream oxygen sensor

OK

- 7 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0136-23, P0136-24 or P0139-62 still exists.

NG >

Replace ECM

www.digitalkhodro.com

OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P1654-62	Throttle Potentiometer Congruence Signal Compare Failure	
DTC	P1655-94	Self Learning Throttle bat Unexpected Operation	
DTC	P1656-94	Self Learning Throttle slc Unexpected Operation	
DTC	P1657-77	Self Learning Throttle Ihp Commanded Position not Reachable	
DTC	P1658-77	Self Learning Throttle trc Commanded Position not Reachable	
DTC	P1659-92	Self Learning Throttle mtc Performance or Incorrect Operation	
DTC	P1660-77	Self Learning Throttle tro Commanded Position not Reachable	


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

021 62 99 92 92

www.digitalkhodro.com

06





06	

DTC	DTC Definition	DTC Detection Condition	Possible Cause	
P1654-62	Throttle Potentiometer Congruence Signal Compare Failure			
P1655-94	Self Learning Throttle bat Unexpected Operation			
P1656-94	Self Learning Throttle slc Unexpected Operation		Unsuccessful throttle self-learning	
P1657-77	Self Learning Throttle Ihp Commanded Position not Reachable	Ignition switch ON Engine running	<ul><li>Insufficient battery voltage</li><li>Throttle mechanical malfunction</li><li>Wire harness or connector</li></ul>	
P1658-77	Self Learning Throttle trc Commanded Position not Reachable		• ECM	
P1659-92	Self Learning Throttle mtc Performance or Incorrect Operation	0		
P1660-77	Self Learning Throttle tro Commanded Position not Reachable	: پھيا		

#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

#### CAUTION

• When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

#### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG

Repair or replace ground wire harness or ground point




ОК

- 2 Check electronic throttle connector
- a. Disconnect the electronic throttle connector E-008.
- b. Check electronic throttle connector

NG

Repair or replace connector



06



- 3 Perform electronic throttle self-learning procedures
- a. Connect the electronic throttle connector E-008.
- b. Perform the electronic throttle self-learning procedures (See page 06-20).
- c. Using X-431 3G diagnostic tester, read ECM DTC.
- d. Check if DTC P1654-62, P1655-94, P1656-94, P1657-77, P1658-77, P1659-92 or P1660-77 still exists.

ок

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

NG

## 021 62 99 92 92

4 Check battery voltage

a. Check the battery voltage (See page 16-6).

NG

**Detect or replace battery** 

OK



(E-001)

### Check electronic throttle actuator circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect the electronic throttle connector E-008.
- c. Disconnect the ECM connector E-001.
- d. Check wire harness between connector terminals.

#### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-001 (B52) - E- 008 (3)	Always	Continuity
E-001 (B51) - E- 008 (5)	Always	Continuity

#### **Check for Short**


Multimeter Connection	Condition	Specified Condition
E-001 (B52), E- 008 (3), E-001 (B51) or E-008 (5) - Body ground	Always	No continuity
E-001 (B52), E- 008 (3), E-001 (B51) or E-008 (5)	درو سامانه ( Always	No continuity
- Battery positive	17	

Repair or replace related wire harness

www.digitalkhodro

### **Check electronic throttle**

a. Check electronic throttle for carbon deposits and foreign matter accumulation inside.



06

RA13T060550

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
Terminal 3 - Terminal 2		1.067 kΩ
Terminal 6 - Terminal 2		Resistance increases as throttle valve opens
Terminal 6 - Terminal 3	Throttle turned	Resistance decreases as throttle valve opens
Terminal 5 - Terminal 2		Resistance decreases as throttle valve opens
Terminal 5 - Terminal 3		Resistance increases as throttle valve opens

06

NG

Clean or replace electronic throttle assembly, and go to next step

OK

### 7 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
  - c. Check if DTC P1654-62, P1655-94, P1656-94, P1657-77, P1658-77, P1659-92 or P1660-77 still exists.

NG Replace ECM

OK

021 62 99 92 92

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.


DTC	P0120-12	Pedal Ootentiometer 1 Circuit Short to Battery
DTC	P0120-14	Pedal Potentiometer 1 Circuit Short to Ground or Open
DTC	P0220-12	Pedal Ootentiometer 2 Circuit Short to Battery
DTC	P0220-14	Pedal Potentiometer 2 Circuit Short to Ground or Open

06





021 62 99 92 92



DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0120-12	Pedal Ootentiometer 1 Circuit Short to Battery		
P0120-14	Pedal Potentiometer 1 Circuit Short to Ground or Open	Ignition switch ON	<ul> <li>Accelerator pedal position sensor 1</li> <li>Wire harness or connector</li> </ul>
P0220-12	Pedal Ootentiometer 2 Circuit Short to Battery	Engine running	ECM
P0220-14	Pedal Potentiometer 2 Circuit Short to Ground or Open		

#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- · Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### CAUTION

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

#### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG >

Repair or replace ground wire harness or ground point

OK


06

### 2 Check electronic accelerator pedal connector

- a. Disconnect the electronic accelerator pedal connector I-012 (arrow).
- b. Check the electronic accelerator pedal connector.

NG

Repair or replace connector



06




### 3 Check electronic accelerator pedal voltage

- a. Turn ignition switch to ON.
- b. Connect the electronic accelerator pedal connector I-012.
- c. Using diagnostic tester, check signal voltage of electronic accelerator pedal.

Multimeter Connection	Condition	Specified Condition
I-012 (1,4) - Body ground	Ignition switch ON	5 V
I-012 (2,5) - Body ground	نال تعمیرکار	سامان۷0 يجيا

NG

Repair or replace related wire harness




ОК

### 4 Check electronic accelerator pedal circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect electronic accelerator pedal connector I-012.
- c. Check wire harness between connector terminals.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
I-012 (2) - E-041 (A28)		
I-012 (1) - E-041 (A21)	Always	Continuity
I-012 (5) - E-041 (A40)	Always	Continuity
I-012 (4) - E-041 (A31)		



06

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
I-012 (1, 2, 4, 5) or E-041 (A13, A21, A28, A40) - Battery positive	درو سامانه (	د دیجیتال خو
I-012 (1, 2, 4, 5) or E-041 (A13, A21, A28, A40) - Battery positive	Always	No continuity

www.digitalkhodro.com

NG

Repair or replace related wire harness (electronic accelerator pedal - ECM)

OK

### Check electronic accelerator pedal sensor circuit

a. Check wire harness between connector terminals.

#### **Check for Open**

Multimeter Connection	Condition	Specified Condition
I-012 (3) - E-041 (A30)	Always	Continuity
I-012 (6) - E-041 (A32)		

#### **Check for Short**

06


Multimeter Connection	Condition	Specified Condition
I-012 (3, 6) or E- 041 (A30,32) - Body ground	Always	No continuity
I-012 (3, 6) or E- 041 (A30, 32) - Battery positive		

Replace wire harness or connector (electronic throttle pedal - ECM)




# Replace electronic throttle pedal and check DTC again

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0120-12, P0120-14, P0220-12 or P0220-14 still exists.





System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.




DTC	P0351-12	Ignition 1 Driver Circuit Short to Battery
DTC	P0351-14	Ignition 1 Driver Circuit Short to Ground or Open

06





021 62 99 92 92



DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0351-12	Ignition 1 Driver Circuit Short to Battery	Ignition switch ON	Ignition coil 1
P0351-14	Ignition 1 Driver Circuit Short to Ground or Open	Engine running	<ul><li>Wire harness or connector</li><li>ECM</li></ul>

#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- · Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

#### CAUTION

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

# Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG

Repair or replace ground wire harness or ground point


www.digitalkhodro.com

OK

- 2 Check ignition coil connector
- a. Turn ignition switch to LOCK.
- b. Disconnect the ignition coil 1 connector E-023 (arrow).
- c. Check the ignition coil connector.

NG

Repair or replace connector







ОК

- 3 Check compression of misfiring cylinder
- a. Measure compression of misfiring cylinder (See page 07-16).

NG

Check engine to confirm cause of low compression

ОК

Check injectors, valve clearance, intake system and fuel pressure, etc. of misfiring cylinder

Ω

06

- 4 Check ignition coil
- a. Check resistance of ignition coil primary winding with an oscilloscope.
- b. Inspect resistance of ignition coil secondary winding.

#### **Primary Ignition Coil Inspection**

Multimeter Connection	Condition	Specified Condition (KΩ)
Posts of high- voltage cable	Normal temperature (25°C ± 5°C)	9.68 - 12.32

RA13T060620

NG

Check engine to confirm cause of low compression

021 62 99 92 92




# 5 Check ignition coil power supply voltage

- a. Turn ignition switch to ON.
- b. Check voltage between ignition coil connector terminal and body ground.
- c. Using diagnostic tester, check signal voltage of ignition coil

Multimeter Connection	Condition	Specified Condition
E-023 (1) - Body ground	Ignition switch ON	11 - 14 V

ок

Go to step 7



NG

# 6 Check ignition coil power supply circuit

0.0

- a. Turn ignition switch to LOCK.
- b. Check fuse EF14 and main relay.
  - c. Check wire harness between ignition coil connector terminal and engine compartment fuse and relay box connector terminal.

### **Check for Open**


5	Multimeter Connection	Condition	Specified Condition
	E-023 (1) - E-067 (46)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-023 (1) or E- 067 (46) - Body ground	Always	No continuity
E-023 (1) or E- 067 (46) - Battery positive	riways	140 continuity

NG >

Replace wire harness or connector (ignition coil- engine compartment fuse and relay box)





# 7 Check ignition coil control circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect the ECM connector E-001.
- c. Check wire harness between ignition coil connector terminal and ECM connector terminal.

### **Check for Open**


Multimeter Connection	Condition	Specified Condition
E-023 (2) - E-001 (B54)	Always	Continuity

#### **Check for Short**

06

	Multimeter Connection	Condition	Specified Condition
	E-023 (2) or E- 001 (B54) - Body ground	Always	No continuity
1,5	E-023 (2) or E- 001 (B54) - Battery positive	درو سامانه (	ديجيتال څو

Repair or replace wire harness or connector (ignition coil - ECM)



www.digitalk

021 62 99 92 92

8 Replace ignition coil 1 and check DTC again

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0351-12 or P0351-14 still exists.


NG Replace ECM

OK

OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC P0335-62 Engine Speed Sensor Signal Compare Failure



DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0335-62	Engine Speed Sensor Signal Compare Failure	Ignition switch ON Engine running	<ul><li>Speed sensor</li><li>Wire harness or connector</li><li>ECM</li></ul>

#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

00

#### CAUTION

06

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG

Repair or replace ground wire harness or ground point

www.digitalkhodro.com

ОК

- 2 Check engine speed sensor signal waveform
- a. Turn ignition switch to ON, start engine and observe signal waveform of engine speed sensor with an oscilloscope.

OK ]

Go to step 9



RA13T060660


NG

# 3 Check engine speed sensor connector

- a. Turn ignition switch to LOCK.
- b. Disconnect the engine speed sensor connector E-039.
- c. Check the engine speed sensor connector.



Repair or replace engine speed sensor connector





06

- 4 Check installation of engine speed sensor
- a. Remove the engine speed sensor.
- b. Check and clean engine speed sensor and installation area, and check for damage, foreign matter or excessive movement, etc. that cause signal incorrectness.

NG

Clean or replace engine speed sensor



- 5 Check engine speed sensor circuit
- a. Disconnect the ECM connector E-001.
- b. Check wire harness between engine speed sensor connector terminal and ECM connector terminal.


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

#### Check for Open

Multimeter Connection	Condition	Specified Condition
E-039 (1) - E-001 (B12)	Always	Continuity
E-039 (2) - E-001 (B24)	Always	Continuity
E-039 (3) - E-001 (B40)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-039 (1,2,3) or E-001 (B12,B40,B24) - Body ground	Always	No continuity



Multimeter Connection	Condition	Specified Condition
E-039 (1,2,3) or E-001 (B12,B40,B24) - Battery positive	Always	No continuity

NG

Replace wire harness or connector (engine speedsensor - ECM)

OK

06

Check injectors, valve clearance, intake system and fuel pressure, etc. of misfiring cylinder

- 6 Check spark of misfiring cylinder with an normally functioning spark plug
- a. Install a normal engine speed sensor and observe signal waveform.
- b. Connect the engine speed sensor connector.
- c. Turn ignition switch to ON, start engine and observe signal waveform of engine speed sensor with an oscilloscope.

ок >

Replace engine speed sensor

NG

7 Check flywheel ring gear

a. Turn crankshaft and check crankshaft and flywheel ring gear for damage or foreign matter, etc. that cause signal incorrectness.

NG

Clear off debris and clean flywheel gear ring. Replace flywheel if necessary

OK

- 8 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0335-62 still exists.

NG Repl

Replace ECM



System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

06






021 62 99 92 92

DTC	P0325-12	Knock Sensor (Engine-Run) Circuit Short to Battery	
DTC	P1652-12	Knock Sensor; Key on Diagnosis Circuit Short to Battery	
DTC	P1652-11	Knock Sensor; Key on Diagnosis Circuit Short to Ground	
DTC	P1652-49	Knock Sensor; Key on Diagnosis Internal Electronic Failure	
DTC	P1652-64	Knock Sensor; Key on Diagnosis Signal Plausibility Failure	





021 62 99 92 92





06-117

DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0325-12	Engine Speed Sensor Signal Compare Failure	Ignition switch ON Engine running	
P1652-12	Knock Sensor; Key on Diagnosis Circuit Short to Battery		
P1652-11	Knock Sensor; Key on Diagnosis Circuit Short to Ground		<ul><li> Knock sensor</li><li> Wire harness or connector</li><li> ECM</li></ul>
P1652-49	Knock Sensor; Key on Diagnosis Internal Electronic Failure		
P1652-64	Knock Sensor; Key on Diagnosis Signal Plausibility Failure		

### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
  - If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
  - If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

## **CAUTION**

06

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG )


Repair or replace ground wire harness or ground point

OK



## 2 Check knock sensor connector

- a. Disconnect the knock sensor connector E-021.
- b. Check the knock sensor connector.



# 3 Check knock sensor signal circuit

- a. Disconnect the ECM wire harness connector E-001.
- b. Check wire harness between terminals of connector E-001 and connector E-021.

### **Check for Open**


	Multimeter Connection	Condition	Specified Condition
	E-001 (B17) - E- 021 (2)	Always	Continuity
,	E-001 (B5) - E- 021 (3)	Always	Continuity

### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-001 (B17,B5) or E-021 (2,3) - Body ground	Always	No continuity
E-001 (B17,B5) or E-021 (2,3) - Battery positive	Always	No continuity

NG

Replace wire harness or connector (knock sensor- ECM)



ОК

### 4 Check installation of knock sensor

- a. Remove the knock sensor.
- b. Check installation area of knock sensor, and check for damage, foreign matter or excessive movement, etc. that cause signal incorrectness.

06

NG

Clean installation area or replace knock sensor

OK

5 Check resistance of knock sensor

a. Check resistance between terminals 1 and 2 of knock sensor.

HINT:

OK: Above 1 M $\Omega$  (at normal temperature)

NG

Replace knock sensor

06

ОК

6 Check knock sensor signal

a. Install the knock sensor.

b. Slightly strike around knock sensor with a rubber hammer, and measure if voltage is generated between 2 terminals of knock sensor with multimeter (mV) at the same time.

NG

Replace knock sensor

خودر و سامانه (مسئول

OK

7 Check for DTCs Chec

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0325-12, P1652-12, P1652-11, P1652-49 or P1652-64 still exists.

NG

Replace ECM

OK


System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0340-11	Cam-shaft Sensor Circuit Short to Ground
DTC	P0340-15	Cam-shaft Sensor Circuit Short to Battery or Open
DTC	P0340-62	Cam-shaft Sensor Signal Compare Failure
DTC	P0016-76	Wrong Assembly Camshaft Wrong Mounting Position





021 62 99 92 92





DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0340-11	Cam-shaft Sensor Circuit Short to Ground		
P0340-15	Cam-shaft Sensor Circuit Short to Battery or Open	Ignition switch ON	<ul> <li>Camshaft position sensor</li> <li>Incorrect installation position of camshaft position sensor</li> </ul>
P0340-62	Cam-shaft Sensor Signal Compare Failure	Engine running	<ul> <li>Engine mechanical malfunction</li> <li>Wire harness or connector</li> <li>ECM</li> </ul>
P0016-76	Wrong Assembly Camshaft Wrong Mounting Position		- Low

#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- · Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### **CAUTION**

When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

# Diagnosis Procedure

www.digitalkhodro.con

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).


NG )

Repair or replace ground wire harness or ground point

OK

2 Check camshaft position sensor signal waveform

a. Turn ignition switch to ON, start engine and observe signal waveform of camshaft position sensor with an oscilloscope.



0.0

ОК

Go to step 10

NG

3 Check camshaft position sensor connector

- a. Turn ignition switch to LOCK.
- b. Disconnect the camshaft position sensor connector E-003.
- c. Check the camshaft position sensor connector.

NG

Repair or replace camshaft position sensor connector

00

ОК


4 Check camshaft position sensor power supply voltage

- a. Turn ignition switch to ON.
- b. Check voltage between terminal 3 of camshaft position sensor connector E-003 and body ground.

Multimeter Connection	Condition	Specified Condition
E-003 (3) - Body ground	Ignition switch ON	5 V

ок

Go to step 6





# 5 Check camshaft position sensor power supply circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect the ECM connector E-001.
- c. Check wire harness between camshaft position sensor connector terminal and ECM connector terminal.

### **Check for Open**


Multimeter Connection	Condition	Specified Condition
E-003 (3) - E- 001(B41)	Always	Continuity
E-003 (3) - E- 001(B41)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-003 (3) or E- 001 (B41) - Body ground	Always	No continuity
E-003 (3) or E- 01(B41) - Battery	Always	No continuity
positive	ال تعميكا،	سامانه ديرجي

NG

Repair or replace wire harness or connector (camshaft position sensor - ECM)



www.digitalkhodro.com



Replace ECM



# 6 Check camshaft position sensor signal circuit and ground circuit

a. Check wire harness between camshaft position sensor connector terminal and ECM connector terminal.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-001 (1) - E-003 (B13)	Always	Continuity

#### **Check for Short**

06

Multimeter Connection	Condition	Specified Condition
E-001 (1) or E- 003 (B13) - Body ground	Always	No continuity
E-001 (1) or E- 003 (B13) - Battery positive	Always	No continuity

NG Replace wire harness or connector (camshaft position sensor - ECM)

(E-001) RA13T060740

ОК

# 7 Check installation of camshaft position sensor

- a. Remove the camshaft position sensor.
- b. Check and clean camshaft position sensor and installation area, and check for damage, foreign matter or excessive movement, etc. that cause signal incorrectness.

NG Clean installation area or replace camshaft position sensor

ОК

- 8 Check camshaft ring gear
- a. Check camshaft ring gear for damage or foreign matter (such as debris), etc. that cause signal incorrectness.

NG Remove debris and clean camshaft ring gear or replace camshaft

ОК

- 9 Install a normal camshaft position sensor and observe signal waveform
- a. Install a normal camshaft position sensor.
- b. Connect the camshaft position sensor connector.
- c. Turn ignition switch to ON, start engine and observe signal waveform of camshaft position sensor with an oscilloscope.

ок

Replace camshaft position sensor

NG

10 Check for DTCs

06

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0340-11, P0340-15, P0340-62 or P0016-76 still exists.

60

NG

Replace ECM

OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

021 62 99 92 92

DTC	P0420-62	Catalizer Diagnosis Signal Compare Failure
-----	----------	--

DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0420-62	Catalizer Diagnosis Signal Compare Failure	Ignition switch ON Engine running	<ul> <li>Three-way catalytic converter</li> <li>Leakage in exhaust system</li> <li>Upstream oxygen sensor</li> <li>Downstream oxygen sensor</li> <li>ECM</li> </ul>

#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
  - Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
  - · Turn ignition switch to ON.
  - Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
  - Start engine and warm it up to normal operating temperature, and then select Read Code.
  - If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
  - If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

## Diagnosis Procedure

- 1 Check for any other DTCs output (in addition to DTC P0420-00)
- a. Connect X-431 3G diagnostic tester to Data Link Connector (DLC).
- b. Turn ignition switch to ON, start engine and warm it up to normal operating temperature, and then select Read Code.

Display (DTC Output)	Proceed to	
DTC P0420-00	wwva.digitalkhodro.	CO
DTC P0420-00 and other DTCs	В	

B Go to DTC chart, and perform troubleshooting to other DTCs first



# 2 Read datastream

- a. Using diagnostic tester, select Read Datastream.
- b. Check datastreams below.

Item	OK (Idling)	If it is NG, proceed to
Upstream Oxygen Sensor Voltage	Quickly fluctuates between 0.1 and 0.9 V	А



Item			OK (Idling)	If it is NG, proceed to
Downstream Voltage	Oxygen	Sensor	Fluctuates slightly at about 0.45 V	В
Average Injection Pulse Width			Approximately 2.15 ms	С

\_A >

Replace upstream oxygen sensor

\_c

Check injector, fuel pressure and other causes for abnormal injection pulse width

В

3 Check exhaust system

06

- a. Turn ignition switch to ON and start engine.
- b. Check exhaust system for leakage.

NG

Repair or replace related exhaust system components

OK

4 Check downstream oxygen sensor

NG

Replace downstream oxygen sensor

OK

Replace three-way catalytic converter, and go to step 5

5 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0420-62 still exists.

NG Replace ECM

OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0443-11	Canister Purge Driver Circuit Short to Ground
DTC	P0443-12	Canister Purge Driver Circuit Short to Battery
DTC	P0443-13	Canister Purge Driver Circuit Open





021 62 99 92 92



06-131

DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0443-11	Canister Purge Driver Circuit Short to Ground		Canister solenoid valve
P0443-12	Canister Purge Driver Circuit Short to Battery	Ignition switch ON Engine running	Wire harness or connector     ECM
P0443-13	Canister Purge Driver Circuit Open		LOW

#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

## **CAUTION**

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

1 Check ECM ground point

- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG ]

Repair or replace ground wire harness or ground point


www.digitalkhodro.com



- 2 Check canister solenoid valve connector
- a. Disconnect the canister solenoid valve connector E-015 (arrow).
- b. Check the canister solenoid valve connector.

NG

Repair or replace connector



06



# 3 Check canister solenoid valve power supply voltage

- a. Turn ignition switch to ON.
- b. Check voltage between canister solenoid valve connector terminals and body ground.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-015 (1) - E-067 (93)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-015 (1) or E- 067 (93) - Body		0
ground E-015 (1) or E-	Always	No continuity
067 (93) - Battery positive	\ a*!   1	00 0 00

ок

Go to step 5

ولین سامانه دیجیتال تعمیرکاران خودرو در اب




# Check canister solenoid valve power supply circuit

- a. Turn ignition switch to LOCK.
- b. Check fuse EF35 and main relay.
- c. Disconnect the engine compartment fuse and relay box connector E-067.
- d. Check wire harness between canister solenoid valve connector terminal and engine compartment fuse and relay box connector terminal.

Multimeter Connection	Condition	Specified Condition
E-003 (3) - Body ground	Ignition switch ON	5 V



Repair or replace wire harness or connector (canister solenoid valve - engine compartment fuse and relay box)







#### 5 Check canister solenoid valve control circuit

- a. Disconnect the ECM connector E-067.
- b. Check wire harness between canister solenoid valve connector terminal and ECM connector terminal.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-015 (2) - E-001 (B50)	Always	Continuity

# 06 **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-015 (2) or E- 001 (B50) - Body ground		
E-015 (2) or E-	Always	No continuity
001 (B50) - Battery positive	\	00 0 00

(E-001) RA13T060780

NG

Repair or replace wire harness connector (canister solenoid valve - ECM)

Check canister solenoid valve

a. Check resistance of canister solenoid valve.

Multimeter Connection	Specified Condition	
Terminal 1 - Terminal 2	26 ± 4 Ω (20°C)	

b. With battery voltage applied between terminals 1 and 2, valve should open when air is sucked into the valve; with battery voltage not applied, valve should close when air is sucked into the valve.

NG

Replace canister solenoid valve

OK

- 7 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0443-11, P0443-12 or P0443-13 still exists.

NG

Replace ECM

OK


System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

06



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




021 62 99 92 92

DTC	P0481-13	Cooling Fan Driver 2 (High) Circuit Open
DTC	P0480-13	Cooling Fan Driver 1 (Low) Circuit Open
DTC	P0480-11	Cooling Fan Driver 1 (Low) Circuit Short to Ground
DTC	P0480-12	Cooling Fan Driver 1 (Low) Circuit Short to Battery
DTC	P0481-11	Cooling Fan Driver 2 (High) Circuit Short to Ground
DTC	P0481-12	Cooling Fan Driver 2 (High) Circuit Short to Battery





021 62 99 92 92



DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0481-13	Cooling Fan Driver 2 (High) Circuit Open		
P0480-13	Cooling Fan Driver 1 (Low) Circuit Open		
P0480-11	Cooling Fan Driver 1 (Low) Circuit Short to Ground		Wire harness or connector
P0480-12	Cooling Fan Driver 1 (Low) Circuit Short to Battery	Ignition switch ON Engine running	<ul><li>Cooling fan control module (relay)</li><li>ECM</li></ul>
P0481-11	Cooling Fan Driver 2 (High) Circuit Short to Ground		
P0481-12	Cooling Fan Driver 2 (High) Circuit Short to Battery		

# DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

#### CAUTION

06

• When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM ground point E-043 (See page 06-19).

NG

Repair or replace ground wire harness or ground point

OK




# 2 Check cooling fan control relay

- a. Remove high speed fan relay and low speed fan relay from engine compartment fuse and relay box.
- b. Check the cooling fan relays.

NG

Repair or replace relay



OK

3 Check cooling fan control relay circuit voltage


00

a. Check voltage of cooling fan control relay connector terminals.

Multimeter Connection	Condition	Specified Condition
-067 (138, 121) - Body ground	Ignition switch ON	11 to 14 V

NG

Check engine compartment fuse and relay box, repairor replace wire harness or connector



ОК

06

# 4 Check cooling fan high speed control circuit

- a. Disconnect the ECM connector E-041.
- b. Check wire harness between fan control module connector and ECM (2) connector.

### **Check for Open**


Multimeter Connection	Condition	Specified Condition
E-041 (A46) - E- 067 (121)	Always	Continuity

#### **Check for Short**

06

Multimeter Connection	Condition	Specified Condition
E-041 (A46) or E-067 (121) - Body ground	Always	No continuity
E-041 (A46) or E-067 (121) - Battery positive	Always	No continuity

NG Repair or replace wire harness



ок

# حبتال توجيب كاللت خوديور

# Check cooling fan low speed control circuit


- a. Disconnect the ECM connector E-041.
- b. Check wire harness between fan control module connector and ECM (2) connector.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-041 (A43) - E-067 (138)	Always	Continuity

#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-041 (A43) or E-067 (138) - Body ground	Always	No continuity
E-041 (A43) or E-067 (138) - Battery positive	Always	No continuity



NG

Repair or replace wire harness



# 6 Check cooling fan high speed power supply circuit

- a. Disconnect the fan control module connector E-045.
- b. Check wire harness between fan control module connector E-045 and engine compartment fuse and relay box connector.

#### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-045 (3) - E-067 (120)	Always	Continuity


#### **Check for Short**

	Multimeter Connection	Condition	Specified Condition
	E-045 (3) or E- 067 (120) - Body ground	Always	No continuity
~	E-045 (3) or E- 067 (120) -	) as ziwaya g j s	140 dollaridity
1	Battery positive	التعميكا	مازمانه درسجت

NG

Repair or replace wire harness

021 62 99 92 92



www.digitalkhokro



# 7 Check cooling fan low speed power supply circuit

- a. Disconnect the fan control module connector E-045.
- b. Check wire harness between fan control module connector E-045 and engine compartment fuse and relay box connector.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-045 (2) - E-067 (135)	Always	Continuity

#### Check for Short

Multimeter Connection	Condition	Specified Condition
E-045 (2) or E- 067 (135) - Body ground	Always	No continuity
E-045 (2) or E- 067 (135) - Battery positive	Aways	THE CONTINUITY

NG

Repair or replace wire harness

اولین سامانه دیجیتال تعمیرکاران خودرو د

OK


- 8 Check cooling fan ground circuit
- a. Disconnect the fan control module connector E-045.
  - b. Check wire harness between fan control module connector E-045 and engine compartment fuse and relay box connector.

#### **Ground Inspection**

Multimeter Connection	Condition	Specified Condition
E-045 (1) - Body ground	Always	Continuity

NG >

Repair or replace wire harness







- 9 Replace fan control module, and check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0480-13, P0481-13, P0480-11, P0480-12, P0481-11 or P0481-12 still exists.

NG

Replace ECM

OK


System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

06



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران




021 62 99 92 92

DTC	P0560-16	ECU Power Supply Circuit Voltage Below Threshold
DTC	P0560-17	ECU Power Supply Circuit Voltage Above Threshold





021 62 99 92 92



DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0560-16	ECU Power Supply Circuit Voltage Below Threshold	Ignition switch ON	<ul><li>Fuse</li><li>Wire harness or connector</li><li>Battery</li></ul>
P0560-17	ECU Power Supply Circuit Voltage Above Threshold		Battery terminal     ECM

Confirm that battery voltage is over 12 V before performing following procedures.

- · Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
  - Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
  - Start engine and warm it up to normal operating temperature, and then select Read Code.
  - If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
  - If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### **CAUTION**

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

1 Check battery voltage

a. Check if battery voltage is normal.

. Officer if battery voltage to fromital.

Recharge or replace battery

www.digitalkhodro.com

OK

2 Check battery terminal

a. Check if battery terminals are loose or corroded.

> Tighten or replace battery terminal

OK

NG

- 3 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check the ECM ground point E-043 (See page 06-19).

NG

Repair or replace ground wire harness or ground point

ОК

- 4 Check ECM connector
- a. Disconnect the ECM connector E-041.
- b. Check the ECM connector.

NG

Repair or replace ECM connector

ОК

06


- 5 Check ECM power supply voltage (battery voltage)
- a. Check voltage between terminal of ECM connector E-041 and body ground.

### حودرو سامانه ( Check for Open م

Multimeter Connection	Condition	Specified Condition
E-041 (A54) - Body ground	Always	11 to 14 V

ок

Go to step 8



NG

- 6 Check ECM fuse
- a. Unplug ECM fuse EF26(10A) from engine compartment fuse and relay box.
- b. Check resistance of fuse EF26.

Standard resistance: less than 1  $\Omega$ 

NG

Replace ECM fuse





### 7 Check wire harness and connector (ECM - engine compartment fuse and relay box)


### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-041 (A54) - E- 067 (75)	Always	Continuity

### **Check for Short**

06

Multimeter Connection	Condition	Specified Condition
E-041 (A54) or E- 067 (75) - Body ground	Always	No continuity
E-041 (A54) or E- 067 (75) - Battery positive	Always	No continuity



NG

Repair or replace wire harness or connector




### بالبدين امانه درحت البتهم بكابات خمد مح

- 8 Check ECM power supply voltage (ignition switch voltage)
- a. Turn ignition switch to ON.
- b. Check voltage between terminals of ECM connector E-041.

Multimeter Connection	Condition	Specified Condition
E-041 (A22) - E- 067 (39)	Ignition switch ON	11 to 14 V

ок 🕽

Go to step 12







### 9 Check ECM fuse

- a. Unplug fuse EF07(10A) from instrument panel fuse and relay box.
- b. Check fuse EF07(10A) on instrument panel fuse and relay box.

Standard resistance: less than 1  $\Omega$ 

NG Replace fuse

OK

10 Check the ignition switch assembly (See page 15-12).

NG

Replace ignition switch assembly

OK

06

Repair or replace instrument panel fuse and relay box or wire harness (instrument panel fuse and relay box - ignitionswitch)

00

00

11 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTC.
  - b. Refer to "DTC Confirmation Procedure".
  - c. Check if DTC P0560-16 or P0560-17 still exists.

NG Replace ECM

21 62 99 92 92

www.digitalk

OK COM

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0645-13	Air Conditioner 1 (Relay I/O) Circuit Open	
DTC	P0645-11	Air Conditioner 1 (Relay I/O) Circuit Short to Ground	
DTC	P0645-12	Air Conditioner 1 (Relay I/O) Circuit Short to Battery	

06






021 62 99 92 92

www.digitalkhodro.com





DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0627-13	ECU Power Supply Circuit Voltage Below Threshold		A/C compressor relay
P0645-11	Air Conditioner 1 (Relay I/O) Circuit Short to Ground	Ignition switch ON Engine running	Wire harness or connector     Battery
P0645-12	Air Conditioner 1 (Relay I/O) Circuit Short to Battery		• EGM

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### **CAUTION**

06

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### ولین سامانه دیجیتال تعمیرکاران حودرو در ا

### **Diagnosis Procedure**

## Check ECM ground point

- a. Check if battery voltage is normal.
- b. Check the ECM ground point E-043 (See page 06-19).

NG >

Repair or replace ground wire harness or ground point



### 06


### 2 Check A/C compressor relay

- a. Unplug A/C compressor relay connector terminal from engine compartment fuse and relay box.
- b. Check the A/C compressor relay terminal.

Multimeter Connection	Condition	Specified Condition
Terminal 30 - Terminal 87	Always	No continuity
Terminal 30 - Terminal 87	Always	Continuity (Battery voltage is applied between terminals 1 and 2)

NG

Replace A/C compressor relay





### 3 Check A/C compressor relay control circuit

0.0


- a. Disconnect the engine compartment fuse and relay box connector E-067.
  - b. Disconnect the ECM connector E-041.
  - c. Check wire harness between ECM connector terminal and engine compartment fuse and relay box connector terminal.

### **Check for Open**

2 33 32 32				
Multimeter Connection	Condition	Specified Condition		
E-067 (98) - B- 041 (A44)	Always	Continuity		

### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-067 (98) or B- 041 (A44) - Body ground	Always	No continuity
E-067 (98) or B- 041 (A44) - Battery positive	Always	No continuity



NG

06

Repair or replace wire harness or connector (ECM- engine compartment fuse and relay box)

OK

### 4 Check A/C compressor relay power supply circuit

- a. Disconnect the engine compartment fuse and relay box connector E-067.
- b. Disconnect the A/C compressor relay connector E-018.
- c. Check wire harness between engine compartment fuse and relay box connector E-067 and A/C compressor relay connector E-018.

### **Check for Open**


Multimeter Connection	Condition	Specified Condition
E-067 (99) - E- 018 (1)	Always	Continuity

### **Check for Short**

Multimeter Connection		Condition	Specified Condition
	E-067 (99) or E-		
į	018 (1) - Body ground	Always	No continuity
	E-067 (99) or E- 018 (1) - Battery positive	Always	No continuity

NG

Replace wire harness between engine compartment fuse and relay box connector and A/C compressor relay connector.



www.digitalkhodro.com

ОК




### 5 Check A/C compressor ground wire harness

- a. Turn ignition switch to LOCK.
- b. Check voltage between A/C compressor wire harness and body ground.

Multimeter Connection	Condition	Specified Condition	
E-018 (2) - Body ground	Ignition switch LOCK	0 V	

NG

Go to step 6



OK

6 Check main relay

NG

Repair or replace engine compartment fuse and relay box or wire harness

ولین سامانه دیجیتال تعمیرکاران خودرو در ایرا

OK

- 7 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0645-13, P0646-11 or P0647-12 still exists.

NG Replace ECM

ОК

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0504-13	Brake Signal Circuit Open
DTC	P0504-62	Brake Signal Compare Failure
DTC	P0504-67	Brake Signal Incorrect After Event
DTC	P0504-86	Brake Signal Invalid

06






021 62 99 92 92

www.digitalkhodro.com





DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0504-13	Brake Signal Circuit Open		• Fuse
P0504-62	Brake Signal Compare Failure	Ignition switch ON	<ul><li> Fuse</li><li> Brake switch</li><li> Wire harness or connector</li></ul>
P0504-67	Brake Signal Incorrect After Event		ECM
P0504-86	Brake Signal Invalid		

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### **CAUTION**

06

When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### اولین سامانه در جینال نافید Diagnosis Procedure

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point E-043 (See page 06-19).

NG Repair or replace ground wire harness or ground point


ОК



- Check fuse
- a. Remove fuses EF07, EF24 from engine compartment fuse and relay box.
- b. Check if fuses EF07, EF24 are normal.

NG

Replace fuse




OK

Check brake switch power supply circuit

00

- a. Disconnect the brake switch connector I-013 (arrow).
- b. Check the brake switch connector.

Repair or replace connector




OK

Check brake switch

- a. Remove the brake switch.
- b. Check the brake switch.

Multimeter Connection	Condition	Specified Condition
Terminal 1 - Terminal 3	Brake pedal depressed (switch	Continuity
Terminal 4 - Terminal 2	pin released)	No continuity





### 06 - SQRD4G15B ENGINE MANAGEMENT SYSTEM

Multimeter Connection	Condition	Specified Condition
Terminal 1 - Terminal 3	Brake pedal released (switch	No continuity
Terminal 4 - Terminal 2	pin pushed)	Continuity

NG

06

Replace brake switch

OK

5 Check brake switch power supply voltage


a. Turn ignition switch to LOCK and check voltage between terminal 1 of brake switch connector and body ground.

b. Turn ignition switch to ON and check voltage between terminal 4 of brake switch connector and body ground.

Multimeter Connection	Condition	Specified Condition
I-013 (1) - Body ground	Ignition switch ON	11 - 14 V
I-013 (4) - Body ground	Igilition switch Oil	11 - 14 V

OK Go to step 6

سامانه ديجيتال نعميا كاران جو



021 62 99 92 92


www.digitalkhong

### Check brake switch power supply circuit

- a. Check the fuses EF24 and EF07.
- b. Disconnect the engine compartment fuse and relay box connector E-067.
- c. Check wire harness between brake switch connector terminals and engine compartment fuse and relay box connector terminals.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
I-013 (1) - E-067 (73)	Always	Continuity
I-013 (4) - E-067 (39)	Always	Continuity



	C	h	е	C	k	f	O	ľ	S	h	10	r	t
--	---	---	---	---	---	---	---	---	---	---	----	---	---

	Multimeter Connection	Condition	Specified Condition
	I-01 <mark>3 (1) or E-</mark> 067 (73) - Body ground	Always	No continuity
	I-013 (1) or E-067 (73) - Battery positive	Always	No continuity
	I-013 (4) or E-067 (39) - Battery positive	Always	No continuity
)	I-013 (4) or E-067 (39) - Battery positive	Always	No continuity

NG

Replace fues, repair or replace wire harness orconnector (brake switch engine compartment fuse and relay box)

### 7 Check brake switch control circuit

- a. Disconnect the ECM connector E-041.
- b. Check wire harness between brake switch connector terminals and ECM connector terminals.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition	
I-013 (3) - E-041 (A17)	Always	Continuity	
I-013 (2) - E-041 (A5)	Always	Continuity	

# 1 1 2 3 3 3 1-013

### **Check for Short**

06

	Multimeter Connection	Condition	Specified Condition
	I-013 (3) or E-041 (A17) - Body ground	, II.	
	I-013 (3) or E-041 (A17) - Battery positive	Always	No continuity
2	I-013 (2) or E-041 (A5) - Battery	کرو Always که (	No continuity
	positive I-013 (2) or E-041 (A5) - Battery	نال تعمیرکار	سامانه ديجيا
	positive		

NG Repair or replace wire harness or connector (brake switch - ECM)

www.digitalkhodro.com

ок

### 8 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0504-13, P0504-62, P0504-67 or P0504-86 still exists.

NG Replace ECM

ОК

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0604-62	RAM Memory Signal Compare Failure
DTC	P0605-41	ROM (EPROM) Memory General Checksum Failure
DTC	P0605-49	ROM (EPROM) Memory Internal Electronic Failure

DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0604-62	RAM Memory Signal Compare Failure		
P0605-41	ROM (EPROM) Memory General Checksum Failure	Ignition switch ON	Wire harness or connector
P0605-49	ROM (EPROM) Memory Internal Electronic Failure	Ignition switch ON  • ECM	
P0601-44	EEPROM Memory Data Memory Failure		

0.0

06

### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).

00

- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### CAUTION

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check the ECM ground point E-043 (See page 06-19).

NG Repair or replace ground wire harness or ground point



- 2 Check ECM connector
- a. Disconnect the ECM connectors E-001 and E-041.
- b. Check if connectors are normal.

NG

Repair or replace connector



Replace ECM

06

- Use X-431 3G diagnostic tester to match ECM, and check for DTCs again
- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0601-44, P0604-62, P0605-41 or P0605-49 still exists.

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

د تختیار حوداه

شرکت دیجیتال خودرو سامانه (مسئولیت محدود

اولین سامانه دیجیتال تعمیرکاران خودرو در ایرار


021 62 99 92 92

www.digitalkhodro.con

ng	
ng	
ed	0

DTC	P1610-51	Immo Secret Key and Security Code Not Programmed Not Programmed
DTC	P1616-81	IMMO Authentication Fail Invalid Serial Data Received
	•	
DTC	P1617-87	IMMO Authentication Message not Received Missing Message
DTC	P1618-87	Fail to Write EOL Immobilizer Data into EEProm Missing Message
DTC	P1614-86	Immo Transferred Transponder Authentication is Failed SignalInvalid





DTC	DTC Definition	DTC Detection Condition	Possible Cause
P1610-51	Immo Secret Key and Security Code Not Programmed Not Programmed		
P1616-81	IMMO Authentication Fail Invalid Serial Data Received		
P1617-87	IMMO Authentication Message not Received Missing Message	Ignition switch ON	<ul><li>Anti-theft module</li><li>ECM</li><li>Wire harness or connector</li></ul>
P1618-87	Fail to Write EOL Immobilizer Data into EEProm Missing Message		• Wife flamess of conflector
P1614-86	Immo Transferred Transponder Authentication is Failed Signal Invalid		

06

### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### **CAUTION**

• When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

- 1 Rematch anti-theft system
- a. Turn ignition switch to LOCK.
- b. Check if information in anti-theft module can be read.

NG

Replace a new anti-theft module and match it.



2 Read SK code in ECM

NG Program ECM again

ОК

3 Check if SK codes in ECM and anti-theft module are the same.

NG Program ECM again after returning ECM

06

ОК

OK

4 Check if SK codes in ECM and anti-theft module are the same again.

0.0

NG Replace ECM and program it again


5 Check ECM power supply and ground

a. Check ECM power supply and ground

	Multimeter Connection	Condition	Specified Condition
	E-041 (A54, A22) - Body ground	Ignition switch ON	11 to 14 V
)	E-041 (A52, A53) - Body ground	ignition switch on	0 V

NG `

Repair or replace connector



ОК



- 6 Use X-431 3G diagnostic tester to match ECM, and check for DTCs again
- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P1610-51, P1614-86, P1616-81, P1617-87 or P1618-87 still exists.



Replace ECM

OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

06



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



021 62 99 92 92

www.digitalkhodro.com

**Lost Communication with BSM DTC** U0129-87 ESP ECM(A) (E-041) E-051) 06 خودر و سامانه (مسئول (E-041) B 021 62 99 92 92 A55 A54 A53 A52 A51 A50 A49 13 E-051) EA13T060280



DTC	DTC Definition	DTC Detection Condition	Possible Cause
U0129-87	Lost Communication with BSM	Ignition switch ON Engine running	<ul><li>CAN line or connector</li><li>ESP (ABS)</li><li>ECM</li></ul>

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- · Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### CAUTION

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check the ECM ground point E-043 (See page 06-19).

NG

Repair or replace ground wire harness or ground point

www.digitalkhodro.com

ок

06

### Replace ECM

- 2 Check ECM connector and ESP (ABS) connector.
- a. Disconnect the ECM connector E-041.
- b. Disconnect the ESP (ABS) connector B-061.
- c. Check if connectors are normal.

NG

Repair or replace connector

ОК



### 3 Check CAN line

a. Check the CAN line.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-041 (A11) - B- 051 (14)	Always	Continuity
E-041 (A23) - B- 061 (2)	Always	Continuity


### **Check for Short**

06

Multimeter Connection	Condition	Specified Condition
E-041 (A11) or B- 051 (14) - Body ground	Always	No continuity
E-041 (A11) or B- 051 (14) - Battery positive	Always	No continuity
E-041 (A23) or B- 061 (2) - Body ground	Always در و سامانه (	No continuity
E-041 (A23) or B-		
061 (2) - Battery positive	Always	No continuity

NG

Repair or replace CAN line



www.digitalkhodro.com

## 4 Replace ECM, and check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC U0129-87 still exists.

NG Replace ESP (ABS)

ОК

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

**Lost Communication with TCU DTC** U0101-87 ECM(A) (E-041) CAN1-L CAN1-H 06 شرکت دیجیتال خودرو سامانه (مسئولید www.digitalkhodro.com **-**7H-A56 A55 A54 A53 A52 A51 A50 A49 (E-041) E-069 B A24A23A22A21A20A19A18A17A16A15A14A13 A12A11A10A9 A8 A7 A6 A5 A4 A3 A2 A1 31 32 33 34 35 36 37 38 39 40 47 48

EA13T060270

DTC	DTC Definition	DTC Detection Condition	Possible Cause
U0101-87	Lost Communication with TCU	Ignition switch ON Engine running	<ul><li>CAN line or connector</li><li>TCU</li><li>ECM</li></ul>

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### CAUTION

06

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check the ECM ground point E-043 (See page 06-19).

NG Repair or replace ground wire harness or ground point

www.digitalkhodro.com

OK

- 2 Check ECM connector and TCU connector.
- a. Disconnect the ECM connector E-041.
- b. Disconnect the TCU connector E-069.
- c. Check if connectors are normal.

NG Repair or replace connector

ОК

### 3 Check CAN line

a. Check the CAN line.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-041 (A11) - E- 069 (32)	Always	Continuity
E-041 (A23) - E- 069 (31)	Always	Continuity

### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-041 (A11) or E- 069 (32) - Body ground	Always	No continuity
E-041 (A11) or E- 069 (32) - Battery positive	Always	No continuity
E-041 (A23) or E- 069 (31) - Body ground	Always درو سامانه (	No continuity
E-041 (A23) or E-		
069 (31) - Battery positive	Always	No continuity

06

NG Repair or replace CAN line

4 Replace ECM, and check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC U0101-87 still exists.

NG Replace TCU

OK

www.digitalkhodro.com

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0403-11	EGR Control Circuit Short to Ground
DTC	P0403-12	EGR Control Circuit Short to Battery
DTC	P0403-13	EGR Control Circuit Open
DTC	P0403-61	EGR Control Circuit Signal Calculation Failure

06






021 62 99 92 92

www.digitalkhodro.com





DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0403-11	EGR Control Circuit Short to Ground	Ignition switch ON	EGR valve
P0403-12	EGR Control Circuit Short to Battery		
P0403-13	EGR Control Circuit Open	Engine running	<ul><li>Wire harness or connector</li><li>ECM</li></ul>
P0403-61	EGR Control Circuit Signal Calculation Failure		

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### **CAUTION**

06

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point E-043 (See page 06-19).

NG >


Repair or replace ground wire harness or ground point



- a. Disconnect the EGR valve connector E-002 (arrow).
- b. Check the EGR valve connector.

NG )

Repair or replace connector





06

3 Check EGR valve drive motor power supply voltage

- a. Turn ignition switch to ON.
- b. Check voltage between connector terminal and body ground.
- c. Check wire harness between connector terminals.

Multime <mark>te</mark> r Connection	Condition	Specified Condition	
E-002 (4) - Body ground	Ignition switch ON	11 - 14 V	

OK

Go to step 5

021 62 99 92 92





### 4 Check EGR valve drive motor power supply circuit and fuse EF35

- a. Turn ignition switch to LOCK.
- b. Check if fuse EF35 is normal.
- c. Disconnect the engine compartment fuse and relay box connector E-067.
- d. Check wire harness between connector terminals.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-002 (4) - E-007 (6)	Always	Continuity
E-035 (6) - E-067 (93)		

## 

### **Check for Short**

06

	Multimeter Connection	Condition	Specified Condition	
	E-002 (4), E-007 (6), E-035 (6) or		<u>un</u>	
>	E-067 (93) - Body ground E-002 (4), E-007 (6), E-035 (6) or	Always 933	No continuity	کت
Į	E-067 (93) - Battery positive	نال تعمیرکار	سامانه ديجيا	

NG

Repair or replace wire harness or connector (EGR valve - engine compartment fuse and relay box)

www.digitalkhodro.com

### 5 Check EGR valve drive motor control circuit

- a. Disconnect the ECM connector E-001.
- b. Check wire harness between connector terminals.


### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-002 (4) - E-001 (B26)	Always	Continuity

### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-002 (4) or E- 001 (B26) - Body ground	Always	No continuity
E-002 (4) or E- 001 (B26) - Battery positive	Always	140 continuity

NG Repair or replace wire harness or connector (EGR valve - ECM)



06

ок

### ولين سامانه در حيتال تعميركاران خودرود

### 6 Check EGR valve drive motor control circuit


- a. Remove the EGR valve.
- b. Check the EGR valve drive motor.

Multimeter Connection	Condition	Specified Condition
Terminal 4 - Terminal 6	Always	8 Ω

c. When battery voltage is applied between terminals 4 and 6, control valve should move quickly.



Replace EGR valve





### 7 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0403-11, P0403-12, P0403-13 or P0403-61 still exists.

NG

Replace ECM

OK


System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

06



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



021 62 99 92 92


DTC	P0409-12	EGR Sensor Circuit Short to Battery
DTC	P0409-14	EGR Sensor Circuit Short to Ground or Open

06





021 62 99 92 92





P0409-12	DTC	DTC Definition	DTC Detection Condition	Possible Cause
EGR Sensor Circuit Engine running • Wire namess or connector	P0409-12		Ignition switch ON	
Open • ECM	P0409-14	Short to Ground or		<ul><li>Wire harness or connector</li><li>ECM</li></ul>

### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### **CAUTION**

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

## Diagnosis Procedure

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point E-043 (See page 06-19).

NG

Repair or replace ground wire harness or ground point


www.digitalkhodro.com

ОК

- 2 Check EGR valve connector
- a. Disconnect the EGR valve connector E-002 (arrow).
- b. Check the EGR valve connector.

NG >

Repair or replace connector





06




- 3 Check EGR valve sensor power supply
- a. Turn ignition switch to ON.
- b. Check voltage between sensor connector terminals.

Multimeter Connection	Condition	Specified Condition
E-002 (1) - E-002 (2)	Ignition switch ON	5 V

ок >

Go to step 5



NG


- 4 Check EGR valve sensor power supply circuit
- a. Turn ignition switch to LOCK.
- b. Disconnect the ECM connector E-001.
- c. Check wire harness between connector terminals.

### **Check for Open**

.,		
Multimeter Connection	Condition	Specified Condition
E-002 (1) - E-001 (B29)	Always	Continuity
E-002 (2) - E-001 (B32)	Always	Continuity

### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-002 (1), E-001 (B29), E-002 (2) or E-001 (B32) - Body ground	Δlwave	No continuity
E-002 (1), E-001 (B29), E-002 (2) or E-001 (B32) - Battery positive	Always	No continuity



NG

Repair or replace wire harness or connector (EGR valve - ECM)



#### 5 Check EGR valve sensor signal circuit


- a. Disconnect the ECM connector E-001.
- b. Check wire harness between connector terminals.


### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-002 (3) - E-001 (B08)	Always	Continuity

#### **Check for Short**

	Multimeter Connection	Condition	Specified Condition
	E-002 (3) or E- 001 (B08) - Body ground	Always	No continuity
1.3	E-002 (3) or E- 001 (B08) - Battery positive	درو سامانه (	ديجيتال خو








#### 6 Check the EGR valve sensor.

- a. Remove the EGR valve.
- b. Check the EGR valve drive motor.

Multimeter Connection	Condition	Specified Condition
Terminal 1 - Terminal 2	Always	2340 Ω ~ 3380 Ω

c. Apply battery voltage to terminals 4 and 6, so that EGR valve can move; check if resistance between terminals 1 and 3, and between terminals 2 and 3 changes equally in reverse direction.



Replace EGR valve



ОК

- 7 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0409-12 or P0409-14 still exists.

NG

Replace ECM


ОК

06

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




021 62 99 92 92


DTC	P1600-11	Thermostat Circuit Short to Ground
DTC	P1600-12	Thermostat Circuit Short to Battery
DTC	P1600-13	Thermostat Circuit Open

06





021 62 99 92 92



DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0409-12	EGR Sensor Circuit Short to Battery	Ignition switch ON	Electronic thermostat
P0409-14	EGR Sensor Circuit Short to Ground or Open	Engine running	<ul><li>Wire harness or connector</li><li>ECM</li></ul>

### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### CAUTION

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### Diagnosis Procedure

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point E-043 (See page 06-19).

NG

Repair or replace ground wire harness or ground point

www.digitalkhodro.com




### 2 Check electronic thermostat connector

- a. Disconnect the electronic thermostat connector E-036 (arrow).
- b. Check the electronic thermostat connector.

NG

Repair or replace connector








- 3 Check electronic thermostat power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-036 (1) - Body ground	Ignition switch ON	11 - 14 V

ок

06

Go to step 5



NG


- 4 Check electronic thermostat power supply circuit and fuse EF35
- a. Turn ignition switch to LOCK.
- b. Check if fuse EF35 is normal.
- c. Disconnect the engine compartment fuse and relay box connector E-067.
- d. Check wire harness between connector terminals.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-036 (1) - E-067 (93)	Always	Continuity

### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-036 (1) or E- 067 (93) - Body ground	Always	No continuity
E-036 (1) or E- 067 (93) - Battery positive	Always	NO continuity



NG

Repair or replace wire harness or connector (electronic thermostat - engine compartment fuse and relay box)

ОК

### 5 Check electronic thermostat control circuit

- a. Disconnect the ECM connector E-041.
- b. Check wire harness between connector terminals.

#### **Check for Open**


Multimeter Connection	Condition	Specified Condition
E-036 (2) - E-041 (A34)	Always	Continuity

### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-036 (2) or E- 041 (A34) - Body ground E-036 (2) or E- 041 (A34) -	) at Always 938	No continuity
Battery positive	14	بامانه در جرنا

NG

Repair or replace wire harness of connector (electronic thermostat - ECM)



www.digitalkhodro.com


# ОК

### 6 Check electronic thermostat

- a. Remove the electronic thermostat.
- b. Check resistance of electronic thermostat.

Multimeter Connection	Condition	Specified Condition
Terminal 1 - Terminal 2	Always	15 Ω

c. Heat thermostat in water to 100°C, then apply battery voltage to terminals 1 and 2 of thermostat, observe if opening travel is 8 mm.





#### 06 - SQRD4G15B ENGINE MANAGEMENT SYSTEM



Energizing time cannot be above 60 seconds ever time.

NG

Replace electronic thermostat

ОК

7 Check for DTCs

06

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P1600-11, P1600-12 or P1600-13 still exists.

NG Replace ECM

OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

021 62 99 92 92


DTC	P0010-11	VVT Driver Circuit Short to Ground
DTC	P0010-12	VVT Driver Circuit Short to Battery
DTC	P0010-13	VVT Driver Circuit Open
DTC	P0010-14	VVT Driver Circuit Short to Ground or Open

06





021 62 99 92 92



DTC	DTC Definition	DTC Detection Condition	Possible Cause
P0010-11	VVT Driver Circuit Short to Ground		
P0010-12	VVT Driver Circuit Short to Battery	Ignition switch ON	VVT control valve
P0010-13	VVT Driver Circuit Open	Engine running	<ul><li>Wire harness or connector</li><li>ECM</li></ul>
P0010-14	VVT Driver Circuit Short to Ground or Open		

### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### **CAUTION**

 When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point E-043 (See page 06-19).

NG >

Repair or replace ground wire harness or ground point


OK

### 2 Check VVT control valve

- a. Disconnect the VVT control valve connector E-020 (arrow).
- b. Check the VVT control valve connector.

NG

Repair or replace connector



06



### 3 Check VVT control valve power supply voltage


- a. Turn ignition switch to ON.
- b. Check voltage between connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-020 (1) - Body ground	Ignition switch ON	11 - 14 V

ОК

Go to step 5

021 62 99 92 92



NG

### 4 Check VVT control valve power supply circuit and fuse EF35

- a. Turn ignition switch to LOCK.
- b. Check if fuse EF35 is normal.
- c. Disconnect the engine compartment fuse and relay box connector E-067.
- d. Check wire harness between connector terminals.

### **Check for Open**


Multimeter Connection	Condition	Specified Condition
E-020 (1) - E-067 (75)	Always	Continuity

### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-036 (1) or E- 067 (93) - Body		0
ground	Always	No continuity
E-036 (1) or E-	Airrayo	The continuity
067 (93) - Battery		00 0 00
positive	\a :  a   a	. II.

NG

Repair or replace wire harness or connector (VVT control valve - engine compartment fuse and relay box)



06




### 021 62 99 92 92

### Check VVT control valve control circuit

- a. Disconnect the ECM connector E-041.
- b. Check wire harness between connector terminals.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
E-020 (2) - E-041 (B35)	Always	Continuity



#### **Check for Short**

Multimeter Connection	Condition	Specified Condition
E-020 (2) or E- 041 (B35) - Body ground	Alwaye	No continuity
E-020 (2) or E- 041 (B35) - Battery positive	Always	NO continuity

NG

Repair or replace wire harness or connector (VVT control valve - ECM)

06

OK


- 6 Check VVT control valve
- a. Remove the VVT control valve.
- b. Check the VVT control valve.

Multimeter Connection	Condition	Specified Condition
Terminal 1 - Terminal 2	Always	ديجي۩ڰڶ خود

c. When battery voltage is applied between terminals 1 and 2, control valve should move quickly.

NG

Replace VVT control valve



2 99 92 92

www.digitallnoxrd.com

- 7 Check for DTCs
- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0010-11, P0010-12, P0010-13 or P0010-14 still exists.

NG Replace ECM

OK

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.


DTC	P0704-23	Clutch Switch Signal Stuck Low
DTC	P0704-24	Clutch Switch Signal Stuck High

06





021 62 99 92 92



DTC	DTC Definition	DTC Detection Condition	Possible Cause
PU/U4-23	Clutch Switch Signal Stuck Low	Ignition switch ON	Clutch switch     Wire harness or connector
	Clutch Switch Signal Stuck High	Engine running	ECM

#### **DTC Confirmation Procedure**

Confirm that battery voltage is over 12 V before performing following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Using X-431 3G diagnostic tester, record and clear DTCs stored in ECM.
- Start engine and warm it up to normal operating temperature, and then select Read Code.
- If DTC is detected, malfunction indicated by DTC is current. Go to diagnosis procedure Step 1.
- If DTC is not detected, malfunction indicated by DTC is intermittent (See page 06-19).

### **CAUTION**

When performing circuit diagnosis and test, always refer to circuit diagram for specific circuit and component information.

شرکت دیجیتال خودرو س

### **Diagnosis Procedure**

- 1 Check ECM ground point
- a. Check if battery voltage is normal.
- b. Check the ECM ground point E-043 (See page 06-19).

NG

Repair or replace ground wire harness or ground point




ОК

### 2 Check clutch switch connector

- a. Disconnect the clutch switch connector I-009 (arrow).
- b. Check the clutch switch connector.

NG `

Repair or replace connector







### 3 Check clutch switch

- a. Remove the clutch switch.
- b. Check the clutch switch.

Multimeter Connection	Condition	Specified Condition
Terminal 1 -	ON (not pushed)	Continuity
Terminal 2	OFF (pushed)	No continuity

Ω 1 2 1 2 RA13T061003

06

NG

Replace clutch switch



### 4 Check clutch switch circuit


- a. Turn ignition switch to LOCK.
- b. Disconnect the ECM connector E-041.
- c. Check wire harness between clutch switch connector terminal and ECM connector terminal.

### Check for Open (a) خودر و سامانه (

Multimeter Connection	Condition	Specified Condition
I-009 (2) - E-041 (A6)	Always	Continuity

### **Check for Short**

Multimeter Connection	Condition	Specified Condition
I-009 (2) or E-041 (A6) - Body ground	Always	No continuity
I-009 (2) or E-041 (A6) - Battery positive		140 continuity



NG

Repair or replace wire harness or connector (clutch switch - ECM)





### 5 Check clutch switch ground circuit


- a. Check the ground point I-005.
- b. Check wire harness between clutch switch connector terminal and body ground.

### **Check for Open**

Multimeter Connection	Condition	Specified Condition
I-009 (1) - Body ground	Always	Continuity

NG )

Repair or replace wire harness or connector (clutch switch - body ground)



06

OK

### 6 Check for DTCs

- a. Using X-431 3G diagnostic tester, read ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0704-23 or P0704-24 still exists.

Replace ECM ART UNITED TO SUIT OF THE PROPERTY OF THE PROPERTY

021 62 99 92 92

System is operating normally. Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

ОК

### **Engine Problem Symptom Diagnosis**

### **Engine Problem Symptom Diagnosis**

Perform primary inspection first before performing malfunction diagnosis procedures:

- 1. Confirm that engine malfunction indicator operates normally;
- 2. Using diagnostic tester, check that no error messages are recorded;
- 3. Confirm that malfunction complained by customer is present, and the condition under which malfunction occurs.

Then, perform appearance inspection:

- 1. Check fuel line for leakage;
- 2. Check if vacuum line is broken or twisted or connected correctly;
- 3. Check intake line for blockage, air leakage, crush or damage;
- 4. Check if high-voltage cable of ignition system is broken or deteriorated, and if ignition sequence is correct;
- 5. Check if wire harness ground points are clean and secure;
- 6. Check each sensor or actuator connector for looseness or poor contact.

#### HINT:

06

If above conditions exist, repair the trouble areas first. Otherwise it will affect the repair work for following trouble diagnosis.

### Diagnostic Help

- 1. Confirm that there are no trouble records for engine;
- Confirm that complained trouble symptoms are present;
- 3. There are no abnormal conditions after performing inspection according to above procedures;
- 4. During servicing, do not ignore vehicle maintenance condition, cylinder pressure, mechanical ignition timing and fuel condition, etc. that can affect the system;
- Replace ECM, and perform a test. If trouble symptom can be eliminated, there may be ECM problem; if trouble symptom still exists, reuse original ECM, repeat procedures, and perform the service again.

### **Problem Symptoms Table**

Symptom	Suspected Area	See page
	Battery	
	Starter motor	
Engine deep not event on events aloudy	Wire harness or ignition switch	
Engine does not crank or cranks slowly while starting	Starter relay	06-19
Willie Starting	ECM, TCM	
	Gear switch (AT)	
	Engine mechanical	
	No fuel in tank	
	Fuel pump	
	Fuel injector	
Engine cranks normally but cannot start	Engine speed sensor	06-19
successfully while starting	Ignition coil	00-19
	Engine immobilizer	
	ECM	
	Engine mechanical	

	Symptom	Suspected Area	See page	
		Water in fuel Fuel pump		
	Difficult to start with hot engine	Coolant temperature sensor Engine speed sensor Ignition coil	06-19	
		Camshaft position sensor Fuel injector Engine mechanical		
	Engine starts normally, but idles roughly or stalls with part load (for example, A/C is ON)	A/C system Fuel injector	06-19	
	Engine starts normally, but idle speed is too high	Throttle valve Vacuum pipe Coolant temperature sensor Ignition timing	06-19	06
		Water in fuel Intake pressure/temperature sensor Intake pipe		
	Low engine speed or stalls when accelerating	Exhaust pipe Ignition timing Throttle position sensor	06-19	7
>	خودرو سامانه (مسئولیت م	Fuel injector Spark plug		
	جیتال تعمیرکاران خودرو در	Intake pressure/temperature sensor Intake pipe		<b>"</b>
6	Slow response when accelerating	Exhaust pipe Ignition timing	06-19 OF O	.com
		Throttle position sensor Fuel injector Spark plug		

### Engine does not crank or cranks slowly while starting Check voltage between two battery posts when engine starts OK: Voltage is 11.5 - 12.5 V NG Replace battery OK 2 Check voltage of starter motor positive post a. Ignition switch remains in START position and check voltage of starter motor positive post. 06 OK: Voltage is 11.5 - 12.5 V Repair or replace starter relay, harnessor ECM OK Check operation of starter motor a. Remove the starter motor. b. Check if there is an open circuit or if it is stuck due to poor lubrication. Repair or replace starter OK Check engine lubricant and gear oil a. If malfunction only occurs in winter, check if starter motor resistance is too strong because of improper engine lubricant and gear oil selection. with Replace lubricant NG appropriate number OK Check engine internal mechanical resistance

a. Check if engine internal mechanical resistance is too strong, causing starter motor not to run or run slowly.

NG and repair engine internal resistance malfunction



Go to Diagnostic Help

06





021 62 99 92 92

### Engine cranks normally but cannot start successfully while starting

1 Check fuel pressure

a. Using a fuel pressure gauge, check the fuel pressure (See page 08-11).

#### **Standard Fuel Pressure**

Condition	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key Lock	400

06

NG

Repair or replace fuel system



2 Using diagnostic tester, observe if any speed signal is output

a. Connect diagnostic tester, start engine and select Read Datastream.

b. Observe if any speed signal is output.

NG

Check and repair engine speed sensor wire harness

OK

3 Check spark plug

a. Remove ignition coil and spark plug of one cylinder, and ground spark plug housing. Start engine, and check if spark is generated.

### OK: Spark is generated

NG )

Check and repair ignition system

ОК

4 Check pressure of cylinder

a. Measure compression of misfiring cylinder (See page 07-16).

NG )

Check engine to confirm cause of low compression

OK


### 5 Check ECM power supply and ground

- a. Disconnect the ECM connector E-041.
- b. Turn ignition switch to ON and check ECM connector terminals.

Multimeter Connection	Condition	Specified Condition
E-041 (A54, A22)	Ignition switch ON	11 to 14 V
E-041 (A52, A53)	Igrition switch ON	0 V

NG

Repair or replace related wire harness



06

ОК

Go to Diagnostic Help

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

021 62 99 92 92

### Difficult to start with hot engine

1 Check fuel pressure

a. Using a fuel pressure gauge, check the fuel pressure (See page 08-11).

#### **Standard Fuel Pressure**

Condition	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key Lock	400

06

NG

Repair or replace fuel system



2 Check spark

a. Remove ignition coil and spark plug of one cylinder, and ground spark plug housing. Start engine, and check if spark is generated.

### OK: Spark is generated

NG

Check and repair ignition system

OK

Discounset coalent temporative concer connector

Disconnect coolant temperature sensor connector, start engine and observe if engine starts successfully at this time

ОК

Check and repair circuit or replace sensor



4 Clamp fuel pump return pipe, measure fuel pressure and observe if fuel pressure rises

NG

Replace fuel pump assembly

OK

5 Check ECM power supply and ground

a. Observe if trouble occurs just after fuel is filled.

NG

Replace fuel



Go to Diagnostic Help

06





121 62 99 92 92

### Difficult to start with cold engine

1 Check fuel pressure

a. Using a fuel pressure gauge, check the fuel pressure (See page 08-11).

#### **Standard Fuel Pressure**

Condition	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key Lock	400

06

NG )

Repair or replace fuel system

ОК

2 Check spark

 Remove ignition coil and spark plug of one cylinder, and ground spark plug housing. Start engine, and check if spark is generated.

OK: Spark is generated

NG

Check and repair ignition system

OK

Disconnect coolant temperature sens

Disconnect coolant temperature sensor connector, start engine and observe if engine starts successfully at this time

021

> 0

Check and repair circuit or replace sensor

NG

4 Depress accelerator pedal slightly, and observe if it is easy to start

NG

Clean throttle valve

ОК

5 Check injector for leakage or blockage

NG

Clean or replace injector

OK

6 Check fuel condition

a. Observe if trouble occurs just after fuel is filled.

NG

Replace fuel

ОК

7 Check pressure of cylinder

a. Measure compression of misfiring cylinder (See page 07-16).

NG

Check engine to confirm cause of low compression

06

OK

Go to Diagnostic Help



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایراز

021 62 99 92 92

Engine speed is normal, but it is difficult to start at anytime

1 Check air filter for blockage, and intake pipe for air leakage

NG

Check and repair intake system

OK

2 Check fuel pressure

a. Using a fuel pressure gauge, check the fuel pressure (See page 08-11).

### **Standard Fuel Pressure**

06

Condition	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key Lock	400

NG

Repair or replace fuel system

OK

3 Check spark plug

a. Check spark plug of each cylinder, and observe if type and gap are as specified.

NG

**Spark Plug Replacement** 

### 021 62 99 92 92

www.digitallhcokro



4 Check spark

a. Remove ignition coil and spark plug of one cylinder, and ground spark plug housing. Start engine, and check if spark is generated.

### OK: Spark is generated

NG

Check and repair ignition system

OK

5	Disconnect coolant temperature sensor connector, start engine and observe if eng successfully at this time	jine starts
ок	Check and repair circuit or replace sensor	
		NG
6	Depress accelerator pedal slightly, and observe if it is easy to start	
NG	Clean throttle valve	
		ОК
7	Check injector for leakage or blockage	
NG	Clean or replace injector	
		ОК
	و ہے دیبیاد ر	
8	Check fuel condition	3
a. Obse	erve if trouble occurs just after fuel is filled.	
NG	Replace fuel	
		ОК
2 99	92 92 www.digitalk	hodr
9	Depress accelerator pedal slightly, and observe if it is easy to start	
a. Meas	sure compression of misfiring cylinder (See page 07-16).	
NG	Check engine to confirm cause of low compression	
10	Check engine ignition sequence and ignition timing	
a. Chec	k if engine ignition sequence and ignition timing are as specified.	
NG	Check and repair ignition timing	
	[	ОК

# Engine starts normally, but idles roughly at anytime 1 Check air filter for blockage, and intake pipe for air leakage NG Check and repair intake system OK 2 Check if throttle is sticking NG Repair or replace throttle 06 OK 3 Check spark plug a. Check spark plug of each cylinder, and observe if type and gap are as specified. NG Spark Plug Replacement 00 Check throttle for carbon deposits Clean throttle valve OK 5 Check injector for leakage or blockage NG Clean or replace injector OK 6 **Check fuel condition** a. Observe if trouble occurs just after fuel is filled. Replace fuel NG OK

06 - SQRD4G15B ENGINE MANAGEMENT SYSTEM



- 7 Check pressure of cylinder
- a. Measure compression of misfiring cylinder (See page 07-16).

NG

Check engine to confirm cause of low compression

OK

- 8 Check engine ignition sequence and ignition timing
- a. Check if engine ignition sequence and ignition timing are as specified.

NG

Check and repair ignition timing

06

OK

Go to Diagnostic Help



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

021 62 99 92 92

06 - SQRD4G15B ENGINE MANAGEMENT SYSTEM

- 7 Check pressure of cylinder
- a. Measure compression of misfiring cylinder (See page 07-16).



Check engine to confirm cause of low compression

OK


Go to Diagnostic Help

06



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



021 62 99 92 92

06 - SQRD4G15B ENGINE MANAGEMENT SYSTEM



Go to Diagnostic Help

06





121 62 99 92 92

1	Check throttle for carbon deposits	
NG	Clean throttle valve	
		ОК
2	Observe if engine output increases when A/Cis turned on. In other word of ignition advance angle, injection pulse width and intake air voluntester	•
ОК	Go to step 4	
		NG
3	Connect ECM adapter, and disconnect cable of ECM corresponding ten harness side is HIGH-level signal with A/C ON	rminal. Check if wi
NG	Check and repair A/C system	0
ىت ە	مرکت دیجیتال خودرو سامانه (مسئول	ОК
4	Connect ECM adapter, and disconnect cableof ECM corresponding ter harness side is HIGH-levelsignal with A/C ON	minal. Check if wi
NG	Check and repair A/C system	O
2 99	92 92 www.d	igitall tok
5	Check injector for leakage or blockage	
NG	Clean or replace injector	
		ОК

1	Check if accelerator pedal is stuck	
NG	Adjust or replace accelerator pedal	
		ОК
2	Check intake system and connected vacuum pipe for air leakage	
ок	Check and repair intake system	
		NG
3	Check throttle for carbon deposits	
NG	Clean throttle valve	
	ے دیجیتالا کو	ОК
<b>4</b>	Disconnect coolant temperature sensor connector, start engine and is normal	observe if engine idlin
NG	Check and repair circuit or replace sensor	ОК
90	992 92	digitalkhodr
5	Check engine ignition timing	
NG	Check and repair ignition timing	
		ок

Low engine speed or stalls when accelerating

1 Check air filter for blockage, and intake pipe for air leakage

NG

Check and repair intake system

OK

2 Check fuel pressure

a. Using a fuel pressure gauge, check the fuel pressure (See page 08-11).

#### **Standard Fuel Pressure**

06

Condition	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key Lock	400

Repair or replace fuel system

OK

Check spark plug

a. Check spark plug of each cylinder, and observe if type and gap are as specified.

**Spark Plug Replacement** 

www.digitallchokro



Check throttle for carbon deposits

NG

Clean throttle valve

OK

5 Check intake pressure/temperature sensor, throttle position sensor and circuit

OK

Check and repair circuit or replace sensor

NG

6	Ch	eck injector for leakage or blockage	
NG	>	Clean or replace injector	
			ОК
7	Ch	eck fuel condition	
Obse	erve i	f trouble occurs just after fuel is filled.	
NG	>	Replace fuel	
			ОК
8	Ch	eck engine ignition sequence and ignition timing	
Chec	ck if e	engine ignition sequence and ignition timing are as sp	ecified.
NG		Check and repair ignition timing	ОК
9	Ch	eck exhaust system	شرک
Chec	ck ex	Repair or replace related exhaust system components	lel lel
. 99	9	2 92	www.digitalkhokro

Slow response when accelerating

1 Check air filter for blockage, and intake pipe for air leakage

NG

Check and repair intake system

ОК

2 Check fuel pressure

a. Using a fuel pressure gauge, check the fuel pressure (See page 08-11).

#### **Standard Fuel Pressure**

06

Condition	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key Lock	400

NG

Repair or replace fuel system

OK

3 Check spark plug

a. Check spark plug of each cylinder, and observe if type and gap are as specified.

NG

**Spark Plug Replacement** 

# 021 62 99 92 92

www.digitalkhokro



4 Check throttle for carbon deposits

NG

Clean throttle valve

ОК

5 Check intake pressure/temperature sensor, throttle position sensor and circuit

ok )

Check and repair circuit or replace sensor

NG

6	Check injector for leakage or blockage	
NG	Clean or replace injector	
		ОК
7	Check fuel condition	
. Obse	rve if trouble occurs just after fuel is filled.	
NG	> Replace fuel	
		ОК
8	Check engine ignition sequence and ignition timing	
. Chec	k if engine ignition sequence and ignition timing are as spec	ified.
NG	Check and repair ignition timing	ОК
9.	Check exhaust system	m
NG NG	k exhaust system for leakage or blockage.  Repair or replace related exhaust system components	
2 99	92 92	www.digitalkhokro

Lack of power and poor performance when accelerating

1 Check if malfunctions that clutch slipping, low tire inflation pressure, brake dragging, incorrect tire size and incorrect four-wheel alignment are present

NG

Check and repair malfunctioning components

OK

2 Check air filter for blockage, and intake pipe for air leakage

06

NG

Check and repair intake system

OK

3 Check fuel pressure

a. Using a fuel pressure gauge, check the fuel pressure (See page 08-11).

#### Standard Fuel Pressure

Condition	Fuel System Pressure (kPa)
عیتال خودر و سKey.ON (مسئولیت	400 شرکت دیع
Engine Idling	400
Key Lock	400

NG

Repair or replace fuel system

# 021 62 99 92 92

www.digitall



4 Check spark plug

a. Check spark plug of each cylinder, and observe if type and gap are as specified.

NG >

**Spark Plug Replacement** 




5 Check spark

a. Remove ignition coil and spark plug of one cylinder, and ground spark plug housing. Start engine, and check if spark is generated.

OK: Spark is generated

NG )

Check and repair ignition system





Go to Diagnostic Help

06





021 62 99 92 92

# **ON-VEHICLE SERVICE**

### **VVT Control Valve**

# **Description**

There is a VVT control valve, which is located on front end of cylinder head.

# **Operation**

ECM controls VVT control valves depending on engine conditions, changes the flowing direction of oil in phasers to advance or retard camshaft, thus changing the timings of intake valve and exhaust valve.


#### Removal

- 1. Turn off all electrical equipment and the ignition switch.
- 2. Disconnect the negative battery cable.
- 3. Remove the engine trim cover.
- 4. Remove the VVT control valve.

خودر و سامانه (مسئولیت محدود)

a. Disconnect VVT control valve connector (arrow), and then remove VVT control valve fixing bolt (1).

(Tightening torque: 8 ± 2 N·m)



Installation is in the reverse order of removal.

021 62 99 92 92

www.digitalkhodro.com

06

# **Coolant Temperature Sensor**

# **Description**

Coolant temperature sensor is a negative temperature coefficient sensor, which is installed into the mounting hole in thermostat holder.

# Operation

Coolant temperature sensor provides an input signal for Engine Control Module (ECM). As temperature increases, the resistance of sensor decreases. As coolant temperature changes, the resistance of coolant temperature sensor varies accordingly, resulting in a change in voltage of coolant temperature sensor signal circuit. ECM uses this input signal to control air-fuel mixture, ignition timing, A/C compressor and radiator fan on/off timing.

#### Removal

- 1. Turn off all electrical equipment and the ignition switch.
  - 2. Disconnect the negative battery cable.

#### **⚠** WARNING

- Always make sure engine is cold before operating cooling system. Never open expansion tank cap or remove drain cock plug, when engine is operating or cooling system overheats. The overheated engine coolant and steam with high-pressure may flow out and cause serious personal injury.
- 3. Remove the engine trim cover.
- 4. Disconnect coolant temperature sensor connector and remove coolant temperature sensor.

(Tightening torque: 14 ± 1 N·m)

#### Installation

Installation is in the reverse order of removal.

#### CAUTION

- Perform sealing with anaerobic seal gum.
- Confirm that sensor is tightened fully during installation.
- After installing engine coolant temperature sensor, check coolant level.

#### **Knock Sensor**

### **Description**

Knock sensor is installed on cylinder block, and used to detect engine vibration caused by detonation.

### **Operation**


Sensitive element of knock sensor is a piezoelectric ceramic. Vibration of engine cylinder block is transferred to the piezoelectric ceramic through a mass block in sensor. Due to pressure generated by vibration of mass block, the piezoelectric ceramic generates a voltage at both electrode faces, and converts vibration signal to an AC voltage signal to output it. As intensity of vibration increases, knock sensor output voltage increases accordingly.

Because frequency of vibration signal caused by engine knocking is far more than that of normal engine vibration signal, Engine Control Module (ECM) can distinguish between knock or non-knock signals by processing these signals from knock sensor.

#### Removal

- 1. Turn off all electrical equipment and the ignition switch.
- 2. Disconnect the negative battery cable.
- 3. Disconnect coolant temperature sensor connector and remove coolant temperature sensor.

(Tightening torque: 14 ± 1 N·m)



# Installation

Installation is in the reverse order of removal.

ودر و سامانه (مسئولیت

### CAUTION

- Never allow any kinds of gasket and washer between sensor and engine block. Only the metal part of sensor can contact with engine block directly.
- DO NOT apply lubricant, grease or seal gum when installing knock sensor. Keep engine block clean and dry, and never allow any foreign matter (such as oil) on the installation area of knock sensor.
- Never tap knock sensor when installing it.





# **Oxygen Sensor**

# **Description**

Oxygen sensors consist of upstream oxygen sensor and downstream oxygen sensor. Oxygen sensors continually monitor the oxygen concentration in exhaust gas.

# Operation


06

Oxygen sensors monitor oxygen content and convert it into voltage. Sensor generates low voltage when oxygen content is high, and high voltage when oxygen content is low. Therefore, sensor acts as controlling injection volume by closed-loop.

Oxygen sensor is equipped with a heating element that keeps sensor at proper operating temperature under all operating conditions.


# **Upstream Oxygen Sensor**

Input signal from heated upstream oxygen sensor is used to inform Engine Control Module (ECM) of the oxygen content in exhaust gas. Based on this input signal, Engine Control Module (ECM) adjusts air-fuel ratio finely by adjusting injector pulse width.



# Downstream Oxygen Sensor

Heated downstream oxygen sensor signal is used to detect the catalytic converter deterioration. As converter deteriorates, signal from downstream sensor begins to match upstream sensor signal except for a slight delay. By comparing signal from heated upstream oxygen sensor to signal from downstream sensor, Engine Control Module (ECM) calculates efficiency of catalytic converter.



# Removal & Installation - Upstream Oxygen Sensor

(See page 09-13)

Removal & Installation - Downstream Oxygen Sensor

(See page 09-15)

### **Camshaft Position Sensor**

### **Description**

Camshaft position sensor is installed on cylinder head cover.

### **Operation**

Camshaft position sensor is a Hall type sensor and a phaser is installed on camshaft. When phaser is in high teeth, applicable circuit output is high level; when phaser is in missing teeth, applicable circuit output is low level. As a result, crankshaft phase information is provided to Engine Control Module (ECM), so that the compression top dead center and exhaust top dead center of crankshaft can be distinguished.


#### Removal

- 1. Turn off all electrical equipment and the ignition switch.
- 2. Disconnect the negative battery cable.
- 3. Remove the engine trim cover.

ودر و سامانه (مسئولیت محدود)

- 4. Remove the camshaft position sensor.
  - a. Disconnect camshaft position sensor connector (arrow), then remove camshaft position sensor fixing bolt (1).

(Tightening torque: 8 ± 1 N·m)



### Installation

Installation is in the reverse order of removal.

# CAUTION

 Sensor should be pressed into mounting hole. Never use tools (such as a hammer) to strike sensor into mounting hole forcibly.

06

# **Engine Speed Sensor**

### **Description**

Engine speed sensor is installed on clutch case, against flywheel teeth. It is used to detect the speed and position of crankshaft.


# Operation

Engine speed sensor is a Hall type sensor. When crankshaft rotates, it drives flywheel to rotate. Flywheel teeth will cut the magnetic line of sensor, and change of magnetic flux causes sensor output signal voltage change, which is sent to Engine Control Module (ECM). And output signal can indicate the speed and position of crankshaft.

#### Removal

06

- 1. Turn off all electrical equipment and the ignition switch.
- 2. Disconnect the negative battery cable.
- 3. Remove the engine trim cover.
- 4. Remove the engine speed sensor.
  - a. Disconnect engine speed sensor connector (arrow), and remove engine speed sensor fixing bolt (1).
     (Tightening torque: 8 ± 2 N·m)



ولین سامانه دیجیتال تعمیرکاران Installation

Installation is in the reverse order of removal.

21 6 CAUTION

Press in crankshaft position sensor rather than tap when installing it.

# **Intake Pressure/Temperature Sensor**

# **Description**

Intake pressure/temperature sensor integrates with the intake manifold absolute pressure sensor and intake temperature sensor, which is installed on the intake manifold upper body assembly.

# Operation

Intake manifold absolute pressure sensing element consists of a piece of silicon chip, which will deform mechanically as the intake manifold absolute pressure changes. The piezoresistor in sensor will also deform, thus changing the resistance. Voltage signal linearly related to the pressure is generated after processing by signal circuit of the silicon chip.


Intake temperature sensor is a negative temperature coefficient thermostat, whose resistance changes with the intake temperature. This sensor sends the voltage of intake temperature change to Engine Control Module (ECM), thus monitoring the change of intake temperature.

#### Removal

- 1. Turn off all electrical equipment and the ignition switch.
- 2. Disconnect the negative battery cable.
- 3. Remove the engine trim cover.

ودر و سامانه (مسئولیت محدود)

4. Disconnect the intake pressure/temperature sensor connector (arrow).



رسامانه دیجیتال تعمیرکاران خودرو در اب

Remove the intake pressure/temperature sensor fixing bolt.
 (Tightening torque: 6 ± 1 N·m)

#### Installation

Installation is in the reverse order of removal.

#### CAUTION

- Remove foreign matter on sensor before installation.
- Apply grease to O-ring before installation to prevent it from being damaged during installation.

06




# **Ignition Coil**

# **Description**

Ignition coil converts low voltage of primary winding into high voltage of secondary winding, and discharges spark plug electrode to produce sparks which will ignite the combustible air-fuel mixture in cylinder.

# **Operation**

Ignition coil consists of primary winding, secondary winding, iron core and housing etc. Primary and secondary windings form an induced circuit. An instant induced voltage generated by turning primary circuit switch on and off, and an instant high voltage generated by secondary circuit will cause spark plugs to discharge, thus igniting the combustible air-fuel mixture. Primary winding will recharge when its ground line is on through an Engine Control Module (ECM) signal. Once Engine Control Module (ECM) cuts off control signal to primary winding circuit, it will stop charging and a high voltage will be induced in secondary winding.




#### **Removal & Installation**

(See page 14-8)

06



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



021 62 99 92 92

# **Electronic Accelerator Pedal Sensor**


# **Description**

Accelerator pedal is installed to cowl of the body, and accelerator pedal sensor is located inside the accelerator pedal.

# Operation

Accelerator pedal sensor outputs the electrical signal which varies linearly depending on the pedal travel to ECM, in order to detect position of the accelerator pedal.

ECM adjusts opening angle of the electronic throttle according to this signal and other information to meet the intake requirements under different operating conditions.



06

#### **Removal & Installation**

(See page 10-17)





021 62 99 92 92

# **Electric Fuel Pump**

### **Description**

Electric fuel pump consists of DC motor, vane pump and end cover (integrated with check valve, pressure regulator and anti-electromagnetic interference element), etc. Pump and motor are installed coaxially, and sealed in the same housing. Fuel is filled around the pump and motor in housing and used for heat dissipation and lubrication.

# **Operation**

Battery supplies power to electric fuel pump via electric fuel pump relay, which can turn on electric fuel pump circuit only when starting and engine running. When engine stops running because of an accident, fuel pump stops running automatically. Maximum pressure at electric fuel pump outlet is adjusted by pressure regulator to keep the whole fuel system pressure at 400 kPa.

06

#### **Removal & Installation**

(See page 08-14)





021 62 99 92 92



# **Fuel Injector**

### **Description**

Fuel injector is located on the cylinder head near to intake valve, and nozzle end is located directly above the intake port.

# Operation

Engine Control Module (ECM) sends electric pulse to injector coil, forming magnetic field force. When magnetic field force increases enough to overcome the resultant force from return spring pressure, needle valve gravity and friction force, the needle valve begins to rise up and the injector starts to inject fuel. Pressure of return spring forces the needle valve to close again when injection pulse stops.

#### **Removal & Installation**

(See page 08-22)

06



021 62 99 92 92


#### **Canister Solenoid Valve**

### **Description**

Electric throttle assembly is located on the intake manifold assembly.

### Operation

Canister solenoid valve consists of solenoid coil, magnet armature and valve, etc. Air volume through canister solenoid valve is related to electric pulse duty ratio output from ECU and pressure difference between canister solenoid valve inlet and outlet. When there is no electric pulse, canister solenoid valve closes.




06

#### **Removal & Installation**

(See page 09-10)





021 62 99 92 92

# **Engine Control Module (ECM)**

### **Description**


Engine Control Module (ECM), mounted on the battery bracket in engine compartment, can be removed only as a unit for replacement.

# **Operation**

Engine Control Module (ECM) is a pre-programmed microprocessor digital computer, which is used to adjust ignition timing, air-fuel ratio, emission control, speed control, A/C compressor and idle speed etc. Engine Control Module (ECM) enables the program to suit ever-changing operation conditions.

#### Removal

- 1. Turn off all electrical equipment and the ignition switch.
- 2. Disconnect the negative battery cable.
- 3. Remove the Engine Control Module (ECM).
  - a. Disconnect the ECM connector (arrow).
  - b. Remove 4 ECM fixing bolts, and take off ECM. (Tightening torque: 7 ± 1 N·m)



www.digitalkhodro.com

# Installation

Installation is in the reverse order of removal.

غودر و سامانه (مسئولیت محدود)

#### **CAUTION**

- Pay attention to static electricity protection when installing.
- Take care to protect connector terminals.
- To prevent water droplets from accumulating on connector joint, face it down.

06



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



021 62 99 92 92