

CH-2

Clutch System

General Information

Specifications

Item	Specification
Clutch operation method	Hydraulic type
Clutch disc Type Facing diameter (outside x inside)mm (in)	Single dry with diaphragm • Gasoline 1.6 : Ø215 × Ø145 (Ø8.5 × Ø5.7) • Gasoline 2.0 : Ø225 × Ø150 (Ø8.9 × Ø5.9)
Clutch cover assembly Type	Diaphragm spring strap
Clutch release cylinder [M5CF only] * I.D. mm (in)	20.64 (0.81)
Clutch master cylinder * I.D. mm(in)	15.87 (0.62)

* I.D: Inside diameter

Service Standard

Standard value Clutch disc thickness [When free] Clutch pedal height [Without carpet] Clutch pedal free play Clutch pedal stroke	Gasoline : 8.55 ± 0.3 mm (0.335 ± 0.012 in) 182.8 mm (7.19 in) 6 ~ 13 mm (0.24 ~ 0.51 in) Gasoline : 140 ± 3mm (5.5 ± 0.12 in)
Limit Clutch disc rivet depth Diaphragm spring end height difference Clutch master cylinder clearance to piston	Gasoline 1.6 : 1.4 mm (0.055 in) Gasoline 2.0 : 1.2 mm (0.047 in)

Tightening Torque

Item	N.m	kgf.m	lb-ft
Clutch pedal to pedal support member (Clutch pedal bracket)	17 ~ 26	1.7 ~ 2.6	12.3 ~ 18.8
Clutch pedal support member to master cylinder	6 ~ 8	0.6 ~ 0.8	4.3 ~ 5.8
Clutch tube flare nut	13 ~ 17	1.3 ~ 1.7	9.4 ~ 12.4
Clutch tube bracket	8 ~ 10	0.8 ~ 1.0	5.8 ~ 7.24
Clutch release cylinder	15 ~ 22	1.5 ~ 2.2	10.9 ~ 16.0
Clutch release cylinder union bolt	25 ~ 35	2.5 ~ 3.5	18.1 ~ 25.5
Clutch cover assembly	15 ~ 22	1.5 ~ 2.2	10.9 ~ 16.0
Ignition lock switch nut	8 ~ 10	0.8 ~ 1.0	5.8 ~ 7.3


General Information

CH-3

Lubricants

Items	Specified lubricants	Quantity
Contact surface of release bearing and fulcrum of clutch release fork	CASMOLY L9508	As required
Inner surface of clutch release bearing	CASMOLY L9508	As required
Inner surface of clutch release cylinder and outer circumference of piston and cup	Brake fluid DOT 3 or DOT 4	As required
Inner surface of clutch disc spline	CASMOLY L9508	As required
Inner surface of clutch master cylinder and outer circumference of piston assembly	Brake fluid DOT 3 or DOT 4	As required
Clutch master cylinder push rod, clevis pin and washer	Wheel bearing grease SAE J310, NLGI No.2V	As required
Clutch pedal shaft and bushings	Chassis grease SAE J310a, NLGI No.1	As required
Contact portion of release fork to release cylinder push rod	CASMOLY L9508	As required
Input shaft spline	CASMOLY L9508	As required

Special Service Tools

Tool (Number and name)	Illustration	Use
09411-25000 Clutch disc guide	 EOKD001A	Installation of the clutch disc.

CH-4

Clutch System

Troubleshooting

Trouble symptom		Suspect area	Remedy (See page)
Clutch slipping • Car will not respond to engine speed during acceleration • Insufficient vehicle speed • Lack of power during uphill driving		Insufficient pedal free play	Adjust
		Clogged hydraulic system	Correct or replace parts
		Excessive wear of clutch disc facing	Replace
		Hardened clutch disc facing, or oil on surface	Replace
		Damaged pressure plate or flywheel	Replace
		Weak or broken pressure spring	Replace
Difficult gear shifting (gear noise during shifting)		Excessive pedal free play	Adjust
		Hydraulic system fluid leaks, air trapping or clogging	Repair or replace parts
		Unusual wear or corrosion of the clutch disc spline	Replace
		Excessive vibration (distortion) of the clutch disc	Replace
Clutch noise	When the clutch is not used	Insufficient play of the clutch pedal	Adjust
		Excessive wear of the clutch disc facing	Replace
	A noise is heard after the clutch is disengaged	Unusual wear and/ or damage of the release bearing	Replace
	A noise is heard when the clutch is disengaged	Insufficient grease on the sliding surface of the bearing sleeve	Repair
		Improperly installed clutch assembly or bearing	Repair
	A noise is heard when the car suddenly rolled up with the clutch partially engaged	Damaged pilot bushing	Replace
Hard pedal effort		Insufficient lubrication of the clutch pedal	Repair
		Insufficient lubrication of the spline part of clutch disc	Repair
		Insufficient lubrication of the clutch release lever shaft	Repair
Hard to shift or will not shift		Excessive clutch pedal free play	Adjust the pedal free play
		Faulty of the clutch release cylinder	Repair the release cylinder
		Clutch disc out of place, runout is excessive or lining broken	Inspect the clutch disc
		Spline on the input shaft or clutch disc dirty or burned	Repair as necessary
		Faulty of the clutch pressure plate	Replace the clutch cover

General Information

CH-5

Trouble symptom	Suspect area	Remedy (See page)
Clutch slips	Insufficient clutch pedal free play	Adjust the pedal free play
	Clogged of the hydraulic system	Repair or replace parts
	Clutch disc lining oily or worn out	Inspect the clutch disc
	Faulty pressure plate	Replace the clutch cover
	Binding of the release fork	Inspect the release fork
Clutch grabs/chatters	Clutch disc lining oily or worn out	Inspect the clutch disc
	Faulty the pressure plate	Replace the clutch cover
	Bent clutch diaphragm spring	Replace the clutch cover
	Worn or broken torsion spring	Replace the clutch disc
	Engine mounts loose	Repair as necessary
Clutch noisy	Damaged the clutch pedal bushing	Replace the clutch pedal bushing
	Loose part inside housing	Repair as necessary
	Worn or dirty release bearing	Replace the replease bearing
	Sticking release fork or linkage	Repair as necessary

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



CH-6

Clutch System

Clutch System

Service Adjustment Procedure

Clutch Pedal Inspection And Adjustment


1. Measure the clutch pedal height (from the face of the pedal pad to the floorboard) and the clutch pedal clevis pin play (measured at the face of the pedal pad.)

Standard value

(A) : 6 ~ 13 mm (0.24~0.51 in)

(B) 182.8 mm (7.19 in)

Clutch pedal



SEDCH7008L


2. If the clutch pedal freeplay and height is not within the standard value range, adjust as follows:

- 1) Turn and adjust the bolt within the standard value, then secure by tightening the lock nut.

NOTICE

If the clutch pedal height is lower than the standard value, loosen the bolt and adjust the push rod.

After adjustment, tighten the bolt so that the clearance with pedal stopper becomes 0.5mm(0.02 in) to 1.0mm (0.04 in) and secure with lock nut.



LOJF003A

- 2) Turn the push rod to agree with the standard value and then secure the push rod with the lock nut.

CAUTION

When adjusting the clutch pedal height or the clutch pedal play, be careful not to push the push rod toward the master cylinder.

3. If the clutch pedal free play and the distance between the clutch pedal and the floor board when the clutch is disengaged, do not meet with the standard values, it may be the result of either air in the hydraulic system or a faulty clutch master cylinder. Bleed the air or disassemble and inspect the master cylinder or clutch.

Clutch System

CH-7

Bleeding


Whenever the clutch tube, the clutch hose, and/or the clutch master cylinder have been removed, or if the clutch pedal is spongy, bleed the system.

⚠CAUTION

Use the specified fluid. Avoid mixing different brands of fluid.

Specified fluid: SAE J1703 (DOT 3 or DOT 4)

1. Loosen the bleeder screw(A) at the clutch release cylinder.




2. Depress the clutch pedal slowly until all air is expelled.
3. Hold the clutch pedal down until the bleeder is retightened.

4. Refill the clutch master cylinder with the specified fluid.

⚠CAUTION

The rapidly-repeated operation of the clutch pedal in B-C range may disrupt the release cylinder's position. During the bleeding operation, press the clutch pedal to the floor after it returns to the "A" point.



EOKD006A


SLDCH7002D

CH-8

Clutch System

Clutch Cover And Disc

Components



STDCH9002L

1. Clutch release fork
2. Clutch disc cover


3. Clutch disc
4. Clutch release bearing

Clutch System

CH-9

Removal

1. Remove the transaxle assembly. (Refer to Manual transaxle's removal in MT group)
2. Insert the special tool (09411-25000) in the clutch disc to prevent the disc from shifting.



STDCH9003L

3. Loosen the bolts (Gasoline : 6ea, Diesel 1.6 : 9ea, Diesel 2.0 : 6ea) which attach the clutch cover to the flywheel in a star pattern. Loosen the bolts in succession, one or two turns at a time, to avoid bending the cover.

NOTICE

Do not clean the clutch disc or the release bearing with cleaning solvent.

Installation


1. Apply multipurpose grease to the spline of the disc.

Grease: CASMOLY L 9508

CAUTION


When installing the clutch, apply grease to each part, but be careful not to apply excessive grease.

It can cause clutch slippage and vibration (shudder).



EOKD011A

2. Temporarily install the clutch disc assembly to the flywheel using the special tool (09411-25000).



STDCH9003L


CH-10

Clutch System

3. Tighten the bolts one or two steps at a time in a star pattern.

Tightening torque :

15 ~ 22 N.m (1.5 ~ 2.2 kgf.m, 10.9 ~ 16.0 lb-ft)



KKNF002E

Inspection**Clutch cover assembly**

1. Check the diaphragm spring end for wear and uneven height.
2. Check the pressure plate surface for wear, cracks and color change.
3. Check the rivets for looseness and replace the clutch cover assembly if necessary.

Clutch disc


1. Check the clutch facing for loose rivets, uneven contact, deterioration due to seizure, adhesion of oil, or grease, and replace the clutch disc if defective.
2. Measure the thickness of the disc when free.

Standard value

Clutch disc thickness(A)[when free]

Clutch disc rivet depth(B)

: refer to 'SERVICE STANDARD' in GENERAL section.



EOKD010A

3. Check for the torsion spring play and damage and if defective, replace the clutch disc.
4. Clean the splines on the input shaft and install the clutch disc.

If the disc does not slide smoothly or if play is excessive, replace the clutch disc and/or the input shaft.

Clutch System

CH-11

Clutch release bearing

⚠ CAUTION

The release bearing is packed with grease. Do not use cleaning solvent or oil.

Standard grease : CASMOLY L9508

1. Check the bearing for seizure, damage or abnormal noise. Also check the diaphragm spring contacting points for wear.
2. Replace the bearing if the release fork contacting points are worn abnormally.

Clutch release fork

If there is abnormal wear at the point of contact with the bearing, replace the release fork assembly.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




CH-12

Clutch System

Clutch Master Cylinder

Components



STDCH9005L

1. Pedal pad
2. Clutch arm assembly
3. Ignition lock switch
4. Clutch member assembly


5. Dust cover
6. Master cylinder assembly
7. Washer
8. Snap pin

Clutch System

CH-13


Removal

1. Drain the brake fluid through the bleeding plug (A).



SLDCH7002D


2. Remove the flexible hose (A) connected to brake reserve tank from the master cylinder.



SHDCH6010D


3. Disconnect the clutch tube (B) from the master cylinder.
4. Disconnect the two ignition lock switch connectors.

5. Remove the clutch pedal mounting nuts(A-2ea) and the bracket mounting nut.



STDCH9006D

6. Disconnect the push rod from the master cylinder by removing the snap pin (A) and washer (B).



STDCH9007D

7. Remove the screws mounting the master cylinder to the clutch pedal assembly.


CH-14

Clutch System

Installation

1. Apply the specified grease to the clutch pedal and bushings.

Chassis grease: SAE J310a, NLGI No.1




AOJF221A

2. Install the screws or nut mounting the master cylinder to the clutch pedal assembly.
3. Apply the specified grease to the snap pin(A) and washer.

Wheel bearing grease: SAE J310, NLGI No.2

4. Connect the push rod to the clutch pedal by installing the snap pin (A) and washer (B).




STDCH9007D


5. Install the clutch pedal mounting nuts (A-2ea).

Tightening torque :

17 ~ 26N.m (1.7 ~ 2.6kgf.m, 12.3 ~ 18.8lb-ft)



STDCH9006D



SEDCH7006L

Clutch System

CH-15

- Adjust the clutch pedal within the standard value, then secure by tightening the lock nut.

Standard value


Free play (A)

6~13mm (0.24~0.51 in)

Height (B)


182.8mm (7.19 in)

Clutch pedal



SHDCH6004L

- Connect the flexible hose of the brake reserve tank to the master cylinder.



SHDCH6010D

- Connect the clutch tube(B) to the master cylinder.
- Refill the brake fluid.
- Bleed the air in the clutch system.(refer to Bleeding in Serive Adjustment Procedure)

Disassembly

- Remove the piston stop ring.
- Pull out the push rod and piston assembly.
- Remove the reserve tank band, reserve tank cap, and reserve tank.

NOTICE

- Use care not to damage the master cylinder body and piston assembly.
- Do not disassemble the piston assembly.

Inspection

- Check the inside of the cylinder body for rust, pitting or scoring.
- Check the piston cup for wear or distortion.
- Check the piston for rust, pitting or scoring.
- Check to make sure the clutch line tube is not clogged or restricted in any way.
- Measure the master cylinder inside diameter and the piston outside diameter with a cylinder gauge micrometer.

NOTICE

Measure the inside diameter of the master cylinder at three places (bottom, middle, and top) in a perpendicular direction.

- If the master cylinder-to-piston clearance exceeds the limit, replace the master cylinder and/or piston assembly.

Limit : 0.15 mm (0.006 in)

Reassembly

- Apply the specified fluid to the inner surface of the master cylinder body (A) and to the entire periphery of the piston assembly (B).

Specified fluid: Brake fluid DOT 3 or DOT 4


- Install the piston assembly.
- Install the piston snap ring.
- Install the push rod assembly.

CH-16

Clutch System

Clutch Pedal

Components (1)



STDCH9004L

1. Pedal pad
2. Clutch arm assembly
3. Ignition lock switch
4. Clutch member assembly


5. Dust cover
6. Master cylinder assembly
7. Washer
8. Snap pin

Clutch System

CH-17


Removal

1. Disconnect the push rod from the master cylinder by removing the snap pin (A) and washer (B).




STDCH9007D

2. Remove the clutch pedal mounting nuts (A-2ea) and the bracket mounting nut.



STDCH9006D

3. Remove the flexible hose (A) connected to brake reservoir tank from the master cylinder.



SHDCH6010D

4. Disconnect the clutch tube (B) from the master cylinder.
5. Disconnect the two ignition lock switch connectors.
6. Remove the screws or nut mounting the master cylinder to the clutch pedal assembly.

CH-18

Clutch System

Inspection

1. Check the pedal shaft and bushing for wear.
2. Check the clutch pedal for bending or torsion.
3. Check the return spring for damage or deterioration.
4. Check the pedal pad for damage or wear.

Ignition lock switch inspection

Remove the ignition lock switch and check for continuity between the terminals. If the continuity is not as specified, replace the switch.


Terminal	1	2
Condition		
Pushed(ON)		
Free(OFF)		

LOJF012A

Standard value

Full stroke(A) : $12.0 \pm 0.3\text{mm}$ (0.472 ± 0.012 in.)

ON-OFF point (B) : $2.0 \pm 0.3\text{mm}$ (0.078 ± 0.012 in)




LOJF002B

Installation


1. Apply the specified grease to the clutch pedal and bushings.

Chassis grease: SAE J310a, NLGI No.1



AOJF221A

2. Install the screws or nut mounting the master cylinder to the clutch pedal assembly.
3. Connect the push rod to the clutch pedal by installing the snap pin (A) and washer (B).



STDCH9007D


Clutch System

CH-19

4. Install the clutch pedal mounting nuts (A-2ea).

Tightening torque :

17 ~ 26N.m (1.7 ~ 2.6kgf.m, 12.3 ~ 18.8lb-ft)



STDCH9006D

5. Adjust the clutch pedal within the standard value, then secure by tightening the lock nut.

Standard value


Free play (A)

6~13mm (0.24~0.51 in)

Height (B)


182.8mm (7.19 in)

Clutch pedal



SEDCH7008L

6. Connect the flexible hose of the brake reserve tank to the master cylinder.



SHDCH6010D


7. Connect the clutch tube (B) to the master cylinder.
8. Refill the brake fluid.
9. Bleed the air in the clutch system. (Refer to Bleeding in Service Adjustment Procedure)

CH-20

Clutch System

Clutch Release Cylinder

Components



STDCH9006L


- | | |
|-----------------|---------------------|
| 1. Union bolt | 7. Bleeder screw |
| 2. Gasket | 8. Release cylinder |
| 3. Tube joint | 9. Return spring |
| 4. Clutch tube | 10. Piston |
| 5. Valve plate | 11. Boot |
| 6. Valve spring | 12. Push rod |

Clutch System

CH-21


Removal

1. Drain the brake fluid through the bleed plug(A).



SLDCH7002D

2. Disconnect the clutch tube(A).




SEDCH7010L

3. Remove the two clutch release cylinder mounting nuts(B-2ea).

Installation

1. Coat the clutch clevis push rod specified grease.

Specified grease: CASMOLY L9508




LOGF006B

2. Install the release cylinder mounting nuts(B-2ea).

Tightening torque :

15 ~ 22N.m (150 ~ 220 kgf.cm, 11 ~ 16 lb-ft)



SEDCH7010L

3. Install the clutch tube(A).
4. Refill the brake fluid.
5. Bleed the air in the clutch system.
(refer to Bleeding in Service Adjustment Procedure)


CH-22

Clutch System

Inspection

1. Check the release cylinder bore for rust and damage.
2. Measure the release cylinder bore at three locations (bottom, middle, and top) with a cylinder gauge and replace the release cylinder assembly if the bore-to-piston clearance exceeds the limit.

Limit clearance to piston: 0.25mm (0.0098 in)



EOKD025A

3. Check the clutch release cylinder for fluid leakage.
4. Check the clutch release cylinder boots for damage.


Disassembly

1. Remove the clutch hose, valve plate, spring, push rod, and boot.
2. Remove any dirt from the piston bore opening of the release cylinder.

3. Remove the piston from the release cylinder using compressed air.

⚠ CAUTION

- Use rags to prevent the piston from popping out and causing injury.
- Apply compressed air slowly. Keep the fluid from splashing in your eyes or on your skin.




EOKD024A

Reassembly

1. Apply specified brake fluid to the release cylinder bore and the outer surface of the piston and piston cup, and push the piston cup assembly into the cylinder.

Specified fluid: Brake fluid DOT 3 or DOT 4

2. Install the valve plate(A), Spring(B), push rod(C) and boot(D).



LOJF003B