


PEPS SYSTEM



GENERAL INFORMATION	20 - 2	B1305	20 - 29
System Overview	20 - 2	B1306	20 - 30
Description	20 - 2	B1500	20 - 31
Tools	20 - 3	B1501	20 - 31
Torque Specifications	20 - 3	B1522	20 - 31
Function Introduction	20 - 4	B1523	20 - 31
Smart Entry Function	20 - 4	B1529	20 - 31
Remote Entry Function	20 - 8	B152A	20 - 31
One-button Start Function	20 - 9	B152B	20 - 31
One-button Stop Function	20 - 11	B152C	20 - 31
Emergency Stop Function	20 - 11	B1502	20 - 34
Back Up Start Function	20 - 12	B1526	20 - 34
Emergency Start Function	20 - 12	B1505	20 - 36
Starting Times Limit Function	20 - 12	B1527	20 - 36
Intelligent Searching Function	20 - 12	B152D	20 - 39
Prompt Function	20 - 13	B1506	20 - 39
Engine and Vehicle Anti-theft Function	20 - 15	B1507	20 - 39
Anti-theft Matching	20 - 15	B1508	20 - 43
Software Configuration Code Writing	20 - 15	B1509	20 - 46
Remote Control Troubleshooting Chart	20 - 18	B1518	20 - 50
Smart Key Replacement After Vehicle Sold	20 - 21	B152F	20 - 53
PEPS Module Replacement After Vehicle Sold	20 - 22	B1530	20 - 53
Engine Management System (EMS) Replacement After Vehicle Sold	20 - 22	B150F	20 - 57
Electric Steering Column Lock (ESCL) Replacement After Vehicle Sold	20 - 22	U0100	20 - 57
ON-VEHICLE SERVICE	20 - 24	U0129	20 - 57
PEPS Control Module Assembly Removal	20 - 24	U0140	20 - 57
Diagnostic Help	20 - 24	U0329	20 - 57
Intermittent DTC Troubleshooting	20 - 24	U0101	20 - 57
Ground Inspection	20 - 25	U0155	20 - 57
Diagnostic Trouble Code (DTC) Chart	20 - 25	U0230	20 - 57
DTC Diagnosis Procedure	20 - 25	ON-VEHICLE SERVICE	20 - 59
B1300	20 - 27	PEPS Control Module Assembly Removal	20 - 59
B1301	20 - 28	PEPS Control Module Assembly Installation	20 - 59
B1515	20 - 28	Front Low Frequency Antenna Removal	20 - 59
B1302	20 - 28	Front Low Frequency Antenna Installation	20 - 59
Rear Bumper Low Frequency Antenna Removal	20 - 25	Front Low Frequency Antenna Removal	20 - 59
Rear Bumper Low Frequency Antenna Installation	20 - 25	Front Low Frequency Antenna Installation	20 - 59
Anti-theft Coil Removal	20 - 27	Front Low Frequency Antenna Removal	20 - 59
Anti-theft Coil Installation	20 - 28	Front Low Frequency Antenna Installation	20 - 59
Removal	20 - 28	Anti-theft Coil Removal	20 - 60
Installation	20 - 28	Anti-theft Coil Installation	20 - 60



GENERAL INFORMATION

System Overview

Description




PE0010

20 - PEPS SYSTEM

1	PEPS Module	2	ENGINE START STOP Switch
3	Front Right Door Outside Handle Sensor	4	Front Interior Low Frequency Antenna
5	Anti-theft Coil	6	High Performance Antenna
7	Front Left Door Outside Handle Sensor	8	Back Door Release Switch
9	Rear Low Frequency Antenna (on Rear Bumper Crossmember Body)	10	High Performance Antenna

PEPS system consists of PEPS controller, ENGINE START STOP switch, built-in low frequency antenna (A total of 2 low-frequency antennas and 1 high-performance antenna are equipped in vehicle to detect key position), immobilizer coil for back up starting, front left/right door handle sensor (front left/right door handle), ESCL module (for MT models), back door microswitch, smart bracelet and remote controller (also called smart key).

Tools

Tool Name	Tool Drawing
X-431 PAD Diagnostic Tester	 RCH0001006
Digital Multimeter	 RCH0002006

Torque Specifications

Description	Torque (N·m)
Hexagon Flange Nut	7 ± 1


Function Introduction

Function	
1 - Smart Entry Function	2 - Keyless Entry Function
3 - Mechanical Entry Function	4 - One-button Start Function
5 - One-button Stop Function	6 - Emergency Stop Function
7 - Back Up Start Function	8 - Emergency Start Function
9 - Starting Times Limit Function	10 - Electric Steering Column Lock Control Function
11 - Prompt Function	12 - Engine Immobilizer Function

Smart Entry Function

CAUTION

- For safety, when remote control/central control or mechanical control is used to lock vehicle, if there is a smart key inside vehicle, system will disable door handle switch while remote control still can be used.
- In order to successfully perform door handle switch operation, do not rapidly operate door handle switch in succession within 0.5 second. and also do not rapidly operate luggage compartment external electronic switch.
- Smart keyless unlock and lock are only valid when power supply is shut off and four doors are closed properly, or system will not operate.
- Smart keyless unlock and lock are only valid when power supply is shut off and four doors are closed properly, or system will not operate.
- For power saving purpose, after vehicle is parked for 15 days, smart entry for front right door handle will be invalid, only smart entry for front left door handle can be used (it will return to normal if performing remote control unlock once or front left door HSU (door handle sensor) unlock once).
- In some particular situations, such as smart key is too close to door, system may determine the key is inside vehicle, induced door handle to be disabled. In this case, keyless entry function will not operate normally. At this time, it is necessary to use remote control to lock and unlock vehicle.



PE0020


Smart Door Unlock (Keyless Fortifying Deactivation)

1. When the doors are locked, carry the smart key and touch the unlock sensing area of the door outside handle with four fingers. The system automatically recognizes the legitimacy of the smart key and the doors are automatically unlocked.

Hint:

Only front left and front right doors are equipped with sensing outside handle.

2. When bringing a smart key close to vehicle, the courtesy light turns on, the system automatically recognizes the legitimacy of the smart key and the doors are automatically unlocked.
3. No matter where the smart key is (put in pocket, hang in the belt or put in bag), as long as the key is within approximately 2.5 m of door handle, touch the sensing area of the door handle with four fingers, vehicle will enter fortifying deactivation mode (turn signal lights will flash twice and four doors will be unlocked).
4. If any of following operations is not performed within 30 seconds after touching the sensing area (- fortifying deactivation) of the door handle under fortifying mode, all doors will be locked automatically.
 - Open any door
 - Press the ENGINE START STOP switch
 - ENGINE START STOP switch is in ACC or ON position

Smart Door Lock (Keyless Fortifying)

1. When the doors are unlocked, carry the smart key and touch the lock sensing area with fingers. The system automatically recognizes the legitimacy of the smart key and the doors are automatically locked.
2. When exiting vehicle with smart key, the system automatically recognizes the legitimacy of the smart key and the doors are automatically locked.

Hint:

If any door is not closed properly, it will be unlocked automatically after locking to avoid leaving key inside vehicle.

3. Operation range:
 - Only distance between smart key and door outside handle is within specified operation range, smart key function can be used.
 - When smart key battery is discharged or there is strong radio wave in operation position, smart key system also will not operate normally.
 - It is recommended that do not place smart key together with mobile phone and other radio equipment.
 - Operation range is within about 250cm from sensing areas of two front door handles.
 - If smart key is too close to door glass, handle or rear bumper, door handle sensor cannot be used.
 - When smart key is within operation range, any one even without carrying smart key can press door handle sensing area on corresponding side to lock/unlock door.
4. When using smart key system, door handle sensor will not function in following conditions:
 - When ENGINE START STOP switch is in following positions (ACC or ON position).
 - Smart key is left in cab or luggage compartment (at this time, alarm will sound, turn signal lights will flash and “Smart Key inside Vehicle” will be prompted on instrument cluster if pressing door handle sensor.)
 - When smart key is not within exterior operation range.

20 - PEPS SYSTEM

- When any door is opened or not closed properly.
- When the smart key battery is discharged.

Smart Keyless Luggage Compartment Open





PE0040

1. If all doors are unlocked, the luggage compartment external electronic switch is activated. At this time, press the switch to open luggage compartment without necessity of carrying smart key.
2. If door is under central lock state, luggage compartment external electronic switch will be disabled. At this time, it is necessary to bring smart key close to rear of vehicle and press electronic switch to open luggage compartment.

CAUTION

- For safety, when remote control/central control or mechanical control is used to lock vehicle, if there is a smart key inside vehicle, system will disable door handle switch while remote control still can be used.
- In order to successfully perform door handle switch operation, do not rapidly operate door handle switch in succession within 0.5 second. and also do not rapidly operate luggage compartment external electronic switch.
- Smart keyless unlock and lock are only valid when power supply is shut off and four doors are closed properly, or system will not operate.
- For power saving purpose, after vehicle is parked for 15 days, smart entry for front right door handle will be invalid, only smart entry for front left door handle can be used (it will return to normal if performing remote control unlock once or front left door HSU (door handle sensor) unlock once).
- In some particular situations, such as smart key is too close to door, system may determine the key is inside vehicle, induced door handle to be disabled. In this case, keyless entry function will not operate normally. At this time, it is necessary to use remote control to lock and unlock vehicle.

Remote Entry Function



1	Unlock Button	2	Back Door Open Button
3	Lock Button	4	Remote Start Button

Remote Lock (Fortifying) Function

Press lock button on smart key with power supply OFF, door will be locked, turn signal lights will flash (- once), horn will sound (once) and vehicle will enter fortifying mode.

1. Press lock button with four doors & two covers closed properly, door will be locked, body anti-theft system will be turned on and vehicle will enter fortifying mode.
2. If any door is not closed properly, lock system will not operate.
3. If power supply is in ACC or ON position, remote lock function will not operate to avoid misoperation.

20 - PEPS SYSTEM

4. If doors are closed properly while hood or luggage compartment door is not closed properly, lock system will lock doors, but body anti-theft system cannot be turned on and vehicle will not enter fortifying mode.

Remote Lock (Fortifying Deactivation) Function

Press the remote control unlock button, 4 door locks are unlocked, and turn signal lights flash twice, the vehicle enters the fortifying deactivation state.

Hint:

If any of following operations is not performed within 30 seconds after pressing remote unlock button (- fortifying deactivation) under fortifying mode, all doors will be locked automatically.

1. Open any door
2. Press the ENGINE START STOP switch
3. ENGINE START STOP switch is in ACC or ON position

Description

- Press unlock button, so that door will be unlocked and luggage compartment door external switch will be activated (at this time, press luggage compartment external switch to open luggage compartment even if user does not bring valid key).
- Under fortifying or anti-theft alarm mode, press unlock button to cancel body anti-theft alarm system.

Remote Back Door Function


Long press remote luggage compartment button (about 1.5 seconds), luggage compartment door will be unlocked, at this time, it is still necessary to press back door release switch to open back door (for vehicles without power back door). For vehicles with power back door, the back door will be unlocked automatically.

Hint:

Opening back door by remote control cannot cancel vehicle fortifying.


One-button Start Function**CAUTION**

- For MT models: If clutch pedal is not depressed fully, system will not perform starting operation. For DCT models, if it is not in P or N position, system will not perform starting operation.
- During starting, if brake pedal (for DCT models) or clutch pedal (for MT models) is released halfway, system will suspend starting.
- Press ENGINE START STOP switch then release it when starting, system will judge if starting is successful and stop starting properly.
- For AT models, if it is not in P position, vehicle power supply state (ACC, IGN) will not return to OFF state.



PE0070


1. Indicator does not come on
 - a. Power supply is OFF and brake pedal (for DCT models) or clutch pedal (for MT models) is not depressed, or engine has been started.
2. Amber
 - a. Power supply state: ACC or ON, brake pedal (for DCT models) or clutch pedal (for MT models) is not depressed.
3. Green
 - a. Brake pedal (for DCT models) or clutch pedal (for MT models) is depressed, and engine will start once pressing the button.
4. One-button start function: It can be activated at any power supply state (OFF, ACC, IGN) with legal smart key inside vehicle. Depress brake pedal (for DCT models) or clutch pedal (for MT models), press ENGINE START STOP switch to start engine.



PE0080


20 - PEPS SYSTEM

a. Power supply state switching



5. There are four positions for vehicle power supply: OFF, ACC, ON, ST (ignition). With brake pedal (for DCT models) or clutch pedal (for MT models) not depressed, press ENGINE START STOP switch:

a. Power supply state switching



One-button Stop Function

For common engine stop mode, 4 km/h of vehicle speed must be met.

Hint:

- For DCT models, if it is not in P position, vehicle power supply mode cannot return to OFF, you must shift to P position before leaving vehicle after stopping. And check if power supply state is in OFF. Make sure that vehicle power supply is in OFF state and then leave vehicle. Otherwise, door cannot be locked.
- Simple method for distinguishing power supply in ACC or OFF:
 - Judged by color of indicator on ignition switch.
 - Under ACC state, instrument cluster will illuminate center display edge of LCD.
 - Operate buttons on remote controller, if lock operation is failed and unlock operation is successful, it indicates that vehicle power supply is not in OFF position.

Emergency Stop Function

In order to stop engine in emergency, this system has emergency stop mode.

Hint:

- When vehicle speed is more than 4 km/h, press ENGINE START STOP switch for more than 3 seconds in succession.
- If pressing ENGINE START STOP switch for 3 times within 2 seconds with vehicle speed more than 4 km/h, engine will stop and power supply will return to ACC.

CAUTION

- If this condition is not met, engine will not shut down and ignition switch is kept in ON.
- During driving, emergency stop will seriously affect normal driving. Do not use this function unless in emergency.

Back Up Start Function

1. If key cannot be recognized by system due to weak battery or interference, PEPS system will not operate normally. At this time, system provides a method to back up engine start, following method can be used to start engine or turn on power supply.
 - a. Lay key on bottom of rear cup holder with face up, and do not depress brake pedal (for DCT models) or clutch pedal (for MT models).
 - b. Press the ENGINE START STOP switch once. Power supply state will switch to ON, and “Verification is Successful, it is Possible to Start” is displayed on instrument cluster.
 - c. Depress brake pedal (for DCT/CVT models) or clutch pedal (for MT models) fully, press ENGINE START STOP switch to start engine.

Hint:

For MT models, communication between ESCL and PEPS is failed or verification does not pass, electric steering column lock cannot be unlocked successfully, power supply cannot switch to ON, engine cannot be started, so back up start function is invalid.

Emergency Start Function

1. To prevent engine cannot be started due to signal failure of brake pedal position (for DCT models) or clutch pedal position (For MT models) detected, this system has emergency start mode.

Hint:

Please contact service station for inspection and repair as soon as possible.

Starting Times Limit Function

CAUTION

- Only MT models have this function.
- Keyless entry and PEPS system obtains wheel speed signal from brake controller (ABS/ESP), if any wheel speed signal is malfunctioning, ABS/ESP system warning light in instrument cluster will come on.
- If malfunction does not be repaired and maximum start times is reached, it is not allowed to start vehicle. Please contact Chery service station for repair immediately and reset “rest start times” with diagnostic tester. Otherwise, if same malfunction occurs next time, start times offered by system will be less than 10 times. (Specific value depends on residual times last time malfunction occurs.)

When serious damage occurs in system, in order to ensure driving safety and prevent steering system locking incorrectly, system will not allow user to start engine limitlessly and engine only can be started for 10 time. And each time engine starts successfully and travel, rest times will reduce one. Please contact Chery service station for repair as soon as possible.

Hint:


This system malfunction may be caused by any or several of the following reasons:

- Serious malfunction in the electric steering column lock
- Speed signal malfunction of front right wheel
- Speed signal malfunction of other three wheels

Intelligent Searching Function

This part includes three functions: Welcome function, approach unlocking function, exit locking function.

20 - PEPS SYSTEM



1. Welcome function

- Customer enters into area A, PEPS controls courtesy light on the vehicle to turn on, realizing welcome function.

2. Approach unlocking function

- Customer enters into area C, PEPS controls the vehicle to unlock.

Hint:

PEPS search strategy for enter unlocking: Within 3 days, if the vehicle searches a legal key, the search cycle is 400 ms; if the vehicle does not search a legal key, the search cycle is 1000 ms; 3 days later, the search stops.

3. Exit locking function

- After customer gets off the vehicle and closes all doors, if there is no key in the vehicle, PEPS controls the vehicle to lock when customer gets off enters the yellow area.

Hint:

PEPS search strategy for exit locking: Within 3 days, if the vehicle searches a legal key, the search cycle is 400 ms; if the vehicle does not search a legal key, the search cycle is 1000 ms; 3 days later, the search stops.

Prompt Function

To reduce misunderstanding of PEPS features from users and to facilitate the daily diagnosis of simple problems, system will prompt corresponding message to users through instrument cluster display, buzzer and external horn. Regardless of power supply state (OFF, ACC or ON), once PEPS sends information, instrument cluster will handle and display it.

Text Message Prompt	Buzzer	External Horn	Possible Cause
Smart key is not detected	Sound	\	There is no key in vehicle
Smart key is not detected	Sound	\	If you are in vehicle, find smart key and place it in vehicle, or check if passenger brings the key outside
System malfunction, it is allowed to start X times	Sound	\	Please contact Chery Service Station for repair immediately
Please check and repair PEPS system	Sound	\	Please contact Chery Service Station for repair immediately
Please shift to P or N to start	Sound	\	If you want to start engine, please shift to P or N.
If you want to start engine, depress brake pedal	Sound	\	If you want to start engine, depress brake pedal (for DCT models).
Please shift to P	Sound	\	Please shift to P and press ENGINE START STOP switch to turn off power supply.
Please pay attention that smart key is in vehicle	Sound	Sound 6 times	Be sure to carry smart key on person when leaving vehicle. Caution: Door handle switch will be disabled by system temporarily, please use remote controller to lock and unlock.
Verification is successful and it is possible to start	Sound	\	It is displayed only when performing back up start and verification passed, and key battery is fully discharged usually
Please turn off power supply	Sound	\	User may leave vehicle with shift position not in P and power supply not in OFF
Smart key battery is low	Sound	\	Key battery still can be used, but it comes to failure due to low voltage, it is necessary to replace battery

Engine and Vehicle Anti-theft Function

1. Anti-theft for models with PEPS can be divided into two types.
2. For DCT models, anti-theft can be divided into two separate parts - “PEPS and ECU encryption engine immobilizer” .
3. For MT models, anti-theft can be divided into two separate parts - “PEPS and ECU encryption engine immobilizer” and “PEPS and ESCL encryption steering column lock anti-theft” .
 - a. For DCT models
 - After power supply is turned to ON, ECU will send one frame of validation data to PEPS via CAN bus to verify. Then PEPS will feedback one frame of validation data as response and send to ECU. If response from PEPS is correct, ECU determines that anti-theft is released. Otherwise, ECU will not inject fuel and ignite.
 - b. For MT models
 - After power supply is turned to ACC, PEPS will perform encrypted anti-theft validation with ESCL via special LIN line. If validation passes, ESCL will unlock, or ESCL keeps locking and steering wheel cannot be turned. And power supply cannot be turned to ON.
 - After power supply is turned to ON, ECU will send one frame of validation data to PEPS via CAN bus to verify. Then PEPS will feedback one frame of validation data as response and send to ECU. If response from PEPS is correct, ECU will determine anti-theft can be canceled. Otherwise, ECU will not inject fuel and ignite.


Anti-theft Matching

Software Configuration Code Writing


1. Click “PEPS (Passive Entry And Passive Start System)” .

2. Select and click “Special Function” .






3. Click “Write Software Configuration Code” .




20 - PEPS SYSTEM

4. Click “Write Vehicle Software Configuration Information Manually” .



5. Input corresponding configuration information and click “Confirm” .

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



Remote Control Troubleshooting Chart

Description		Remote control button failure, vehicle cannot enter fortifying/deactivation/fortifying mode				
Inspection Sequence	Problem Symptom	Troubleshooting Items	Test Result	Subsequent Step	Step Description	Step Instruction
1	One wireless key fails	Put the invalid wireless key into cup holder (the cup holder with key mark), and use a diagnostic tester to read if a legal transponder is searched through anti-theft system status detection.	No	It detects that the transponder is illegal, indicating that the key does not match with the vehicle, which may be caused by mixed installation.	\	Add a new key with another key.
			Yes	It detects that the transponder is legal, indicating that the key matches	\	Add a new key with another key.

20 - PEPS SYSTEM

Description		Remote control button failure, vehicle cannot enter fortifying/deactivation/fortifying mode				
Inspection Sequence	Problem Symptom	Troubleshooting Items	Test Result	Subsequent Step	Step Description	Step Instruction
				with the vehicle, and it is determined as a quality problem in remote controller itself.		
2	Two wireless keys fail	Disconnect and reconnect the first connector of PEPS module, and check if fault disappears.	Yes	It is determined that the connector is not connected properly, disconnect and reconnect J1 connector.	\	\
			No	Eliminate the interference occurred after installation, and test the remote controller in an open area. If fault still exists, apply for replacing the PEPS module.	Consider the PEPS module fault.	Replace PEPS module, if fault still exists after replacement, contact the technical support department for on-site system troubleshooting.
3	Remote control distance between two keys is very short	Confirm if there is interference source when fault occurs. (If electrical appliances are installed on vehicle, if there are interference sources on site, and if there are	Yes	Eliminate the interference source (- remove installed electrical appliances, move vehicle to an open area, and remove metal trims on the	\	Eliminate the external interference.

Description		Remote control button failure, vehicle cannot enter fortifying/deactivation/fortifying mode				
Inspection Sequence	Problem Symptom	Troubleshooting Items	Test Result	Subsequent Step	Step Description	Step Instruction
		metal trims on the remote controller)		remote controller).		
					Fault disappears, it is considered as interference problem in 360 module.	Replace the 360 module.
		Confirm if vehicle is equipped with 360 panoramic view monitor.	Yes	Unplug 360 module connector, and confirm if fault disappears.	Fault still exists, it is considered as problem in PEPS module.	Replace PEPS module, if fault still exists after replacement, contact the technical support department for on-site system troubleshooting.
			No	Test remote control distance in an open area. If fault still exists, take replacing PEPS module into consideration.	After replacing PEPS module, if fault disappears, reason is searched; if fault still exists, it is necessary to perform on-site system troubleshooting.	Replace PEPS module, if fault still exists after replacement, contact the technical support department for on-site system troubleshooting.

Smart Key Replacement After Vehicle Sold

Description

CAUTION

If user lost a smart key with one key left, when replacing with a new smart key, perform as follows to replace with a new one: Learn the new key by “Add new key” service, delete all smart keys by “Delete all keys” service, then learn the remain two smart keys in order by “Add old key” service. If user finds the lost key, it can be reactivated by “Add old key” service on diagnostic tester. If not, even if the lost one is found, it cannot be used normally.

There are two match methods between smart key and system: “Replace with new key” and “Add old key” .

1. “Add new key” refers to match blank key (never match with any system) with system. It usually happens when user would have additional new key on the basis of the old ones.
2. “Add old key” refers to rematch learned key with system (it must be previous system).

Match Operation

CAUTION

Perform “Add new key” and “Add old key” when the ignition switch is in OFF position.

1. Anti-theft match description for “Add new key” is as follows:
 - a. Technician reads VIN in EMS of user’ s vehicle with diagnostic tester, then obtain PIN through VIN.
 - b. Place the smart key to be matched on the key mark in cup holder, enter anti-theft control system program on diagnostic tester, select “Add new key” menu, input PIN, diagnostic tester will perform “Add new key” program automatically.
 - c. After that, press unlock button and check if left and right turn signal light indicators on instrument cluster blink. If the indicators blink, new key is matched successfully, otherwise, new key is not matched successfully.
2. Anti-theft match description for “Add old key” is as follows:
 - a. Technician reads VIN in EMS of user’ s vehicle with diagnostic tester, then obtain PIN through VIN.
 - b. Enter anti-theft control system program on diagnostic tester, select “Delete all keys” menu.
 - c. Place the smart key to be matched on the key mark in cup holder, enter anti-theft control system program on diagnostic tester, select “Add old key” menu, input PIN, diagnostic tester will perform “Add old key” program automatically.
 - d. After that, press unlock button and check if left and right turn signal light indicators on instrument cluster blink. If the indicators blink, new key is matched successfully, otherwise, new key is not matched successfully.

CAUTION

- When performing “Add old key” , it is necessary to carry previous matched smart key and perform match operation one by one according to match procedures, or previous matched key will be disabled.
- Regardless of “Add new key” or “Add old key” , only one smart key can be kept in vehicle and keep key on key mark in cup holder. Make sure that there is no other key in vehicle. If there is other key, bring it to a position 2 m away from vehicle.

PEPS Module Replacement After Vehicle Sold

CAUTION

- Please contact Chery service station to obtain PIN.
- Unmatched smart keyless entry and PEPS can switch power supply from IGN OFF to IGN ON for 50 times. Once it exceeds 50 times, PEPS cannot be used. So, do not turn on and off power supply at will with PEPS unmatched.
- If ESCL accidentally enters “Anti-scanning” safe mode, it is necessary to perform “Delete ESCL”.

1. Technician reads VIN in EMS with diagnostic tester, then obtains PIN through VIN.
2. If vehicle is equipped with ESCL, make sure that ESCL is unlocked. After new PEPS is assembled successfully, press ignition switch (IG) to turn on power supply.
3. Enter anti-theft control system program on diagnostic tester, select “Program IMMO” menu; input PIN according to prompt on diagnostic tester, after “Program IMMO” is performed successfully, it will display “Program IMMO is successful”.
4. Then match previous keys one by one according to instructions of “Add old key”.
5. If vehicle is equipped with ESCL, enter anti-theft control system program on diagnostic tester and complete “Add old key”, then keep power supply in OFF position, check state of ESCL with diagnostic tester, if ESCL is not in Anti-scanning state, replacement is completed, if ESCL is in Anti-scanning state, select “Delete ESCL”, input PIN according to prompt on diagnostic tester, ESCL will be deleted successfully after about 10 minutes, then match ESCL according to description for ESCL replacement.

Engine Management System (EMS) Replacement After Vehicle Sold

1. Technician reads VIN in old EMS or smart keyless entry and PEPS unit with diagnostic tester, then obtains PIN through VIN.
2. After new EMS is assembled successfully, press ignition switch (IG) to turn on power supply.
3. Enter anti-theft control system program on diagnostic tester, select “Program EMS” menu; input VIN and PIN according to prompts on diagnostic tester. After “Program EMS” is performed successfully, it will display “Match EMS is successful”.
4. Depress brake pedal (for DCT models)/clutch pedal (for MT models), press ignition switch once to check if vehicle can be started successfully. If vehicle can be started successfully, EMS replacement is completed, if vehicle cannot be started successfully, EMS replacement is not completed.

Electric Steering Column Lock (ESCL) Replacement After Vehicle Sold

CAUTION

- Only apply to PEPS + MT models
- Please contact Chery service station to obtain PIN.

1. Technician reads VIN in old EMS or smart keyless entry and PEPS unit with diagnostic tester, then obtains PIN through VIN.
2. After new ESCL is assembled successfully, keep power supply in OFF position.
3. Enter immobilizer control system program on diagnostic tester, select Program ESCL menu; Input PIN according to prompt on diagnostic tester, after Program ESCL is successful, “ESCL matching is successful” will be displayed on diagnostic tester.
4. Press ignition switch to switch power supply to IGN OFF state, open driver door and close it again, check if lock sound can be heard, then check if steering wheel can be turned. If lock sound can be heard and steering wheel cannot be turned, electric steering column lock is locked successfully.

20 - PEPS SYSTEM

5. Press ignition switch to switch vehicle power supply to IGN ON state, check if unlock sound can be heard, then check if steering wheel can be turned. If unlock sound can be heard and steering wheel can be turned, electronic steering column lock is unlocked successfully, ESCL matching is successful, or matching fails.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DIAGNOSIS & TESTING

Diagnosis Contents

Problem Symptoms Table

Symptom	Suspected Area
Luggage compartment cannot be opened	Back door switch fails (open, water leakage or sticking)
	Back door lock malfunction
	PEPS malfunction
	Short or open in wire harness
	BCM malfunction
Vehicle cannot be started (PEPS) (starter runs)	Anti-theft verification does not pass
Vehicle cannot be started (PEPS) (starter does not run)	Gear position is not in P/N (for DCT models)
	Clutch (for MT models)/brake switch (for DCT models) is abnormal
	ENGINE START STOP switch malfunction
	Circuit or starter relay is abnormal
	Starter malfunction
ESCL cannot be locked or unlocked	Start times limit is activated
	Vehicle is parked on slope (lock pin is stuck)
	Door signal is abnormal
	ENGINE START STOP switch cannot be turned on or off
	Short or open in wire harness
	Anti-theft verification fails
	Network communication malfunction

Problem Repair (No DTC)

If PEPS system has problems, but no DTC is stored in PEPS system, this problem is called a problem without DTC. Problems without DTC for PEPS system are divided into following types:

1. Indicator in instrument cluster does not come on or illuminates constantly (incorrect wire harness connection or indicator is damaged).
2. Troubleshooting recommendation: Check corresponding components according to problem symptom, and troubleshoot by following the vehicle repair manual.

Diagnostic Help

1. Connect diagnostic tester X-431 3G (the latest software) to Data Link Connector (DLC), and make it communicate with vehicle electronic module through data network.
2. Confirm that malfunction is current, and carry out diagnostic test and repair procedures.

20 - PEPS SYSTEM

3. If Diagnostic Trouble Code (DTC) cannot be cleared, it indicates that there is a current malfunction.
4. Only use a digital multimeter to measure voltage of electronic system.
5. Refer to any Technical Bulletin that may apply to this malfunction.
6. Visually check related wire harness and connector.
7. Check and clean all CD system grounds related to the latest DTCs.
8. If numerous trouble codes are set, refer to circuit diagram and look for any common ground circuit or power supply circuit applied to DTC.

Intermittent DTC Troubleshooting

If malfunction is intermittent, perform the followings:

- Check if connector is loose.
- Check if wire harness is worn, pierced, pinched or partially broken.
- Monitor diagnostic tester (the latest software) data that is related to this circuit.
- Wiggle related wire harnesses and connectors and observe if signal is interrupt in related circuit.
- If possible, try to duplicate the conditions under which DTC was set.
- Look for data that has changed or DTC to reset during wiggling test.
- Look for broken, bent, protruded or corroded terminals.
- Inspect airbag components and mounting areas for damage, foreign matter, etc. that will cause incorrect signals.
- Check and clean all wire harness connectors and ground parts related to DTC.
- If multiple trouble codes were set, refer to circuit diagrams to look for any common ground circuit or power supply circuit applied to DTC.
- Refer to any Technical Bulletin that may apply to this malfunction.

Ground Inspection

Ground points are very important to the proper operation of circuits. Ground points are often exposed to moisture, dirt and other corrosive environments. Corrosion (rust) may increase load resistance. This situation may change the way in which a circuit operates. Circuits are very sensitive to proper grounding. A loose or corroded ground can seriously affect the control circuit. Check the ground points as follows:

1. Remove ground bolt or nut.
2. Check all contact surfaces for tarnish, dirt and rust, etc.
3. Clean as necessary to ensure that contact is in good condition.
4. Reinstall ground bolt or nut securely.
5. Check if any additional accessories interfere with ground circuit.
6. If several wire harnesses are crimped into one ground terminal, check for proper crimp condition. Make sure that all wire harnesses are clean and securely fastened while providing a proper ground path.

Diagnostic Trouble Code (DTC) Chart

DTC	DTC Definition
B1300	Internal Control Module EEPROM Error
B1301	Immobilizer and ECM Authentication Failed
B1302	VIN Not Programmed
B1305	Immobilizer with No Key Stored
B1306	Security Code Not Programmed

DTC	DTC Definition
B1500	Open Circuit of Driver Door Outside LF Antenna
B1501	Open Circuit of Passenger Door Outside LF Antenna
B1502	Open Circuit of Front Internal LF Antenna
B1505	Open Circuit of Bumper LF Antenna
B1521	Open Circuit of Backup Antenna
B1522	Open Circuit on Drive Door PSU
B1523	Open Circuit on Passenger Door PSU
B1524	Short Circuit of (Driver Side) Rear Left LF Antenna
B1525	Short Circuit of (Passenger Side) Rear Right LF Antenna
B1526	Short Circuit of Front Internal LF Antenna
B1527	Short Circuit of Bumper LF Antenna
B1528	Short Circuit of Backup Antenna
B1529	Short Circuit on Driver Door HSU/PSU
B152A	Short Circuit on Passenger Door HSU/PSU
B152B	Stuck on Driver Door HSU/PSU
B152C	Stuck on Passenger Door HSU/PSU
B1518	Trunk/Back Door Unclock Switch Stuck Failure
B152D	SSB Stuck
B1506	Abnormality on Switches of Engine Switch
B1507	Abnormality in IG Circuit
B1508	Abnormality in ACC Circuit
B152E	START Fail
B1509	Abnormality in Brake Signal
B150C	Clutch Switch Signal Error
B1515	ROM Checksumm Failure
B152F	Battery Voltage Low Detection
B1530	Battery Voltage High Detection
U0073	CAN Bus Off
U0100	Lost of communication with EMS
U0101	Lost of Communication with Transmission Control Unit
U0129	Lost communication with BSM

20 - PEPS SYSTEM

DTC	DTC Definition
U0140	Lost communication with BCM
U1190	Lost Communication with ESCL
U0155	Lost Communication with ICM
U0230	Lost Communication with PLG
U0531	Invalid Data Received From PLG
U0401	Invalid Data Received From EMS
U0418	Invalid Data Received From BSM
U0402	Invalid Data Received From TCU
U059C	Invalid Data Received From ESCL
U1300	Software Configuration Error

DTC Diagnosis Procedure

DTC	B1300	Internal Control Module EEPROM Error
DTC	DTC Definition	Possible Causes
B1300-00	Internal Control Module EEPROM Error	PEPS module

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing the following procedures.


- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

1	Check for DTCs
---	----------------


(a) Using diagnostic tester, clear DTC and read DTC again.
 (b) Check if DTC occurs again.



OK

2	Reconfirm DTCs
---	----------------

(a) Connect diagnostic tester and clear DTCs.
 (b) Run the vehicle as specified procedure. The operating way should meet the conditions for corresponding fault diagnosis.
 (c) Read the fault information and confirm that the fault has been solved.



DTC	B1301	Immobilizer and ECM Authentication Failed
DTC	B1515	ROM Checksum Failure

DTC	DTC Definition	Possible Causes
B1301-00	Immobilizer and ECM Authentication Failed	It may be necessary to perform anti-theft match for PEPS and ECU module again
B1515-45	ROM Checksum Failure	

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing the following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

1 Check for DTCs

- Using diagnostic tester, clear DTC and read DTC again.
- Check if DTC occurs again.

It may be necessary to perform anti-theft match for PEPS and EMS module again.

2 Reconfirm DTCs

Use circuit diagram as a guide to perform the following inspection procedures:

- Connect diagnostic tester and clear DTCs.
- Run the vehicle as specified procedure. The operating way should meet the conditions for corresponding fault diagnosis.
- Read the fault information and confirm that the fault has been solved.

Replace with a new PEPS module to check if fault reoccurs.

Conduct test and confirm malfunction has been repaired

DTC	B1302	VIN Not Programmed
------------	--------------	---------------------------

20 - PEPS SYSTEM

DTC	DTC Definition	Possible Causes
B1302	VIN Not Programmed	It may be necessary to input VIN into PEPS again

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing the following procedures.


- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

1	Check for DTCs
---	-----------------------


(a) Using diagnostic tester, clear DTC and read DTC again.
 (b) Check if DTCs occur again.



2	Reconfirm DTCs
---	-----------------------

Use circuit diagram as a guide to perform the following inspection procedures:

(a) Connect diagnostic tester and clear DTCs.
 (b) Run the vehicle as specified procedure. The operating way should meet the conditions for corresponding fault diagnosis.
 (c) Read the fault information and confirm that the fault has been solved.



DTC	B1305	Immobilizer with No Key Stored
-----	-------	--------------------------------

DTC	DTC Definition	Possible Causes
B1305-00	Immobilizer with No Key Stored	PEPS control module assembly is damaged

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing the following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

1 Check for DTCs

(a) Using diagnostic tester, clear DTC and read DTC again.
 (b) Check if DTCs occur again.

NG

Enter anti-theft system and add key

OK

2 Reconfirm DTCs

Use circuit diagram as a guide to perform the following inspection procedures:

(a) Connect diagnostic tester and clear DTCs.
 (b) Run the vehicle as specified procedure. The operating way should meet the conditions for corresponding fault diagnosis.
 (c) Read the fault information and confirm that the fault has been solved.

NG

Replace with a new PEPS control module to check if fault reoccurs

OK

Conduct test and confirm malfunction has been repaired

DTC	B1306	Security Code Not Programmed
------------	--------------	-------------------------------------

DTC	DTC Definition	Possible Causes
B1306	Security Code Not Programmed	PEPS control module assembly is damaged

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing the following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

1 Check for DTCs

(a) Using diagnostic tester, clear DTC and read DTC again.
 (b) Check if DTCs occur again.

NG

Rematch PEPS module


OK

20 - PEPS SYSTEM

2 Reconfirm DTCs

Use circuit diagram as a guide to perform the following inspection procedures:

- Connect diagnostic tester and clear DTCs.
- Run the vehicle as specified procedure. The operating way should meet the conditions for corresponding fault diagnosis.
- Read the fault information and confirm that the fault has been solved.



DTC	B1500	Open Circuit of Driver Door Outside LF Antenna
DTC	B1501	Open Circuit of Passenger Door Outside LF Antenna
DTC	B1522	Open Circuit on Drive Door PSU
DTC	B1523	Open Circuit on Passenger Door PSU
DTC	B1529	Short Circuit on Driver Door HSU/PSU
DTC	B152A	Short Circuit on Passenger Door HSU/PSU
DTC	B152B	Stuck on Driver Door HSU/PSU
DTC	B152C	Stuck on Passenger Door HSU/PSU

DTC	DTC Definition	Possible Causes
B1500	Open Circuit of Driver Door Outside LF Antenna	
B1501	Open Circuit of Passenger Door Outside LF Antenna	
B1522	Open Circuit on Drive Door PSU	
B1523	Open Circuit on Passenger Door PSU	PEPS control module or interior wire harness is damaged
B1529	Short Circuit on Driver Door HSU/PSU	
B152A	Short Circuit on Passenger Door HSU/PSU	
B152B	Stuck on Driver Door HSU/PSU	
B152C	Stuck on Passenger Door HSU/PSU	

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing the following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.

- If DTC is not detected, malfunction is intermittent.


Hint:

- Take driver side micro switch as an example to explain troubleshooting procedures for reference.
- When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

1 Check if PEPS module output voltage is normal

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect the PEPS module connector I-028.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Connect the negative battery cable, turn ENGINE START STOP switch to ON, use DC voltage band of digital multimeter to measure if voltage between terminals 16 and 36 of PEPS connector I-028 is normal.

Multimeter Connection	Condition	Specified Condition
I-028 (16) - I-028 (36)	Always	12V



NG


Replace PEPS control module assembly

OK

2 Check door handle sensor

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect the front left door sensor connector F-014.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- The outside handle is capacitive sensing type. Using ohm band of digital multimeter, measure the resistance of front left door outside handle.

Multimeter Connection	Condition	Specified Condition
F-014 (1) - F-014 (2)	OK	No continuity



NG

Replace left door handle sensor

OK

20 - PEPS SYSTEM


3 | Check front left door wire harness for open or short

- Disconnect the front left door outside handle wire harness connector F-014.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, check for continuity between terminals 1, 2 of connector F-014 and terminals 16, 36 of PEPS module connector I-028 to check for open in front left door wire harness.

Multimeter Connection	Condition	Specified Condition
F-014 (1) - I-028 (16)	Always	$\leq 1 \Omega$
F-014 (2) - I-028 (36)	Always	$\leq 1 \Omega$

NG


Repair or replace ground circuit of front left door handle sensor



PE0220

- Using ohm band of digital multimeter, measure resistance between terminals 1, 2 of front left door wire harness connector F-014 and body ground separately to check for short to body ground in front left door wire harness.

Multimeter Connection	Condition	Specified Condition
F-014 (1) - Body ground	Always	No continuity
F-014 (2) - Body ground	Always	No continuity



PE0230

NG


Replace interior wire harness

OK

4 | Reconfirm DTCs

Use circuit diagram as a guide to perform the following inspection procedures:

- Connect diagnostic tester and clear DTCs.
- Run the vehicle as specified procedure. The operating way should meet the conditions for corresponding fault diagnosis.
- Read the fault information and confirm that the fault has been solved.



DTC	B1502	Open Circuit of Front Internal LF Antenna
DTC	B1526	Short Circuit of Front Internal LF Antenna

DTC	DTC Definition	Possible Causes
B1502-13	Open Circuit of Front Internal LF Antenna	Front internal low frequency antenna or interior wire harness is damaged
B1526	Short Circuit of Front Internal LF Antenna	

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing the following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

1 Check if PEPS module software configuration code is correct

- (a) Use diagnostic tester to enter PEPS system.
- (b) Read software configuration code and check if it is correct.



2 Measure resistance of front low frequency antenna


20 - PEPS SYSTEM

Use circuit diagram as a guide to perform the following inspection procedures:

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect the front low frequency antenna connector I-079.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, measure if resistance between terminals 1 and 2 of front low frequency antenna connector I-079 is normal.

Multimeter Connection	Condition	Specified Condition
I-079 (1) - I-079 (2)	Always	Always $\approx 10 \text{ k}\Omega$

NG Replace low frequency antenna




3 Check interior wire harness for open or short

Use circuit diagram as a guide to perform the following inspection procedures:

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect front low frequency antenna connector I-079 and PEPS module connector I-028.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, check for continuity between terminals 1, 2 of connector I-079 and terminals 13, 33 of connector I-028 to check for open in instrument panel wire harness.


Multimeter Connection	Condition	Specified Condition
I-079 (1) - I-028 (13)	Always	$\leq 1 \Omega$
I-079 (2) - I-028 (33)	Always	$\leq 1 \Omega$



Use circuit diagram as a guide to perform the following inspection procedures:

(h) Using ohm band of digital multimeter, check for continuity between terminals 1, 2 of connector I-079 and body ground to check for short to ground in instrument panel wire harness.

Multimeter Connection	Condition	Specified Condition
I-079 (1) - Body ground	Always	No continuity
I-079 (2) - Body ground	Always	No continuity



PE0260

NG

Replace instrument panel wire harness

OK

4 Reconfirm DTCs

Use circuit diagram as a guide to perform the following inspection procedures:

(a) Connect diagnostic tester and clear DTCs.
 (b) Run the vehicle as specified procedure. The operating way should meet the conditions for corresponding fault diagnosis.
 (c) Read the fault information and confirm that the fault has been solved.

NG

Replace PEPS module

OK

Conduct test and confirm malfunction has been repaired

DTC	B1505	Open Circuit of Bumper LF Antenna
DTC	B1527	Short Circuit of Bumper LF Antenna

DTC	Description	Possible Causes
B1505	Open Circuit of Bumper LF Antenna	Low frequency antenna or wire harness is damaged
B1527	Short Circuit of Bumper LF Antenna	

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing the following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

20 - PEPS SYSTEM

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

1	Check if PEPS module software configuration code is correct
---	---

- (a) Use diagnostic tester to enter PEPS system.
- (b) Read software configuration code and check if it is correct.


NG	Input configuration code again and clear DTC
----	--

OK

2	Measure resistance of bumper low frequency antenna
---	--

Use circuit diagram as a guide to perform the following inspection procedures:

- (a) Turn ENGINE START STOP switch to OFF.
- (b) Disconnect the negative battery cable.
- (c) Disconnect the bumper low frequency antenna connector B-080.
- (d) Check if wire harnesses are worn, pierced, pinched or partially broken.
- (e) Check for broken, bent, protruded or corroded terminals.
- (f) Check if related connector pins are in good condition.
- (g) Using ohm band of digital multimeter, measure if resistance between terminals 1 and 2 of front low frequency antenna connector B-080 is normal.



Multimeter Connection	Condition	Specified Condition
B-080 (1) - B-080 (2)	Always	$\approx 10 \text{ K}\Omega$

NG	Replace bumper low frequency antenna
----	--------------------------------------


OK

3	Check interior wire harness for open or short
---	---

Use circuit diagram as a guide to perform the following inspection procedures:

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect bumper low frequency antenna connector B-080 and PEPS module connector I-028.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, check for continuity between terminals 1 and 2 of B-080 and terminals 14 and 34 of I-028 to check for open in instrument panel wire harness.


Multimeter Connection	Condition	Specified Condition
B-080 (1) - I-028 (14)	Always	$\leq 1 \Omega$
B-080 (2) - I-028 (34)	Always	$\leq 1 \Omega$



Use circuit diagram as a guide to perform the following inspection procedures:

- Using digital multimeter, measure voltage between terminal 1 of bumper low frequency antenna B-080 and body ground, to check if the PEPS module has power output.

Multimeter Connection	Condition	Specified Condition
B-080 (1) - Body ground	Always	12 V




20 - PEPS SYSTEM

Use circuit diagram as a guide to perform the following inspection procedures:

(i) Using ohm band of digital multimeter, check for continuity between terminals 1, 2 of connector I-080 and body ground to check for short to ground in instrument panel wire harness.

Multimeter Connection	Condition	Specified Condition
B-080 (1) - Body ground	Always	No continuity
B-080 (2) - Body ground	Always	No continuity



NG

Replace instrument panel wire harness

OK

4 Reconfirm DTCs

Use circuit diagram as a guide to perform the following inspection procedures:

(a) Connect diagnostic tester and clear DTCs.
 (b) Run the vehicle as specified procedure. The operating way should meet the conditions for corresponding fault diagnosis.
 (c) Read the fault information and confirm that the fault has been solved.

NG

Replace PEPS module

OK

Conduct test and confirm malfunction has been repaired

DTC	B152D	SSB Stuck
DTC	B1506	Abnormality on Switches of Engine Switch
DTC	B1507	Abnormality in IG Circuit
DTC	B152E	START Fail

DTC	Description	Possible Causes
B152D	SSB Stuck	PEPS control module is damaged, ignition switch has failed, wire harness is damaged
B1506	Abnormality on Switches of Engine Switch	
B1507	Abnormality in IG Circuit	
B152E	START Fail	

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing the following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.


1	Enter PEPS system and read related datastream
---	--

(a) Read datastream “Power Supply Management and Starting State” and “Engine Switch Backlight State” .

(b) Press ENGINE START STOP switch, check datastream conversion activation state and backlight illumination state, To determine whether the ENGINE START STOP switch input is normal.

 OK

Turn off vehicle power supply (- disconnect the negative battery cable), then clear DTC again

 NG

2	Check ENGINE START STOP switch
---	---------------------------------------

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

20 - PEPS SYSTEM


Use circuit diagram as a guide to perform the following inspection procedures:

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect the ENGINE START STOP switch connector I-019.
- Using ohm band of digital multimeter, measure resistance of ENGINE START STOP switch to check if ENGINE START STOP switch is normal.

Multimeter Connection	Condition	Specified Condition
ENGINE START STOP switch terminal 2 - 1	Not pressed	No continuity
ENGINE START STOP switch terminal 2 - 1	Pressed	$\leq 1 \Omega$
ENGINE START STOP switch terminal 2 - 3	Not pressed	No continuity
ENGINE START STOP switch terminal 2 - 3	Pressed	$\leq 1 \Omega$
ENGINE START STOP switch terminal 1 - 3	Not pressed	No continuity
ENGINE START STOP switch terminal 1 - 3	Pressed	$\leq 1 \Omega$
ENGINE START STOP switch terminal 4 - 2	Not pressed	$\approx 6.33 K\Omega$

NG

Replace ENGINE START STOP switch




OK

3	Check instrument cluster wire harness for open or short
---	---

Use circuit diagram as a guide to perform the following inspection procedures:

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect ENGINE START STOP switch connector I-019 and PEPS module connector I-028.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, check for continuity between I-019 (1) and I-028 (8), I-019 (2) and I-028 (28), I-019 (3) and I-028 (7), I-019 (4) and I-028 (25) to check for open circuit.


Multimeter Connection	Condition	Specified Condition
I-019 (1) - I-028 (8)	Always	$\leq 1 \Omega$
I-019 (2) - I-028 (28)	Always	$\leq 1 \Omega$
I-019 (3) - I-028 (7)	Always	$\leq 1 \Omega$
I-019 (4) - I-028 (25)	Always	$\leq 1 \Omega$



Use circuit diagram as a guide to perform the following inspection procedures:

- Using ohm band of digital multimeter, check for continuity between terminals 1, 2, 3 and 4 of connector I-019 and body ground to check for short to ground in instrument panel wire harness.


Multimeter Connection	Condition	Specified Condition
I-019 (1) - Body ground	Always	No continuity
I-019 (2) - Body ground	Always	No continuity
I-019 (3) - Body ground	Always	No continuity
I-019 (4) - Body ground	Always	No continuity



20 - PEPS SYSTEM

Use circuit diagram as a guide to perform the following inspection procedures:

(i) Connect the negative battery cable (confirm that connectors I-019 and I-028 are disconnected). Bridge joint ACC relay and IGN1 relay (ENGINE START STOP switch is disabled). Using DC voltage band of digital multimeter, measure voltage between terminals 1, 2, 3 and 4 of connector I-019 and body ground to check for short to power supply in instrument panel wire harness.




Multimeter Connection	Condition	Specified Condition
I-019 (1) - Body ground	Always	0V
I-019 (2) - Body ground	Always	0V
I-019 (3) - Body ground	Always	0V
I-019 (4) - Body ground	Always	0V



4 **Reconfirm DTCs**

Use circuit diagram as a guide to perform the following inspection procedures:

(a) Connect diagnostic tester and clear DTCs.
 (b) Run the vehicle as specified procedure. The operating way should meet the conditions for corresponding fault diagnosis.
 (c) Read the fault information and confirm that the fault has been solved.



DTC	B1508		Abnormality in ACC Circuit
DTC	DTC Definition		Possible Causes
B1508	Abnormality in ACC Circuit		ACC relay, body ground and wire harness malfunction

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing the following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

1 Check fuse

(a) Use circuit diagram as a guide to perform the following inspection procedures:

(b) Check if fuse SB02 15A is blown or no power.

NG

Replace fuse or check the cause for no power

OK

2 Check if fuse base jack is abnormal

Use circuit diagram as a guide to perform the following inspection procedures:

(a) Remove fuse SB02-15A in engine compartment fuse and relay box, and check fuse base jack for excessive clearance.

NG

Adjust fuse base jack

OK

3 Exchange ACC relay

NG

Replace ACC relay

OK

4 Check if relay switch power supply is normal

Use circuit diagram as a guide to perform the following inspection procedures:

(a) Unplug ERLY14 relay in engine compartment fuse box.
 (b) Using 21 W test light or digital multimeter, measure if power supply of ACC relay base No.30 jack is normal.

Multimeter Connection	Condition	Specified Condition
ACC relay base 30 - Body ground (digital multimeter)	Always	Not less than 12 V
ACC relay base 30 - Body ground (21 W test light)	Always	ON

20 - PEPS SYSTEM

NG

Replace front bumper wire harness

OK

5

Short connect the ACC relay base jack control switch

Use circuit diagram as a guide to perform the following inspection procedures:

(a) Use a wire to bridge joint jacks 30 and 87 of ERLY14 relay base in engine compartment fuse and relay box, and check for open in engine compartment fuse and relay box.

NG

Replace front bumper wire harness

OK

6

Check ACC relay control body ground

Use circuit diagram as a guide to perform the following inspection procedures:

(a) Using ohm band of digital multimeter, check for continuity between jack 86 of ACC relay base and terminal H8 of engine compartment fuse and relay box B-024 to check for open in engine compartment fuse and relay box.

Multimeter Connection	Condition	Specified Condition
ACC relay base 86 - B-024 (H8) 4	Always	$\leq 1 \Omega$



Use circuit diagram as a guide to perform the following inspection procedures:

(b) Using ohm band of digital multimeter, check for continuity between terminal H7 of engine compartment fuse and relay box B-024 and ground point GB-603 to check if ground circuit is normal.

Multimeter Connection	Condition	Specified Condition
B-024 (H7) - GB-603	Always	$\leq 1 \Omega$

NG

Adjust GB-603 ground position or replace front bumper wire harness

OK

7

Check ACC relay control power supply terminal

Use circuit diagram as a guide to perform the following inspection procedures:

- Disconnect the negative battery cable.
- Disconnect the PEPS module connector I-028.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, measure resistance between terminal H8 of engine compartment fuse and relay box B-024 and terminal 40 of I-028.

Multimeter Connection	Condition	Specified Condition
B-024 (H8) - I-028 (40)	Always	$\leq 1 \Omega$

NG

Replace wire harness

OK

8 Reconfirm DTCs

Use circuit diagram as a guide to perform the following inspection procedures:

- Connect diagnostic tester and clear DTCs.
- Run the vehicle as specified procedure. The operating way should meet the conditions for corresponding fault diagnosis.
- Read the fault information and confirm that the fault has been solved.

NG

Replace PEPS module

OK

Conduct test and confirm malfunction has been repaired

DTC	B1509	Abnormality in Brake Signal
-----	-------	-----------------------------

DTC	Description	Possible Causes
B1509	Abnormality in Brake Signal	Wire harness, PEPS controller or brake switch is damaged

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing the following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

20 - PEPS SYSTEM

1 Check for DTCs

(a) Using diagnostic tester, clear DTC and read PEPS control module assembly DTC again.
 (b) Check if DTCs occur again.



System is normal

NG

2 Using diagnostic tester, enter other system


(a) Using diagnostic tester, enter other system (such as ESP module, TCU) and check if same DTC occurs.

NG

3 Check interior wire harness and connector

Use circuit diagram as a guide to perform the following inspection procedures:

(a) Turn ENGINE START STOP switch to OFF.
 (b) Disconnect the negative battery cable.
 (c) Disconnect instrument panel wire harness connector, interior wire harness connector and PEPS module connector I-028.
 (d) Check if wire harnesses are worn, pierced, pinched or partially broken.
 (e) Check for broken, bent, protruded or corroded terminals.
 (f) Check if related connector pins are in good condition.
 (g) Using ohm band of digital multimeter, check for continuity between terminal 26 of connector I-028 and terminal 3 of brake switch connector B-101 to check for open.




Multimeter Connection	Condition	Specified Condition
I-028 (26) - B-101 (3)	Always	$\leq 1 \Omega$

Use circuit diagram as a guide to perform the following inspection procedures:

(h) Using ohm band of digital multimeter, check for continuity between terminal 26 of connector I-028 and body ground to check for short to body ground.

Multimeter Connection	Condition	Specified Condition
I-028 (26) - Body ground	Always	No continuity



NG

Replace interior wire harness

OK

Replace PEPS module

4

Check fuse

Use circuit diagram as a guide to perform the following inspection procedures:

(a) Measure fuse EF32-10A in engine compartment fuse and relay box with 21 W test light.

NG

Replace fuse

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

OK

5


Check brake switch

20 - PEPS SYSTEM

Use circuit diagram as a guide to perform the following inspection procedures:

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect the connector B-101.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using digital multimeter, measure internal resistance of brake switch to check if brake switch is abnormal

Multimeter Connection	Condition	Specified Condition
B-101(1) - B-101 (3)	Brake pedal not depressed	No continuity
B-101(1) - B-101 (3)	Brake pedal depressed	$\leq 1 \Omega$
B-101(2) - B-101 (4)	Brake pedal not depressed	$\leq 1 \Omega$
B-101(2) - B-101 (4)	Brake pedal depressed	No continuity




6 Check fuse base jack

Use circuit diagram as a guide to perform the following inspection procedures:

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Remove fuse EF32-10A in engine compartment fuse and relay box and check base jack for excessive clearance.



PE0370



7 Check fuse base jack input power supply

Use circuit diagram as a guide to perform the following inspection procedures:

- Connect the negative battery cable.
- Turn ignition switch to ON.
- Measure fuse jack input power supply with 21 W test light and check if test light comes on.

OK

NG


Replace fuse EF32-10A

8 Check brake switch power supply voltage

Use circuit diagram as a guide to perform the following inspection procedures:

- Connect the negative battery cable.
- Turn ignition switch to ON.
- Using digital multimeter, check if there is 12 V voltage between terminal E9 of engine compartment fuse and relay box B-022 and body ground.
- Using digital multimeter, check for continuity between terminal E9 of engine compartment fuse and relay box B-022 and terminal 1 of brake light switch B-101 to check for open in wire harness.

Multimeter Connection	Condition	Specified Condition
B-022 (E9) - B-101 (1)	Brake pedal not depressed	$\leq 1 \Omega$



PE0380

NG

Replace interior wire harness

OK

Replace PEPS module

DTC	B1518	Trunk/Back Door Unlock Switch Stuck Failure
DTC	Description	Possible Causes
B1518	Trunk/Back Door Unlock Switch Stuck Failure	Back door lock button, wire harness or PEPS control module is damaged

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing the following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

1

Check vehicle malfunction condition

- Press back door release switch to check if back door is open.


NG

Turn off vehicle power supply (- disconnect the negative battery cable), then turn on power supply again and clear DTC.

OK

2 Check back door release switch

- Turn ENGINE START STOP switch to OFF.
- Disconnect the negative battery cable.
- Disconnect the back door release switch connector T-012.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, measure resistance of back door release switch to check if back door release switch is damaged.



PE0390

Multimeter Connection	Condition	Specified Condition
T-012 (1) - T-012 (2)	Not pressed	No continuity
T-012 (1) - T-012 (2)	Pressed	$\leq 1 \Omega$

NG

Replace back door release switch


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

OK

3 Check back door release switch ground side

Use circuit diagram as a guide to perform the following inspection procedures:

- Using ohm band of digital multimeter, check for continuity between terminal 2 of connector T-012 and ground point GB-608 to check if ground side is normal.



PE0400

Multimeter Connection	Condition	Specified Condition
T-012 (2) - GB-608	Always	$\leq 1 \Omega$

NG

Handle GB-608 ground point


OK

4 Check back door release switch circuit signal voltage

Use circuit diagram as a guide to perform the following inspection procedures:

- Connect the negative battery cable.
- Turn ENGINE START STOP switch to ON.
- Using DC voltage band of digital multimeter, measure if signal voltage at terminal 1 of connector T-012 is normal.

Multimeter Connection	Condition	Specified Condition
T-012 (1) - Body ground	ON state	Approximately 12 V



NG

Repair or replace back door wire harness


OK

5 Check interior wire harness for open or short

Use circuit diagram as a guide to perform the following inspection procedures:

- Disconnect the PEPS module connector I-028.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Check for broken, bent, protruded or corroded terminals.
- Check if related connector pins are in good condition.
- Using ohm band of digital multimeter, measure resistance between terminal 6 of PEPS module connector I-028 and body ground to check for short to ground in interior wire harness.

Multimeter Connection	Condition	Specified Condition
I-028 (6) - Body ground	Always	No continuity




20 - PEPS SYSTEM

Use circuit diagram as a guide to perform the following inspection procedures:

(f) Using voltage band of digital multimeter, measure voltage between terminal 6 of PEPS module connector I-028 and body ground to check for short to power supply in interior wire harness.

Multimeter Connection	Condition	Specified Condition
I-028 (6) - Body ground	Always	Approx. 0V



Replace interior wire harness



6 Reconfirm DTCs

Use circuit diagram as a guide to perform the following inspection procedures:

(a) Connect diagnostic tester and clear DTCs.
 (b) Run the vehicle as specified procedure. The operating way should meet the conditions for corresponding fault diagnosis.
 (c) Read the fault information and confirm that the fault has been solved.



Replace PEPS module



Conduct test and confirm malfunction has been repaired

DTC	B152F	Battery Voltage Low Detection
DTC	B1530	Battery Voltage High Detection

DTC	Description	Possible Causes
B152F	Battery Voltage Low Detection	Battery, wire harness or PEPS control module is damaged
B1530	Battery Voltage High Detection	

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing the following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

1 Check battery voltage

- (a) Turn ENGINE START STOP switch to OFF.
- (b) Disconnect the negative battery cable.
- (c) Check battery voltage (not less than 12 V) with a digital multimeter.

NG

Replace battery

OK

2 Check charging system

Use circuit diagram as a guide to perform the following inspection procedures:

- (a) Turn ENGINE START STOP switch to OFF.
- (b) Check positive and negative battery cables for broken or damage.
- (c) Turn ENGINE START STOP switch to ON.
- (d) Start the engine.
- (e) Check if voltage of positive and negative battery is normal with a digital multimeter (13.5V-14.8V).

NG

Repair or replace positive and negative battery cables and alternator

OK

3 Check PEPS module power supply fuse

Use circuit diagram as a guide to perform the following inspection procedures:

- (a) Turn ENGINE START STOP switch to OFF.
- (b) Check if PEPS module power supply fuses RF01 10A and RF21 7.5A are blown.

NG

Replace power supply fuse

OK


4 Check engine compartment fuse and relay box

20 - PEPS SYSTEM

Use circuit diagram as a guide to perform the following inspection procedures:

- Turn ENGINE START STOP switch to OFF.
- Disconnect the engine compartment fuse and relay box connector.
- Using digital multimeter, check for continuity between fuse RF01 and Pin 7 of fuse and relay box.
- Using digital multimeter, check for continuity between fuse RF21 and Pin 50 of engine compartment fuse and relay box.

Multimeter Connection	Condition	Normal Condition
RF01 - Fuse and relay box (7)	Always	$\leq 1 \Omega$
RF21 - Fuse and relay box (50)	Always	$\leq 1 \Omega$




5 Check PEPS module power wire harness

Use circuit diagram as a guide to perform the following inspection procedures:

- Turn ENGINE START STOP switch to ON.
- Disconnect the PEPS connector I-028.
- Using digital multimeter, check if voltage between terminals 17 and 20 of connector I-028 and body ground is normal.

Multimeter Connection	Condition	Normal Condition
I-028 (17) - Body ground	Always	Not less than 12 V
I-028 (20) - Body ground	Always	Not less than 12 V



Use circuit diagram as a guide to perform the following inspection procedures:

(d) Using digital multimeter, check for continuity between terminal 17 of PEPS module connector I-028 and terminal 7 of instrument panel fuse and relay box, terminal 20 of connector I-028 and terminal 50 of instrument panel fuse and relay box to check for open in power supply wire harness.

Multimeter Connection	Condition	Normal Condition
I-028 (17)- Instrument panel fuse and relay box terminal 7	Always	$\leq 1 \Omega$
I-028 (20)- Instrument panel fuse and relay box terminal 50	Always	$\leq 1 \Omega$

NG

Repair or replace instrument panel wire harness


OK

6 Check the PEPS module ground circuit

Use circuit diagram as a guide to perform the following inspection procedures:

- Turn ENGINE START STOP switch to ON.
- Disconnect the PEPS module connector.
- Using digital multimeter, check for continuity between terminal 37 of connector I-028 and ground wire harness connector GI-502 to check for open in ground wire harness.

Multimeter Connection	Condition	Normal Condition
I-028 (37) - GI-502	Always	$\leq 1 \Omega$





20 - PEPS SYSTEM

Use circuit diagram as a guide to perform the following inspection procedures:

(d) Using voltage band of digital multimeter, measure voltage between terminal 37 of connector I-028 and body ground to check for short to power supply.

Multimeter Connection	Condition	Normal Condition
I-028 (37) - Body ground	Always	0V



DTC	B150F	ESCL Anti Scanning (Only for MT)
U1300-55	Description	Possible Causes

DTC

Description

Possible Causes

U1300-55

Software Configuration Error

Configuration has error.

DTC Confirmation Procedure

Confirm that battery voltage is not less than 12 V before performing the following procedures.

- Turn ENGINE START STOP switch to OFF.
- Connect the diagnostic tester (the latest software).
- Start engine and warm it up, and then read DTC again. If DTC is detected, malfunction is current.
- If DTC is not detected, malfunction is intermittent.

Hint:

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

1	Electric steering column lock enters anti-scanning state
---	--

(a) Enter anti-theft control system, delete and learn ESCL.

DTC	U0100	Lost of Communication with Engine Control System Module
DTC	U0129	Lost Communication with Brake System Module
DTC	U0140	Lost Communication with Body Control Module
DTC	U0329	Lost Communication with Electronic Steering Column Lock
DTC	U0101	Lost of Communication with TCM
DTC	U0155	Lost Communication with ICM
DTC	U0230	Lost Communication with PLG

DTC Confirmation Procedure

Refer to CAN communication system

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



ON-VEHICLE SERVICE

PEPS Control Module Assembly


Removal

CAUTION

- DO NOT separate PEPS controller and fixing bracket at will, or clamping structure of controller will be damaged, unless controller malfunction is confirmed by troubleshooting result, it can be removed and cannot be reused.
- DO NOT replace PCB board of PEPS controller at will, or it cannot be traced back and may make abnormal sound.
- After replacing PEPS controller assembly, before performing key learning and anti-theft matching, do not press ENGINE START STOP switch at will if nor necessary, to prevent PEPS controller from being locked and causing vehicle power supply not to be turned on.

- Turn off all electrical equipment and ENGINE START STOP switch.
- Disconnect the negative battery cable.
- Remove the glove box assembly.
- Remove the PEPS module.
 - Remove 2 coupling bolts (arrow) between PEPS module mounting bracket and instrument panel crossmember, and disconnect PEPS module connector (1).

Tightening torque
 $7 \pm 1 \text{ N}\cdot\text{m}$



- Carefully remove the PEPS module and mounting bracket assembly.

Installation


- Installation is in the reverse order of removal.

Front Low Frequency Antenna

Removal

- Turn off all electrical equipment and ENGINE START STOP switch.
- Disconnect the negative battery cable.
- Remove the auxiliary fascia console assembly.
- Remove the front low frequency antenna.

- a. Disconnect the connector (arrow) from front low frequency antenna.
- b. Using an interior crow plate, detach low frequency antenna fixing clip from mounting bracket, and remove low frequency antenna assembly (1).



PE0500

Hint:


DO NOT repeatedly remove and install it, and dispose it if it becomes loosen.

Installation

1. Installation is in the reverse order of removal.

Rear Bumper Low Frequency Antenna**Removal**

1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the rear bumper assembly.
4. Remove the rear low frequency antenna assembly.
 - a. Disconnect the connector (arrow) from rear bumper low frequency antenna.
 - b. Using a tool, detach low frequency antenna fixing clip (1) from rear bumper crossmember.



PE0490

Hint:

DO NOT repeatedly remove and install it, and dispose it if it becomes loosen.

Installation


1. Installation is in the reverse order of removal.

Anti-theft Coil**Removal**

1. Turn off all electrical equipment and ENGINE START STOP switch.
2. Disconnect the negative battery cable.
3. Remove the auxiliary fascia console assembly.

20 - PEPS SYSTEM

4. Remove the anti-theft coil.
 - a. Disconnect the anti-theft coil connector.
 - b. Press two clips with left hand while holding coil with right hand, and unplug it in opposite direction of installation direction with large force to remove anti-theft coil (arrow).

**Installation****CAUTION**

The anti-theft coil must be installed with a smooth surface against the mounting surface, and ensure it is installed in place, otherwise it may fall off from the bracket, thus failing to carry out normal key learning and anti-theft matching.

1. Installation is in the reverse order of removal.

