

## WD-2

## Transfer System

### Transfer Case Assembly

#### POWER FLOW MECHANISM

- Normal driving situation: 2WD base driving
- 4WD driving in driving situations (rapid activation, cornering etc.)
- Input the information from each sensor in vehicle
  - Input torque (Throttle position sensor)
  - Cornering situation (Steering angle sensor)
  - Vehicle speed and different wheel speed front & rear (Wheel speed sensor)
  - Braking situation (Brake signal and ABS signal)
- Distributed the required driving force after 4WD ECU operates.
- EMC (Electric Magnetic Clutch) operates the primary clutch.

دیجیتال خودرو


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



## Transfer Case Assembly

## WD-3




LMIF001V

## WD-4

## Transfer System

- Control the cam's opening gap by operation of primary clutch.




LMIF001W

# Transfer Case Assembly

**WD-5**

- Control the slip of inner & outer plate.  
Control variably the driving force distribution to optimize front & rear driving force.




LMIF001X

## WD-6

## Transfer System

## SYSTEM SCHEMATICS




LMIF001Y

# Transfer Case Assembly

## WD-7


### ITM confroller

#### 1. NON-ABS controller



LMIF001Z

#### 2. ABS/TCS controller




LMIF012A

## WD-8

## Transfer System


## 3. ESP controller



دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




# Transfer Case Assembly

## WD-9

### Control Algorithm Flow Chart

The base control algorithm of the ITM ECM is defined by the following flowchart:



LMIF012C




## WD-10

## Transfer System

## Lock Mode Description

- Based on a driver request for lock mode, the system will supply a fixed torque to the ITM-I clutch.
- When the vehicle exceeds 30KPH the system will begin to disable lock mode by ramping down the ITM clutch torque. When the vehicle exceeds 40 KPH the ITM clutch is reduced to its minimum torque value. Lock mode is re-enabled following the same speed-to-torque map.
- Lock mode is activated based on part number.



LMIF012D


- Lock mode will override all other system requests except for during an ABS event. During an ABS event the ITM clutch is turned off.
- If there is a speed sensor signal fault, the speeds are no longer considered reliable and lock mode will be disabled.



# Transfer Case Assembly

WD-11

## DTC TROUBLESHOOTING



LMIF012E

## 4WD ECM PIN DESCRIPTION

13	12	11	10	9	8	7	6	5	4	3	2	1
26	25	24	23	22	21	20	19	18	17	16	15	14

C01 (2.0 GSL)

C51 (2.7 GSL)

C101 (2.0 DSL)

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

LMIF012F

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

## WD-12

## Transfer System

Terminal Number	Wire Color	Description
1	R	BATTERY INPUT
2	-	BRAKE INPUT
3	B	ECU GROUND
4	G	CAN L
5	O	CAN H
6	L	GND RTN 4
7	Br	GND RTN 3
8	L	GND RTN 2
9	Br	GND RTN1
10	R	LOCK SWITCH INPUT
11	L/B	STEERING REF C
12	B/O	STEERING REF RTN
13	B	EMC RTN
14	W	ISO9141 K LINE
15	R/B	IGNITION INPUT
16	Gr/O	4WHEEL DRIVE INDICATOR
17	O	FRONT RIGHT SPEED SENSOR
18	R	FRONT LEFT SPEED SENSOR
19	R	REAR LEFT SPEED SENSOR
20	O	REAR RIGHT SPEED SENSOR
21	Y	DIAGNOSTIC OUT
22	-	TPS INPUT
23	Gr/O	STEERING 1 INPUT
24	L	STEERING 2 INPUT
25	Gr/B	STEERING REF 5V
26	R	EMC OUTPUT


C01(2.0GSL)  
C51(2.7GSL)  
C101(2.0DSL)

# Transfer Case Assembly

WD-13

## Transfer Case

### COMPONENTS(1)




1. Circlip
2. Hollow shaft
3. Typer roller bearing
4. Oil seal
5. Spacer set
6. Typer roller bearing
7. Hypoid gear shaft asseembly
8. O-ring
9. Pinion shaft
10. Pinion case

11. Oil seal
12. Lock nut
13. Rear plange
14. Typer roller bearing
15. Oil seal
16. Transfer corver
17. Inner drive shaft
18. Circlip
19. Oil seal
20. Hoop ring

21. Snap ring
22. Ball bearing
23. Snap ring
24. Oil guide
25. Spacer set
26. Typer roller bearing
27. Spacer set
28. Collapsible spacer
29. Typer roller bearing

LMIF012G

**WD-14****Transfer System****COMPONENTS(2)**

1. Coil
2. Rotor
3. Primary Clutch
4. Cam
5. Secondary clutch


LMIF012H

# Transfer Case Assembly

## WD-15

### REMOVAL

1. Remove the battery (-) terminal.
2. Lift up the vehicle.
3. Remove the propellar shaft (See 'DS' group-'PROPELLAR SHAFT')
4. Remove the front muffler(A).



LMIF012I

5. Remove the RH driveshaft (See 'DS' group-'DRIVESHAFT').
6. Loosen the oil drain plug and drain the fluid.
7. After draining, re-tighten the oil drain plug.

Tightening torque:

39.2 ~ 58.8 Nm (400 ~ 600 kgf-cm, 28.9 ~ 43.4 lbf-ft)

8. Support the transfer assembly with a jack.
9. Remove the transfer assembly by loosening the mounting bolts.

### CAUTION

Remove the transfer bracket mounting bolts(2EA) together.

### REPLACEMENT

#### TRANSFER OIL


1. Replace the oil every 100,000km(62,137miles) in a general condition and every 40,000km(24,854miles) in severe usage conditions.

### NOTICE

1. Severe usage (marked "\*\*") is defined as
  - a. Frequent driving on rough road (Bumpy road, gravel road, snowy road, unpaved road . Etc.)
  - b. Frequent driving on mountain road, ascent/descent.
  - c. Police, taxi, commercial type operation or trailer towing. Etc.)
2. Transfer & diff carrier lubricants should be changed anytime transfer & diff carrier have been submerged in water.

### INSTALLATION

1. Remove the filler plug(A).



LMIF012J

2. Refill the specification to the specified quantity.

Specification : SAE 80w/90

Quantity : 0.8L

3. Fix it in proper position with mounting bolts.

### INSPECTION

#### TRANSFER OIL

1. Check and replenish the transfer oil every 40,000km(24855 miles).

## WD-16

## Transfer System


## Coupling Assembly

## REMOVAL

1. Remove the 4WD coupling bolts (A-3EA) mounted to the rear propellar shaft.


## Tightening torque :

49.1~68.7N.m (5.0~7.0kgf.m, 36.2~50.6lb-ft)




LMIF012L

2. Using a flat tool(A), separate the propellar shaft(C) from 4WD coupling(B).



LMIF012M




LMIF012N

3. Remove the rear axle (B-Differential carrier) bolts mounted to the 4WD coupling(A) by a socket(C).

## Tightening torque :

58.9~63.8N.m (6.0~6.5kgf.m, 43.4~47.0lb-ft)




LMIF012O

# Transfer Case Assembly


## WD-17

4. Remove the electric magnetic clutch connector(A).




LMIF012P

5. Using a flat tool(A), separate the 4WD coupling assembly(B) from the rear differential carrier(C).



LMIF012Q

6. Remove the 4WD coupling assembly(A).



LMIF012R

## INSTALLATION


Installation is the reverse of the removal.

## DISASSEMBLY

### ⚠ CAUTION


Don't disassemble the coupling assembly more than bleow procedure because its performance may get bad influence after disassembling.

1. Remove the coupling(A) flange(B) mounting nut(C).



LMIF012S

2. Remove the flange spacer(A).




LMIF012T



## WD-18


## Transfer System

3. Remove the coupling flange oil seal(A).




LMIF012U

4. Using a general tool, 3-way puller(A), remove the flange assembly(B) from the coupling(C).




LMIF012V

5. Remove the flange oil seal(A) using special tool (09432-33200).



LMIF012W

6. Remove the coupling case assembly(A).



LMIF012X