

5-SPEED MANUAL TRANSAXLE

GENERAL INFORMATION	08-247	Disassemble	08-279
Description	08-247	Assemble	08-281
Operation	08-250	Inspection	08-285
Specifications	08-251		
Special Tools	08-253	Output Shaft	08-287
		Disassemble	08-287
		Assemble	08-290
DIAGNOSIS & TESTING	08-259	Output Gear For Reverse Gear	08-296
Abnormal Noise	08-259	Disassemble	08-296
Symptom Diagnostics	08-259	Inspection	08-296
ON-VEHICLE SERVICE	08-260	5th-Reverse Gear Shift Fork	08-297
Manual Transaxle Assembly	08-260	Disassemble	08-297
Removal & Installation	08-260	Assemble	08-298
Gear Selector & Shifter Assembly	08-264	3rd-4th Gear Shift Fork	08-298
Removal & Installation	08-264	Disassemble	08-298
Disassembly	08-267	Assemble	08-299
Assembly	08-268	1st-2nd Gear Shift Fork	08-299
		Disassemble	08-299
MANUAL TRANSAXLE UNIT REPAIR	08-270	Assemble	08-300
Transaxle	08-270	Transaxle Clutch Housing Assembly	08-301
Specifications	08-270	Disassemble	08-301
Disassembly	08-270	Assemble	08-303
Inspection	08-274	Transaxle Main Housing Assembly	08-305
Assembly	08-275	Assembly	08-305
Input Shaft	08-278		
Specifications	08-278		

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

GENERAL INFORMATION

Description

The QR523 five-speed transaxle is a constant-mesh manual transaxle that is synchronized in all gear ranges, including reverse.

The transaxle consists of three major sub-assemblies:

- Input shaft
- Output shaft
- Differential transaxle assembly

The transaxle shift system consists of the following components:

- Mechanical shift cover
- Shift rails
- Shift forks

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



GENERAL INFORMATION

- Shift cables

QR523 External View




Itsm080021

1 - Transaxle Housing Assembly
2 - Bearing Cap Assembly
3 - Stud Bolt
4 - Gear-Shifting Mechanism Assembly

5 - Release Fork Dust Boot
6 - Release Fork
7 - Clutch Housing Assembly
8 - Hydraulic Clutch Line Bracket

GENERAL INFORMATION

QR523 Internal View



Itsm080020

08

1 - Idler Assembly
2 - Pinion Gear, 4th Gear
3 - 3rd-4th Gear Synchronizer
4 - Pinion Gear, 3rd Gear
5 - Transaxle Housing
6 - Clutch Housing
7 - Release Bearing Saddle
8 - Input Shaft

9 - Output Shaft
10 - Differential Assembly
11 - Driven Gear of 1st Gear
12 - 1st-2nd Gear Synchronizer
13 - Driven Gear, 2nd Gear
14 - Driven Gear, 5th Gear
15 - Synchronizer of 5th-Gear and Reserve Gear
16 - Gear, Reverse Gear

GENERAL INFORMATION

Operation

The following are the details of the manual transaxle:

Neutral

Engine power is transmitted to the input shaft via the clutch assembly and the input shaft turns. Since no synchronizers are engaged on either the input or output shafts, power is not transmitted to the output shafts, power is not transmitted to the output shaft and the differential does not turn.

1st Gear

Engine power is transmitted to the input shaft via the clutch assembly and the input shaft turns. The input shaft first gear is integral to the input shaft, and is in constant mesh with the intermediate shaft first speed gear. Because of this constant mesh, the output shaft first speed gear freewheels until first gear is selected. As the gearshift lever is moved to the first gear position, the 1-2 fork moves the 1-2 synchronizer sleeve towards first gear on the output shaft. The synchronizer sleeve engages the first gear clutch teeth, engaging the gear to the output shaft, and allowing power to transmit through the output shaft to the differential.

2nd Gear

Engine power is transmitted to the input shaft via the clutch assembly and the input shaft turns. The input shaft second gear is integral to the input shaft, and is in constant mesh with the output shaft second speed gear. Because of this constant mesh, the output shaft second speed gear freewheels until second gear is selected. As the gearshift lever is moved to the second gear position, the 1-2 fork moves the 1-2 synchronizer sleeve towards second gear on the output shaft. The synchronizer sleeve engages the second gear clutch teeth, engaging the gear to the output shaft, and allowing power to transmit through the output shaft to the differential.

3rd Gear

Engine power is transmitted to the input shaft via the clutch assembly and the input shaft turns. The input shaft third speed gear is in constant mesh with the output shaft 3-4 cluster gear which is fixed to the output shaft. Because of this constant mesh, the input shaft third speed gear freewheels until third gear is selected. As the gearshift lever is moved to the third gear position, the 3-4 fork moves the 3-4 synchronizer sleeve towards third gear on the input shaft. The synchronizer sleeve engages the third gear clutch teeth, engaging the gear to the input shaft, and allowing power to transmit through the output shaft to the differential.

4th Gear

Engine power is transmitted to the input shaft via the clutch assembly and the input shaft turns. The input shaft fourth speed gear is in constant mesh with the output shaft 3-4 cluster gear which is fixed to the output shaft. Because of this constant mesh, the input shaft fourth speed gear freewheels until fourth gear is selected. As the gearshift lever is moved to the fourth gear position, the 3-4 fork moves the 3-4 synchronizer sleeve towards fourth gear on the input shaft. The synchronizer sleeve engages the fourth gear clutch teeth, engaging the gear to the input shaft, and allowing power to transmit through the output shaft to the differential.

5th Gear

Engine power is transmitted to the input shaft via the clutch assembly and the input shaft turns. The input shaft fifth speed gear is pressed on to the input shaft, and is in constant mesh with the output shaft fifth speed gear. Because of this constant mesh, the output shaft fifth speed gear freewheels until fifth gear is selected. As the gearshift lever is moved to the fifth gear position, the 5-R fork moves the 5-R synchronizer sleeve towards the output shaft fifth speed gear. The synchronizer sleeve engages the fifth gear clutch teeth, engaging the gear to the input shaft, and allowing power to transmit through the output shaft to the differential.


Reverse Gear

Engine power is transmitted to the input shaft via the clutch assembly and the input shaft turns. The input shaft reverse gear is integral to the input shaft, and is in constant mesh with the reverse idler gear. The reverse idler gear, which reverses the rotation of the output shaft, is in constant mesh with the output shaft reverse gear. Because of this constant mesh, the output shaft reverse gear freewheels until reverse gear is selected. As the gearshift lever is moved to the reverse gear position, the 5-R fork moves the 5-R synchronizer sleeve towards the output shaft reverse gear. The synchronizer sleeve engages the reverse gear clutch teeth, engaging the gear to the output shaft, and allowing power to transmit through the output shaft to the differential.

GENERAL INFORMATION

Transaxle Identification Number

The transaxle serial number can be found on a metal tag (1) fastened to the transaxle case on the clutch housing. The third row data is the transaxle serial number.



Itsm020209

08

Specifications

Maintenance Specifications

DESCRIPTION	ALLOWABLE RANGE (mm)	LIMIT VALUE (mm)
Axial Clearance Of Input Shaft Front Bearing	-0.01 - 0.21	-
Axial Clearance Of Input Shaft Rear Bearing	-0.01 - 0.12	-
Axial Clearance Of Input Shaft Fifth Gear	-0.01 - 0.09	-
Axial Clearance Of Output Shaft Front Bearing	-0.01 - 0.12	-
Axial Clearance Of Output Shaft Rear Bearing	-0.01 - 0.09	-
Axial Clearance Of Output Shaft Third Gear	-0.01 - 0.09	-
Back Clearance Of Differential Case Planetary Gear	0.025 - 0.150	-
Clearance Between The Gear And The Back Of Synchronizer Ring	-	0.05
Pretension Of Differential Case	0.05 - 0.11	-

GENERAL INFORMATION

Sealants and Adhesives

DESCRIPTION	SPECIFIED SEALANTS AND ADHESIVES
Clutch Housing to Transaxle Housing	Three Arrow 1216E
Control Case to Transaxle Housing	
Lower Head to Transaxle Housing	

Torque Specifications





DESCRIPTION	TORQUE (N.m)
Bottom Cover-Transaxle Installation Bolts	6.2 - 7.6
Backup Lamp Switch	28.7 - 35.3
Clutch Housing-Transaxle Housing Installation Bolts	39.5 - 48.5
Clutch Release Bearing Saddle Retainer Installation Bolts	8.8 - 10.8
Gear-Shifting Mechanism Assembly Installation Bolts	16.1 - 19.9
Gear-Shifting Staying Wire Bracket Installation Bolts	16.1 - 19.9
Idling Gear Assembly Installation Bolts	43.1 - 52.9
Main Gearbox Driven Gear Installation Bolts	118.5 - 145.5
Speedometer Gear Installation Bolts	3.5 - 4.3

Technical Data





TYPE	MECHANICAL GEAR COUPLING	
Gear Position	Transaxle Ratio	Gear Ratio
1st	3.583	43/12
2nd	1.947	37/19
3rd	1.379	40/29
4th	1.030	34/33
5th	0.820	32/39
Reverse	3.363	37/11
Final Drive	4.313	69/16
Transaxle Fluid Type	GL-4 75W-90	
Transaxle Fluid Quantity	2.2 L	
Rated Torque	230 N.m	
Rated Speed	5500 RPM	
Rated Power	100 KW	
Center Distance	204 mm	
Input Shaft Spline	Tooth number	20
	Module	1.0583
	Pressure angle	30°
	External diameter	φ22.224 mm (0/-0.3)
	Inner diameter	φ19.675 mm (0/-0.2)
Physical Dimension	398.5×522×355.7	

GENERAL INFORMATION





Special Tools

Installer Connector MB-990926	 Itsm080001
Installer Connector MB-990934	 Itsm080002
Installer Connector MB-990935	 Itsm080003
Fluid Seal/Differential Installer MB-998325	 Itsm080004





GENERAL INFORMATION

Bearing Outer Race Remover MB-998346	 Itsm080005
Handle MB-990938	 Itsm020026
Valve Spring Compressor MB-998772	 Itsm020012
Bearing Remover MB-998801	 Itsm080006





GENERAL INFORMATION

Installer Cap MB-998812	 Itsm080007
Installer (100) MB-998813	 Itsm080008
Installer Connector (200) MB-998814	 Itsm080009
Installer Connector (30) MB-998816	 Itsm080010





GENERAL INFORMATION

Installer Connector (34) MB-998817	 Itsm080011
Installer Connector (38) MB-998818	 Itsm080012
Installer Connector (40) MB-998819	 Itsm080013
Installer Connector (46) MB-998822	 Itsm080014

GENERAL INFORMATION

Installer Connector (48) MB-998823	 Itsm080015
Installer Connector (50) MB-998824	 Itsm080016
Installer Connector (52) MB-998825	 Itsm080017
Bearing Remover MB-998917	 Itsm080018

GENERAL INFORMATION

Hook MB-999566	 Itsm080019
Flywheel Fixture CH-20043	 Itsm020211
Bearing Installer CH-30028	 Itsm020213
Bearing Extractor 09917-58010	 Itsm020212

DIAGNOSIS & TESTING

Abnormal Noise

Transaxle noise is most often a result of worn or damaged components. Chipped, broken gear or synchronizer teeth, and worn bearings all cause noise.

Inspect the following:

- Insufficient lubrication
- Incorrect lubricant
- Mis-assembled or damaged internal components
- Improper operation

Symptom Diagnostics

Hard Shifting

- Hard shifting may be caused by a mis-adjusted crossover cable. If hard shifting is accompanied by gear clash, synchronizer clutch and stop rings or gear teeth may be worn or damaged.

Slips Out Of Gear

- Transaxle disengagement may be caused by misaligned or damaged shift components, or worn teeth on the drive gears or synchronizer components. Incorrect transaxle assembly also causes gear disengagement.

Low Lubricant Level

- Insufficient transaxle lubricant is usually the result of leaks, or inaccurate fluid level check or refill method. Vehicle must be level to accurately check fluid level. Leakage is evident by the presence of fluid around the leak point. If leakage is not evident, the condition is probably the result of an under fill.
- If air-powered lubrication equipment is used to fill a transaxle, be sure the equipment is properly calibrated. Equipment out of calibration can lead to an under fill condition.

Clutch Problems

- Worn, damaged, or misaligned clutch components can cause difficult shifting, gear clash, and noise.
- A worn or damaged clutch disc, pressure plate, or a faulty slave cylinder can cause hard shifting and gear clash.

Abnormal Noise

- Transaxle noise is most often a result of worn or damaged components. Chipped, broken gear or synchronizer teeth, and worn bearings all cause noise.

Inspect the following:

- Insufficient lubrication
- Incorrect lubricant
- Improperly assembled or damaged internal components

ON-VEHICLE SERVICE


Manual Transaxle Assembly

Removal & Installation


NOTE :

The following special tools are required to perform the repair procedure:

- MB-990938 - Handle
 - MB-990935 - Installer Connector
1. Raise and support the vehicle.
 2. Disconnect the negative battery cable.
 3. Remove the battery and battery tray (See Battery Removal & Installation in Section 05 Starting & Charging).
 4. Remove air cleaner and air duct.




5. Drain the cooling system (See Cooling System Draining Procedure in Section 06 Cooling System).
6. Remove the base mounting of the air cleaner housing assembly.
7. Remove the backup lamp switch (2) and vehicle speed sensor (1).




ON-VEHICLE SERVICE


8. Remove the two shift cables (1) from the transaxle.



9. Remove the shift cable clamp (1) from the shift cable bracket.




10. Remove the clutch master cylinder outlet pipe (1) from the clutch slave cylinder.
(Tighten: Outlet pipe bolt to 17 ± 1 N·m)
11. Remove the starter motor (See Starter Removal & Installation in Section 05 Starting & Charging).
12. Support the engine using an engine support fixture or suitable jack.
13. Remove the engine to transaxle upper bolts and remove the bracket.
(Tighten: Engine to transaxle upper bolts to 80 N·m)




ON-VEHICLE SERVICE


14. Remove transaxle mount nuts (2) and the transaxle mount bracket bolts (1).
(Tighten: Transaxle mount nuts to 120 N·m)



15. Raise the vehicle.
16. Remove the transaxle drain plug (1) and drain the transaxle fluid.




17. Remove both front axle shafts (See Front Axle Shaft Removal & Installation in Section 09 Driveline & Axle).
18. Remove the engine undercover and splash shields.
19. Remove the front engine mount bolts (1).
(Tighten: Front mount bolts to 60 N·m)




ON-VEHICLE SERVICE

20. Remove the rear engine mount bolts (2) and the rear engine mount bracket bolts (1).
(Tighten: Rear mount bolts to 40 N·m)



21. Remove the sub-frame assembly (See Sub-Frame Assembly Removal & Installation in Section 10 Suspension).
22. Remove the engine to transaxle lower bolts (1).
(Tighten: Transaxle mount bolts to 40 N·m)
23. Separate the transaxle from the engine and remove it from the vehicle.



08


WARNING!

Support the transaxle with a suitable jack while removing the transaxle.

24. Installation is in the reverse order of removal.


Installation Notes:

- Refill 2.2L transaxle fluid through the fill hole (1) until the fluid starts to leak from the fill hole.
- After installation, check for any fluid leakage and verify the transaxle fluid level is correct.



Gear Selector & Shifter Assembly

Removal & Installation




ON-VEHICLE SERVICE


1 - Backup Lamp Switch Assembly
2 - Limit Stop Screw-Interlocking Plate
3 - Plain Washer-Interlocking Plate Limit Stop Screw
4 - Bearing-Gear Shift Mechanism
5 - Lower Lining - Selector Lever
6 - Selector Lever Assembly
7 - Washer
8 - Bolt
9 - Upper Dust Boot - Selector Lever
10 - Nut
11 - Plain Washer-Gear Selecting Arm Nu
12 - Gear Shifting Arm Assembly
13 - Gear Shifting Drive Slider
14 - Dust Cap-Gear Shifting Shaft Fluid Seal
15 - Lower Dust Cap-Gear Selecting Arm
16 - Lower Bushing-Gear Selecting Arm

17 - Gear Selecting Arm Assembly
18 - Upper Bushing-Gear Selecting Arm
19 - Baffle-Rear Neutral Position Return Spring
20 - Rear Neutral Retracting Spring
21 - Reverse Gear Lock Assembly
22 - Reverse Gear Lock Assembly Pin
23 - Selector Finger Pin
24 - Selector Finger
25 - Interlock Plate Assembly
26 - Front Neutral Retracting Spring Assembly
27 - Gearshift Shaft
28 - Retainer-Reverse Gear Lock
29 - Gear Shift Mechanism Housing
30 - Air Duct
31 - Air Duct Cap
32 - Bolt

1. Disconnect the negative battery cable.
2. Remove the air cleaner housing assembly.
3. Remove the two shift cables (1) from the transaxle.




4. Remove the shift cable clamp (1) from the shift cable bracket.




5. Raise and support the vehicle.

ON-VEHICLE SERVICE


6. Remove the gearshift knob.
7. Remove the gearshift boot from the lower console.




8. Apply the parking brake (apply parking brake handle to clear lower console upon removal).



9. Remove the lower console (See Lower Console Removal & Installation in Section 15 Body & Accessories).
10. Remove the clip on the gearshift mechanism and then remove the crossover cable and the selector cable (1) from the gearshift mechanism.




11. Remove the four bolts (1) and then remove the gearshift mechanism from the bracket.




ON-VEHICLE SERVICE


12. Remove the selector cable clamps (1) and bracket retaining bolts (2).
13. Remove the gear selector & shifter assembly.
14. Installation is in the reverse order of removal.

**NOTE :**

Selector cable can be adjusted with the adjusting bolt (1). Adjust bolts as needed to obtain proper cable adjustment.


**Disassembly**

1. Drive out the locking selector finger (1) pin following the direction as shown in the diagram.
2. Drive out the locking pin (2) reverse gear lock assembly pin.
3. Remove all of the components from shaft.
4. Thoroughly clean and check all parts, replace any worn parts as necessary.



Assembly

1. Carefully press and fit two gear shift mechanism (1) & (2) bearings to the corresponding position on the gear shift mechanism housing. The bearing (1) should be pressed to the end, both end faces of the bearing should align with the hole end faces of the housing bearing. The side of the bearing with letters should be placed outwards.




2. Press the air duct into the housing orifice to ensure the air duct is in the proper position.
3. Press and fit the fluid seal of the gearshift shaft into the fluid seal hole of the housing, ensure the fluid seal is pressed and fitted in position.


NOTE :

Apply transaxle fluid to the fluid lip seal.

4. Install the gearshift shaft through the fluid seal and into the housing of gear shift mechanism.
5. Following the direction of the arrow, install the rear neutral return spring stop, rear neutral return spring, reverse gear lock assembly, selector finger and interlock plate assembly, front neutral return spring assembly onto the gearshift shaft (as shown in the figure). Check the turn-down rims of rear neutral return spring stop, and ensure they have entered into corresponding vent groove of the housing. One end of main body of reverse gear lock with blind hole shall face rear neutral return spring stop. And the small end face of front neutral return spring assembly shall face towards selector finger.



6. Insert the gearshift shaft into the bearing.
7. Install the reverse gear limiter lock mechanism (1) (as shown in the figure).
(Tighten: Reverse gear limiter bolt to 22 N·m)




8. Install the gearshift fluid seal dust boot to the gearshift shaft fluid seal.
9. Install the gearshift lever assembly to the gearshift shaft, then press it in the pin hole of gearshift lever assembly, finally install the pin.

NOTE :


Neither end of the pin is allowed to protrude beyond the two end surfaces of the pin holes.

ON-VEHICLE SERVICE


10. Align the selector finger (1) and fork shaft spring pin (2), install the spring pin of selector finger (as shown by the arrow in the figure).




11. Tighten the interlock plate limit bolt (1) together with the shim to the housing (as shown in the figure). The tightening torque of the bolt is 30 N·m. Check front end circular cylinder of the bolt to ensure it is in the corresponding groove of selector finger.



12. Check the gearshift shaft to ensure it is able to rotate and perform axial movement freely.
13. Install air duct (1) and air duct cap (2). Apply sealant to the surface of the inserted part of air duct.



14. Install the backup light switch assembly (1).
(Tighten: Backup light switch to 32 N·m)



MANUAL TRANSAXLE UNIT REPAIR

Transaxle

Specifications


Torque Specifications

DESCRIPTION	TORQUE (N·m)
Gear Shift Mechanism Housing Bolt	18
Gear Positions Self-Locking Bolt	35
Reverse Gear Bolt	20
Reverse Gear Cap Bolt	20
Rear Transaxle Bearing End-Plate Bolt	6.9
Transaxle To Clutch Housing Bolt	44
Bearing Input Shaft Bolt	18


Disassembly

1. Place the transaxle on a workbench.
2. Remove the clutch fork (2) and remove the release bearing (1).

NOTE: The release bearing (1) is not serviceable.




3. Set the transaxle gear in the neutral position. Remove the gear shift mechanism housing retaining bolts (1), and remove the gear shift mechanism housing. (Tighten: Gear shift mechanism housing bolts to 18 N·m)




MANUAL TRANSAXLE UNIT REPAIR


4. Remove the three gear positions self-locking bolts (1).
(Tighten: Three gear positions self-locking bolts to 35 N·m)




5. Remove the reverse gear bolt (1).
(Tighten: Reverse gear bolt to 20 N·m)



6. Remove the 6 reverse gear cap bolts (1), and remove the cap.
(Tighten: Reverse gear cap bolts to 20 N·m)




7. Gently pry the idler gear downward using a screwdriver, and then remove the idler gear assembly.




MANUAL TRANSAXLE UNIT REPAIR


8. Remove the 10 rear transaxle bearing end-plate bolts (1), and then remove the bearing cap.
(Tighten: Rear transaxle bearing end-plate bolts to 6.9 N·m)




9. Remove shaft clip (3) and shaft clip (1) from the shafts, and then remove bearing collar (2).



10. Remove the transaxle to clutch housing bolts (1), and then use a pry bar to remove the transaxle housing.
(Tighten: Transaxle to clutch housing bolts to 44 N·m)




11. Perform the following steps to remove the transaxle housing (1).




MANUAL TRANSAXLE UNIT REPAIR

12. Tap the transaxle housing and use a suitable tool to remove the transaxle housing.




13. Remove the 3 front bearing input shaft bolts (1).
(Tighten: Bearing input shaft bolts to 18 N·m)




14. Grasp the input shaft assembly, output shaft assembly, 1st-2nd shift fork, 3rd-4th shift fork and 5th-reverse fork shaft together and remove.

15. Remove the differential assembly (1) upward (as shown in the figure).

NOTE: Pre-tighten the shim of the differential cone bearing.




16. Remove the magnet (1) and wipe the magnet clean.




MANUAL TRANSAXLE UNIT REPAIR

Inspection


1. Place a tin solder sheet (1) (approximate length is 10 mm and diameter is 1.6 mm) on the specified part of the transaxle housing, and then install the differential outer bearing race.
2. Install the clutch housing, and tighten the bolts to the specified torque.
3. Replace the tin solder sheets with thicker tin solder sheets.



4. With a micrometer, measure the thickness (T) of the flattened tin solder sheet.
 - Select the thickness of the shim to be installed according to the following equation.
 - Thickness of washer: $(T + 0.005 \text{ mm}) - (T + 0.11 \text{ mm})$




5. Do not clean the release bearing.
6. Clean the sealing surface of all contaminants, remove all old sealant, and clean all bolt holes.
7. Check all parts for damage, replace any damaged parts if necessary.
8. Always align the bearing cap (1) with the shaft opening. Align the bearing collar to the bearing cap opening (as the two circular rings indicate in the figure).




MANUAL TRANSAXLE UNIT REPAIR

9. Place the transaxle in the neutral position when installing the self-locking bolts for the gear positions. The notches (1) of the shift fork guide block should align in the same line.




10. Place the transaxle in the neutral position (1) when the gear shift mechanism housing assembly is in the position of the selector finger in the gear shift mechanism housing assembly shown in the figure.



11. Alternate tightening each bolt to the specified torque.


Assembly

1. Install the input shaft together with the output shaft.
2. Install the 5th-reverse gear shifting fork/fork stalk-5th-reverse gear fork/3rd-4th gear shifting fork/fork stalk-3rd-4th fork.
3. Move the gear bushing-3rd-4th gear (1) and the gear bushing-5th-reverse gear (2) in the direction shown in the figure.




MANUAL TRANSAXLE UNIT REPAIR

4. Install the 3rd-4th gear shifting fork (2) and its fork stalk (1) and the 5th-reverse gear shifting fork (3) and its stalk (4).




Itsm080029

5. Install all gear shifting forks into the gear hub, and at the same time, move the fork stalks (1) & (2) in the direction shown in the figure.




Itsm080024

6. Install the locking pin.



Itsm080030

7. Using special tools MB-990938 (1) and MB-990935 (2), install the outer bearing race.




Itsm080031

MANUAL TRANSAXLE UNIT REPAIR

8. Install the transaxle housing.
9. Apply a 1 mm to 1.2 mm diameter of sealant on the specified position of the transaxle housing.

CAUTION:


The sealant line applied should be uniform and continuous and without breaks.




10. Tighten the transaxle housing bolts to the specified torque.
11. Install the bottom transaxle cover.
12. Apply a 1 mm to 1.2 mm diameter of sealant on the specified position of the transaxle housing.

CAUTION:

The sealant line applied should be uniform and continuous and without breaks.





13. Apply transaxle fluid to the O-ring of speed sensor.
(Transaxle fluid: 75W-90)



MANUAL TRANSAXLE UNIT REPAIR

14. Install the vehicle speed sensor.
15. Install the gear shifting arm assembly. Apply lubricating fluid on the contact surface of the gear shifting drive slider and the gear shifting arm assembly. (The specified lubricating fluid: Mobilux Ep2)



STATUS OF SWITCH	CIRCUIT
Pressed	Off
Released	On

16. Inspect the backup lamp switch. Inspect the switch for broken terminal or an open circuit.

Input Shaft


Specifications

Clearance Specifications

SYNCHRONIZER RING	VALUE OF A (mm)	WEARING LIMIT
1st-2nd Gear	1.10 - 1.17	0.05 mm
3rd-4th Gear	1.35 - 1.90	0.05 mm
5th Gear	1.10 - 1.17	0.05 mm

MANUAL TRANSAXLE UNIT REPAIR

Disassemble



1 - Input Shaft
2 - Input Shaft Front Bearing
3 - Snap Ring
4 - Needle Bearing-3rd Gear
5 - 3rd Driving Gear Assembly
6 - Synchronizer Ring-3rd-4th Gear
7 - Gear Hub-3rd-4th Gear
8 - Guide Block
9 - Spring-3rd-4th Gear Synchronizer
10 - Hub Sleeve-3rd-4th Gear

11 - Gear Bushing-4th Gear
12 - Needle Bearing-2nd-4th Gear
13 - 4th Driving Gear Assembly
14 - 5th Driving Gear
15 - Thrust Ring-5th Driving Gear
16 - Clip-5th Driving Gear Thrust Plate
17 - Input Shaft Rear Bearing
18 - Snap Ring-Input Shaft Rear Bearing
19 - Seal-Input Shaft Fluid-Collecting Hole


MANUAL TRANSAXLE UNIT REPAIR

NOTE :


The following special tools are required to perform the repair procedure:

- MB-998801 - Bearings Remover
- MB-998812 - Installer Cap
- MB-998813 - Installer (100 mm)
- MB-998816 - Installer Connector (30 mm)
- MB-998825 - Installer Connector (52 mm)
- MB-998824 - Installer Connector (50 mm)


1. Using special tool MB-998801 (1), disassemble the input shaft rear bearing.



2. Using special tool MB-998801 (1), disassemble the 5th driving gear.




3. Disassemble the sleeve-4th gear.
Mount special tool MB-998801 (1) on the 3rd driving gear to disassemble the sleeve-4th gear.




MANUAL TRANSAXLE UNIT REPAIR


- Using special tool MB-998801 (1), disassemble the input shaft front bearing.

**Assemble**


- Install the input shaft seal.
Press the seal in until the dimension shown in the figure is obtained.



- Using special tools MB-998801 (4), MB-998812 (1), MB-998813 (2) and MB-998816 (3), install the input shaft front bearing.




- Install the input shaft front shaft snap ring.
Select a snap ring to maintain the axial clearance standard.
(The standard value: 0.01 mm - 0.12 mm)




MANUAL TRANSAXLE UNIT REPAIR

4. Install the synchronizer spring.
Install the synchronizer spring in the specified position of the synchronizer ring, shown in the figure.




5. Install the gear hub-3rd-4th gear.
Install the gear hub-3rd-4th gear in the direction shown in the figure.




CAUTION: شرکت دیجیتال خودرو سامانه (مسئولیت)
Ensure that the synchronizer ring is not locked when installing the gear hub.

6. Using special tools MB-998801 (4), MB-998812 (1), MB-998813 (2) and MB-998825 (3), install the gear bushing-3rd-4th gear.




7. Install the hub sleeve in the direction shown in the figure.




MANUAL TRANSAXLE UNIT REPAIR


8. Ensure that these two deep tooth spaces of gear hub (1) & (2) are correctly aligned with the two high racks of the gear hub during the installation of gear bushing.




9. Using special tools MD-998801 (4), MD-998812 (1), MD-998813 (2), and MD-998824 (3), install the sleeve-4th gear.



10. Using special tools MD-998801 (4), MD-998812 (1), MD-998813 (2), and MD-998824 (3), install the 5th driving gear.




11. Installation of transaxle housing assembly.
Select the thickness of the thrust plate (1) 5th driving gear to maintain the proper axial clearance of input shaft 5th driving gear shaft.
(The Standard Value: 0.01 mm to 0.09 mm)




MANUAL TRANSAXLE UNIT REPAIR


12. Install the clip-5th driving gear thrust plate (1).
Ensure that the thrust plate doesn't tilt when installing the clip.



13. Using special tools MD-998801 (3), MD-998812 (1) and MD-998818 (2), install the input shaft rear bearing.




14. Install the snap ring.
Select the thickness of snap ring (1) to maintain the proper axial clearance of input shaft rear bearing.
(Standard Value: 0.01 mm to 0.12 mm)



Inspection

1. Input Shaft

- Inspect the external surface of the input shaft and needle bearings (1) for any damage or excessive wear.
- Inspect the input shaft spline for any damage or excessive wear.




2. Needle Bearing


Inspect the input shaft and gears for smooth operation.

3. Synchronizer Ring

- Inspect the synchronizer rings for any damage or signs of breakage in the surface of synchronizer rings.



- Press synchronizer ring (1) 3rd-4th gear (2), and then examine the clearance "A". If the "A" is less than the limit value, the synchronizer ring and 3rd-4th gear should be replaced. (Limit Value: 0.5 mm)



1 - Synchronizer Ring


2 - Gear

MANUAL TRANSAXLE UNIT REPAIR

4. Gear Hub and Hub of Synchronizer


- Assemble the gear bushing together with the gear hub of synchronizer, and then inspect for smooth operation without lockup.
- Inspect the front/rear of the interior surface of the gear bushing for any damage.
- Inspect the synchronizer springs for any weak springs or damage.

NOTE: If it is necessary to replace the gear bushing and gear hub of the synchronizer, they are only serviced as a complete set.



5. 3rd-4th Driven Gear

- Inspect the gear surface of the skew gear and clutch gear (1) for any damage.
- Inspect the conical surface of the synchronizer (2) for thickening, damage or wear.
- Inspect the internal diameter of the front/rear surface of the gear.



دیجیتال خودرو


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

MANUAL TRANSAXLE UNIT REPAIR

Output Shaft

Disassemble



Itsm080060

08

1 - Outer Ring-1st-2nd Synchronization Ring
2 - Gear Hub Sleeve-1st-2nd Synchronizer
3 - Guide Block
4 - Spring-1st-2nd Gear And 5th-Reverse Gear Synchronizer
5 - Gear Hub-1st-2nd Gear
6 - Steel Ring-1st-2nd Synchronization Ring
7 - Inner Ring-1st-2nd Synchronization Ring
8 - 4th Driven Gear
9 - Gear Bushing-5th Gear
10 - Needle Bearing-Reverse Gear
11 - 5th Driven Gear Assembly
12 - Reverse Driven Gear Assembly
13 - Sleeve-Reverse Gear
14 - Synchronization Ring-3rd-4th Gear And 5th-Reverse Gear
15 - Gear Hub Sleeve-5th-Reverse Gear

16 - Gear Hub-5th-Reverse Gear
17 - Snap Ring-3rd Driven Gear
18 - 3rd Driven Gear
19 - 2nd Driven Gear Assembly
20 - Needle Bearing-2nd Gear
21 - Sleeve-2nd Gear
22 - 1st Driven Gear Assembly
23 - Needle Bearing-1st Gear
24 - Sleeve-1st Gear
25 - Snap Ring-Output Shaft Front Bearing
26 - Output Shaft Front Bearing
27 - Output Shaft
28 - Output Shaft Rear Bearing
29 - Snap Ring-Output Shaft Rear Bearing


MANUAL TRANSAXLE UNIT REPAIR

NOTE :


The following special tools are required to perform the repair procedure:

- MB-998801 - Bearing Remover
- MB-998812 - Installer Cap
- MB-998814 - Installer Connector (200 mm)
- MB-998813 - Installer (100)
- MB-998818 - Installer Connector (38 mm)
- MB-998819 - Installer Connector (40 mm)
- MB-998822 - Installer Connector (46 mm)
- MB-998825 - Installer Connector (52 mm)


1. Using special tool MB-998917 (2), disassemble the output shaft rear bearing (1).



2. Disassemble the reverse gear sleeve (1).
Install special tool MB-998801 (2) on the reverse driven gear, and then disassemble the sleeve.




3. Disassemble the 5th-reverse gear synchronizer hub (1).
Install special tool MB-998801 (2) on the 4th driven gear, and then disassemble the gear hub-5th-reverse gear.




MANUAL TRANSAXLE UNIT REPAIR


4. Disassemble the 3rd driven gear (1).
Install special tool MB-998917 (2) on the 2nd driven gear, and then disassemble the 3rd driven gear.




5. Disassemble the sleeve-2nd gear (1).
Install special tool MB-998917 (2) on the 1st driven gear, and then disassemble the sleeve-2nd gear.



6. Using special tool MB-998801 (2), disassemble the sleeve-1st gear (1).




7. Using special tool MB-998917 (2), disassemble the output shaft front bearing race (1).




MANUAL TRANSAXLE UNIT REPAIR

Assemble


1. Using special tools MB-998801 (4), MB-998812 (1) and MB-998818 (2), install the output shaft front bearing race (3).




2. Install the snap ring-output shaft front bearing (1). Select the snap ring and install it to maintain the proper axial clearance of the output shaft front bearing.
(Standard Value: 0.01 mm to 0.12 mm)



3. Using special tools MB-998812 (1), MB-998814 (2) and MB-998825 (3), install the sleeve-1st gear (4).




4. Install the 1st-2nd gear synchronization ring. Install the 1st-2nd gear synchronizer ring correctly on the specified position of synchronizer ring shown in the figure.




MANUAL TRANSAXLE UNIT REPAIR

5. Install the gear hub-1st-2nd gear.
Install the gear hub-1st-2nd gear in the position (1) shown in the figure.


**CAUTION:**

Using special tools MD-998814 (1), MD-998815 (2) and MD-998825 (3), install the synchronizer ring (4). Ensure that the synchronizer ring is not locked when installing the gear hub.




6. Install the gear hub sleeve-1st-2nd gear synchronizer.

- Install the gear bushing on the position (1) shown in the figure.




- Ensure that the two deep tooth spaces of the gear hub (1) are correctly aligned with the two high racks of the gear hub during the installation of gear bushing.




MANUAL TRANSAXLE UNIT REPAIR

7. Install the synchronizer Ring.




Itsm080073

8. Using special tools MB-998812 (1), MB-998814 (2) and MB-998822 (3), install the sleeve-2nd gear (4).




Itsm080074

9. Using special tools MB-998812 (1), MB-998814 (2) and MB-998822 (3), install the 3rd driven gear (4).



Itsm080075


10. Install the snap ring-3rd driven gear (1). Install the snap ring to maintain the proper axial clearance of the output shaft 3rd driven gear.
(Standard Value: -0.01 mm to 0.09 mm)




Itsm080076

MANUAL TRANSAXLE UNIT REPAIR


11. Using special tools MB-998812 (1), MB-998813 (2) and MB-998819 (3), install the 4th driven gear (4).




12. Using special tools MB-998812 (1), MB-998813 (2) and MB-998819 (3), install the sleeve-5th gear (4).



13. Install the gear hub-5th-reverse gear.
Install the gear hub-5th-reverse gear in the position (1) shown in the figure.


**CAUTION:**

Using special tools MD-998812 (1), MD-998813 (2) and MD-998819 (3), install the synchronizer ring (4). Ensure that the synchronizer ring is not locked when installing the gear hub-5th-reverse gear.




MANUAL TRANSAXLE UNIT REPAIR

14. Using special tools MB-998812 (1) and MB-998818 (2), install the reverse driven gear/needle bearing-reverse gear/sleeve-reverse gear (3).




15. Using special tools MB-9988112 (1) and MB-998818 (2), install the input shaft rear bearing (3).



16. Install the outer ring-1st-2nd gear synchronizer ring/steel ring-1st-2nd gear synchronization ring/inner ring-1st-2nd gear synchronization ring (1).


- Inspect the conical surface of the clutch gear for any damage or breakage on the gear surface.



- Install the outer ring (2) and inner ring (4), and then press them down to the gear (1) to measure the clearance "A". If "A" is less than the limit value, the rings (3) should be replaced. Limit Value: 0.5 mm

CAUTION:

The outer ring, inner ring or steel, are replaced as a complete set.




MANUAL TRANSAXLE UNIT REPAIR

17. Install the gear bushing and hub of synchronizer:


- Assemble the gear bushing together with the gear hub of synchronizer, and then inspect for smooth operation without lockup.
- Inspect the front/rear of the interior surface of the gear bushing for any damage.
- Inspect the synchronizer springs for any weak springs or damage.

CAUTION: The gear bushing or gear hub of the synchronizer are replaced as a complete set.



18. Install the transaxle gear:


- Inspect the gear surface of the skew gear and clutch gear (1) for any damage.
- Inspect the conical surface of the synchronizer (2) for thickening, damage or wear.
- Inspect the internal diameter of the front/rear surface of the gear.



MANUAL TRANSAXLE UNIT REPAIR

Output Gear For Reverse Gear

Disassemble



Itsm080086

1 - Idler Gear Shaft

2 - Needle Bearing

3 - Reverse Gear

4 - Thrust Plate

5 - Thrust Plate Snap Ring

1. Remove the thrust plate snap ring (5)
2. Separate the thrust plate (4) and the reverse gear (3).
3. Separate the needle bearing (2) and idle gear shaft (1).

Inspection

Needle Bearing


- Assemble the shaft together with the gear, and then examine whether they can slide smoothly without sagging or noise.
- Inspect the bearing cage for any damage.

MANUAL TRANSAXLE UNIT REPAIR


5th-Reverse Gear Shift Fork

Disassemble


1. Separate the 5th-Reverse shift fork from the shift fork assembly.



2. Use a suitable tool to remove the shift fork spring pin from the shift fork and the shift fork shaft.



08



Itsm080136

1 - 5th Shift Fork Shaft

2 - 5th Shift Fork

3 - Spring Pin for Fork Shaft

4 - Reverse Fork Rack

5 - Driving Block - Backup Light Switch

6 - 5th-Reverse Shift Fork Shaft Assembly

3. Remove the spring pins (3) from the 5th shift fork shaft (1).
4. Separate the 5th shift fork (2) and the reverse fork rack (4) from the 5th shift fork shaft (1).
5. Separate the backup lamp switch driving block (5) from the 5th shift fork shaft (1).

MANUAL TRANSAXLE UNIT REPAIR**Assemble**


Assemble in the reverse order of disassembly.

NOTE :


- Check and ensure the shift fork is properly installed to the fork shaft, there should be NO axial or radial motion in the fork shaft.
- Check and ensure the fork rack is properly installed to the fork shaft, there should be NO axial or radial motion in the fork shaft.
- Check and ensure backup light driving block is properly installed to the fork shaft, there should be NO axial or radial motion in the fork shaft.
- Check the fork shaft surface for any damage.
- Check the position of the three spring pins, ensure the pins are in proper alignment. The extension of both ends of the three spring pins should not exceed 3 mm.

3rd-4th Gear Shift Fork**Disassemble**


1. Separate the 3rd-4th shift fork from the shift fork assembly.



2. Use a suitable tool to remove the shift fork spring pin from the shift fork and the shift fork shaft.



MANUAL TRANSAXLE UNIT REPAIR



Itsm080137

1 - 3rd-4th Shift Fork Shaft

2 - Fork Rack - 3rd-4th Gear Shift Fork

3 - Spring Pin for Fork Shaft

4 - 3rd-4th Shift Fork

5 - 3rd-4th Shift Fork Shaft Assembly

3. Remove the spring pins (3) from the 3rd-4th shift fork shaft (1).

4. Separate the 5th shift fork (4) and the fork rack (2) from the 3rd-4th shift fork shaft (1).

Assemble


Assemble in the reverse order of disassembly.

NOTE :

- Check and ensure the shift fork is properly installed to the fork shaft, there should be NO axial or radial motion in the fork shaft.
- Check and ensure the fork rack is properly installed to the fork shaft, there should be NO axial or radial motion in the fork shaft.
- Check the fork shaft surface for any damage.
- Check the position of the three spring pins, ensure the pins are in proper alignment. The extension of both ends of the three spring pins should not exceed 3 mm.

1st-2nd Gear Shift Fork**Disassemble**



1. Separate the 1st-2nd shift fork from the shift fork assembly.



vism020016

MANUAL TRANSAXLE UNIT REPAIR

2. Use a suitable tool to remove the shift fork spring pin from the shift fork and the shift fork shaft.



1 - 1st-2nd Shift Fork Shaft

2 - Fork Rack - 1st-2nd Gear Shift Fork

3 - Spring Pin for Fork Shaft

4 - 1st-2nd Shift Fork

5 - 1st-2nd Shift Fork Shaft Assembly

3. Remove the spring pins (3) from the 1st-2nd shift fork shaft (1).
 4. Separate the 1st-2nd shift fork (4) and the fork rack (2) from the 1st-2nd shift fork shaft (1).

Assembly


Assemble in the reverse order of disassembly.

NOTE :

- Check and ensure the shift fork is properly installed to the fork shaft, there should be NO axial or radial motion in the fork shaft.
- Check and ensure the fork rack is properly installed to the fork shaft, there should be NO axial or radial motion in the fork shaft.
- Check the fork shaft surface for any damage.
- Check the position of the three spring pins, ensure the pins are in proper alignment. The extension of both ends of the three spring pins should not exceed 3 mm.

Transaxle Clutch Housing Assembly

Disassemble



MANUAL TRANSAXLE UNIT REPAIR

1 - Clutch Housing
2 - Pin GB119 A10x20
3 - Fluid Seal-Input Shaft
4 - Bushing-Gear Shifting Mechanism
5 - Output Shaft Front Bearing
6 - Bearing-Gear Shifting Mechanism
7 - Magnetic Assembly


8 - Front/Rear Bearing Of Differential
9 - Fluid Seal-Differential
10 - Speedometer Banking Cover
11 - Bolt GB5787 M6x12
12 - Release Bearing Race
13 - Buttonhead-Seat Release Fork

NOTE :

The following special tools are required to perform the repair procedure:


- MB-998772 - Valve Spring Compressor
- MB-999566 - Hook
- MB-990938 - Handle
- MB-990935 - Installer Connector
- MB-990934 - Installer Connector
- MB-998325 - Fluid Seal Installer
- MB-990926 - Installer Connector

1. Using special tools MB-999566 (1), MB-996772 (3), and MD-998348 (4), disassemble the outer race of the front/rear bearing (2) of the differential.




Assembly

1. Install the bushing.
Press the bushing (1) into position (2) as shown in the figure.




08

2. Using special tools MB-990938 (2) and MB-990934 (3), install the outer race-output shaft bearing (1). Install the outer race with the stamped side in the position shown in the figure.




MANUAL TRANSAXLE UNIT REPAIR


3. Using special tools MB - 990938 (1), and MB - 990935 (2), install the race-differential bearing.



4. Using special tools MB-998325 (1), install the fluid seal-differential.
Apply transaxle fluid on the fluid seal lip.
(Specified fluid: 75W-90)




5. Using special tool MB-990938 (1) and MB-990926 (2), install the input shaft fluid seal.
Apply the lubricating grease on the fluid seal lip.
(Specified lubricating grease: Mobilux Ep2 or equivalents)



MANUAL TRANSAXLE UNIT REPAIR

Transaxle Main Housing Assembly

Assembly



Itsm080106

1 - Transaxle Housing

2 - Bearing-Gear Shifting Mechanism

3 - Pin GB119

4 - Outer Race Of Front/Rear Bearing Of Differential

5 - Adjustment Gasket-Differential Rear Bearing

6 - Fluid Seal-Differential

7 - Fluid Baffle

8 - Fluid Draining Screw Plug

9 - Plain Washer-Fluid Draining Screw Plug

10 - Plain Washer-Fluid Limiting Screw Plug

11 - Fluid Limiting Screw Plug


NOTE :

The following special tools are required to perform the repair procedure:


- MD-998325 - Fluid Installer

MANUAL TRANSAXLE UNIT REPAIR

1. Install the bearing-gear shifting mechanism (1).
Press the bearing in until it is flush with the surface of housing.



2. Install the differential fluid seal.
Inspect the fluid seal for damage. Apply lubricating grease on the external diameter and inner lip of the fluid seal, and then use special tool MD-998325 (1) to install the seal into position.
(Lubricating grease: Mobilux Ep2)



دیجیتال خودرو
شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

FRONT DIFFERENTIAL

GENERAL INFORMATION

Description	08-308
Operation	08-310
Specifications	08-310
Special Tools	08-310

DIFFERENTIAL UNIT REPAIR

Differential Carrier	08-312
Removal & Installation	08-312
Inspection	08-313
Assembly	08-313

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



GENERAL INFORMATION

Description

The differential includes the differential side gears and the shaft mounted differential pinion gears. Direct contact between the gears and the differential case is prevented by the differential side gear thrust washers installed under the gears. The differential pinion shaft is held in position by a differential pinion shaft lock pin that extends through the end of the differential pinion shaft and the differential case.

The differential transaxle assembly consists of the following components:

- Differential case (part of the final drive carrier)
- 2 pinion gears supported by a pinion shaft
- 2 side gears supported by the differential case and half-shafts


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



GENERAL INFORMATION



GENERAL INFORMATION

1 - Front/Rear Bearing Of Differential
2 - Adjustment Gasket-Axle Shaft Gear
3 - Axle Shaft Gear
4 - Planetary Gear Shaft
5 - Thrust Washer
6 - Spherical Washer-Planetary Gear

7 - Anchor Pin-Planetary Gear Shaft
8 - The Driving Gear-Speedometer
9 - Differential Housing
10 - The Driven Gear Of Main Reducing Gear
11 - Bolt-The Driven Gear Of Main Reducing Gear And The Differential Housing

Operation



The differential operates through the gear mesh with the ring gear bolted to the differential case. The engine power is transmitted to the axle shafts through the pinion mate and side gears. The side gears are connected to the axle shafts.

Specifications



Clearance Specifications

Clearance Between Side Gear And Planetary Gear	0.028 - 0.150 mm
Adjusting Washer	0.93 - 1.00 mm

Special Tools

شرکت دیجیتال خودرو (مسئولیت محدود) اولین سامانه دیجیتال، تعمیرکاران خودرو در ایران Installer Connector (40 mm) MD-998819	 Itsm080013
Installer Cap MD-998812	 Itsm080007

GENERAL INFORMATION

Bearing Remover MD-998801	 Itsm080006
Fluid Installer MD-998325	 Itsm080004

شرکت دیجیتال خودرو (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

DIFFERENTIAL UNIT REPAIR


Differential Carrier

Removal & Installation


NOTE :

The following special tools are required to perform the repair procedure:


- MD-998801 - Bearing Remover
1. Remove the transaxle input shaft assembly, transaxle output shaft assembly, 1st-2nd shift fork, 3rd-4th shift fork and 5th-reverse fork shaft together as a unit (See Transaxle Assembly Unit Repair in Section 08 Transaxle).
 2. Remove the transaxle differential assembly.
 3. Mount the differential in a vice.
 4. Remove the drive gear bolts (1).



5. Using special tool MD-998801 (1), disassemble the differential-front/rear shaft bearing.



6. Tap the drive gear off the differential case assembly using a suitable tool.
7. Remove the pinion mate shaft use a suitable tool.



DIFFERENTIAL UNIT REPAIR


8. Turn the pinion mate gear, then remove the pinion mate gear, pinion mate thrust washer, side gear and side gear thrust washer from the differential case.

Inspection

1. Clean all components.
2. Inspect the following components for wear:
 - Ring gear
 - Adjusting washers
 - Side gears
 - Spherical washers
 - Planetary gears
 - Planetary gear shaft

Assembly

1. Install the adjustment shim-axle shaft gear/axle shaft gear/spherical washer-planetary gear/planetary gear/planetary gear shaft.
2. Assemble the spherical washer on the back of axle shaft gear, and then install the axle shaft gear on the differential.



08


NOTE :

The adjustment shim with intermediate thickness (0.93 to 1.00 mm) shall be assembled when a new axle shaft gear is installed.

3. Place the spherical washer on the back of any planetary gear to make two planetary gears engage simultaneously with the axle shaft gear. Turn these gears, and at the same time, install them in their proper positions.
4. Insert and install the planetary gear shaft.
5. Measure the gear clearance between the axle shaft gear and the planetary gear.
(Standard value: 0.08 to 0.15 mm)
6. If the measured gear clearance doesn't conform to the standard value, select and install the adjustment shim, and then measure the gear clearance again.

NOTE :

Adjust the gear clearance until the gear clearance of both sides is the same as each other.




DIFFERENTIAL UNIT REPAIR

7. Install the lock pin (2).
8. Install the lock pin in the position shown in the figure.


CAUTION:

After the lock pin is taped in, the axle shaft gear and the planetary gear should operate normally.




1 - Differential Housing
2 - Lock Pin
3 - Pinion Shaft

9. Using special tools MD-998812 (1) and MB-998819 (2), install the differential front/rear bearing (3).




10. Install the driven gear of main reducing gear.
11. Apply thread sealant to the threads of all bolts.



DIFFERENTIAL UNIT REPAIR

12. Tighten the ring gear bolts (1) in the sequence shown in the figure.
(Tighten: Ring gear bolts to 132 N·m)



دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



CLUTCH SYSTEM

GENERAL INFORMATION

	08-317	Clutch Pedal Free Travel	08-321
Description	08-317		
Operation	08-317	Clutch Master Cylinder	08-322
Specifications	08-317	Description	08-322
Special Tools	08-318	Operation	08-322
		Removal & Installation	08-322

CLUTCH ASSEMBLY SERVICE

	08-319	Clutch Slave Cylinder	08-324
Clutch and Pressure Plate	08-319	Removal & Installation	08-324
Removal & Installation	08-319	Bleeding Hydraulic Clutch	08-325
Clutch Pedal Height	08-321	Operation	08-325

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



GENERAL INFORMATION

Description

The hydraulic clutch system consists of a clutch master cylinder (2), slave cylinder (3), and an interconnecting hydraulic fluid line. Hydraulic fluid is supplied by the clutch system from the clutch master cylinder reservoir (1).



Operation

The hydraulic clutch system is responsible for engaging and disengaging the clutch. Depressing the clutch pedal develops fluid pressure in the clutch master cylinder. This pressure is transmitted to the integral release bearing which is in contact with the pressure plate diaphragm spring. As additional force is applied, the bearing depresses the diaphragm spring fingers inward on the fulcrums. The action moves the pressure plate rearward, relieving clamping force on the clutch disc.





Specifications

Torque Specifications

DESCRIPTION	TORQUE (N·m)
Transaxle Mounting Bolts	6.9
Clutch Housing Mounting Bolts	44
Clutch Release Bearing Seat Retainer Mounting Bolts	9.8
Gear Shift Mechanism Assembly Mounting Bolts	18
Shift Gear Control Cable Bracket Mounting Bolts	18
Speedometer Gear Mounting Bolts	3.9
Final Drive Driven Gear Mounting Bolts	132
Back Up Lamp Switch	32
Idler Gear Assembly Mounting Bolt	48
Clutch Slave Cylinder Mounting Bolts	11 ± 1

GENERAL INFORMATION

Special Tools


Flywheel Fixture 09924 - 17810	 Itsm020211
Bearing Extractor 09917 - 58010	 Itsm020212
Input Shaft Bearing Mounting Device 09925 -98210	 Itsm020213
Clutch Pressure Plate Installer CH-20014	 besm080041

CLUTCH ASSEMBLY SERVICE


Clutch and Pressure Plate

Removal & Installation


1. Remove the transaxle assembly (See Transaxle Assembly Removal & Installation in Section 08 Transaxle).
2. Remove the clutch pressure plate bolts (1).
(Tighten: Clutch pressure plate bolts to 25 N·m)
3. Remove the modular clutch assembly.



4. Using special tool CH-20043 (1), hold the flywheel.




5. Remove the flywheel-to-crankshaft bolts (1) and remove flywheel assembly (if necessary for resurfacing).
(Tighten: Flywheel-to-crankshaft bolts to 75 N·m)




CLUTCH ASSEMBLY SERVICE

6. Remove the input shaft bearing using special tool 09917-58010 (1) and spanner, as shown in the figure.



Inspect


- Check the input shaft bearing to ensure it is able to rotate freely, replace the bearing if necessary.
- Measure the depth of the recesses of the clutch friction lining rivet head, i.e., the distance between rivet head and friction lining surface (as shown in the figure). If the depth of any hole comes to the limit, replace friction lining assembly.
 - Standard: 1.2 mm
 - Limit: 0.5 mm



- Check clutch pressure plate diaphragm spring for irregular wear or damage.
- Check clutch pressure plate for wear or hot spots.
- If found abnormal, replace the clutch plate assembly. Never separate the clutch plate assembly into the diaphragm spring and clutch plate.
- Check the contact surface of the flywheel and friction lining for irregular wear or hot spots. Repair or replace if necessary.

Installation


- Prior to assembling, check the flywheel surface and clutch plate surface to ensure they are clean and dry.
- Using special tools CH-30028 (1), install the input shaft bearing to the crankshaft (as shown in the figure). Align the clutch friction lining assembly and flywheel center using special tools (as shown in the figure), and then install the clutch plate assembly and bolts. Tighten the bolts to the specified torque. (Tighten: Clutch pressure plate bolts to 25 N·m)



CLUTCH ASSEMBLY SERVICE

NOTE :

When tightening the clutch pressure plate bolts (1), tighten by hand until the friction lining assembly is properly aligned.




- Apply a thin layer of grease to the input shaft, and then assemble the transaxle and engine.

NOTE: Turn the splines when installing the transaxle input shaft into the clutch friction lining assembly until the splines are engaged.

Clutch Pedal Height

Adjust the clutch pedal height using the adjusting bolts (1) on the pedal bracket (3) in accordance with the following requirements. When the clutch pedal (4) is approximately 8 mm higher than the brake pedal (5), the clutch pedal height is normal.




08

Clutch Pedal Free Travel


Depress the clutch pedal (1) until the clutch resistance can be felt. Stop accordingly and measure the distance (clutch pedal free travel A). The free travel should be within 15 - 25 mm.

After checking clutch pedal free travel, check the clutch to ensure it is in normal working condition while the engine is running.



CLUTCH ASSEMBLY SERVICE**Clutch Master Cylinder****Description**


The clutch master cylinder mounts to the clutch pedal and consists of a piston and cylinder housing, an actuating push rod, and an interconnecting hydraulic line. Fluid is supplied to the clutch master cylinder via the brake fluid reservoir.

**Operation**


When the clutch pedal is depressed, the push rod moves the piston in the master cylinder, displacing fluid through the hydraulic line and into the release bearing. The release bearing is extended and forces the fingers of the clutch diaphragm springs to move. As the fingers move, they release the clamping pressure on the clutch disc between the clutch pressure plate and the flywheel. The clutch becomes disengaged as this pressure is released. When the clutch pedal is released, the system hydraulic pressure is released. This allows the force of the clutch diaphragm springs to return themselves to their original position, re-clamping the clutch disc between the flywheel and the clutch pressure plate. Also, the release bearing is forced to return, which reverses the movement of the hydraulic system and returns the pedal to its original position against the up stop.

Removal & Installation

1. Disconnect hydraulic supply line to clutch master cylinder (1) to completely drain clutch master cylinder and tubing.




2. Disconnect hydraulic line (1) and drain fluid into suitable container.




CLUTCH ASSEMBLY SERVICE

3. Remove instrument panel lower trim panel (1) (See Instrument Panel Removal & Installation in Section 15 Body & Accessories).



4. Disconnect clutch master cylinder push-rod (1) from clutch pedal.



5. Remove hydraulic line from rail retainer.
6. Release master cylinder by rotating to disengage from pedal bracket assembly.


CAUTION:

Use care when removing clutch master cylinder from engine compartment. Aggressive handling can result in a damaged hydraulic line and improper clutch release operation upon reassembly.

CAUTION:

Brake fluid will damage painted surfaces. If brake fluid is spilled on any painted surfaces, wash it off immediately with water.

7. Remove the master cylinder assembly (1) from the mounting position and carefully maneuver the hydraulic pipe from the engine compartment.



8. Installation is in the reverse order of removal.

CLUTCH ASSEMBLY SERVICE


Clutch Slave Cylinder

Removal & Installation


NOTE :

After replacing the slave cylinder, it is necessary to make sure brake master cylinder fluid level is full and the reservoir cap is installed tightly.

1. Remove the clutch master cylinder outlet pipe (1) from the clutch slave cylinder.
(Tighten: Outlet pipe bolt to 17 ± 1 N.m)



2. Remove the clutch slave cylinder bolts (1) from the transaxle housing.
(Tighten: Clutch slave cylinder bolts to 11 ± 1 N.m)




3. Installation is in the reverse order of removal.
4. Bleed the hydraulic clutch (See Bleeding Hydraulic Clutch in Section 08 Transaxle).


NOTE: Check pipes for leakage of brake fluid.

CLUTCH ASSEMBLY SERVICE**Bleeding Hydraulic Clutch****Operation**

1. Verify fluid level in brake master cylinder. Top off with DOT 4 brake fluid as necessary. Leave cap off.



2. Raise the vehicle on hoist.
3. Remove the bleed port protective cap and install a suitable size and length of clear hose to monitor and divert fluid into a suitable container.
4. Loosen the bleed port (1).



5. Actuate the clutch pedal until the brake master cylinder fluid drains from the bleed port.
6. Depress the clutch pedal, tighten the bleed port.
7. From driver's seat, actuate the clutch pedal until the hydraulic clutch system has pressure.
8. Depress the clutch pedal, loosen the bleed port and bleed the brake master cylinder fluid.
9. Repeat steps 6 to 8 several times until there is no air in the hydraulic clutch system.

NOTE :

Do not allow clutch master cylinder to run dry while fluid exits bleed port.

10. Close the hydraulic bleed port, remove the drain hose and replace the dust cap on the bleed port.
11. Top off the brake master cylinder fluid level with DOT 4 brake fluid as necessary.

CAUTION:

During the bleeding process, make sure the brake master cylinder fluid is always full.

TRANSFER CASE (4X4)**GENERAL INFORMATION**

Description

08-327

Operation

08-327

08-327

ON-VEHICLE SERVICE

08-328

Transfer Case

08-328

Removal & Installation

08-328

TRANSFER CASE UNIT REPAIR

08-329

Transfer Case

08-329

Disassembly

08-329

Assembly

08-331

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



GENERAL INFORMATION

Description

Transfer case is attached to the transaxle housing.



1 - Transaxle Housing

2 - Rear Transaxle Cover

3 - Axle Shaft Guide

4 - Front Different Housing

08

Operation


The transfer case transfers the torque output from the transaxle to the ITM controller.

ON-VEHICLE SERVICE


Transfer Case

Removal & Installation

1. Drain the gear fluid from the transfer case.
 - Fluid-filling plug (1)
 - Fluid-limiting plug (2)
 - Fluid-drain plug (3)



2. Remove the front intermediate drive shaft assembly.
3. Remove the sub-frame assembly.
4. Remove the left and right front axle shaft mounting bolts (1).




5. Remove the transaxle and transfer case assembly (See Transaxle Assembly Removal & Installation in Section 08 Transaxle).
6. Remove the transfer case from the transaxle (8 bolts).
(Tighten: Transaxle and transfer case bolts to 80 N·m)
7. Installation is in the reverse order of removal.

TRANSFER CASE UNIT REPAIR


Transfer Case

Disassembly

1. Remove the front housing. Loosen 9 bolts (1) of the housing, then remove the housing.
(Tighten: Transfer case front housing bolts to 35 N·m)




2. Remove the small rear housing components. Loosen the 4 bolts (1) and remove the rear housing components.
(Tighten: Rear intermediate shaft and rear differential bolts to 65 ± 6 N·m)




TRANSFER CASE UNIT REPAIR

3. Lock up the drive gear (1) and loosen the driven gear axle (2) locking nut.




Itsm160015

4. Loosen the 7 bolts (1) and remove the right bearing support components.
(Tighten: Transfer case right bearing support bolts to 35 N·m)



Itsm160017


5. Remove the input clutch and the drive gear. Remove the retainer ring of the input clutch with snap-ring pliers; punch the output end out of the input clutch with a copper punch, and remove the input clutch and the drive gear.



Itsm160018

TRANSFER CASE UNIT REPAIR

6. Remove the fluid seal of the input clutch.
Pry out the fluid seal with a slotted screwdriver.



Assembly

1. Put a standard-sized 1.4 mm adjusting shim from the front bearing driven gear axle into the transfer case housing. Press in the front outer bearing race of the driven gear axle, then the rear outer bearing race, and press the front bearing of the driven gear axle into the driven gear axle; then put it into the collar and press in the rear inner bearing race. Attach the locknut, and adjust the tightening torque of the driven gear by adjusting the locknut until the driven gear axle can be driven with a torque of 1.0-1.5 N·m.
2. Assemble the flange axle.
Link the drive gear ring of the transfer case to the flange axle with a mounting bolt, tighten the bolt to 110 N·m. Install the bearing to the left of the flange axle and the bearing to the left of the right bearing seat.
3. Choose the 2.4 mm standard-sized adjusting shim for the left bearing for the flange axle. Put the adjusting shim for the right bearing for the flange axle, the outer bearing race to the left of the flange axle and the flange axle into the transfer case.
Measure the distance (A) from the contact surface of the right bearing seat and the transfer case to the right bearing seat and the left bearing's right end surface.
Measure the distance (B) from the contact surface of the right bearing seat and the transfer case to the place where the right and left bearings on the right bearing seat.
4. Calculate the thickness value of the adjusting gasket $S = A - B$.
5. Select the adjusting gasket: $S + (0.05 - 0.10)$ mm.
6. Assembly of the right bearing seat.
Assemble the right bearing to the right bearing seat, install the retainer ring of the right bearing to the right bearing seat, install the fluid seals to the left and right of the right bearing seat, install the O-ring and link the right bearing seat to the transfer case housing with the bolt. Tighten the bolt to 35 N·m. The subassembly should be able to rotate with 3.0-5.0 N·m torque.
7. Adjust the hypoid gear engagement: first, spread red lead powder on the teeth of the driven bevel gear so that there will appear red prints on both working sides of the gear teeth of the driving bevel gear when turning it by hand. If the gear pattern prints on both engaging sides of the drive gear ring is higher than the center of the gear height near to the small end and occupy over 60% of the gear tooth width, then the pattern is correct; and the backlash between various gear teeth should fall between 0.13 mm and 0.18 mm.
A: If the clearance between one lateral side of a tooth and that of the adjacent tooth are not correct, choose bearing shims to the left and right of the flange axle, repeat procedures 3, 4 and 5 to measure the clearance between one lateral side of a tooth and that of the adjacent tooth on the hypoid gear until the adjustment is correct.
B: If the gear pattern print leans to the tooth tip, replace the adjusting shim from the front bearing of the driven gear to a thicker 1 mm; If the gear pattern print leans to the tooth root, then get the adjusting shim of the front bearing of driven gear axle needs to be subtracted by 1 mm. Examine the gear pattern print, repeat procedures 3, 4, 5, 6, and 7 until the gear pattern is correct.
8. Assemble the transfer case front shell, and tighten to 35 N·m.
9. Assemble the transfer case small rear housing onto the transfer case, and tighten to 35 N·m.
10. Assemble the input clutch fluid seal, O-ring, retainer ring and the input clutch; install the transfer case onto the transaxle and tighten to 80 N·m.

NOTE: When assembling bearings and fluid seals, it is necessary to apply lubricating grease. The sealing surface of the housing must have sealant applied.