06

SQR484F ENGINE MANAGEMENT SYSTEM

GENERAL INFORMATION	06-3	P0137 16		06-78
Description	06-3	P0138 17		06-78
System Function	06-4	P0140 00		06-78
Precautions	06-5	P2270 00		06-78
Specifications	06-6	P2271 00		06-78
Tools	06-8	P0201 13		06-84
ECM Pin Definition	06-10	P0271 12		06-89
Circuit Diagram	06-12	P1102 00		06-94
_		P1102 29		06-94
DIAGNOSIS & TESTING	06-20	P1103 00		06-94
Diagnostic Help	06-20	P1106 00		06-94
Intermittent DTC Troubleshooting	06-20	P1106 21		06-94
Ground Inspection	06-20	P1106 22		06-94
Throttle Self-learning	06-21	P1111 00		06-94
Diagnostic Trouble Code (DTC)	00.04	P2106 92		06-94
Chart	06-21	P2106 12		06-94
ECM Power Supply Circuit &	00.04	P2106 13		06-94
Ground Circuit Testing	06-24	P2106 19		06-94
P0030 13	06-32	P0300 21		06-101
P0031 11	06-32	P0301 21	~ 0	06-101
P0032 12	06-32	P0302 21	Q	06-101
P0053 1E	06-32	P0303 21		06-101
P0036 13	06-39	P0304 21		06-101
رو سامانه (مستولیه 14-90037	06-39	P0304 21	0	06-101
P0038 12	06-39	P0327 00		06-109
P0054 1E	06-39	P0327 00	0-	06-114
P0105 28	06-46	P0328 00		06-114
P0106 00	06-46	P0341 00 P0346 00		06-119
P0107 11	06-46			
P0108 12	06-46	P0420 00		06-125
P0111 00	06-53	P0444 13		06-128
P0112 16	06-53	P0458 16		06-128
P0113 17	06-53	P0459 17		06-128
P0116 00	06-59	P0480 13		06-135
P0117 16	06-59	P0481 13		06-135
P0118 17	06-59	P0691 11		06-135
P0121 29	06-66	P0560 00		06-141
P0122 16	06-66	P0562 16		06-141
P0123 17	06-66	P0563 17		06-141
P0130 00	06-72	P0627 13		06-148
P0131 16	06-72	P0628 11		06-148
P0132 17	06-72	P0629 12		06-148
P0133 00	06-72	P0645 13		06-153
P0134 00	06-72	P0646 11		06-153
P2195 00	06-72	P0647 12		06-153
P2196 00	06-72	P0688 91		06-158
P0136 00	06-78	P0688 92		06-158

-	P0604 43	06-164	Removal & Installation -	
	P0605 43	06-164	Downstream Oxygen Sensor	06-248
	P0606 00	06-164	Camshaft Position Sensor	06-249
	P1619 00	06-166	Description	06-249
	U0101 87	06-168	Operation	06-249
	U0129 87	06-171	Removal	06-249
	U0140 87	06-174	Installation	06-249
	U0155 87	06-177	Engine Speed Sensor	06-250
	U0164 87	06-181	Description	06-250
	U0140 00	06-185	Operation	06-250
	P000A 00	06-188	Removal	06-250
	P000B 00	06-188	Installation	06-250
	P0010 13	06-191	Intake Pressure/Temperature	
	P0013 13	06-191	Sensor	06-251
6	P0012 00	06-198	Description	06-251
	P0015 00	06-198	Operation	06-251
	P0016 29	06-200	Removal & Installation	06-251
	P0018 29	06-200	Ignition Coil	06-252
	Engine Problem Symptom		Description	06-252
	Diagnosis	06-210	Operation	06-252
	ON-VEHICLE SERVICE	06-243	Removal & Installation	06-252
,	A IIII A	(f)	Electric Fuel Pump	06-253
	Intake/Exhaust VVT Control Valve	06-243	Description	06-253
	Description	06-243	Operation	06-253
	Operation	06-243	Removal & Installation	06-253
10	Removal	06-243	Fuel Injector	06-254
Jy	درو سامانه (مسئوnstallation		Description	06-254
	Coolant Temperature Sensor	06-244	Operation	06-254
	Description	06-244	Removal & Installation	06-254
	Operation	06-244	Electronic Throttle Assembly	06-255
	Removal	06-244	Description	06-255
	Installation	06-245	Operation	06-255
	Knock Sensor	06-246	Removal & Installation	06-255
	Description	06-246	Canister Solenoid Valve	06-256
	Operation	06-246	Description	06-256
	Removal	06-246	Operation	06-256
	Installation	06-247	Removal & Installation	06-256
	Oxygen Sensor	06-248	Engine Control Module (ECM)	06-257
	Description	06-248	Description	06-257
	Operation	06-248	Operation	06-257
	Upstream Oxygen Sensor	06-248	Removal	06-257
	Downstream Oxygen Sensor	06-248	Installation	06-258
	Removal & Installation -	06 040		
	Upstream Oxygen Sensor	06-248		

GENERAL INFORMATION


Description

The engine of T21 model adopts UAES engine management system. This system mainly consists engine Control Module (ECM), sensors and actuators, which controls intake air amount, injection volume and ignition timing, etc. when engine is operating.

In engine management system, sensors are used as the input part to measure various physical signals (temperature and pressure, etc.), and converts them into corresponding electrical signals; the function of ECM is to receive the input signals from sensors and perform calculation according to set procedure, producing corresponding control signals and outputting them to power drive circuit. The power drive circuit drives each actuator to perform various actions, thus making the engine run according to preset program.

Also, the trouble diagnosis system of ECM monitors each component and control function in this system. Once detecting and confirming a fault, it will store trouble code and recall "Limp Home" function. When detecting that fault has been eliminated, it will return to use normal value.

Basic Components of Engine Management System



1 - Canister	2 - Intake Pressure/Temperature Sensor
3 - Canister Solenoid Valve	4 - Intake VVT Control Valve
5 - Camshaft Position Sensor (Intake)	6 - Ignition Coil
7 - Camshaft Position Sensor (Exhaust)	8 - Fuel Injector
9 - Exhaust VVT Control Valve	10 - Upstream Oxygen Sensor
11 - Downstream Oxygen Sensor	12 - Coolant Temperature Sensor
13 - Crankshaft Position Sensor	14 - Knock Sensor
15 - Electronic Throttle	16 - Engine Control Module (ECM)
17 - Electronic Accelerator Pedal	18 - Electric Fuel Pump

06 System Function

Calculate air flow

ECM calculates air flow by the signals from Intake Pressure/Temperature Sensor and then adjusts injection volume to make air-fuel ratio meet the requirements of various operating conditions.

· Measure crankshaft position and engine speed

ECM determines crankshaft position and engine speed according to the signals from crankshaft position sensor and accurately controls engine ignition and injection timing.

Determine operating sequence of cylinders

ECM recognizes the top dead center of No.1 cylinder by camshaft position sensor, so as to determine the operating sequence of cylinders.

Fuel control

There are two modes of fuel control: closed-loop fuel control and open-loop fuel control. The closed-loop fuel control can accurately regulate the air-fuel ratio of engine, thus effectively controlling emissions. The open-loop fuel control is applied when engine is starting or warming up, or when a oxygen sensor is malfunctioning.

Ignition control

The ignition control system of engine adopts packet control.

Knock control

When a knocking is detected by knock sensor, the system will calculate the ignition advance angle that needs to be delayed or advanced according to current operating conditions and knock intensity and adjusts ignition angle, thus avoiding or reducing knocking.

· Emission control

The three-way catalytic converter can convert engine exhaust gas into harmless gas and discharge it into atmosphere. When engine temperature becomes normal after warming up, ECM will activate closed-loop fuel control to correct air-fuel ratio, thus realizing the optimum conversion efficiency of three-way catalytic converter.

Three-way catalytic converter protection

The engine management system has the function to protect three-way catalytic converter. The ECM estimates three-way catalytic converter temperature according to engine operating conditions. When it is estimated that exhaust temperature will exceed the converter's maximum permissible temperature for a long time, ECM will automatically activate the protection function of three-way catalytic converter to keep the temperature normal.

System voltage protection

When system voltage becomes extremely high due to charging system malfunction, engine management system will activate the protection program to limit engine speed, thus avoiding damage to ECM and battery.

Precautions

General service requirements

- Only digital multimeter can be used to perform inspection for engine management system.
- Use genuine components to perform service work, otherwise, the appropriate engine management system operation cannot be guaranteed.
- Only use unleaded gasoline during servicing.
- Please observe normative service and diagnostic flowchart to perform service work.
- Never disassemble the components of engine management system during servicing.
- When holding electronic elements (ECM, sensor, etc.) during servicing, take extra care not to drop them on the ground.
- Set up a consciousness of environmental protection and dispose of the waste effectively that is produced during servicing.

Precautions during servicing

- 1. Do not causally remove any component or its connector of engine management system from its installation 06position to prevent damage accidentally, or foreign matter, such as moisture, oil from entering connectors, which will affect the normal operation of engine management system.
- 2. Be sure to turn ignition switch off when disconnecting and connecting connectors. Otherwise, electric elements may be damaged.
- 3. When simulating hot operating condition of malfunction and performing other service work that may cause the temperature to rise, never allow ECM temperature to exceed 80°C.
- 4. As the supplying pressure of fuel system is high (approximately 400 kPa), all the fuel pipes are high pressure resistant pipe. The fuel pressure in fuel lines is still high even when engine is not running. Therefore, be careful not to casually remove the fuel pipe during servicing; when it is necessary to service the fuel system, discharge the pressure in fuel system before removing fuel pipe. The way to discharge pressure is as follows:
- Remove fuel pump relay, start the engine and idle it until the engine stops running by itself. Then attempt to start the engine 2 - 3 times to ensure fuel pressure is discharged completely. The removal of fuel pipe and replacement of fuel filter should be performed in a well-ventilated area by professional service men.
- 5. Do not energize electric fuel pump when removing it from fuel tank to prevent electric sparks, which will cause a fire.
- 6. Running test for fuel pump is prohibited when it is empty or in water; otherwise, it will shorten the service life. Never connect the positive and negative of fuel pump in reverse.
- 7. When checking ignition system, only perform spark jump test when it is necessary and the time should be shortened as much as possible. Do not open throttle during test; otherwise, a large amount of unburned gasoline will enter the exhaust pipe, causing damage to three-way catalytic converter.
- 8. As idling adjustment is performed by engine management system completely, manual adjustment is not required. The accelerator pedal stopper screw of throttle body has been adjusted at the factory, and the user is not allowed to change its original position.
- 9. Do not connect battery with its polarity reversed to prevent damage to electronic elements. This system adopts negative ground.
- 10. Never remove battery cable when engine is running.
- 11. The positive, negative battery cables and ECM must be removed before performing welding on vehicle.
- 12.Do not puncture wire outer coat to detect electric signals input and output by components.

Specifications

Torque Specifications

Description	Torque (N·m)
Coolant Temperature Sensor	11 - 16
Knock Sensor Fixing Bolt	20 ± 5
Engine Speed Sensor Fixing Bolt	8 ± 2
Camshaft Position Sensor Fixing Bolt	8 ± 0.5
VVT Control Valve Fixing Bolt	8 ± 2
Engine Control Module Bracket Fixing Nut	7 ± 1

06 General Specifications


	Parameters	
ECM	Working voltage	9 - 16 V
ECIVI	Working temperature	-40 - 105°C
	Working voltage	9 - 16 V
Oxygen sensor	Working temperature	350°C
	Heater resistance (20°C)	7 - 11 Ω
Knock sensor	Working temperature	-40 - 130°C
NITOCK SETISOF	Rated resistance (20°C)	4.9 MΩ ± <mark>20%</mark>
رسوبيت سر	Working voltage	5 V
Engine coolant temperature	Working temperature	-30 - 130°C
sensor	Rated resistance (20°C)	2.5 kΩ ± 5%
	Rated resistance (100°C)	300 - 400 Ω
VVT control valve	Working voltage	9 - 16 V
	Rated resistance (20°C)	8 ± 0.5 Ω
	Working voltage	9 - 16 V
Ignition coil	Rated resistance of primary winding (23 ± 3°C)	0.50 - 0.64 Ω
	Rated resistance of secondary winding (23 ± 3°C)	9.50 - 12.10 kΩ
	Working voltage	6 - 16 V
Fuel injector	Working temperature	-40 - 110°C
i dei injectoi	Working injection pressure	300 - 550 kPa
	Rated resistance (20°C)	11 - 16 Ω
	Working voltage	9 - 16 V
Canister solenoid valve	Working temperature	-30 - 120°C
	Rated resistance (20°C)	26 ± 4 Ω

	Items	Parameters
	Working temperature	-40 - 120°C
Crankshaft position sensor	Rated resistance (23°C)	860 Ω ± 20%
	Installation clearance with signal gear	0.2 - 1.8 mm
	Working voltage	5 V
Intake Pressure/ Temperature Sensor	Working temperature	-40 - 130°C
Tomporataro concor	Rated resistance (20°C)	$2.5 \text{ k}\Omega \pm 5\%$
	Throttle position sensor 1 (Accelerator pedal released)	0.78 V
	Throttle position sensor 1 (Accelerator pedal depressed)	4.29 V
Electronic throttle	Throttle position sensor 2 (Accelerator pedal released)	4.22 V
	Throttle position sensor 2 (Accelerator pedal depressed)	0.71 V
	Working voltage	9 - 16 V
Fuel pump	Working temperature	-30 - 70°C
	System pressure	300 - 550 kPa
Spark plug	Spark plug clearance	0.8 - 0.9 mm
	Working voltage	4.5 - 16 V
Camshaft position sensor	Working temperature	-30 - 130°C
انه (مسئولیت محد	Installation clearance with signal gear	0.2 - 1.8 mm
رکاران خودرو در ایرار	Electronic accelerator pedal sensor 1 (Accelerator pedal released)	0.72 - 0.74 V
Electronic appelerator nedal	Electronic accelerator pedal sensor 2 (Accelerator pedal released)	0.36 - 0.37 V
Electronic accelerator pedal	Electronic accelerator pedal sensor 1 (Accelerator pedal depressed)	3.95 V
	Electronic accelerator pedal sensor 2 (Accelerator pedal depressed)	1.97 V


Tools


Special Tool

X-431 3G Diagnostic Tester




General Tools









ECM Pin Definition

ECM connector 1


Pin No.	Definition	Pin No.	Definition
65	-	89	Knock Sensor B
66	-	90	Knock Sensor A
67	Fuel Injector (Bank 2)	91	Intake Pressure Sensor
68	Fuel Injector (Bank 1)	92	-
69	Variable Camshaft Timing Valve (Exhaust)	93	Camshaft Position Sensor 1 (Intake)
70	-	94	Canister Solenoid Valve
71	Variable Camshaft Timing Valve (Intake)	95	Sensor Ground
72	Fuel Injector (Bank 3)	96	Engine Speed Sensor A
73	Upstream Oxygen Sensor Heater	97	Engine Speed Sensor B
74	Fuel Injector (Bank 4)	98	5 V Power Supply 1
75	Throttle Actuator (+)	99	Ignition Coil Drive 2
76	- • • • • • • • • • • • • • • • • • • •	100	Ignition Coil Drive 1
77	Throttle Position Sensor 1	101	Engine Coolant Temperature Sensor
78	Throttle Position Sensor 2	102	Intake Temperature Signal
79	ميتال خودروسامانه (مسئ	103	-
80	Oxygen Sensor Ground	104	Upstream Oxygen Sensor
درو 81 ایران	انه دیجیتال تعمیرکاران خو	اولـ105 سام	Camshaft Position Sensor 2 (Exhaust)
82	-	106	-
83	-	107	Throttle 5 V Power Supply
84	Ground	108	-
85	Sensor Ground	109	5 V Power Supply
86	Throttle Ground	110	-
87	Throttle Actuator (-)	111	ECM Ground 4
88	-	112	ECM Ground 3

ECM connector 2


Pin No.	Definition	Pin No.	Definition
1	CAN Bus Line High	33	-
2	-	34	-
3	-	35	Ignition Switch
4	-	36	5 V Power Supply
5	Main Relay Coil	37	5 V Power Supply
6	Clutch Switch (MT)	38	-
7	Accelerator Pedal Position Sensor 1 Ground	39	-
8	-	40	-
9	-	41	Fuel Pump Relay Coil
10	-	42	A/C Compressor Relay Coil (MT)
11	-	43	Oxygen Sensor Ground
12	-	44	PEPS (w/ PEPS)
13	Starter Relay	45	Electronic Accelerator Pedal Sensor 1
14	- 0	46	
15	Noncontinuous Power Supply	47	Ground
16	Noncontinuous Power Supply	48	Downstream Oxygen Sensor Heater
17	CAN Bus Line Low	49	
18	بيتان فورو مدين	50	
19	المديدة التحميكاليث	51	
20	Battery Continuous Power Supply	52	. 0
21	Downstream Oxygen Sensor	53	-
22	-	54	-
23	Brake Switch	55	-
24	A/C Pressure Sensor	56	Low-speed Fan Control
25	Brake Light Switch	57	-
26	-	58	Starter Relay Coil
27	-	59	Electronic Accelerator Pedal Sensor 2 Ground
28	A/C Switch	60	-
29	-	61	-
30	Electronic Accelerator Pedal Sensor 2	62	-
31	High-speed Fan Control	63	ECM Ground 2
32	5 V Power Supply	64	ECM Ground 1

Circuit Diagram


SQR484F Engine Management System (Page 1 of 8)




SQR484F Engine Management System (Page 2 of 8)




SQR484F Engine Management System (Page 3 of 8)




SQR484F Engine Management System (Page 4 of 8)




SQR484F Engine Management System (Page 5 of 8)




SQR484F Engine Management System (Page 6 of 8)



SQR484F Engine Management System (Page 7 of 8)



SQR484F Engine Management System (Page 8 of 8)



DIAGNOSIS & TESTING

Diagnostic Help

- 1. Connect X-431 3G Diagnostic tester (the latest software) to Data Link Connector (DLC), and make it communicate with vehicle electronic module by the data network.
- 2. Confirm that malfunction is current, and carry out diagnostic test and repair procedures.
- 3. If DTC cannot be deleted, the malfunction is current.
- 4. Only use a digital multimeter to measure the voltage of electronic system.
- 5. Refer to any Technical Bulletin that may apply to the malfunction.
- 6. Visually check the related wire harness.
- 7. Check and clean all Engine Control Module (ECM) grounds related to the current DTC.
- 8. If multiple trouble codes were set, use circuit diagrams and look for any common ground circuit or power supply circuit applied to the DTC.

Intermittent DTC Troubleshooting

If malfunction is intermittent, perform the following:

- · Check if connectors are loose.
- Check if wire harnesses are worn, pierced, pinched or partially broken.
- Monitor X-431 3G diagnostic tester (the latest software) data that is related to this circuit.
- · Wiggle related wire harnesses and connectors and observe if the signal is interrupted in the related circuit.
- If possible, try to duplicate the conditions under which the DTC was set.
- Look for the data that has changed or the DTC to reset during the wiggle test.
- Look for broken, bent, protruded or corroded terminals.
- Inspect sensors and mounting areas for damage, foreign matter, etc. that will cause incorrect signals.
 - Use data recorder and/or oscilloscope to help diagnose intermittent malfunctions.
 - Remove the Engine Control Module (ECM) from the malfunctioning vehicle and install it on a new car to perform test. If DTC cannot be cleared, ECM is malfunctioning. If DTC can be cleared, reinstall ECM to the original vehicle.

Ground Inspection

Groundings are very important to proper operation of circuits. Ground points are often exposed to moisture, dirt and other corrosive environments. Corrosion (rust) can increase resistance which will change the way in which a circuit works.

Electrical control circuits are very sensitive to proper grounding. A loose or corroded ground can seriously affect control circuit. Perform the following operations when checking ground points:

- 1. Remove the ground bolt or nut.
- 2. Check all contact surfaces for tarnish, dirt and rust, etc.
- 3. Clean as necessary to ensure that contacting is in a good condition.
- 4. Reinstall the ground bolt or nut securely.
- 5. Check if add-on accessories interfere with the ground circuit.
- 6. If several wire harnesses are crimped into one ground terminal, check if they are installed correctly. Make sure all wire harnesses are clean, securely fastened and well contacted without crimping any excessive insulation coat.

Throttle Self-learning

Perform throttle self-learning in the following conditions:

- Battery is removed and negative battery cable is disconnected.
- · ECM is replaced.
- ECM is disconnected and reconnected.
- Throttle is replaced or cleaned.

Throttle self-learning conditions:

- Engine intake temperature > 5°C
- 100.5°C > coolant temperature > 5°C
- Engine speed less than 250 rpm
- Vehicle speed = 0
- Battery voltage > 10 V
- Accelerator pedal opening angle < 14.9%

Throttle self-learning procedures:

Turn ignition switch to OFF and then to ON. Wait for 1 minute to finish throttle self-learning.

Diagnostic Trouble Code (DTC) Chart


DTC Code	DTC Definition
P000A 00	Camshaft control Slow Response (inlet)
P000B 00	Camshaft control Slow Response (outlet)
P0010 13	Control Circuit of camshaft control valve (inlet)
P0013 13	Control Circuit of camshaft control valve (outlet)
P0012 00	Inlet camshaft not in locking position during start
P0015 00	Outlet camshaft not in locking position during start
P0016 29	Npl error for alignment between camshaft (inlet) and crankshaft
P0018 29	Npl error for alignment between camshaft (outlet) and crankshaft
P0030 13	O2 Sensor Heater Control Circuit Open (upstream of the catalyzer)
P0031 11	O2 Sensor Heater Control Circuit Low (upstream of the catalyzer)
P0032 12	O2 Sensor Heater Control Circuit High (upstream of the catalyzer)
P0036 13	O2 Sensor Heater Control Circuit Open (downstream of the catalyzer)
P0037 11	O2 Sensor Heater Control Circuit Low (downstream of the catalyzer)
P0038 12	O2 Sensor Heater Control Circuit High (downstream of the catalyzer)
P0053 1E	O2 Sensor Heater Resistance too large (upstream of the catalyzer)
P0054 1E	O2 Sensor Heater Resistance too large (downstream of the catalyzer)
P0105 28	Manifolt Absolut Pressure Circuit No Change
P0106 00	Manifold Abs. Pressure Performance Non-plausible
P0107 11	Manifold Abs. Pressure Low Input
P0108 12	Manifold Abs. Pressure High Input
P0111 00	Intake Air Temp. Circ. Performance Non-plausible
P0112 16	Intake Air Temp. Circ. Low Input

DTC Code	DTC Definition	
P0113 17	Intake Air Temp. Circ. High Input	
P0116 00	Engine Coolant Temp. Circ. Performance Non-plausible	
P0117 16	Engine Coolant Temp. Circ. Low Input	
P0118 17	Engine Coolant Temp. Circ. High Input	
P0121 29	Throttle Pos. Sensor 1 Circ. Performance Non-plausible	
P0122 16	Throttle Pos. Sensor 1 Circ. Low Input	
P0123 17	Throttle Pos. Sensor 1 Circ. High Input	
P0130 00	O2 Sensor Circ. Malfunction (upstream of the catalyzer)	
P0131 16	O2 Sensor Circ. Low Voltage (upstream of the catalyzer)	
P0132 17	O2 Sensor Circ. High Voltage (upstream of the catalyzer)	
P0133 00	O2 Sensor Circ. Slow Response (upstream of the catalyzer)	
P0134 00	O2 Sensor Circ. No Activity Detected (upstream of the catalyzer)	
P0136 00	O2 Sensor Circ. Malfunction (downstream of the catalyzer)	
P0137 16	O2 Sensor Circ. Low Voltage (downstream of the catalyzer)	
P0138 17	O2 Sensor Circ. High Voltage (downstream of the catalyzer)	
P0140 00	O2 Sensor Circ. No Activity Detected (downstream of the catalyzer)	
P0201 13	Cylinder 1 - Injector Circuit error	
P0271 12	Cylinder 4 - Injector Circuit High	
P0300 21	Random/Multiple Cylinder Misfire Detected (over emission limit)	
P0301 21	Cylinder 1 Misfire Detected (over emission limit)	
P0302 21	Cylinder 2 Misfire Detected (over emission limit)	
P0303 21	Cylinder 3 Misfire Detected (over emission limit)	
P0304 21	Cylinder 4 Misfire Detected (over emission limit)	
P0322 00	EPM - Crankshaft signal fault	
P0327 00	Knock Sensor 1 Circuit Low	
P0328 00	Knock Sensor 1 Circuit High	
P0341 00	EPM - Camshaft signal fault	
P0346 00	EPM - Camshaft 2 signal fault	
P0420 00	Catalyst conversion insufficient	
P0444 13	Evaporativ Emiss. System Purge Control Valve Circuit Open	
P0458 16	Evaporative Emission System Purge Control Valve Circuit Low	
P0459 17	Evaporative Emission System Purge Control Valve Circuit High	
P0480 13	Cooling Fan 1 Control Circuit error	
P0481 13	Cooling Fan 2 Control Circuit error	
P0560 00	Non-plausible error of battery voltage	
P0562 16	System Voltage Low	
P0563 17	System Voltage High	


DTC Code	DTC Definition
P0604 43	Internal contr. module RAM error
P0605 43	Internal contr. module ROM error
P0606 00	Safety monitoring fuel cutoff error
P0627 13	Fuel Pump Control Circuit Open
P0628 11	Fuel Pump Control Circuit Low
P0629 12	Fuel Pump Control Circuit High
P0645 13	AC clutch relais circuit open
P0646 11	A/C Clutch Relay Control Circuit Low
P0647 12	A/C Clutch Relay Control Circuit High
P0688 91	Power Relay Sense Circuit Non-plausible error
P0688 92	Power Relay Sense Circuit Signal error
P0691 11	Fan 1 Control Circuit Low
P2195 00	O2 Sensor Signal Stuck Lean (upstream of the catalyzer)
P2196 00	O2 Sensor Signal Stuck Rich (upstream of the catalyzer)
P2270 00	O2 Sensor Signal Stuck Lean (downstream of the catalyzer)
P2271 00	O2 Sensor Signal Stuck Rich (downstream of the catalyzer)
U0101 87	Lost Communication with TCM
U0129 87	Lost Communication With Brake System Control Module
U0140 87	Lost Communication with Body Control Module (BCM)
U0293 87	Lost Communication with HCU
P1106 00	Throttle position deviation error
P1111 00	Return spring check max error
P1619 00	ECM not programed (virgin state)
U0140 00	Lost Communication With Body Control Module (Immo)

ECM Power Supply Circuit & Ground Circuit Testing

Power Supply Circuit (Page 1 of 1)



Ground Circuit (Page 1 of 1)



Confirmation Procedure

Before performing the following procedures, confirm that battery voltage is higher than 12 V.


- · Turn ignition switch off.
- Connect X-431 3G diagnostic tester (the latest version) to Data Link Connector (DLC).
- Turn ignition switch ON.
- Using diagnostic tester, select Read Datastream.
- If the datastream is not detected, the malfunction indicated by the datastream is current. Go to the diagnosis procedure - Step 1.
- If the datastream is detected, the malfunction indicated by the datastream is intermittent (See page 06-20).

Diagnosis Procedure

Check ECM power supply circuit

- a. Turn ignition switch off.
 - b. Disconnect ECM connector E-557.
 - c. Check voltage between terminals of ECM connector E-557 and body ground.

	Multimeter Connection	Condition		pecified ondition		
	E-557 (20) - Body Ground	Always 11 to		to 14 V	14 V	
	OK Go to	step 4	••	-	<u></u>	
20	بيئوليت محدر	.رو سامانه (می	، خود	حىتا	ادر	



NG

2 **Check ECM fuse**

- a. Unplug ECM fuse EF19 (10A) from engine compartment fuse and relay box.
- b. Check resistance of fuse.

Standard resistance: less than 1 Ω

Replace ECM fuse NG

OK

3 Check wire harness and connector (ECM - engine compartment fuse and relay box)


- a. Disconnect engine compartment fuse and relay box connector E-094.
- b. Check wire harness between connector terminals on wire harness side.

Check for Open

Multimeter Connection	Specified Condition
E-557 (20) - E-094 (A2)	Continuity

Check for Short

Multimeter Connection	Specified Condition
E-557 (20) or E-094 (A2) - Body ground	No continuity
E-557 (20) or E-094 (A2) - Battery positive	No continuity



NG

Repair or replace wire harness or connector

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ОК

Repair or replace engine compartment fuse and relay box or wire harness (engine compartment fuse and relay box - battery)


4 Check main relay circuit voltage

- a. Remove main relay from engine compartment fuse and relay box.
- b. Measure voltage between terminals of main relay and body ground.

Multimeter Connection	Condition	Specified Condition
Main relay terminals 85 and 87 (engine compartment fuse and relay box side) - Body ground	Always	11 to 14 V

NG

Repair or replace wire harness or connector (main relay - battery)





5 Check main relay and fuse EF40


- a. Check if fuse EF40 is normal.
- b. Check for continuity between terminals of main relay.

Multimeter Connection	Specified Condition
30 - 87	No continuity
	Continuity
30 - 87	(when battery voltage is applied between terminals 85 and 86)

NG

06

Replace fuse or main relay






- Check wire harness and connector (ECM engine compartment fuse and relay box)
- a. Check wire harness between connector terminals.
- b. Disconnect engine compartment fuse and relay box connector E-093.

Check for Open

Multimeter Connection	Specified Condition
E-557 (15, 16) - E-094 (A6)	Continuity

Check for Short

Multimeter Connection	Specified Condition
E-557 (15, 16) or E-094 (A6) - Body ground	No continuity
E-557 (15, 16) or E-094 (A6) - Battery positive	No continuity



Check for Open


Multimeter Connection	Specified Condition
E-557 (5) - E-093 (F14)	Continuity

Check for Short

Multimeter Connection	Specified Condition
E-557 (5) or E-093 (F14) - Body ground	No continuity
E-557 (5) or E-093 (F14) - Battery positive	No continuity



Repair or replace wire harness or connector



06

ОК


7 Check ECM power supply circuit (ignition switch voltage)

- a. Connect fuse and relay box connector E-094.
- b. Turn ignition switch to ON.
- c. Check voltage between terminals of ECM connector.

Multimeter Connection	Condition	Specified Condition
E-557 (35) - E-557 (63, 64)	Ignition switch ON	11 to 14 V

OK

Replace ECM



NG

- 8 Check ECM fuse
- a. Unplug ECM fuse EF17 (10A) from engine compartment fuse and relay box.
- b. Check resistance of fuse.

Standard resistance: less than 1 Ω

NG

Replace ECM fuse



- 9 Check wire harness and connector (ECM body ground and engine compartment fuse and relay box)
- a. Disconnect engine compartment fuse and relay box connector E-094.
- b. Check wire harness between connector terminals on wire harness side.

Check for Open

Multimeter Connection	Specified Condition
E-557 (35) - E-094 (A4)	Continuity

Check for Short

06

Multimeter Connection	Specified Condition
E-557 (35) or E-094 (A4) - Body ground	No continuity
E-557 (35) or E-094 (A4) - Battery positive	No continuity


- c. Disconnect ECM ground point E-049 and E-050.
- d. Check ECM ground point (See page 06-20).
- e. Check ECM ground wire harness.


Check for Open

Multimeter Connection	Specified Condition
E-557 (63, 64) - E-049	Continuity
E-558 (47, 48) - E-050	Continuity

NG

Repair or replace wire harness or connector





OK

10 Check ignition switch assembly (See page 24-14)

NG

Replace ignition switch assembly

OK

Repair or replace engine compartment fuse and relay box or wire harness (engine compartment fuse and relay box - ignition switch)








DTC	P0030 13	O2 Sensor Heater Control Circuit Open (upstream of the catalyzer)
DTC	P0031 11	O2 Sensor Heater Control Circuit Low (upstream of the catalyzer)
DTC	P0032 12	O2 Sensor Heater Control Circuit High (upstream of the catalyzer)
DTC	P0053 1E	O2 Sensor Heater Resistance too large (upstream of the catalyzer)







DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P0030 13	O2 Sensor Heater Control Circuit Open (upstream of the catalyzer)	Ignition switch ON Engine running	Upstream oxygen sensorWire harness or connectorFuseECM
P0031 11	O2 Sensor Heater Control Circuit Low (upstream of the catalyzer)		
P0032 12	O2 Sensor Heater Control Circuit High (upstream of the catalyzer)		
P0053 1E O2 Sensor Heater Resistance too large (upstream of the catalyzer)			

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC). 00
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Start the engine and warm it up to normal operating temperature, and then select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure - Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

· When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 **Check ECM ground point**
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).


Repair or replace ground wire harness or NG ground point

OK

- 2 Check upstream oxygen sensor connector
- a. Disconnect upstream oxygen sensor connector E-567.
- b. Check upstream oxygen sensor connector.

NG

Repair or replace connector



ОК

06

- 3 Check upstream oxygen sensor heater power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between terminal 4 of upstream oxygen sensor connector E-567 and body ground.

	Multimeter Connection	Condition	Specified Condition
	E-567 (4) - Body ground	Ignition switch ON	11 to 14 V
C	بيئوليت محد	درو سامانه (می	دىجىتال خود

ок

Go to step 5

NG

4 Check upstream oxygen sensor power supply circuit

- a. Turn ignition switch to LOCK.
- b. Check fuse EF39 and main relay.
- c. Disconnect engine compartment fuse and relay box connector E-094.
- d. Check wire harness between upstream oxygen sensor connector terminals and engine compartment fuse and relay box connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-567 (4) - E-094 (A7)	Always	Continuity


Check for Short

06

Multimeter Connection	Condition	Specified Condition	
E-567 (4) or E-094 (A7) - Body ground	Always	No continuity	
E-567 (4) or E-094 (A7) - Battery positive	Always	No continuity	

NG

Replace fuse, main relay, wire harness or connector (upstream oxygen sensor - engine compartment fuse and relay box)





OK

5 Check upstream oxygen sensor heater control circuit


- a. Disconnect ECM connector E-558.
- b. Check wire harness between upstream oxygen sensor connector terminals and ECM connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-567 (3) - E-558 (73)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-567 (3) or E-558 (73) - Body ground	Always	No continuity
E-567 (3) or E-558 (73) - Battery positive	Always	No continuity



NG

Repair or replace wire harness or connector (upstream oxygen sensor - ECM)


ОК

ولین سامانه دیجیتال تعمیرکاران خودر و در ایران

6 Check upstream oxygen sensor heater

a. Measure resistance of upstream oxygen sensor.

Multimeter Connection	Condition	Specified Condition
Terminal C - Terminal D	20°C	7 - 11 Ω
Terminal A - Terminal B		
Terminal A - Terminal C		
Terminal A - Terminal D	Always	No continuity
Terminal B - Terminal C		
Terminal B - Terminal D		



NG

Replace upstream oxygen sensor

ОК

7 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0030 13, P0031 11, P0032 12, P0053 1E still exists.

NG Replace ECM

OK

06

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




DTC	P0036 13	O2 Sensor Heater Control Circuit Open (downstream of the catalyzer)
DTC	P0037 11	O2 Sensor Heater Control Circuit Low (downstream of the catalyzer)
DTC	P0038 12	O2 Sensor Heater Control Circuit High (downstream of the catalyzer)
DTC	P0054 1E	O2 Sensor Heater Resistance too large (downstream of the catalyzer)

06



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران





DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P0036 13	O2 Sensor Heater Control Circuit Open (downstream of the catalyzer)		
P0037 11	O2 Sensor Heater Control Circuit Low (downstream of the catalyzer)	Ignition switch ON	Downstream oxygen sensorWire harness or connector
P0038 12	O2 Sensor Heater Control Circuit High (downstream of the catalyzer)	Engine running	FuseECM
P0054 1E	O2 Sensor Heater Resistance too large (downstream of the catalyzer)		

06

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC). 00
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Start the engine and warm it up to normal operating temperature, and then select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure - Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

· When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 **Check ECM ground point**
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).


NG

Repair or replace ground wire harness or ground point

- 2 Check downstream oxygen sensor connector
- a. Disconnect downstream oxygen sensor connector.
- b. Check downstream oxygen sensor connector.

NG)

Repair or replace connector



06




- 3 Check downstream oxygen sensor heater power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between terminal 4 of downstream oxygen sensor connector E-555 and body ground.

	Multimeter Connection	Condition	Specified Condition
	E-555 (4) - Body ground	Ignition switch ON	11 to 14 V
20	سولست محد	ر و سامانه (می	دىجىتا ، جود

ок

Go to step 5



NG

4 Check downstream oxygen sensor power supply circuit

- a. Turn ignition switch to LOCK.
- b. Check fuse EF39 and main relay.
- c. Disconnect engine compartment fuse and relay box connector E-094.
- d. Check wire harness between downstream oxygen sensor connector terminals and engine compartment fuse and relay box connector terminals.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-555 (4) - E-094 (A7)	Always	Continuity

Check for Short


Multimeter Connection	Condition	Specified Condition
E-555 (4) or E-076 (A7) - Body ground	Always	No continuity
E-555 (4) or E-094 (A7) - Battery positive	Always	No continuity

NG

Replace fuse, main relay, wire harness or connector (downstream oxygen sensor - engine compartment fuse and relay box)



06



5 Check downstream oxygen sensor heater control circuit


- a. Disconnect ECM connector E-557.
- b. Check wire harness between downstream oxygen sensor connector terminals and ECM connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-555 (3) - E-557 (48)	Always	Continuity

Check for Short

Multimeter
ConnectionConditionSpecified
ConditionE-555 (3) or
E-557 (48) - Body
groundAlwaysNo continuityE-555 (3) or
E-557 (48) -
Battery positiveAlwaysNo continuity



NG

06

Repair or replace wire harness or connector (downstream oxygen sensor - ECM)


ОК

اولین سامانه دیجیتال تعمیرکاران خودر و در ایرار

6 Check downstream oxygen sensor heater

a. Measure resistance of downstream oxygen sensor.

Multimeter Connection	Condition	Specified Condition
Terminal C - Terminal D	20°C	7 - 11 Ω
Terminal A - Terminal B		
Terminal A - Terminal C		
Terminal A - Terminal D	Always	No continuity
Terminal B - Terminal C		
Terminal B - Terminal D		



NG

Replace downstream oxygen sensor



7 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0036 13, P0037 11, P0038 12, P0054 1E still exists.





System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.








DTC	P0105 28	Manifolt Absolut Pressure Circuit No Change
	1	T
DTC	P0106 00	Manifold Abs. Pressure Performance Non-plausible
DTC	P0107 11	Manifold Abs. Pressure Low Input
DTC	P0108 12	Manifold Abs. Pressure High Input







DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P0105 28	Manifolt Absolut Pressure Circuit No Change		
P0106 00	Manifold Abs. Pressure Performance Non-plausible	Ignition switch ON Engine running	Intake Pressure/Temperature SensorWire harness or connector
P0107 11	Manifold Abs. Pressure Low Input		• ECM
P0108 12	Manifold Abs. Pressure High Input		

06 DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure - Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

∆c ◆ CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- **Check ECM ground point**
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG


Repair or replace ground wire harness or ground point

2 Check Intake Pressure/Temperature Sensor connector

- a. Disconnect Intake Pressure/Temperature Sensor connector E-511.
- b. Check Intake Pressure/Temperature Sensor connector.

NG

Repair or replace connector






06

- 3 Check Intake Pressure/Temperature Sensor signal voltage
- a. Connect air flow meter connector E-511.
- b. Turn ignition switch to ON and start the engine.
- c. Using multimeter, measure voltage between connector E-511 terminal 1 and body ground.

	Multimeter Connection	Condition	Specified Condition
200	سئوليت محد	رو سامانه (می Idle	Voltage is about 1.3 V (value changes with
	E 511 (1) Pody	. 1 1 /	model)
1	E-511 (1) - Body ground	ں تعمیر صارات	Instantaneous
		Rapidly depress accelerator pedal	voltage is about 4 V (value changes with model)

ОК

Go to step 8



NG

4 Check Intake Pressure/Temperature Sensor power supply voltage


- a. Disconnect Intake Pressure/Temperature Sensor connector E-511.
- b. Check voltage between Intake Pressure/Temperature Sensor connector terminals and body ground.

Multimeter Connection	Condition	Specified Condition
E-511 (2) - Body ground	Ignition switch ON	5 V

ок

06

Go to step 6



NG


5 Check Intake Pressure/Temperature Sensor power supply circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect ECM connector E-558 and engine compartment fuse and relay box connector E-558.
 - c. Check wire harness between connector terminals.
 - Check for Open

Multimeter Connection	Condition	Specified Condition
E-511 (2) - E-558 (109)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-511 (2) or E-558 (109) - Body ground	Always	No continuity
E-511 (2) or E-558 (109) - Battery positive	Always	No continuity




Check for Open

Multimeter Connection	Condition	Specified Condition
E-551 (4) - E-558 (85)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-551 (4) or E-558 (85) - Body ground	Always	No continuity
E-551 (4) or E-558 (85) - Battery positive	Always	No continuity



06

OK

NG

Replace wire harness or connector (Intake Pressure/Temperature Sensor - ECM or engine compartment fuse and relay box)

6 Check Intake Pressure/Temperature Sensor signal circuit

 a. Check wire harness between Intake Pressure/ Temperature Sensor connector terminals and ECM connector terminals.

سامانه د حیثال تعمیر کار


	CONTRACT MANAGEMENT CONTRACTOR	9400300 000
Multimeter Connection	Condition	Specified Condition
E-551 (1) - E-558 (91)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-551 (1) or E-558 (91) - Body ground	Always	No continuity
E-551 (1) or E-558 (91) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (Intake Pressure/Temperature Sensor - ECM)



7 Check Intake Pressure/Temperature Sensor

- a. Remove Intake Pressure/Temperature Sensor.
- b. Check Intake Pressure/Temperature Sensor for debris and damage.

NG

06

Clean or replace Intake Pressure/ Temperature Sensor, and go to next step

OK

8 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0105 28, P0106 00, P0107 11, P0108 12 still exists.

NG Replace ECM

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

DTC	P0111 00	Intake Air Temp. Circ. Performance Non-plausible
DTC	P0112 16	Intake Air Temp. Circ. Low Input
DTC	P0113 17	Intake Air Temp. Circ. High Input







DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P0111 00	Intake Air Temp. Circ. Performance Non- plausible		Intake Pressure/Temperature Sensor
P0112 16	Intake Air Temp. Circ. Low Input	Ignition switch ON Engine running	Wire harness or connectorECM
P0113 17	Intake Air Temp. Circ. High Input		

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- · Select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

ولین سامانه دیجیتال تعمیر Chagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG)

Repair or replace ground wire harness or ground point

OK

- 2 Check air flow meter connector
- a. Disconnect Intake Pressure/Temperature Sensor connector E-551.
- b. Check Intake Pressure/Temperature Sensor connector.

NG Repair or replace connector

OK


- 3 Check intake temperature sensor voltage
- a. Disconnect Intake Pressure/Temperature Sensor connector E-017.
- b. Turn ignition switch to ON.
 - c. Check voltage between connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-551 (3) - Body ground	Ignition switch ON	5 V

OK Go to step 6

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



NG

4 Check intake temperature sensor signal circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect ECM connector E-035.
- c. Check wire harness between Intake Pressure/ Temperature Sensor connector terminals and ECM connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-551 (3) - E-558 (102)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-551 (3) or E-558 (102) - Body ground	Always	No continuity
E-551 (3) or E-558 (102) - Battery positive	Always	No continuity

NG

Replace wire harness or connector (Intake Pressure/Temperature Sensor - ECM)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایرار

5 Check intake pressure sensor ground circuit


a. Check wire harness between connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-551 (4) - E-558 (85)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-551 (4) or E-558 (85) - Body ground	Always	No continuity
E-551 (4) or E-558 (85) - Battery positive	Always	No continuity



06

NG

Repair or replace wire harness or connector (Intake Pressure/Temperature Sensor - ECM)

OK

Replace Intake Pressure/Temperature Sensor, and go to step 7

6 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0111 00, P0112 16, P0113 17 still exists.

NG

06

Replace ECM

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.


شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

DTC	P0116 00	Engine Coolant Temp. Circ. Performance Non-plausible
DTC	P0117 16	Engine Coolant Temp. Circ. Low Input
DTC	P0118 17	Engine Coolant Temp. Circ. High Input







DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P0116 00	Engine Coolant Temp. Circ. Performance Non-plausible		Engine coolant temperature sensor
P0117 16	Engine Coolant Temp. Circ. Low Input	Ignition switch ON Engine running	Wire harness or connectorECM
P0118 17	Engine Coolant Temp. Circ. High Input		

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- · Select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

ولین سامانه دیجیتال تعمیر Chagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG)


Repair or replace ground wire harness or ground point

OK

- 2 Check engine coolant temperature sensor connector
- a. Disconnect engine coolant temperature sensor connector E-521.
- b. Check engine coolant temperature sensor connector.

NG)

Repair or replace connector




06



- 3 Check engine coolant temperature sensor power supply voltage
- a. Turn ignition switch to ON.
- b. Check voltage between engine coolant temperature sensor terminal and body ground.

	Multimeter Connection	Condition	Specified Condition
	E-521 (2) - Body ground	Ignition switch ON	●● 5 V
9	OK Go to	رو سامانه (میا step 5	ديجيتال حود

سامانه دیدیتال تعمیر کاران خودر و در ایران



NG

4 Check engine coolant temperature sensor power supply circuit


- a. Turn ignition switch to LOCK.
- b. Disconnect ECM connector E-035.
- c. Check wire harness between engine coolant temperature sensor connector terminals and ECM connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-521 (2) - E-558 (101)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-521 (2) or E-558 (101) - Body ground	Always	No continuity
E-521 (2) or E-558 (101) - Battery positive	Always	No continuity



NG

Replace wire harness or connector (engine coolant temperature sensor - ECM)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



5 Check engine coolant temperature sensor ground circuit


 a. Check wire harness between engine coolant temperature sensor connector terminals and ECM connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-521 (1) - E-558 (84)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-521 (1) or E-558 (84) - Body ground	Always	No continuity
E-521 (1) or E-558 (84) - Battery positive	Always	No continuity



NG

06

Repair or replace wire harness or connector (engine coolant temperature sensor - ECM)

ОК

اولين سامانه ديجيتال تعميركاران خودرو درايرا

6 Check engine coolant temperature sensor

- a. Remove engine coolant temperature sensor.
- b. Check resistance of engine coolant temperature sensor.

Multimeter Connection	Specified Condition	
1 - 2	Resistance is 2.5 k Ω ± 5% (20°C), 300 - 400 Ω in boiled water (value changes with boiled water temperature)	

NG

Replace engine coolant temperature sensor

7 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0116 00, P0117 16, P0118 17 still exists.

NG >

Replace ECM

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.


06



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC	P0121 29	Throttle Pos.Sensor 1 Circ. Performance Non-plausible
DTC	P0122 16	Throttle Pos.Sensor 1 Circ. Low Input
DTC	P0123 17	Throttle Pos.Sensor 1 Circ. High Input



DTC Code	DTC Definitions	DTC Detection Conditions	Possible Cause
P0121 29	Throttle Pos.Sensor 1 Circ. Performance Non-plausible	Ignition switch ON Engine running	Throttle position sensor 1
P0122 16	Throttle Pos.Sensor 1 Circ. Low Input		Wire harness or connectorECM
P0123 17	Throttle Pos.Sensor 1 Circ. High Input		

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- · Select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

ولین سامانه دیجیتال تعمیر Chagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG

Repair or replace ground wire harness or ground point


OK

2 Check electronic throttle connector

- a. Disconnect electronic throttle connector E-513.
- b. Check electronic throttle connector.

NG)

Repair or replace connector



06




3 Check throttle position sensor 1 signal voltage

- a. Connect throttle position sensor connector E-513.
- b. Turn ignition switch to ON.
- c. Using diagnostic tester, check throttle position sensor 1 signal voltage.

Condition	Standard Value (V)
Accelerator pedal released	0.78
Accelerator pedal depressed	4.29





NG


4 Check throttle position sensor power supply voltage

- a. Turn ignition switch to LOCK.
- b. Disconnect electronic throttle connector E-513.
- c. Turn ignition switch to ON and check voltage between electronic throttle connector terminal and body ground.

Multimeter Connection	Condition	Specified Condition
E-513 (3) - Body ground	Ignition switch ON	5 V

ок >

Go to step 6



NG

5 Check throttle position sensor power supply circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect ECM connector E-558.
 - c. Check wire harness between electronic throttle connector terminals and ECM connector terminals.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-513 (3) - E-558 (107)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-513 (3) or E-558 (107) - Body ground	Alwaya	No continuity
E-513 (3) or E-558 (107) - Battery positive	Always	No continuity

NG

Replace wire harness or connector (electronic throttle - ECM)



Check throttle position sensor 1 signal circuit and ground circuit

a. Check wire harness between electronic throttle connector terminals and ECM connector terminals.


Check for Open

Multimeter Connection	Condition	Specified Condition
E-513 (6) - E-558 (77)	Alwaya	Continuity
E-513 (2) - E-558 (86)	Always	Continuity

Check for Short

06

Multimeter Connection	Condition	Specified Condition
E-513 (6) or E-558 (77) - Body ground		
E-513 (6) or E-558 (77) - Battery positive	<u> </u>	•
E-513 (2) or E-558 (86) - Body	Always	No continuity
ground	.ر و سامانه (می	ديجيتال خود
E-513 (2) or E-558 (86) - Battery positive	. 112 - 11	, , , , , ,




OK

Repair or replace wire harness or NG connector (electronic throttle - ECM)

7 Check electronic throttle

- a. Check electronic throttle for carbon deposits and foreign matter accumulation inside.
- b. Check if throttle valve body is stuck.
- c. Check resistance of electronic throttle.

Multimeter		Specified
Connection	Condition	Specified Condition
Terminal 3 - Terminal 2	At normal temperature	1.067 kΩ
Terminal 6 - Terminal 2	minal 6 - rminal 3 Throttle valve is rotated minal 5 - rminal 2	Resistance increases as throttle valve opens
Terminal 6 - Terminal 3		Resistance decreases as throttle valve opens
Terminal 5 - Terminal 2		Resistance decreases as throttle valve opens
Terminal 5 - Terminal 3		Resistance increases as throttle valve opens



06

Clean or replace electronic throttle assembly, and go to next step

ОК

8 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0121 29, P0122 16, P0123 17 still exists.

NG Replace ECM

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.


_					
	DTC	P0130 00	O2 Sensor Circ. Malfunction (upstream of the catalyzer)		
	DTC	P0131 16	O2 Sensor Circ. Low Voltage (upstream of the catalyzer)		
-					
	DTC	P0132 17	O2 Sensor Circ. High Voltage (upstream of the catalyzer)		
	DTC	P0133 00	O2 Sensor Circ. Slow Response (upstream of the catalyzer)		
06	DTC	P0134 00	O2 Sensor Circ. No Activity Detected (upstream of the catalyzer)		
06					
	DTC	P2195 00	O2 Sensor Signal Stuck Lean (upstream of the catalyzer)		
					
	DTC	P2196 00	O2 Sensor Signal Stuck Rich (upstream of the catalyzer)		



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران





DTC Code	DTC Definitions	DTC Detection Conditions	Possible Cause
P0130 00	O2 Sensor Circ. Malfunction (upstream of the catalyzer)		
P0131 16	O2 Sensor Circ. Low Voltage (upstream of the catalyzer)		
P0132 17	O2 Sensor Circ. High Voltage (upstream of the catalyzer)		
P0133 00	O2 Sensor Circ. Slow Response (upstream of the catalyzer)	Ignition switch ON Engine running	Upstream oxygen sensorWire harness or connectorECM
P0134 00	O2 Sensor Circ. No Activity Detected (upstream of the catalyzer)		• ECM
P2195 00	O2 Sensor Signal Stuck Lean (upstream of the catalyzer)	00	
P2196 00	O2 Sensor Signal Stuck Rich (upstream of the catalyzer)	: يجي	

شرکت دیجیتال خودرو DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Start the engine and warm it up to normal operating temperature, and then select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check upstream oxygen sensor connector
- a. Disconnect upstream oxygen sensor connector E-567.
- b. Check upstream oxygen sensor connector.

NG)

Repair or replace connector



يجيتاك خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)




- Check upstream oxygen sensor signal
- a. Connect upstream oxygen sensor connector E-567.
- b. Turn ignition switch to ON, start the engine and idle it for about 3 minutes.
- c. Using multimeter, measure voltage between terminals 2 and 1 of connector E-567.

Multimeter Connection	Condition	Specified Condition
E-567 (2) - E-567 (1)	Engine running	Fluctuates fast between 0.1 and 0.9 V (when operating temperature is 350°C)

ок

Go to step 7



NG

4 Check upstream oxygen sensor signal circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect ECM connector E-558.
- c. Disconnect upstream oxygen sensor connector E-567.
- d. Check wire harness between upstream oxygen sensor connector terminals and ECM connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-567 (2) - E-558 (104)	Always	Continuity

Check for Short

06

Multimeter Connection	Condition	Specified Condition
E-567 (2) or E-558 (104) - Body ground		N
E-567 (2) or E-558 (104) - Battery positive	Always	No continuity

Replace wire harness or connector (upstream oxygen sensor - ECM)


ولین سامانه دیجیتال تعمیرکاران خودرو در ایرار




a. Check wire harness between upstream oxygen sensor connector terminals and ECM connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-567 (1) - E-558 (16)	Always	Continuity







WWW.DIGITALKHODRO.COM

Check for Short

Multimeter Connection	Condition	Specified Condition
E-567 (1) or E-558 (16) - Body ground	Alwaya	No continuity
E-567 (1) or E-558 (16) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (upstream oxygen sensor -ECM)

OK

06

- 6 Check upstream oxygen sensor
- a. Remove upstream oxygen sensor.
- b. Check upstream oxygen sensor for following problems.
 - Moisture enters the internal of sensor, temperature changes greatly, and probe is broken.
 - Oxygen sensor is "poisoned" (Pb, S, Br, Si, etc.).

Replace upstream oxygen sensor

OK

Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0130 00, P0131 16, P0132 17, P0133 00, P0134 00, P2195 00 or P2196 00 still exists.

NG Replace ECM

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

06


06 - SQR484F ENGINE MANAGEMENT SYSTEM

DTC	P0136 00	O2 Sensor Circ. Malfunction (downstream of the catalyzer)
	_	
DTC	P0137 16	O2 Sensor Circ. Low Voltage (downstream of the catalyzer)
DTC	P0138 17	O2 Sensor Circ. High Voltage (downstream of the catalyzer)
	_	
DTC	P0140 00	O2 Sensor Circ. No Activity Detected (downstream of the catalyzer)
	_	
DTC	P2270 00	O2 Sensor Signal Stuck Lean (downstream of the catalyzer)
DTC	P2271 00	O2 Sensor Signal Stuck Rich (downstream of the catalyzer)

د تخيبار حوداه

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC Code	DTC Definitions	DTC Detection Conditions	Possible Cause
P0136 00	O2 Sensor Circ. Malfunction (downstream of the catalyzer)		
P0137 16	O2 Sensor Circ. Low Voltage (downstream of the catalyzer)		
P0138 17	O2 Sensor Circ. High Voltage (downstream of the catalyzer)	Ignition switch ON Engine running • Downstrea • Wire harno	Downstream oxygen sensor
P0140 00	O2 Sensor Circ. No Activity Detected (downstream of the catalyzer)		Wire harness or connector
P2270 00	O2 Sensor Signal Stuck Lean (downstream of the catalyzer)		
P2271 00	O2 Sensor Signal Stuck Rich (downstream of the catalyzer)	ے حیت	

شرکت دیجیتال خودر و DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Start the engine and warm it up to normal operating temperature, and then select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

• When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check downstream oxygen sensor connector
- a. Disconnect downstream oxygen sensor connector.
- b. Check downstream oxygen sensor connector.

NG

Repair or replace connector



يجيتاك خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود




- 3 Check downstream oxygen sensor signal
- a. Connect downstream oxygen sensor connector E-555.
- b. Turn ignition switch to ON, start the engine and idle it for about 3 minutes.
- c. Using diagnostic tester, measure downstream oxygen sensor signal voltage, or using multimeter, measure voltage between terminals 2 and 1 of connector E-555.

Multimeter Connection	Condition	Specified Condition
E-555 (2) - E-555 (1)	Engine running	Fluctuates slightly at about 0.45 V

ok

Go to step 7



NG

4 Check downstream oxygen sensor signal circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect ECM connector E-557.
- c. Disconnect downstream oxygen sensor connector E-555.
- d. Check wire harness between downstream oxygen sensor connector terminals and ECM connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-555 (2) - E-557 (21)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-555 (2) or E-557 (21) - Body ground	Ahueue	No postinuity
E-555 (2) or E-557 (21) - Battery positive	Always	No continuity

Replace wire harness or connector (downstream oxygen sensor - ECM)


ولین سامانه دیجیتال تعمیرکاران خودرو در ایرار





 a. Check wire harness between downstream oxygen sensor connector terminals and ECM connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-555 (1) - E-557 (43)	Always	Continuity







Check for Short

Multimeter Connection	Condition	Specified Condition
E-555 (1) or E-557 (43) - Body ground		No seed to the
E-555 (1) or E-557 (43) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (downstream oxygen sensor -ECM)

OK

06

- 6 Check downstream oxygen sensor
- a. Remove downstream oxygen sensor.
- b. Check downstream oxygen sensor for following problems.
 - Moisture enters the internal of sensor, temperature changes greatly, and probe is broken.
 - Oxygen sensor is "poisoned" (Pb, S, Br, Si, etc.).

Replace downstream oxygen sensor

OK

Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0136 00, P0137 16, P0138 17, P0140 00, P2270 00, P2271 00 still exists.


NG Replace ECM

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC P0201 13 Cylinder 1 - Injector Circuit error



DTC Code	DTC Definitions	DTC Detection Conditions	Possible Cause
P0201 13	Cylinder 1 - Injector Circuit error	Engine running	Injector of cylinder 1Wire harness or connectorECM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

• When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

شرکت دیجیتال خودرو سامانه (مسئولیت محدود

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check injector connector of cylinder 1
- a. Disconnect injector connector E-505 of cylinder 1.
- b. Check injector connector.

NG)

Repair or replace connector





3 Check injector power supply voltage of cylinder 1


- a. Disconnect injector connector E-505 of cylinder 1.
- b. Turn ignition switch to ON.
- c. Check voltage between injector connector terminal of cylinder 1 and body ground.

Multimeter Connection	Condition	Specified Condition
E-505 (1) - Body ground	Ignition switch ON	11 to 14 V

ок

06

Go to step 5




ديجيتال خودرو



- 4 Check injector power supply circuit of cylinder 1
- a. Turn ignition switch to LOCK.
- b. Check fuse EF08 and main relay.
- c. Disconnect engine compartment fuse and relay box connector E-027.
- d. Check wire harness between injector connector terminals and engine compartment fuse and relay box connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-505 (1) - E-027 (C3)	Always	Continuity



Check for Short

Multimeter Connection	Condition	Specified Condition
E-505 (1) or E-027 (C3) - Body ground	Alwaya	No continuity
E-505 (1) or E-027 (C3) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (injector of cylinder 1 - engine compartment fuse and relay box)

OK

06

5 Check injector control circuit of cylinder 1

- a. Disconnect ECM connector E-558.
- b. Check wire harness between injector connector terminals and ECM connector terminals.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-505 (2) - E-558 (68)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-505 (2) or E-558 (68) - Body ground	Always	No continuite
E-505 (2) or E-558 (68) - Battery positive		No continuity

NG

Repair or replace wire harness or connector (injector of cylinder 1 - ECM)



OK


6 Check injector of cylinder 1

a. Check resistance of injector of cylinder 1.

Multimeter Connection	Specified Condition
1 - 2	12 Ω (at 20°C)

NG >

Replace injector of cylinder 1



06



7 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0201 13 still exists.

NG


Replace ECM

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC P0271 12 Cylinder 4 - Injector Circuit High



DTC Code	DTC Definitions	DTC Detection Conditions	Possible Cause
P0271 12	Cylinder 4 - Injector Circuit High	Engine running	Injector of cylinder 4Wire harness or connectorECM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- · Select Read Code.

06

- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

شرکت دیجیتال خودرو سامانه (مسئولیت محدود

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check injector connector of cylinder 4
- a. Disconnect injector connector E-508 of cylinder 4.
- b. Check injector connector.

NG

Repair or replace connector






3 Check injector power supply voltage of cylinder 4

- a. Disconnect injector connector E-508 of cylinder 4.
- b. Turn ignition switch to ON.
- c. Check voltage between injector connector terminal of cylinder 4 and body ground.

Multimeter Connection	Condition	Specified Condition
E-508 (1) - Body ground	Ignition switch ON	11 to 14 V

ок >

Go to step 5




ديجيتاك خودرو



- 4 Check injector power supply circuit of cylinder 4
- a. Turn ignition switch to LOCK.
- b. Check fuse EF08 and main relay.
- c. Disconnect engine compartment fuse and relay box connector E-027.
- d. Check wire harness between injector connector terminals and engine compartment fuse and relay box connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-508 (1) - E-027 (C3)	Always	Continuity



Check for Short

Multimeter Connection	Condition	Specified Condition
E-508 (1) or E-027 (C3) - Body ground	Alwaya	No continuity
E-508 (1) or E-027 (C3) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (injector of cylinder 4 - engine compartment fuse and relay box)

06

ОК

5 Check injector control circuit of cylinder 4

- a. Disconnect ECM connector E-558.
- b. Check wire harness between injector connector terminals and ECM connector terminals.

Check for Open


/	Multimeter Connection	Condition	Specified Condition
(20	E-508 (2) - E-558 (74)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-508 (2) or E-558 (74) - Body ground	Ahueue	No continuity
E-508 (2) or E-558 (74) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (injector of cylinder 4 - ECM)



OK


6 Check injector of cylinder 4

a. Check resistance of injector of cylinder 4.

Multimeter Connection	Specified Condition
1 - 2	12 Ω (at 20°C)

NG

Replace injector of cylinder 4





06

- 7 Check for DTCs
- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0271 12 still exists.

NG

Replace ECM


OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

	DTC	P1102 00	Throttle limphome position self learning error	
DTC P1102		P1102 29	Throttle lower mechanic stop re-learning error	
	DTC	P1103 00	Throttle lower mechanic stop first learning error	
	DTC	P1106 00	Throttle position deviation error	
	DTC	P1106 21	Throttle PID adjustment min error	
	DTC	P1106 22	Throttle PID adjustment max error	
6	DTC	P1111 00	Return spring check max error	
	DTC	P2106 92	Throttle power stage Non-plausible error	
	DTC	P2106 12	Throttle power stage max error	
	DTC	P2106 13	Throttle power stage Signal error	
(10	DTC		Load monitoring error	
120		7		

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



	DTC Code	DTC Definitions	DTC Detection Conditions	Possible Cause
	P1102 00	Throttle limphome position self learning error		
	P1102 29	Throttle lower mechanic stop re-learning error		
	P1103 00	Throttle lower mechanic stop first learning error		
	P1106 00	Throttle position deviation error		
	P1106 21	Throttle PID adjustment min error	Ignition switch ON	 Electronic throttle Wire harness or connector
	P1106 22	Throttle PID adjustment max error		• ECM
	P1111 00	Return spring check max error		
	P2106 92	Throttle power stage Non-plausible error	" ı — ı –	- 0
	P2106 12	Throttle power stage max error	-يجي	
9	P2106 13	Throttle power stage Signal error	کت دیجیتال خود	شر — شر
	P2106 19	Load monitoring error		

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Start the engine and warm it up to normal operating temperature, and then select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

• When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG

Repair or replace ground wire harness or ground point


ОК

06

- 2 Check electronic throttle connector
- a. Disconnect electronic throttle connector E-513.
- b. Check electronic throttle connector.

NG)

Repair or replace connector



يجيتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ОК

- 3 Check throttle position sensor signal voltage
- a. Connect electronic throttle connector E-513.
- b. Turn ignition switch to ON.
- c. Using diagnostic tester, check throttle position sensor signal voltage.

Item	Condition	Standard Value (V)
Throttle position	Accelerator pedal released	0.78
sensor 1	Accelerator pedal depressed	4.29
Throttle position	Accelerator pedal released	4.22
sensor 2	Accelerator pedal depressed	0.71

Datastream name	Value	Unit	-
ambda controller output	1.00		
multiplicative correction of the mixture adaptation	1.03		4
sensor voltage from throttle potentiometer 1	0.78	V	_
sensor voltage from throttle potentiometer 2	4.22	V	→
additive correction of the mixture adaptation	0.00	%	0
Voltage PWG potentiometer 1	0.77	V	9
Voltage PWG potentiometer 2	0.38	V	_
Doubled PWG potentiometer-2 voltage	0.75	V	G

RT21060180

ок

Go to step 7

NG

Check electronic throttle actuator circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect electronic throttle connector E-513.
- c. Disconnect ECM connector E-558.
- d. Check wire harness between connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-558 (87) - E-513 (1)	Always	Continuity
E-558 (75) - E-513 (4)	Always	Continuity


Check for Short


06

	Multimeter Connection	Condition	Specified Condition
	E-558 (87) or E-513 (1) - Body ground	Always	No continuity
	E-558 (87) or E-513 (1) - Battery positive	Always	No continuity
9	E-558 (75) or E-513 (4) - Body ground	رو سامانه (می Always	ا دیجیتال خود No continuity
	E-558 (75) or E-513 (4) - Battery positive	Always	No continuity

NG

Repair or replace related wire harness





OK

5 Check throttle position sensor circuit

a. Check wire harness between connector terminals.Check for Open

Multimeter Connection	Condition	Specified Condition	
E-558 (86) - E-513 (2)	Always	Continuity	
E-558 (78) - E-513 (5)	Always	Continuity	
E-558 (107) - E-513 (3)	Always	Continuity	
E-558 (77) - E-513 (6)	Always	Continuity	

Check for Short

Multimeter Connection	Condition	Specified Condition
E-558 (86, 78, 107, 77) or E-513 (2, 5, 3, 6) - Body ground	Always	No continuity
E-558 (86, 78, 107, 77) or E-513 (2, 5, 3, 6) - Battery positive	Always	No continuity

NG

Replace wire harness or connector (electronic throttle - ECM)




WWW.DIGITALKHODRO.COM

021 62 99 92 92

6 Check electronic throttle

- a. Check electronic throttle for carbon deposits and foreign matter accumulation inside.
- b. Check if throttle valve body is stuck.
- c. Check resistance of electronic throttle.

Multimeter Connection	Condition	Specified Condition
Terminal 3 - Terminal 2	At normal temperature	1.067 kΩ
Terminal 6 - Terminal 2	Throttle valve is rotated	Resistance increases as throttle valve opens
Terminal 6 - Terminal 3		Resistance decreases as throttle valve opens
Terminal 5 - Terminal 2		Resistance decreases as throttle valve opens
Terminal 5 - Terminal 3		Resistance increases as throttle valve opens



NG

06

Clean or replace electronic throttle assembly, and go to next step



7 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P1102 00, P1102 29, P1103 00, P1106 00, P1106 21, P1106 22, P1111 00, P2106 92, P2106 12, P2106 13, P2106 19 still exists.

NG >

Replace ECM

OK


System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0300 21	Random/Multiple Cylinder Misfire Detected		
DTC	P0301 21	Cyl.1 Misfire Detected		
DTC	P0302 21	Cyl.2 Misfire Detected		
DTC	P0303 21	Cyl.3 Misfire Detected		
DTC P0304 21 Cyl.4 Misfire Detected				







DTC Code	DTC Definitions	DTC Detection Conditions	Possible Cause
P0300 21	Random/Multiple Cylinder Misfire Detected		Ignition coil
P0301 21	Cyl.1 Misfire Detected	Engine running	Spark plugWire harness or connectorECM
P0302 21	Cyl.2 Misfire Detected		
P0303 21	Cyl.3 Misfire Detected		
P0304 21	Cyl.4 Misfire Detected		

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG

Repair or replace ground wire harness or ground point


OK

2 Check ignition coil connector

- a. Turn ignition switch to LOCK.
- b. Disconnect ignition coil connector E-532.
- c. Check ignition coil connector.

NG

Repair or replace connector



06

ОК

- 3 Check spark plug of misfiring cylinder
- a. Remove the spark plug of misfiring cylinder.
- b. Check spark plug for burns, cracks or deposits.
- c. Check spark plug gap.

OK: 0.8 - 0.9 mm

NG

Clean or replace spark plug

شركت ديجيتال خودرو سامانه (مسئوليت محدود)

RT21140100

ولین سامانه دیجیتال تعمیرکاران خودرو در ایرا

OK

- 4 Check spark
- a. Connect ignition coil connector.
- b. Connect spark plug and ignition coil, and ground spark plug housing.
- c. Start and run the engine for no more than 2 seconds, and check if spark is generated.

NG Go to step 6

OK

5 Check compression of misfiring cylinder

a. Measure the compression of misfiring cylinder (See page 07-20).

NG

Check engine to confirm cause of low compression

OK

Check injectors, valve clearance, intake system and fuel pressure, etc. of misfiring cylinder

6 Check spark of misfiring cylinder with a normally functioning spark plug

06

- a. Replace the spark plug with a normally functioning one.
- b. Perform spark test.
 - Connect ignition coil connector.
 - Connect spark plug and ignition coil, and ground spark plug housing.
 - Start and run the engine for no more than 2 seconds, and check if spark is generated.


OK

Replace spark plug

NG

- 7 Check ignition coil
- a. Check resistance of primary winding of ignition coil.


Multimeter Connection	Condition	Specification (Ω)
Terminal 1 - Terminal 3	Normal temperature	0.50 - 0.64
Terminal 2 - Terminal 3	Normal temperature	0.50 - 0.64



b. Check resistance of secondary winding of ignition coil.

Multimeter Connection	Condition	Specification (kΩ)
Post 1 - Post 4	Normal temperature	9.5 - 12.1
Post 2 - Post 3	Normal temperature	9.5 - 12.1

NG Replace ignition coil





8 Check ignition coil power supply voltage


- a. Turn ignition switch to ON.
- b. Check voltage between ignition coil connector terminals and body ground.

Multimeter Connection	Condition	Specified Condition
E-532 (3) - Body ground	Ignition switch ON	11 to 14 V

06

ок

Go to step 10



ديجيتال خودرو




- 9 Check ignition coil power supply circuit
- a. Turn ignition switch to LOCK.
- b. Check fuse EF07 and main relay.
- c. Check wire harness between ignition coil connector terminals and engine compartment fuse and relay box connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-532 (3) - E-027 (C4)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-532 (3) or E-027 (C4) - Body ground	Always	No continuity
E-532 (3) or E-027 (C4) - Battery positive	Always	No continuity



NG

Replace wire harness or connector (ignition coil - engine compartment fuse and relay box)

ОК

10 Check ignition coil control circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect ECM connector E-558.
- c. Check wire harness between ignition coil connector terminals and ECM connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-532 (1) - E-558 (100)	Always	Continuity
E-532 (2) - E-558 (99)		

Check for Short

Multimeter Connection	Condition	Specified Condition
E-532 (1) or E-558 (100) - Body ground	رو سامانه (می Always	No continuity
E-532 (1) or E-558 (100) - Battery positive	Always	No continuity
E-532 (2) or E-558 (99) - Body ground	Always	No continuity
E-532 (2) or E-558 (99) - Battery positive	Always	No continuity


NG

Repair or replace wire harness or connector (ignition coil - ECM)



11 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0300 21, P0301 21, P0302 21, P0303 21 or P0304 21 still exists.





ОК

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.





DTC Code	DTC Definitions	DTC Detection Conditions	Possible Cause
P0322 00	EPM - Crankshaft signal fault	Engine running	Engine speed sensorFlywheel gear ringWire harness or connectorECM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION


 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

شرکت دیجیتال خودر و ساماندDiagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG Repair or replace ground wire harness or ground point

OK




5 Check resistance of engine speed sensor

a. Check resistance between engine speed sensor terminals 1 and 2.

Normal resistance: 860 Ω ± 20% (at normal temperature)

NG >

Replace engine speed sensor



06



6 Check engine speed sensor circuit

- a. Disconnect ECM connector E-558.
- b. Check wire harness between engine speed sensor connector terminals and ECM connector terminals.


00

Check for Open

Multimeter Connection	Condition	Specified Condition
E-522 (1) - E-558 (96)	رو سامانه (می	Continuity
E-522 (2) - E-558	Always	Continuity
(97)	الرتعم بركاران	سامانه در دیتا

Check for Short

Multimeter Connection	Condition	Specified Condition
E-522 (1) or E-558 (96) - Body ground		
E-522 (1) or E-558 (96) - Battery positive	Alorena	No continuit.
E-522 (2) or E-558 (97) - Body ground	Always	No continuity
E-522 (2) or E-558 (97) - Battery positive		



Replace wire harness or connector (engine speed sensor - ECM)

OK

- 7 Install a normal engine speed sensor and observe signal waveform
- a. Install a normal engine speed sensor.
- b. Connect engine speed sensor connector.
- c. Turn ignition switch to ON, start the engine and observe the signal waveform of the engine speed sensor with an oscilloscope.

ок

Replace engine speed sensor

06

NG

- 8 Check flywheel gear ring
- a. Turn crankshaft, and check crankshaft and flywheel gear ring for damage and foreign matter, etc. that cause signal incorrectness.

NG

Clear off debris and clean flywheel gear ring. Replace flywheel if necessary (See page 07-42)

OK

ولین سامانه دیجیتال تعمیرکاران خودرو در ایرار

9 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0322 00 still exists.

NG

Replace ECM

OK


System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0327 00	Knock Sensor 1 Circuit Low
DTC	P0328 00	Knock Sensor 1 Circuit High







DTC Code	DTC Definitions	DTC Detection Conditions	Possible Cause
P0327 00	Knock Sensor 1 Circuit Low	Engine rupping	Knock sensorWire harness or connector
P0328 00	Knock Sensor 1 Circuit High	Engine running	ECM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Start the engine and warm it up to normal operating temperature, and then select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

شرکت دیجیتال خودر و سامان Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check knock sensor connector
- a. Disconnect knock sensor connector E-516.
- b. Check knock sensor connector.

NG

Repair or replace connector





- 3 Check installation of knock sensor
- a. Remove knock sensor.
- b. Check installation area of knock sensor, and check for damage, foreign matter and excessive movement, etc. that cause signal incorrectness.

NG]

Clean installation area or replace knock sensor

OK

06

4 Check resistance of knock sensor

a. Check resistance between knock sensor terminals 1 and 2.

OK: $4.9 \pm 20\%$ M Ω (at normal temperature)

NG

Replace knock sensor

حتضتار حودا



- 5 Check knock sensor signal circuit
- a. Disconnect ECM wire harness connector E-558.
- b. Check wire harness between terminals of connector E-558 and connector E-516.

Check for Open


Multimeter Connection	Specified Condition
E-558 (90) - E-516 (1)	Continuity
E-558 (89) - E-516 (2)	Continuity

Check for Short

Multimeter Connection	Specified Condition
E-558 (90) or E-516 (1) - Body ground	No continuity
E-558 (90) or E-516 (1) - Battery positive	No continuity
E-558 (89) or E-516 (2) - Body ground	No continuity
E-558 (89) or E-516 (2) - Battery positive	No continuity

NG)

Replace wire harness or connector (knock sensor - ECM)



ОК

6 Check knock sensor signal

- a. Install knock sensor.
- b. Slightly strike around the knock sensor with a rubber hammer, and measure if voltage is generated between the 2 terminals of knock sensor with multimeter at the same time.

NG Replace knock sensor

OK

06

7 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0327 00 or P0328 00 still exists.

NG Replace ECM


OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران





ET21065012

DTC Code	DTC Definitions	DTC Detection Conditions	Possible Cause
P0341 00	EPM - Camshaft signal fault		Camshaft position sensor (intake)Camshaft position sensor (exhaust)
P0346 00	EPM - Camshaft2 signal fault	Engine running	CamshaftWire harness or connectorECM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- · Select Read Code.

06

- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

1 Check ECM ground point

، خودر و سامانه (مسئولیت محدود)

- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).


NG)

Repair or replace ground wire harness or ground point

OK

2 Check camshaft position sensor signal waveform

a. Turn ignition switch to ON, start the engine and observe the signal waveform of camshaft position sensor with an oscilloscope.



OK]

Go to step 10

NG

- 3 Check camshaft position sensor connector
- a. Turn ignition switch to LOCK.
- b. Disconnect camshaft position sensor connectors E-520 and E-526.
- c. Check camshaft position sensor connector.

NG

Repair or replace camshaft position sensor connector

OK

4 Check camshaft position sensor power supply voltage


- a. Turn ignition switch to ON.
- b. Check voltage between terminal 3 of camshaft position sensor connector E-520 or E-526 and body ground.

Multimeter Connection	Condition	Specified Condition
E-520 (3) or E-526 (3) - Body ground	Ignition switch ON	5 V

ок

06

Go to step 6



NG

5 Check camshaft position sensor power supply circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect ECM connector E-558.
 - c. Check wire harness between camshaft position sensor connector terminals and ECM connector terminals.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-520 (3) - E-558 (98)	Always	Continuity
E-526 (3) - E-558 (98)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-520 (3), E-526 (3) or E-558 (98) - Body ground	Always	No continuity
E-520 (3), E-526 (3) or E-558 (98) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (camshaft position sensor - ECM)





Replace ECM

6 Check camshaft position sensor signal circuit and ground circuit

 a. Check wire harness between camshaft position sensor connector terminals and ECM connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-520 (2) - E-558 (93)		
E-526 (2) - E-558 (105)	Always	Continuity
E-020 (1), E-526 (1) - E-558 (95)		

Check for Short


Multimeter Connection	Condition	Specified Condition		
E-520 (2) or E-558 (93) - Body ground	رو سامانه (می	ديجيتال خود	ركت	
E-520 (2) or E-558 (93) - Battery positive	ل تعميركاران	سامانه ديجيتا	ولين	
E-526 (2) or E-558 (105) - Body ground	Alwaya	No continuity		
E-526 (2) or E-558 (105) - Battery positive	Always	No continuity		

H H 00

NG)

E-520 (1), E-526 (1) or E-558 (98) -Body ground E-520 (1), E-526 (1) or E-558 (98) -Battery positive

Replace wire harness or connector (camshaft position sensor - ECM)



06

OK

7 Check installation of camshaft position sensor

- a. Remove camshaft position sensor.
- b. Check and clean camshaft position sensor and installation area, and check for damage, foreign matter and excessive movement, etc. that cause signal incorrectness.

NG

Clean installation area or replace camshaft position sensor

OK

8 Check camshaft gear ring

a. Check camshaft gear ring for damage and foreign matter (such as debris), etc. that cause signal incorrectness.

NG

06

Clear off debris and clean camshaft gear ring or replace camshaft

OK

- 9 Install a normal camshaft position sensor and observe signal waveform
- a. Install a normal camshaft position sensor.
- b. Connect camshaft position sensor connector.
 - c. Turn ignition switch to ON, start the engine and observe the signal waveform of camshaft position sensor with an oscilloscope.

OK

Replace camshaft position sensor

NG

10 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0341 00 or P0346 00 still exists.

NG Replace ECM

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0420 00	Catalyst System, Bank1 Efficiency Below Threshold

DTC Code	DTC Definitions	DTC Detection Conditions	Possible Cause
P0420 00	Catalyst System, Bank1 Efficiency Below Threshold	Engine running	 Three-way catalytic converter Leakage in exhaust system Upstream oxygen sensor Downstream oxygen sensor ECM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Start the engine and warm it up to normal operating temperature, and then select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure - Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

Diagnosis Procedure

- 1 Check for any other DTCs output (in addition to DTC P0420 00)
- a. Connect X-431 3G diagnostic tester to Data Link Connector (DLC).
- b. Turn ignition switch to ON. Start the engine and warm it up to normal operating temperature, and then select Read Code.

Display (DTC Output)	Proceed to
DTC P0420 00	A
DTC P0420 00 and other DTCs	В

B Go to DTC chart, and perform troubleshooting for other DTCs first

Α

- 2 Read datastream
- a. Read datastream using diagnostic tester.
- b. Check datastream below.

Item	OK (Idling)	If it is NG, proceed to
Upstream Oxygen Sensor Voltage	Quickly fluctuates between 0.1 to 0.9 V	Α
Downstream Oxygen Sensor Voltage	Fluctuates slightly at about 0.45 V	В
Average Injection Pulse Width	1.5 - 2.9 ms	С

A Replace upstream oxygen sensor

C Check injector, fuel pressure and other causes for abnormal injection pulse width

В

- 3 Check exhaust system
- a. Turn ignition switch to ON and start the engine.
- b. Check exhaust system for leakage.

NG Repair or replace related exhaust system components

OK

4 Check downstream oxygen sensor

NG Replace downstream oxygen sensor

OK

Replace three-way catalytic converter, and go to step 5

- 5 Check for DTCs
- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0420 00 still exists.

NG Replace ECM

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

06




اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC	P0444 13	Evaporative Emiss. System Purge Control Valve Circ. Open
DTC	P0458 16	Evaporative Emission System Purge Control Valve Circuit Low
DTC	P0459 17	Evaporative Emission System Purge Control Valve Circuit High







DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P0444 13	Evaporative Emiss. System Purge Control Valve Circ. Open		
P0458 16	Evaporative Emission System Purge Control Valve Circuit Low	Engine running	Canister solenoid valveWire harness or connectorECM
P0459 17	Evaporative Emission System Purge Control Valve Circuit High		

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Start the engine and warm it up to normal operating temperature, and then select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG


Repair or replace ground wire harness or ground point

OK

- 2 Check canister solenoid valve connector
- a. Disconnect canister solenoid valve connector E-512.
- b. Check canister solenoid valve connector.

NG)

Repair or replace connector



ОК

06


- 3 Check canister solenoid valve power supply voltage
- a. Turn ignition switch to ON.
- b. Measure voltage between canister solenoid valve connector terminal and body ground.

	Multimeter Connection	Condition	Specified Condition
	E-512 (1) - Body ground	Ignition switch ON	11 to 14 V
Ċ	بيئوليت محدر	دروسامانه (می	دىجىتا ، خود

ок

Go to step 5

ن سامانه دیجیتال تعمیرکاران خودر



NG

4 Check canister solenoid valve power supply circuit

- a. Turn ignition switch to LOCK.
- b. Check fuse EF27 and main relay.
- c. Disconnect engine compartment fuse and relay box connector E-027.
- d. Check wire harness between canister solenoid valve connector terminals and engine compartment fuse and relay box connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-512 (1) - E-027 (C9)	Always	Continuity


Check for Short


06

Multimeter Connection	Condition	Specified Condition
E-512 (1) or E-027 (C9) - Body ground	Always	No continuity
E-512 (1) or E-027 (C9) - Battery positive	Always	No continuity
سئولىت محد	ر و سامانه (می	دىجىتال خود

NG

Repair or replace wire harness or connector (canister solenoid valve - engine compartment fuse and relay box)





OK

Check canister solenoid valve control circuit


- a. Disconnect ECM connector E-558.
- b. Check wire harness between canister solenoid valve connector terminals and ECM connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-512 (2) - E-558 (90)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-512 (2) or E-558 (90) - Body ground	Aluene	No continuity
E-512 (2) or E-558 (90) - Battery positive	Always	No continuity



Repair or replace wire harness or connector (canister solenoid valve - ECM)

حیتال خودرو سامانه (مسئولیت م

OK

Check canister solenoid valve


a. Check resistance of canister solenoid valve.

Multimeter Connection	Specified Condition	
1 - 2	26 ± 4 Ω (20°C)	

b. With battery voltage applied between terminals 1 and 2, the valve should open when air is sucked into the valve. With battery voltage not applied, the valve should close when air is sucked into the valve.



Replace canister solenoid valve



OK

7 **Check for DTCs**

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0444 00, P0458 00 or P0459 00 still exists.



ОК

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.






DTC	P0480 13	Cooling Fan 1 Control Circuit error
DTC	P0481 13	Cooling Fan 2 Control Circuit error
DTC	P0691 11	Cooling Fan 1 Control Circuit Low







DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P0480 13	Cooling Fan 1 Control Circuit error		Cooling fan relay Cooling fan controller
P0481 13	Cooling Fan 2 Control Circuit error	Ignition switch ON	 Cooling fan controller Fuse
P0691 11	Cooling Fan 1 Control Circuit Low		Wire harness or connectorECM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Start the engine and warm it up to normal operating temperature, and then select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

1 Check ECM ground point

- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

شرخت دیجیتال خودر و سامانه (مسئولیت محدود)

NG >

Repair or replace ground wire harness or ground point

OK

- 2 Check cooling fan controller connector
- a. Disconnect cooling fan controller connector E-576.
- b. Check cooling fan controller connector.

NG

06

Repair or replace connector



OK

3 Check cooling fan fuse and relay


- a. Unplug cooling fan fuse and relay from engine compartment fuse and relay box.
- b. Check if fuse is normal.
- c. Check cooling fan relay.

Multimeter Connection	Specified Condition	
30 - 87	No continuity	
30 - 87	Continuity (when battery voltage is applied between terminals 85 and 86)	

NG >

Replace fuse or relay

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران



WWW.DIGITALKHODRO.COM


4 Check cooling fan relay circuit voltage

a. Check terminal voltage of cooling fan relay (engine compartment fuse and relay box side).

Multimeter Connection	Condition	Specified Condition
Terminal 87 - Body ground	Always	11 to 14 V
Terminal 85 - Body ground	Ignition switch ON	11 to 14 V
Terminal 86 - Body ground	Always	0 V

NG

Check engine compartment fuse and relay box, repair or replace wire harness or connector (fan relay - battery)



ОК

5 Check wire harness and connector


- a. Disconnect fuse and relay box connector E-093.
- b. Disconnect ECM connector E-557.
 - c. Check wire harness between fan controller connector and ECM connector, engine compartment fuse and relay box connector and body ground.

Check for Open

Multimeter Connection	Specified Condition
E-557 (56) - E-093 (F17)	Continuity
E-557 (31) - E-093 (F15)	Continuity

Check for Short

Multimeter Connection	Specified Condition
E-557 (56), E-093 (F17), E-557 (31), E-093 (F15) - Body ground	No continuity
E-557 (56), E-093 (F17), E-557 (31), E-093 (F15) - Battery positive	No continuity



Check for Open

Multimeter Connection	Specified Condition
E-576 (2) - FB08	Continuity
E-576 (3) - FB02	Continuity

Check for Short


Multimeter Connection	Specified Condition
E-576 (2/3) - Body ground	No continuity
E-576 (2/3) - Battery positive	No continuity

06



Repair or replace wire harness or connector

II II 00





Replace cooling fan controller, and go to step 6

- 6 Check for DTCs
- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
 - c. Check if DTC P0480 13, P0481 13 or P0691 11 still exists.



Replace ECM




System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0560 00	Non-plausible error of battery voltage	
DTC	P0562 16	System Voltage Low	
DTC	P0563 17	System Voltage High	







DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P0560 00	System Voltage Malfunction		FuseWire harness or connector
P0562 16	System Voltage Low	Ignition switch ON	Battery
P0563 17	System Voltage High		Battery terminalECM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- · Select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

شرکت دیجیتال خودرو سامانهDiagnosis Procedure)

- 1 Check battery _______
- a. Check if battery voltage is normal.

NG Recharge or replace battery

OK

- 2 Check battery terminals
- a. Check if battery terminals are loose or corroded.

NG Tighten or replace battery terminals

OK

WWW.DIGITALKHODRO.COM

021 62 99 92 92

- 3 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG)

Repair or replace ground wire harness or ground point

OK

- 4 Check ECM connector
- a. Disconnect ECM connector E-557 and E-558.
- b. Check ECM connector.

NG

06

Repair or replace ECM connector


OK

- 5 Check ECM power supply voltage (battery voltage)
- a. Measure voltage between ECM connector E-557 terminal and body ground.

Multimeter Connection	Condition (Qu	Specified Condition
E-557 (20) - Body ground	Always	11 to 14 V

OK

Go to step 8



NG

- 6 Check ECM fuse
- a. Unplug ECM fuse EF19 (10 A) from engine compartment fuse and relay box.
- b. Check resistance of fuse EF19.

Standard resistance: less than 1 Ω

NG

Replace ECM fuse

ОК

- 7 Check wire harness and connector (ECM engine compartment fuse and relay box)
- a. Disconnect engine compartment fuse and relay box connector E-094.
- b. Check wire harness between connector terminals.


Check for Open

Multimeter Connection	Specified Condition
E-557 (20) - E-094 (A2)	Continuity

Check for Short

Multimeter Connection	Specified Condition
E-557 (20) or E-094 (A2) - Body ground	No continuity
E-557 (20) or E-094 (A2) - Battery positive	No continuity






ОК

Repair or replace engine compartment fuse and relay box or wire harness (engine compartment fuse and relay box - battery)

Check ECM power supply voltage (ignition switch voltage)

- a. Connect engine compartment fuse and relay box connector E-094.
- b. Turn ignition switch to ON.
- c. Check voltage between terminals of ECM connector E-557.

Multimeter Connection	Condition	Specified Condition
E-557 (35) - E-558 (63) or E-557 (64)	Ignition switch ON	11 to 14 V



NG

OK

06

Go to step 12

Check ECM fuse

a. Unplug fuse EF17 (10 A) from engine compartment fuse and relay box.

1 00

b. Check resistance of fuse EF17.

Standard resistance: less than 1 Ω

Replace fuse NG

OK

10 Check wire harness and connector (ECM - engine compartment fuse and relay box)

WWW.DIGITALKHODRO.COM

021 62 99 92 92


- a. Disconnect engine compartment fuse and relay box connector E-094.
- b. Check wire harness between ECM connector terminals and engine compartment fuse and relay box connector terminals.

Check for Open

Multimeter Connection	Specified Condition
E-557 (35) - E-094 (A4)	Continuity

Check for Short

Multimeter Connection	Specified Condition
E-557 (35) or E-094 (A4) - Body ground	No continuity
E-557 (35) or E-094 (A4) - Battery positive	No continuity



06

NG

Repair or replace wire harness or connector

11 Check ignition switch assembly (See page 24-14)

OK

NG

Replace ignition switch assembly

OK

Repair or replace engine compartment fuse and relay box or wire harness (engine compartment fuse and relay box - ignition switch)

12 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0560 00, P0562 16 or P0563 17 still exists.

NG Replace ECM

OK


System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0627 13	Fuel Pump Control Circuit/Open
DTC	P0628 11	Fuel Pump Control Circuit Low
DTC	P0629 12	Fuel Pump Control Circuit High







DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P0627 13	Fuel Pump Control Circuit/Open		Fuel pump relay
P0628 11	Fuel Pump Control Circuit Low	Ignition switch ON Engine running • Wire harness or connector • ECM • Engine compartment fuse box	• ECM
P0629 12	Fuel Pump Control Circuit High		Engine compartment fuse and relay box

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- · Select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

1 Check ECM ground point

- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

شرخت دیجیتال خودر و سامانه (مسئولیت محدود)

NG >

Repair or replace ground wire harness or ground point

OK


2 Check fuel pump relay

- a. Unplug fuel pump relay from engine compartment fuse and relay box.
- b. Check fuel pump relay terminals.

Multimeter Connection	Specified Condition	
3 - 5	No continuity	
3 - 5	Continuity (when battery voltage is applied between terminals 1 and 2)	

NG

Replace fuel pump relay



OK

3 Check fuel pump relay control circuit

a. Disconnect engine compartment fuse and relay box connector E-093.

III 00

- b. Disconnect ECM connector E-557.
- c. Check wire harness between connector terminals.

Check for Open


Multimeter Connection	Specified Condition
E-557 (41) - E-093 (F6)	Continuity

Check for Short

Multimeter Connection	Specified Condition
E-557 (41) or E-093 (F6) - Body ground	No continuity
E-557 (41) or E-093 (F6) - Battery positive	No continuity

NG

Repair or replace wire harness or connector (engine compartment fuse and relay box - ECM)



OK


- 4 Check fuel pump relay terminal voltage
- a. Turn ignition switch to ON.
- b. Measure voltage between terminal of fuel pump relay and body ground.

Multimeter Connection	Condition	Specified Condition
Fuel pump relay terminal 1 (engine compartment fuse and relay box side) - Body ground	Ignition switch ON	11 to 14 V

ок

06

Go to step 6



NG

5 Check main relay and fuse EF38

NG

Replace main relay or fuse

ОК

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Repair or replace engine compartment fuse and relay box or wire harness (engine compartment fuse and relay box - battery)

- 6 Check for DTCs
- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0627 13, P0628 11 or P0629 12 still exists.

NG Replace ECM

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.


WWW.DIGITALKHODRO.COM

021 62 99 92 92

DTC	P0645 13	A/C Clutch Relay Circuit	
DTC	P0646 11	A/C Clutch Relay Control Circuit Low	
DTC P0647 12 A/C Clutch Relay Control Circuit High			







DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P0645 13	A/C Clutch Relay Circuit		A/C compressor relay
P0646 11	A/C Clutch Relay Control Circuit Low	Ignition switch ON Engine running	A/C compressor relayWire harness or connector
P0647 12	A/C Clutch Relay Control Circuit High		• ECM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Start the engine and warm it up to normal operating temperature, and then select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

1 Check ECM ground point

- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

شرخت دیجیتال خودر و سامانه (مسئولیت محدود)

NG >

Repair or replace ground wire harness or ground point

OK

2 Check A/C compressor relay


- a. Unplug A/C compressor relay from engine compartment fuse and relay box.
- b. Check A/C compressor relay terminals.

Multimeter Connection	Specified Condition
3 - 5	No continuity
3 - 5	Continuity (when battery voltage is applied between terminals 1 and 2)

06

NG

Replace A/C compressor relay



ОК


3 Check A/C compressor relay control circuit

III 00

- a. Disconnect engine compartment fuse and relay box connector E-093.
- b. Disconnect ECM connector E-557.
- c. Check wire harness between ECM connector terminals and engine compartment fuse and relay box connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-557 (42) - E-094 (F12)	Always	Continuity



Check for Short

Multimeter Connection	Condition	Specified Condition
E-557 (42) or E-094 (F12) - Body ground	Always	No continuity
E-557 (42) or E-094 (F12) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (ECM - engine compartment fuse and relay box)

OK

06

4 **Check for DTCs**

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0645 13, P0646 11 or P0647 12 still exists.

Replace ECM

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

OK


System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0688 91	Power Relay Sense Circuit Non-plausible error
DTC	P0688 92	Power Relay Sense Circuit Signal error







DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P0688 91	error Ignition switch ON		Main Relay Wire harness or connector
P0688 92			• ECM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- · Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- · Select Read Code.

06

- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

شرکت دیجیتال خودر و سامان Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG Ì

Repair or replace ground wire harness or ground point

OK

WWW.DIGITALKHODRO.COM

021 62 99 92 92


2 Check main relay and fuse

- a. Unplug main relay and fuse EF40 from engine compartment fuse and relay box.
- b. Check if fuse EF40 is normal.
- c. Check for continuity between terminals of main relay.

Multimeter Connection	Specified Condition	
30 - 87	No continuity	
30 - 87	Continuity (when battery voltage is applied between terminals 85 and 86)	

NG

Replace main relay



OK


3 Check main relay circuit voltage

a. Measure voltage between terminals of main relay (engine compartment fuse and relay box side) and body ground.

Multimeter Connection	Condition	Specified Condition
Main relay	ں تعمیرت ران	255500000000000000000000000000000000000
terminals 87 and 85 (engine compartment fuse and relay box side) - Body ground	Always	11 to 14 V

NG

Repair or replace wire harness or connector (main relay - battery)



OK

4 Check wire harness and connector (ECM - engine compartment fuse and relay box)

- a. Disconnect fuse and relay box connectors E-069 and E-094.
- b. Disconnect ECM connector E-557.
- c. Check wire harness between connector terminals.Check for Open

Multimeter Connection	Specified Condition
E-557 (5) - E-093 (F23)	Continuity

Check for Short

06


Multimeter Connection

E-557 (5) or E-093 (F23) Body ground

E-557 (5) or E-094 (F23) Battery positive

Specified Condition

No continuity



Check for Open


	Multimeter Connection	Specified Condition
	E-557 (15) - E-094 (A6)	Continuity
0	E-557 (16) - E-076 (A6) U 9 J	Continuity

II III 00

Check for Short

Multimeter Connection	Specified Condition
E-557 (15, 16) or E-094 (A6) - Body ground	No continuity
E-557 (15, 16) or E-094 (A6) - Battery positive	No continuity





ОК

5 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0688 91, P0688 92 still exists.





System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.





DTC	P0604 43	Internal contr.module RAM error
DTC	P0605 43	Internal contr.module ROM error

DTC P0606 00 Safety monitoring fuel cutoff error

DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P0604 43	Internal contr.module RAM error		
P0605 43	Internal contr.module ROM error	Ignition switch ON	Wire harness or connectorECM
P0606 00	Safety monitoring fuel cutoff error		

06

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
 - If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

• When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG Repair or replace ground wire harness or ground point

OK

- 2 Check ECM connector
- a. Disconnect ECM connector E-557 and E-558.
- b. Check if connector is normal.

NG Repair or replace connector

OK

Replace ECM





DTC	P1619 00	ECM Not Programmed (Virgin State)

DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P1619 00	ECM Not Programmed (Virgin State)	Ignition switch ON	Wire harness or connectorECM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- · Select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

شركت ديجيتال خودرو سامانا

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG >

Repair or replace ground wire harness or ground point

OK

- 2 Check ECM connector
- a. Disconnect ECM connector E-557 and E-558.
- b. Check if connector is normal.

NG

Repair or replace connector

OK

- 3 Use X-431 3G diagnostic tester to match ECM (See page 67-3), and check for DTCs
- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P1619 00 still exists.

NG Replace ECM

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

06



اولین سامانه دیجیتال تعمیرگاران خودر و در ایران



DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
U0101 87	Lost Communication With TCM (CVT only)	Ignition switch ON Engine running	CAN line or connectorECMTCM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG

Repair or replace ground wire harness or ground point

ОК

- 2 Check ECM connector and TCM connector
- a. Disconnect ECM connector E-557.
- b. Disconnect TCU connector E-556.
- c. Check if connectors are normal.

NG >

Repair or replace connector

OK

3 Check CAN line


a. Check CAN line.

Check for Open

Multimeter Connection	Specified Condition
E-557 (1) - E-556 (41)	Continuity
E-557 (17) - E-556 (42)	Continuity

Check for Short

Multimeter Connection	Specified Condition
E-557 (1) or E-556 (41) - Body ground	No continuity
E-557 (1) or E-556 (41) - Battery positive	No continuity
E-557 (17) or E-556 (42) - Body ground	No continuity
E-557 (17) or E-556 (42)- Battery positive	No continuity



NG

Repair or replace CAN line

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

OK


- Replace ECM, and check for DTCs
- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC U0101 87 still exists.

NG Replace TCU

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.



DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
U0129 87	Lost Communication With Brake System Control Module	Ignition switch ON Engine running	CAN line or connectorECMABS

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Start the engine and warm it up to normal operating temperature, and then select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

© CAUTION

06

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG

Repair or replace ground wire harness or ground point

OK

- 2 Check ECM connector and ABS connector
- a. Disconnect ECM connector E-050.
- b. Disconnect ABS connector E-053.
- c. Check if connectors are normal.

NG

Repair or replace connector

OK

3 Check CAN line


a. Check CAN line.

Check for Open

Multimeter Connection	Specified Condition
E-557 (1) - E-053 (26)	Continuity
E-557 (17) - E-053 (14)	Continuity

Check for Short

Multimeter Connection	Specified Condition
E-557 (1) or E-053 (26) - Body ground	No continuity
E-557 (1) or E-053 (26) - Battery positive	No continuity
E-557 (17) or E-053 (14) - Body ground	No continuity
E-557 (17) or E-053 (14) - Battery positive	No continuity



NG

Repair or replace CAN line

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

OK

- Replace ECM, and check for DTCs
- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC U0129 87 still exists.

NG Replace ABS control module

ок

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
U0140 87	Lost Communication with Body Control Module (BCM)	Ignition switch ON Engine running	CAN line or connectorECMBCM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Start the engine and warm it up to normal operating temperature, and then select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG

Repair or replace ground wire harness or ground point

OK

- 2 Check ECM connector and BCM connector
- a. Disconnect ECM connector E-557.
- b. Disconnect BCM connector I-006.
- c. Check if connectors are normal.

NG

Repair or replace connectors

OK

3 Check CAN line

a. Check CAN line.

Check for Open

Multimeter Connection	Specified Condition
E-557 (1) - I-006 (A15)	Continuity
E-557 (17) - I-006 (A14)	Continuity

Check for Short

Multimeter Connection	Specified Condition
E-557 (1) or I-006 (A15) - Body ground	No continuity
E-557 (1) or I-006 (A15) - Battery positive	No continuity
E-557 (17) or I-006 (A14) - Body ground	No continuity
E-557 (17) or I-006 (A14) - Battery positive	No continuity

NG

Repair or replace CAN line

OK

4 Replace ECM, and check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC U0140 87 still exists.


NG Replace BCM

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

Lost Communication With Instrument Panel Cluster U0155 87 **DTC** (IPC) Control Module



DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
U0155 87	Lost Communication With Instrument Panel Cluster (IPC) Control Module	Ignition switch ON Engine running	CAN line or connectorECMICMBCM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- · Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
 - Start the engine and warm it up to normal operating temperature, and then select Read Code.
 - If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
 - If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure شرکت دیجیتال خودر و سامانه (مسئولیت محدود

1 Check ECM ground point

- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG

Repair or replace ground wire harness or ground point

OK

- 2 Check ECM connector, instrument cluster connector and BCM connector
- a. Disconnect ECM connector E-557.
- b. Disconnect instrument cluster connector I-009.
- c. Disconnect BCM connector I-006.
- d. Check if connectors are normal.

NG

Repair or replace connectors

OK

WWW.DIGITALKHODRO.COM

021 62 99 92 92

3 Check CAN line (ECM - BCM)

a. Check CAN line.

Check for Open

Multimeter Connection	Specified Condition
E-557 (1) - I-006 (A15)	Continuity
E-557 (17) - I-006 (A14)	Continuity

Check for Short

Multimeter Connection	Specified Condition
E-557 (1) or I-006 (A15) - Body ground	No continuity
E-557 (1) or I-006 (A15) - Battery positive	No continuity
E-557 (17) or I-006 (A14) - Body ground	No continuity
E-557 (17) or I-006 (A14) - Battery positive	No continuity

NG >

Repair or replace CAN line

امل نسامانه در مرتال تصم کابل خود می

OK

4 Check CAN line (BCM - ICM)

a. Check CAN line.

Check for Open

Multimeter Connection	Specified Condition
I-009 (30) - I-005 (A31)	Continuity
I-009 (29) - I-005 (A30)	Continuity

Check for Short

Multimeter Connection	Specified Condition
I-009 (30) or I-006 (A31) - Body ground	No continuity
I-009 (30) or I-006 (A31) - Battery positive	No continuity
I-009 (29) or I-006 (A30) - Body ground	No continuity
I-009 (29) or I-006 (A30) - Battery positive	No continuity

NG

Repair or replace CAN line

OK

5 Replace ECM, and check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC U0155 87 still exists.

NG Check or replace BCM and ICM

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
U0164 87	Lost Communication with HCU	Ignition switch ON Engine running	 CAN line or connector ECM CLM (A/C control module) BCM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- · Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
 - Start the engine and warm it up to normal operating temperature, and then select Read Code.
 - If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
 - If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure شرکت دیجیتال خودر و سامانه (مسئولیت محدود

1 Check ECM ground point

- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG

Repair or replace ground wire harness or ground point

OK

- 2 Check ECM connector, A/C control panel connector and BCM connector
- a. Disconnect ECM connector E-557.
- b. Disconnect A/C control panel connector K-008.
- c. Disconnect BCM connector I-006.
- d. Check if connectors are normal.

NG

Repair or replace connectors

OK

WWW.DIGITALKHODRO.COM

021 62 99 92 92

3 Check CAN line (ECM - BCM)


a. Check CAN line.

Check for Open

Multimeter Connection	Specified Condition
E-557 (1) - I-006 (A15)	Continuity
E-557 (17) - I-006 (A14)	Continuity

Check for Short

Multimeter Connection	Specified Condition
E-557 (1) or I-006 (A15) - Body ground	No continuity
E-557 (1) or I-006 (A15) - Battery positive	No continuity
E-557 (17) or I-006 (A14) - Body ground	No continuity
E-557 (17) or I-006 (A14) - Battery positive	No continuity



NG Repair of

Repair or replace CAN line

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

ОК

4 Check CAN line (BCM - A/C control panel)

a. Check CAN line.

Check for Open

Multimeter Connection	Specified Condition
K-008 (13) - I-006 (A31)	Continuity
K-008 (14) - I-006 (A30)	Continuity

Check for Short

Multimeter Connection	Specified Condition
K-008 (13) or I-006 (A31) - Body ground	No continuity
K-008 (13) or I-006 (A31) - Battery positive	No continuity
K-008 (14) or I-006 (A30) - Body ground	No continuity
K-008 (14) or I-006 (A30) - Battery positive	No continuity

NG

06

Repair or replace CAN line

OK

5 Replace ECM, and check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC U0164 87 still exists.

NG Check or replace BCM and A/C control panel

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

WWW.DIGITALKHODRO.COM

DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
U0140 00	Lost Communication With Body Control	Ignition switch ON	CAN line or connector ECM
	Module (Immo)		Engine immobilizer module

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- · Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Select Read Code.

06

- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG]

Repair or replace ground wire harness or ground point

OK

- 2 Check ECM connector and engine immobilizer module connector
- a. Disconnect ECM connector E-557.
- b. Disconnect engine immobilizer module connector I-047.
- c. Check if connectors are normal.

NG

Repair or replace connectors


- 3 Check CAN line (ECM engine immobilizer module)
- a. Check CAN line.

Check for Open

Multimeter Connection	Specified Condition
E-557 (1) - I-047 (8)	Continuity
E-557 (17) - I-047 (6)	Continuity

Check for Short

Multimeter Connection	Specified Condition
E-557 (1) or I-047 (8) - Body ground	No continuity
E-557 (1) or I-047 (8) - Battery positive	No continuity
E-557 (17) or I-047 (6) - Body ground	No continuity
E-557 (17) or I-047 (6) - Battery positive	No continuity



NG

Repair or replace CAN line

ОК

- 4 Replace ECM, and check for DTCs
- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC U0140 00 still exists.

NG

Replace engine immobilizer module



System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P000A 00	Camshaft control Slow Response (inlet)

DTC | P000B 00 | Camshaft control Slow Response (outlet)

DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P000A 00	Camshaft control Slow Response (inlet)	Ignition switch ON	Camshaft phaserVVT control valve
P000B 00	Camshaft control Slow Response (outlet)	Engine running	Wire harness or connectorECM

06

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Start the engine and warm it up to normal operating temperature, and then select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

ولین سامانه دیجیتال تعمیرکاران خودرو در ایرار

Diagnosis Procedure

1 Check ECM ground point


- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG

Repair or replace ground wire harness or ground point

ΟK


- 2 Check VVT control valve connector
- a. Disconnect intake VVT control valve connector E-510.



- b. Disconnect exhaust VVT control valve connector E-501.
- c. Check VVT control valve connectors.

NG

Repair or replace connector



جيتالـخودرو

OK

06

- 3 Check intake/exhaust camshaft phaser
- a. Check if intake/exhaust camshaft phaser is blocked or stuck.

NG

Replace intake/exhaust camshaft phaser

شرکت دیجیتال خود و سامانه (مسئولیت




- 4 Check intake/exhaust VVT control valve
- a. Turn ignition switch to LOCK.
- b. Remove intake/exhaust VVT control valves.
- c. Check intake/exhaust VVT control valves.

Multimeter Connection	Specified Condition
Terminal 1 - Terminal 2	8 Ω

d. When battery voltage is applied between terminals 1 and 2, control valve should move quickly.



Replace intake/exhaust VVT control valve



WWW.DIGITALKHODRO.COM

ОК

- 5 Check for DTCs
- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P000A 00 or P000B 00 still exists.

NG >

Replace ECM

OK

06

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.




اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC	P0010 13	Control Circuit of camshaft control valve (inlet)	
DTC	P0013 13	Control Circuit of camshaft control valve (outlet)	







DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P0010 13	Control Circuit of camshaft control valve (inlet)	Ignition switch ON	VVT control valve Wise berroes or connector
P0013 13	Control Circuit of camshaft control valve (outlet)	Engine running	Wire harness or connectorECM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Start the engine and warm it up to normal operating temperature, and then select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

شرکت دیجیتال خودرو سامانه (مسئولیت محد Diagnosis Procedure


- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG >

Repair or replace ground wire harness or ground point

OK

- 2 Check VVT control valve connector
- a. Disconnect intake VVT control valve connector E-510.




- b. Disconnect exhaust VVT control valve connector E-501.
- c. Check VVT control valve connectors.

NG)

3

Repair or replace connector



ОК

06


Check VVT control valve power supply voltage

- a. Turn ignition switch to ON.
- b. Check voltage between connector terminals and body ground.

Multimeter Connection	Condition	Specified Condition	
E-510 (1) - Body ground	Lawities autitals ON	11 to 14 V	
E-501 (1) - Body ground	Ignition switch ON	11 to 14 V	

OK Go to step 5

ن سامانه دیجیتال تعمیرکاران خودرو در ایران



NG

RT21065070

4 Check VVT control valve power supply circuit and fuse EF08

- a. Turn ignition switch to LOCK.
- b. Check if fuse EF08 is normal.
- c. Disconnect engine compartment fuse and relay box connector E-027.
- d. Check wire harness between connector terminals.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-510 (1) - E-027 (C3)	Alwaya	Continuity
E-501 (1) - E-027 (C3)	Always	Continuity




Multimeter Connection	Condition	Specified Condition
E-510 (1), E-501 (1) or E-027 (C3) - Body ground	Always	No continuity
E-510 (1), E-501 (1) or E-027 (C3) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (VVT control valve - engine compartment fuse and relay box)



06



5 Check VVT control valve control circuit

- a. Disconnect ECM connector E-558.
- b. Check wire harness between connector terminals.Check for Open

Multimeter Connection	Condition	Specified Condition
E-510 (2) - E-558 (71)	Alwaya	Continuity
E-501 (2) - E-558 (69)	Always	Continuity

d n

06

Check for Short

Multimeter Connection	Condition	Specified Condition
E-510 (2) or E-558 (71) - Body ground	Always	No continuity
E-510 (2) or E-558 (71) - Battery positive	Always	No continuity
E-501 (2) or E-558 (69) - Body ground	Always	No continuity
E-501 (2) or E-558 (69) - Battery positive	Always	No continuity

E-510 E-501

101 102 103 104 105 106 107 108 109 110 111 112 89 90 91 92 93 94 95 96 97 98 99 100 77 78 79 80 81 82 83 84 85 86 87 88

65 66 67 68 69 70 71 72 73 74 75 76

(E-558)

NG

Repair or replace wire harness or connector (VVT control valve - ECM)



RT21065072

6 Check intake/exhaust VVT control valve


- a. Remove intake/exhaust VVT control valves.
- b. Check intake/exhaust VVT control valves.

Multimeter Connection	Specified Condition
Terminal 1 - Terminal 2	8 Ω

c. When battery voltage is applied between terminals 1 and 2, control valve should move quickly.



Replace intake/exhaust VVT control valve



7 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0010 13 or P0013 13 still exists.

NG Replace ECM

OK

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

06



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



DTC	P0012 00	Inlet camshaft not in locking position during start
-----	----------	---

DTC | P0015 00 | Outlet camshaft not in locking position during start

DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P0012 00	Inlet camshaft not in locking position during start	Ignition switch ON	Camshaft phaserWire harness or connectorECM
P0015 00	Outlet camshaft not in locking position during start	Engine running	

06

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- Start the engine and warm it up to normal operating temperature, and then select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

 When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure


- 1 Check ECM ground point
- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).

NG)

Repair or replace ground wire harness or ground point

2 Check VVT control valve connector


a. Disconnect intake VVT control valve connector E-510.



- b. Disconnect exhaust VVT control valve connector E-501.
- c. Check VVT control valve connectors.

NG)

Repair or replace connector



يجيتال خودرو

OK

06

- 3 Check intake/exhaust camshaft phaser
- a. Check if intake/exhaust camshaft phaser is blocked or stuck.

NG

Replace intake/exhaust camshaft phaser

شرکت دیجیتال خودرو سامانه (مسئولیت مح



- 4 Check for DTCs
- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0012 00 or P0015 00 still exists.

NG Replace ECM

OK


System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

DTC	P0016 29	Npl error for alignment between camshaft (inlet) and crankshaft
DTC	P0018 29	Npl error for alignment between camshaft (outlet) and crankshaft







DTC Code	DTC Definition	DTC Detection Condition	Possible Cause
P0016 29	Npl error for alignment between camshaft (inlet) and crankshaft	Ignition switch ON	Camshaft position sensorCrankshaft position sensorWire harness or connector
P0018 29	Npl error for alignment between camshaft (outlet) and crankshaft	Engine running	Flywheel gear ringCamshaft gear ringECM

DTC Confirmation Procedure

Confirm that battery voltage is over 12 V before performing the following procedures.

- Turn ignition switch to LOCK.
- Connect X-431 3G diagnostic tester (the latest software) to Data Link Connector (DLC).
- Turn ignition switch to ON.
- Use X-431 3G diagnostic tester to record and clear the DTCs stored in the ECM.
- · Select Read Code.
- If the DTC is detected, the malfunction indicated by the DTC is current. Go to the diagnosis procedure Step 1.
- If DTC is not detected, the malfunction indicated by the DTC is intermittent (See page 06-20).

CAUTION

When performing circuit diagnosis and test, always refer to the circuit diagram for specific circuit and component information.

Diagnosis Procedure

1 Check ECM ground point

جیتال حودر و سامانه (مسئولیت محدود<u>)</u>

- a. Turn ignition switch to LOCK.
- b. Check ECM grounds E-049 and E-050 (See page 06-20).


NG >

Repair or replace ground wire harness or ground point

OK

2 Check camshaft position sensor signal waveform

a. Turn ignition switch to ON, start the engine and observe the signal waveform of camshaft position sensor with an oscilloscope.



ок

Go to step 8


NG

3 Check camshaft position sensor connector

- a. Disconnect intake camshaft position sensor connector E-520 (1).
- b. Disconnect exhaust camshaft position sensor connector E-526 (2).
 - c. Check camshaft position sensor connectors.

NG

Repair or replace connector



4 Check camshaft position sensor power supply voltage


- a. Turn ignition switch to ON.
- b. Check voltage between terminal 3 of camshaft position sensor connector E-520 or E-526 and body ground.

Multimeter Connection	Condition	Specified Condition
E-520 (3) or E-526 (3) - Body ground	Ignition switch ON	5 V

ок

06

Go to step 6



NG

5 Check camshaft position sensor power supply circuit

- a. Turn ignition switch to LOCK.
- b. Disconnect ECM connector E-558.
 - c. Check wire harness between camshaft position sensor connector terminals and ECM connector terminals.

Check for Open


Multimeter Connection	Condition	Specified Condition
E-520 (3) - E-558 (98)	Always	Continuity
E-526 (3) - E-558 (98)	Always	Continuity

Check for Short

Multimeter Connection	Condition	Specified Condition
E-520 (3), E-015 (3) or E-558 (98) - Body ground	Always	No continuity
E-520 (3), E-015 (3) or E-558 (98) - Battery positive	Always	No continuity

NG

Repair or replace wire harness or connector (camshaft position sensor - ECM)





Replace ECM

6 Check camshaft position sensor signal circuit and ground circuit

a. Check wire harness between camshaft position sensor connector terminals and ECM connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-520 (2) - E-558 (93)		
E-526 (2) - E-558 (105)	Always	Continuity
E-520 (1), E-526 (1) - E-558 (95)		

Check for Short

E-526 (2) or E-558 (105) -Battery positive E-520 (1), E-526 (1) or E-558 (105) - Body ground E-520 (1), E-526 (1) or E-558 (105) - Battery positive

0			
Multimeter Connection	Condition	Specified Condition	
E-520 (2) or E-558 (93) - Body ground	رو سامانه (می	•• • •• ديجيتال خود	ىركت
E-520 (2) or E-558 (93) - Battery positive	ل تعميركاران	سامانه ديجيتا	ولين
E-526 (2) or E-558 (105) - Body ground			

No continuity

Always

NG

Replace wire harness or connector (camshaft position sensor - ECM)

OK

7 Check camshaft position sensor

- a. Remove camshaft position sensor.
- b. Check and clean camshaft position sensor and installation area, and check for damage, foreign matter and excessive movement, etc. that cause signal incorrectness.

NG

Clean installation area or replace camshaft position sensor

ОК

Replace ECM

06

- 8 Check engine speed sensor signal waveform
- a. Turn ignition switch to ON, start the engine and observe the signal waveform of engine speed sensor with an oscilloscope.



OK

Go to step 15

NG

- 9 Check engine speed sensor connector
- a. Turn ignition switch to LOCK.
- b. Disconnect engine speed sensor connector E-522.
- c. Check engine speed sensor connector.

NG Repair or replace engine speed sensor connector

10 Check installation of engine speed sensor

- a. Remove engine speed sensor.
- b. Check and clean engine speed sensor and installation area, and check for damage, foreign matter or excessive movement, etc. that cause signal incorrectness.

NG)

Clean or replace engine speed sensor




11 Check resistance of engine speed sensor

a. Check resistance between engine speed sensor terminals 1 and 2.

Normal resistance: 860 Ω ± 20% (at normal temperature)

NG)

Replace engine speed sensor



يجيتالـخودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

12 Check engine speed sensor circuit

- a. Disconnect ECM connector E-558.
- b. Check wire harness between engine speed sensor connector terminals and ECM connector terminals.

Check for Open

Multimeter Connection	Condition	Specified Condition
E-522 (1) - E-558 (96)	Always	Continuity
E-522 (2) - E-558 (97)		Continuity

06

Check for Short

	Multimeter Connection	Condition	Specified Condition	
	E-522 (1) or E-558 (96) - Body ground			
	E-522 (1) or E-558 (96) - Battery positive			
9	E-522 (2) or E-558 (97) - Body ground	Always رو سامانه (می	No continuity دیجیتال خود	— شرکت
	E-522 (2) or E-558 (97) - Battery positive	ل تعميركاران	سامانه ديجيتا	اولین

NG

Replace wire harness or connector (engine speed sensor - ECM)

OK

13 Check crankshaft and flywheel gear ring

a. Rotate crankshaft, and check crankshaft and flywheel gear ring for damage, foreign matter, etc. that cause signal incorrectness.

NG

Clear off debris and clean flywheel gear ring. Replace flywheel if necessary (See page 07-42).

14 Check engine timing

a. Check for timing deviation.

NG Correct engine timing

ОК

15 Check for DTCs

- a. Use X-431 3G diagnostic tester to read the ECM DTC.
- b. Refer to "DTC Confirmation Procedure".
- c. Check if DTC P0016 29 or P0018 29 still exists.

NG Replace ECM

OK

06

System is operating normally.

Reassemble vehicle and perform a road test to confirm that malfunction reported by customer has been repaired.

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Engine Problem Symptom Diagnosis

Perform primary inspection first before performing malfunction diagnosis procedures:

- 1. Confirm that engine malfunction indicator operates normally;
- 2. Using diagnostic tester, check that no error messages are recorded;
- Confirm that malfunction complained by customer is present, and confirm the condition under which the malfunction occurs.

Then, perform appearance inspection:

- 1. Check fuel line for leakage;
- 2. Check if vacuum line is broken or twisted, and if connection is correct;
- 3. Check intake line for blockage, air leakage, crush or damage;
- 4. Check if high-voltage cable of ignition system is broken or deteriorated, and if ignition sequence is correct;
- 5. Check if wire harness ground points are clean and secure;
- 6. Check each sensor or actuator connector for looseness or poor contact.

HINT:

If above conditions exist, repair the trouble areas first. Otherwise, it will affect the repair work for the following trouble diagnosis.

Diagnostic Help

- 1. Confirm that there are no trouble records for engine;
- 2. Confirm that complained trouble symptoms are present;
- 3. There are no abnormal conditions after performing the inspection according to above procedures;
- 4. During servicing, do not ignore vehicle maintenance condition, cylinder pressure, mechanical ignition timing and fuel condition, etc. that can affect the system;
- 5. Replace ECM, and perform a test. If the trouble can be eliminated, the trouble area is in ECM; if the trouble symptom still exists, reuse the original ECM, repeat the procedures, and perform service again.

Problem Symptoms Table

یتال تعمیر Symptomو درو در ایرار	Suspected Area	See page
	Battery	
Engine does not crank or cranks slowly	Starter motor	06-213
while starting	Wire harness or ignition switch	00-213
	Engine mechanical	
	No fuel in tank	
	Fuel pump	
Engine cranks normally but cannot startsuccessfully while starting	Engine speed sensor	06-215
	Ignition coil	
	Engine mechanical	
	Water in fuel	
	Fuel pump	
Difficult to start with hot engine	Coolant temperature sensor	06-217
	Fuel pressure regulator	
	Ignition coil	

Symptom	Suspected Area	See page
	Water in fuel	
	Fuel pump	
	Coolant temperature sensor	
Difficult to start with cold engine	Injector	06-219
	Ignition coil	
	Throttle	
	Engine mechanical	
	Water in fuel	
	Fuel pump	
	Coolant temperature sensor	
	Injector	
Engine speed is normal, but it is difficult to	Ignition coil	00.004
start at anytime	Throttle	06-221
	Intake pipe	
	Ignition timing	
	Spark plug	
	Engine mechanical	2
	Water in fuel	
ودرو سامانه (مسئولیت محدود	Injector	
	Spark plug	
Engine starts normally, but idles roughly at anytime	Throttle	06-224
Carryunics 97000 City English City	Intake pipe	
	Ignition timing	
	Engine mechanical	
	Water in fuel	
	Coolant temperature sensor	
Engine starts normally, but idles roughly	Spark plug	00.000
during warming up	Throttle	06-226
	Intake pipe	
	Engine mechanical	
	Water in fuel	
	Coolant temperature sensor	
Engine starts normally, but idles roughly	Spark plug	06.000
after warming up	Throttle body	06-228
	Intake pipe	
	Engine mechanical	

Symptom	Suspected Area	See page
Engine starts normally, but idles roughly or	Air conditioning system	
stalls with part load (for example, A/C is ON)	Injector	06-230
	Throttle	
Engine starts normally, but idle speed is too	Vacuum pipe	06.222
high	Coolant temperature sensor	06-232
	Ignition timing	
	Water in fuel	
	Air flow meter and throttle position sensor	
	Spark plug	
Low engine speed or stalls when	Throttle	06-234
accelerating	Intake pipe	00-234
	Injector	
	Ignition timing	
	Exhaust pipe	
	Water in fuel	
	Air flow meter and throttle position sensor	0
	Spark plug	2
Slow response when accelerating	Throttle inlet pipe	06-237
غودرو سامانه (مسئولیت محدو	Injector شرکت دید	
	Ignition timing	
ئیتال تعمیرکاران خودرو در ایران	Exhaust pipe	
	Water in fuel	
	Air flow meter and throttle position sensor	
	Spark plug	
	Ignition coil	
Lack of power and poor performance when accelerating	Throttle	06-240
	Intake pipe	
	Injector	
	Ignition timing	
	Exhaust pipe	

Engine does not crank or cranks slowly while starting **Diagnosis Procedure** Check voltage between two battery posts when engine starts OK: Voltage is 8 to 12 V. Replace battery NG OK 06 2 Check voltage of positive post of starter motor a. The ignition switch remains in START position and check voltage of positive post of starter motor. OK: Voltage is 8 to 12 V. Repair or replace wire harness NG OK Check operation of starter motor شرکت دیجیتال خودر و سامانه.a. Remove starter motor b. Check if there is an open circuit or if it is stuck due to poor lubrication. Repair or replace starter OK Check engine lubricant and gear oil a. If malfunction only occurs in winter, Check if starter motor resistance is too strong because of improper engine lubricant and gear oil selection. Replace lubricant with appropriate NG number OK 5 Check engine internal mechanical resistance a. Check if engine internal mechanical resistance is too strong, causing starter motor not to run or run slowly. Check and repair engine internal NG resistance



Go to Diagnostic Help



Engine cranks normally but cannot start successfully while starting

Diagnosis Procedure

1 Check fuel pressure

a. Using a fuel pressure gauge, check fuel pressure (See page 10-11).

Standard Fuel Pressure

Condition	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key LOCK	400

06

NG)

Repair or replace fuel system

OK

- 2 Using diagnostic tester, observe if any speed signal is output
- a. Connect diagnostic tester, start the engine and select Read Datastream.
- b. Observe if any speed signal is output.

NG

Check and repair crankshaft position sensor wire harness

ولین سامانه دیجیتال تعمیرکاران خودرو در ایرا

OK

- 3 Check spark
- a. Remove ignition coil and spark plug of one cylinder, and ground spark plug housing. Start the engine, and check if spark is generated.

OK: Spark is generated.

NG)

Check and repair ignition system

OK

- 4 Check pressure of cylinder
- a. Measure compression of misfiring cylinder (See page 07-20).

NG)

Check engine to confirm cause of low compression


5 Check ECM power supply and ground

- a. Disconnect ECM connector E-557.
- b. Turn ignition switch to ON and check ECM connector terminals.

Multimeter Connection	Condition	Specified Condition
E-557 (35, 20) - E-557 (63 or 64)	Ignition switch ON	11 to 14 V

NG

Repair or replace related wire harness



OK

Go to Diagnostic Help

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

00

ولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Difficult to start with hot engine

Diagnosis Procedure

1 Check fuel pressure

a. Using a fuel pressure gauge, check fuel pressure (See page 10-11).

Standard Fuel Pressure

Condition	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key LOCK	400

06

NG

Repair or replace fuel system

OK

2 Check spark

a. Remove ignition coil and spark plug of one cylinder, and ground spark plug housing. Start the engine, and check if spark is generated.

OK: Spark is generated.

NG

Check and repair ignition system

ولین سامانه دیجیتال تعمیرکاران خودرو در ایرار

1 00

OK

Disconnect coolant temperature sensor connector, start engine and observe if engine starts successfully at this time

OK

Check and repair wire harness or replace sensor

NG

4 Check fuel pressure regulator

NG

Replace fuel pressure regulator

OK

5 Check fuel condition

a. Observe if trouble occurs just after fuel is filled.

NG Replace fuel

ОК

6 Check ECM power supply and ground

- a. Disconnect ECM connector E-557.
- b. Turn ignition switch to ON and check ECM connector terminals.

Multimeter Connection	Condition	Specified Condition	
E-557 (35, 20) - E-557 (63 or 64)	Ignition switch ON	11 to 14 V	

NG >

06

Repair or replace related wire harness

بجيبالحوداه

، دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودر و در ایران

495051525354556575859606162.63.64 3333455393738394041424344.65.647148 17.68192021222324252627282980.311.32 11.2.3.445.67.8.91011121314.155.16

ОК

Go to Diagnostic Help

Difficult to start with cold engine

Diagnosis Procedure

- 1 Check fuel pressure
- a. Using a fuel pressure gauge, check fuel pressure (See page 10-11).

Standard Fuel Pressure

Condition	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key LOCK	400

06

NG]

Repair or replace fuel system

OK

- 2 Check spark
- a. Remove ignition coil and spark plug of one cylinder, and ground spark plug housing. Start the engine, and check if spark is generated.

OK: Spark is generated.

NG

Check and repair ignition system

ولین سامانه دیجیتال تعمیرکاران خودرو در ایرار

1 00

OK

Disconnect coolant temperature sensor connector, start engine and observe if engine starts successfully at this time

OK

Check and repair wire harness or replace sensor

NG

4 Depress accelerator pedal slightly, and observe if it is easy to start

ОК

Clean throttle

NG

5 Check injector for leakage or blockage NG Clean or replace injector **OK** 6 **Check fuel condition** a. Observe if trouble occurs just after fuel is filled. Replace fuel NG 06 OK 7 Check pressure of cylinder a. Measure compression of misfiring cylinder (See page 07-20). Check engine to confirm cause of low compression OK Check ECM power supply and ground a. Disconnect ECM connector E-557. b. Turn ignition switch to ON and check ECM connector terminals. Multimeter **Specified** Condition Condition Connection E-557 (35, 20) -Ignition switch ON 11 to 14 V E-557 (63 or 64) 4950515253545556575859606162 63 64 NG Repair or replace related wire harness 33 34 35 36 37 38 39 40 41 42 43 44 45 6 47 48 17 (8 19 20 21 22 23 24 25 26 27 28 29 30 31 32 1234567891011121314 15 16 (E-557) RT21065069 **OK** Go to Diagnostic Help

Engine speed is normal, but it is difficult to start at anytime

Diagnosis Procedure

1 Check air filter for blockage, and intake pipe for air leakage

NG

Check and repair intake system

OK

06

2 Check fuel pressure

a. Using a fuel pressure gauge, check fuel pressure (See page 10-11).

Standard Fuel Pressure

Condition	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key LOCK	400

NG

Repair or replace fuel system

OK

ولین سامانه دیجیتال تعمیر Check spark plug

شرکت دیچیتال خودرو سامانه (مسئولیت محدود)

a. Check spark plug of each cylinder, and observe if the type and gap are as specified.

NG Replace spark plug

OK

4 Check spark

a. Remove ignition coil and spark plug of one cylinder, and ground spark plug housing. Start the engine, and check if spark is generated.

OK: Spark is generated.

NG Check and repair ignition system

OK

5	Disconnect coolant temperature sensor connector, start engine and observ successfully at this time	e if engine starts
ОК	Check and repair wire harness or replace sensor	
		NG
6	Depress accelerator pedal slightly, and observe if it is easy to start	
ОК	Clean throttle	
		NG
7	Check injector for leakage or blockage	
NG	Clean or replace injector	
	م درستال خور	ОК
8	Check fuel condition	
a. Obse	erve if trouble occurs just after fuel is filled.	
NG	Replace fuel	ОК
9	Check pressure of cylinder	
a. Meas	sure compression of misfiring cylinder (See page 07-20).	
NG	Check engine to confirm cause of low compression	
		ОК
10	Check engine ignition sequence and ignition timing	
a. Chec	k if engine ignition sequence and ignition timing are as specified.	
NG	Check and repair ignition timing	


11 Check ECM power supply and ground

- a. Disconnect ECM connector E-557.
- b. Turn ignition switch to ON and check ECM connector terminals.

Multimeter Connection	Condition	Specified Condition	
E-557 (35, 20) - E-557 (63 or 64)	Ignition switch ON	11 to 14 V	

NG)

Repair or replace related wire harness



06

OK

Go to Diagnostic Help

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

00

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Engine starts normally, but idles roughly at anytime Diagnosis Procedure	
Check air filter for blockage, and intake pipe for air leakage	
NG Check and repair intake system	
	ОК
2 Check if throttle is stuck	
NG Repair or replace throttle	
	ОК
3 Check spark plug	
a. Check spark plug of each cylinder, and observe if the type and gap are as specified. NG Replace spark plug	2
شرکت دیجیتال خودرو سامانه (مسئولیت محدو	ОК
Check throttle for carbon deposits	
NG Clean throttle	
	ОК
5 Check injector for leakage or blockage	
NG Clean or replace injector	
	ОК
6 Check fuel condition	
a. Observe if trouble occurs just after fuel is filled.	
NG Replace fuel	
	ОК



a. Measure compression of misfiring cylinder (See page 07-20).



OK


- 8 Check engine ignition sequence and ignition timing
- a. Check if engine ignition sequence and ignition timing are as specified.




06

OK

- 9 Check ECM power supply and ground
- a. Disconnect ECM connector E-557.
- b. Turn ignition switch to ON and check ECM connector terminals.





ОК

Go to Diagnostic Help

Ŀ	ngır	ne starts normally, but idles roughly during warming up	
Di	agno	osis Procedure	
	1	Check air filter for blockage, and intake pipe for air leakage	
	NG	Check and repair intake system	
			ОК
	2	Check spark plug	
a.	Chec	ck spark plug of each cylinder, and observe if the type and gap are as specified.	
	NG	Replace spark plug	
			ОК
	3	Check throttle for carbon deposits	0
r	NG	Clean throttle	
دو	مح	شرکت دیجیتال خودرو سامانه (مسئولیت	ОК
ان	4	Unplug coolant temperature sensor connector, start engine and observe if eng normally during warming up	ine idles
	ОК	Check and repair wire harness or replace sensor	
			NG
	5	Check injector for leakage or blockage	
	NG	Clean or replace injector	
			ОК
	6	Check fuel condition	
a.	Obse	erve if trouble occurs just after fuel is filled.	
	NG	Replace fuel	
_			



7 Check pressure of cylinder

a. Measure compression of misfiring cylinder (See page 07-20).



Check engine to confirm cause of low compression

OK

06

8 Check ECM power supply and ground

a. Disconnect ECM connector E-557.

b. Turn ignition switch to ON and check ECM connector terminals.


Multimeter Connection	Condition		Specified Condition
E-557 (35, 20) - E-557 (63 or 64)	Ignition switch ON	00	11 to 14 V

NG

Repair or replace related wire harness

دیجیتال خودرو سامانه (مسئولیت محدود)

ن سامانه دیجیتال تعمیرکاران خودرو در ایران



OK

Go to Diagnostic Help

Ŀ	ngır	ne starts normally, but idles roughly after warming up	
Di	iagno	osis Procedure	
	1	Check air filter for blockage, and intake pipe for air leakage	
	NG	Check and repair intake system	
			ОК
	2	Check spark plug	
a.	Chec	ck spark plug of each cylinder, and observe if the type and gap are as specified.	
	NG	Replace spark plug	
			ОК
	3	Check throttle for carbon deposits	0
	NG	Clean throttle	
92	مح	شرکت دیجیتال خودرو سامانه (مسئولیت	ОК
ان	ر 4	Unplug coolant temperature sensor connector, start engine and observe if enginormally during warming up	ne idles
	ОК	Check and repair wire harness or replace sensor	
			NG
	5	Check injector for leakage or blockage	
	NG	Clean or replace injector	
			ОК
	6	Check fuel condition	
a.	Obse	erve if trouble occurs just after fuel is filled.	
	NG	Replace fuel	



7 Check pressure of cylinder

a. Measure compression of misfiring cylinder (See page 07-20).



Check engine to confirm cause of low compression

OK

06

8 Check ECM power supply and ground

a. Disconnect ECM connector E-557.

b. Turn ignition switch to ON and check ECM connector terminals.


Multimeter Connection	Condition		Specified Condition
E-557 (35, 20) - E-557 (63 or 64)	Ignition switch ON	00	11 to 14 V

NG

Repair or replace related wire harness

دیجیتال خودرو سامانه (مسئولیت محدود)

ن سامانه دیجیتال تعمیرکاران خودرو در ایران



OK

Go to Diagnostic Help

	_	ne starts normally, but idles roughly or stalls with part load (for example, s ON)
I	Diagno	osis Procedure
	1	Check throttle for carbon deposits
	NG	Clean throttle
		ОК
)6	2	Observe if engine output increases when A/C is turned on. This means that observe changes of ignition advance angle, injection pulse width and intake air volume using diagnostic tester
	ОК	Go to step 4
		NG
	3	Connect ECM adapter, and disconnect pin cable of ECM corresponding terminal. Check if wire harness side is HIGH-level signal with A/C ON
(29	∆NG)	Check and repair A/C system
	ر ایرار	اولین سامانه دیجیتال تعمیرکاران خودرو د
	4	Check if A/C system pressure, compressor magnetic clutch and A/C compressor pump are normal
	NG	Check and repair A/C system
		ОК
	5	Check injector for leakage or blockage
	NG	Clean or replace injector
		ОК


6 Check ECM power supply and ground

- a. Disconnect ECM connector E-557.
- b. Turn ignition switch to ON and check ECM connector terminals.

Multimeter Connection	Condition	Specified Condition
E-557 (35, 20) - E-557 (63 or 64)	Ignition switch ON	11 to 14 V

NG

Repair or replace related wire harness



OK

Go to Diagnostic Help

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Engir	ne s	starts normally, but idle speed is too high	
Diagno	sis	Procedure	
1	Ch	neck if accelerator pedal is stuck	
NG	>	Adjust or replace accelerator pedal	
			OK
2	Ch	neck intake system and connected vacuum pipe for air leakage	
NG	>	Check and repair intake system	
			ОК
3	Ch	neck throttle for carbon deposits	
NG	>	Clean throttle	ОК
		شرکت دیجیتال خودرو سامانه (مسئولی sconnect coolant temperature sensor connector, start engine and observe	if engine idles
ر ابدار		ormally at this time	
ОК	>	Check and repair wire harness or replace sensor	
			NG
5	Ch	neck engine ignition timing	
a. Chec	k if e	engine ignition timing is as specified.	
NG	>	Check and repair ignition timing	
			ОК


6 Check ECM power supply and ground

- a. Disconnect ECM connector E-557.
- b. Turn ignition switch to ON and check ECM connector terminals.

Multimeter Connection	Condition	Specified Condition
E-557 (35, 20) - E-557 (63 or 64)	Ignition switch ON	11 to 14 V

NG

Repair or replace related wire harness



OK

Go to Diagnostic Help

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Low engine speed or stalls when accelerating

Diagnosis Procedure

1 Check air filter for blockage, and intake pipe for air leakage

NG Check and repair intake system

OK

2 Check fuel pressure

a. Using a fuel pressure gauge, check fuel pressure (See page 10-11).

Standard Fuel Pressure

06

Condition	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key LOCK	400

NG Repair or replace fuel system

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

OK

ولین سامانه دیجیتال تعمیرCheck spark plug را 3

a. Check spark plug of each cylinder, and observe if the type and gap are as specified.

NG Replace spark plug

OK

4 Check throttle for carbon deposits

NG Clean throttle


OK

5 Check air flow meter and throttle position sensor and wire harness

NG Check and repair wire harness or replace sensor

WWW.DIGITALKHODRO.COM

021 62 99 92 92



10 Check ECM power supply and ground


- a. Disconnect ECM connector E-557.
- b. Turn ignition switch to ON and check ECM connector terminals.

Multimeter Connection	Condition	Specified Condition
E-557 (35, 20) - E-557 (63 or 64)	Ignition switch ON	11 to 14 V

NG

06

Repair or replace related wire harness



OK


Go to Diagnostic Help

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

00

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Slow res	sponse when accelerating	
Diagnosis	s Procedure	
1 CI	heck air filter for blockage, and intake p	ipe for air leakage
NG	Check and repair intake system	
		ОК
2 CI	heck fuel pressure	
_	fuel pressure gauge, check fuel pressure (\$ d Fuel Pressure	See page 10-11).
	Condition	Fuel System Pressure (kPa)
	Key ON	400
	Engine Idling	400
-	Key LOCK	400
NG	Repair or replace fuel system	
ت محد	عيتال خودرو سامانه (مسئولي	οκ شرکت دیج
3 C	heck spark plug انه دیجیتال تعمیا	اولین سام
a. Check sp	park plug of each cylinder, and observe if the	ne type and gap are as specified.
NG	Replace spark plug	
		ОК
4 CI	heck throttle for carbon deposits	
NG	Clean throttle	
		ОК
5 CI	heck air flow meter and throttle position	sensor and wire harness
NG	Check and repair wire harness or repl	ace




10 Check ECM power supply and ground

- a. Disconnect ECM connector E-557.
- b. Turn ignition switch to ON and check ECM connector terminals.

Multimeter Connection	Condition	Specified Condition
E-557 (35, 20) - E-557 (63 or 64)	Ignition switch ON	11 to 14 V

NG)

Repair or replace related wire harness



OK

Go to Diagnostic Help

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

00

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Lack of power and poor performance when accelerating

Diagnosis Procedure

1 Check if malfunctions that clutch slipping, low tire inflation pressure, brake dragging, incorrect tire size, and incorrect four-wheel alignment are present

NG >

Check and repair malfunctioning component

OK

06

2 Check air filter for blockage, and intake pipe for air leakage

NG Check and repair intake system

OK

- 3 Check fuel pressure
- a. Using a fuel pressure gauge, check fuel pressure (See page 10-11).

 Standard Fuel Pressure

خودرو سامانه (مسئولیت محدو	Fuel System Pressure (kPa)
Key ON	400
Engine Idling	400
Key LOCK	400

NG Repair or replace fuel system

OK

- 4 Check spark plug
- a. Check spark plug of each cylinder, and observe if the type and gap are as specified.

NG Replace spark plug

OK

	T	
5	Check spark	
chec	ove ignition coil and spark plug of one cylinder, and ground spark plug housing. Start k if spark is generated. Spark is generated.	the engine, and
NG	Check and repair ignition system	
		ОК
6	Check throttle for carbon deposits	
NG	Clean throttle	
		ОК
7	Check air flow meter and throttle position sensor and wire harness	
NG	Check and repair wire harness or replace sensor شرکت دیجیتال خودر و سامانه (مسئولیت	ОК
8	Check injector for leakage or blockage	
NG	Clean or replace injector	
		ОК
9	Check fuel condition	
a. Obse	erve if trouble occurs just after fuel is filled.	
NG	Replace fuel	
		ОК

10 Check engine ignition sequence and ignition timing

a. Check if engine ignition sequence and ignition timing are as specified.

NG Check and repair ignition timing

OK

11 Check exhaust system

a. Check exhaust system for leakage or blockage.

06

NG Repair or replace related exhaust system components

OK


12 Check ECM power supply and ground

- a. Disconnect ECM connector E-557.
- b. Turn ignition switch to ON and check ECM connector terminals.

Multimeter Connection

E-557 (35, 20) - E-557 (63 or 64)

Repair or replace related wire harness



ОК

Go to Diagnostic Help

ON-VEHICLE SERVICE

Intake/Exhaust VVT Control Valve

Description

There are two VVT control valves, which are located on intake side and exhaust side respectively.

Operation


ECM controls the VVT control valve depending on the engine condition, changes the flowing direction of oil in the phasers to advance or retard intake/exhaust camshaft, thus changing the timing of intake valve and exhaust valve.

Removal


Use the same procedures of removal for exhaust VVT control valve and intake VVT control valve. The procedures listed below are for the intake VVT control valve.

- 1. Turn off all electrical equipment and ignition switch.
- 2. Disconnect negative battery cable.
- 3. Remove engine trim cover.
- 4. Remove intake VVT control valve.
 - a. Disconnect intake VVT control valve connector.





b. Remove intake VVT control valve fixing bolt and intake VVT control valve. (Tightening torque: 8 ± 2 N·m)



Installation

Installation is in the reverse order of removal.

Coolant Temperature Sensor

Description

The coolant temperature sensor is a negative temperature coefficient sensor, which is installed into the mounting hole in thermostat holder.

Operation


The coolant temperature sensor provides an input signal for Engine Control Module (ECM). As temperature increases, the resistance of sensor decreases. As coolant temperature changes, resistance of coolant temperature sensor varies accordingly, resulting in a change in voltage of coolant temperature sensor signal circuit. The ECM uses input signal to control air-fuel mixture, ignition timing, A/C compressor and radiator fan on/off timing.

Removal

- 1. Turn off all electrical equipment and ignition switch.
 - 2. Disconnect negative battery cable.
 - 3. Drain coolant (See page 18-13).

⚠ WARNING

- Make sure engine is in low temperature before operating cooling system. Never open the expansion tank cover and remove the drain cock plug when engine is operating or cooling system is in high temperature. High-pressurized hot engine coolant and steam may flow out and cause serious injury.
- Remove engine trim cover.
- 5. Remove coolant temperature sensor.
 - a. Disconnect coolant temperature sensor connector and remove coolant temperature sensor. (Tightening torque: 11 - 16 N·m)



⚠ WARNING

Remove the coolant temperature sensor when engine cools down to avoid scalding injury.

Installation

Installation is in the reverse order of removal.

CAUTION

- Perform sealing with anaerobic seal gum.
- Confirm that the sensor is tightened fully during installation.
- After installing engine coolant temperature sensor, add coolant and check coolant level.





Knock Sensor

Description

The knock sensor is installed on cylinder block, and used to detect engine vibration caused by detonation.

Operation

The sensitive element of knock sensor is a piezoelectric ceramic. Vibration of engine cylinder block is transferred to the piezoelectric ceramic through a mass block in knock sensor. Due to the pressure generated by vibration of mass block, the piezoelectric ceramic generates a voltage at both electrode faces, and converts the vibration signal to an AC voltage signal to output it. As intensity of vibration increases, knock sensor output voltage increases accordingly.

Because frequency of vibration signal caused by engine knocking is far more than that of normal engine vibration signal, Engine Control Module (ECM) can distinguish between knock or non-knock signals by processing these signals from knock sensor.


Removal

- 1. Turn off all electrical equipment and ignition switch.
- 2. Disconnect negative battery cable.
- 3. Remove engine trim cover.
- 4. Remove knock sensor.
 - a. Disconnect knock sensor connector, and move away the knock sensor cable from bracket.




، دیجیتال خودرو سامانه (مسئولیت محدود)





- b. Remove intake manifold assembly (See page 14-23).
- c. Remove knock sensor fixing bolt and knock sensor. (Tightening torque: 20 ± 5 N·m)



Installation

Installation is in the reverse order of removal.

CAUTION

- Never allow any kinds of gasket and washer between sensor and engine block. Only the metal part of sensor can contact with the engine block directly.
- DO NOT apply lubricant, grease or seal gum when installing knock sensor. Keep engine block clean and dry, and never allow any foreign matter (such as oil) on the installation area of knock sensor.
- Never tap knock sensor when installing it.







Oxygen Sensor

Description

This vehicle is equipped with two oxygen sensors (upstream oxygen sensor and downstream oxygen sensor). Oxygen sensors continually monitor the oxygen concentration in exhaust gas.

Operation

The oxygen sensor generates voltage depending on the oxygen content in exhaust gas. The sensor generates low voltage when oxygen content is high, and high voltage when oxygen content is low. Therefore, the sensor acts as a rich-lean switch.

The oxygen sensor is equipped with a heating element that keeps sensor at proper operating temperature under all operating conditions.

Upstream Oxygen Sensor

The input signal from upstream heated oxygen sensor informs Engine Control Module (ECM) of the oxygen content in exhaust gas. Based on this input signal, Engine Control Module (ECM) adjusts air-fuel ratio finely by adjusting injector pulse width.

Downstream Oxygen Sensor

The downstream heated oxygen sensor signal is used to detect the catalytic converter deterioration. As converter deteriorates, the signal from downstream oxygen sensor begins to match upstream oxygen sensor signal except for a slight time delay. By comparing the signal from upstream heated oxygen sensor to the signal from downstream oxygen sensor, Engine Control Module (ECM) calculates the efficiency of catalytic converter.

Removal & Installation - Upstream Oxygen Sensor

شرکت دیجیتال خودر و سامانه (میبر (See page 16-10) د

Removal & Installation - Downstream Oxygen Sensor

(See page 16-11)

Camshaft Position Sensor

Description


This vehicle is equipped with an intake camshaft position sensor and an exhaust camshaft position sensor, which are installed on cylinder head cover.

Operation

The camshaft position sensor is a Hall type sensor and a sensor plate is installed on camshaft. When the sensor plate is in high teeth, the applicable circuit output is low; when the sensor plate is in missing teeth, the applicable circuit output is high. As a result, the crankshaft phase information is provided to Engine Control Module (ECM) so that the compression top dead center and exhaust top dead center of crankshaft can be distinguished.

Removal

- 1. Turn off all electrical equipment and ignition switch.
- 2. Disconnect negative battery cable.
- 3. Remove engine trim cover.
- 4. Remove camshaft position sensor.
 - a. Disconnect intake camshaft position sensor connector
 (1) and exhaust camshaft position sensor connector
 (2).
 - b. Remove intake camshaft position sensor fixing bolt (3)
 and exhaust camshaft position sensor fixing bolt (4).
 (Tightening torque: 8 ± 0.5 N·m)



، دیجیتال خودرو سامانه (مسئولیت محدود)

c. Remove intake camshaft position sensor and exhaust camshaft position sensor.

Installation

Installation is in the reverse order of removal.

CAUTION

 The sensor should be pressed into mounting hole. Never use tools (such as a hammer) to strike the sensor into mounting hole forcibly.

Engine Speed Sensor

Description


The engine speed sensor is installed on clutch case, against flywheel teeth. It is used to detect the speed and position of crankshaft.

Operation

The engine speed sensor operates by using magnetoelectric effect. When crankshaft rotates, it drives flywheel to rotate. The flywheel teeth will cut the magnetic line of sensor, and change of magnetic flux causes both ends of sensor coil to generate output voltage with a certain frequency that is sent to Engine Control Module (ECM). And the output signal can indicate the speed and position of crankshaft.

Removal

- 1. Turn off all electrical equipment and ignition switch.
- 2. Disconnect negative battery cable.
- 3. Remove engine trim cover.
- 4. Remove engine speed sensor.
 - Disconnect engine speed sensor connector (arrow), and move away the engine speed sensor cable from bracket.






دیجیتال خودرو سامانه (مسئولیت محدود

 Remove engine speed sensor fixing bolt and engine speed sensor.

(Tightening torque: 8 ± 2 N·m)



Installation

Installation is in the reverse order of removal.

CAUTION

Press in the engine speed sensor rather than tap when installing it.

06

Intake Pressure/Temperature Sensor

Description

Intake pressure/temperature sensor integrates with intake manifold absolute pressure sensor and intake temperature sensor.

Operation

Intake manifold absolute pressure sensing element consists of a piece of silicon chip, which will deform mechanically as intake manifold absolute pressure changes. Piezoresistor in sensor will also deform, thus changing the resistance. Voltage signal linearly related to the pressure is generated, after processing by signal circuit of silicon chip.

Intake temperature sensor is a negative temperature coefficient thermistor, whose resistance changes with intake temperature. This sensor converts temperature signal into voltage value and sends it to Engine Control Module (ECM), thus monitoring the change of intake temperature.

Removal & Installation

(See page 14-12)





Ignition Coil

Description

The ignition coil converts the low voltage of primary winding into the high voltage of secondary winding, and discharges spark plug electrode to produce sparks which will ignite the combustible air-fuel mixture in cylinder.

Operation

An ignition coil consists of primary winding, secondary winding, iron core and housing etc. The primary and secondary windings form an induced circuit. An instant induced voltage generated by turning primary circuit switch on and off and an instant high voltage generated by secondary circuit will cause spark plugs to discharge, thus igniting the combustible air-fuel mixture. The primary winding will recharge when its ground passage is on through an Engine Control Module (ECM) signal. If Engine Control Module (ECM) cuts off the control signal to primary winding circuit, it will stop charging and a high voltage will be induced in the secondary winding.

Removal & Installation

(See page 06-252)





Electric Fuel Pump

Description

The electric fuel pump consists of DC motor, vane pump and end cover (integrated with check valve, pressure regulator and anti-electromagnetic interference element) etc. The pump and motor are installed coaxially, and sealed in the same housing. Fuel is filled around the pump and motor in the housing and used for heat dissipation and lubrication.

Operation

The battery supplies power to electric fuel pump via electric fuel pump relay, which can turn on electric fuel pump circuit only when starting and engine running. When engine stops running because of an accident, the fuel pump stops running automatically. The maximum pressure at electric fuel pump outlet is adjusted by pressure regulator to keep the whole fuel system pressure at 400 kPa.

Removal & Installation

(See page 06-253)





Fuel Injector

Description

The fuel injector is located on the cylinder head near to intake valve, and the nozzle end is located directly above the intake port.

Operation

The Engine Control Module (ECM) sends electric pulse to injector coil, forming magnetic field force. When magnetic field force increases enough to overcome the resultant force from return spring pressure, needle gravity and friction force, the needle begins to rise up and injector starts to inject fuel. The pressure of return spring forces the needle to close again when injection pulse stops.

Removal & Installation

(See page 10-26)





06

Electronic Throttle Assembly

Description

The electronic throttle assembly is located on intake manifold assembly.

Operation

The electronic throttle assembly is a critical part for engine intake system. Its main function is to adjust intake passage area according to driver's driving intention, and control intake air volume to meet the intake requirement for engine in different operating conditions, and send back the position signals of throttle valve plate to control unit to achieve accurate control. The throttle valve plate will stop at the limp home position (NLP) determined in a mechanical way when a malfunction occurs.

The electronic throttle assembly consists of four parts: drive module, train module, executive module and feedback module, and all components are integrated into the same throttle valve housing.

Removal & Installation

(See page 14-19)





Canister Solenoid Valve

Description

The canister solenoid valve opens when power is on, and closes when power is off.

Operation

The canister solenoid valve consists of solenoid coil, magnet armature, valve, etc. The air volume through canister solenoid valve depends on electric pulse duty ratio that outputs from Engine Control Module (ECM) and pressure difference between canister inlet and outlet. When there is no electric pulse, the canister solenoid valve closes.

Removal & Installation

(See page 12-7)





Engine Control Module (ECM)

Description

The Engine Control Module (ECM), mounted on the lower right side of engine compartment rain gutter front end panel assembly, can be removed only as a unit for replacement.

Operation

The Engine Control Module (ECM) is a pre-programmed microprocessor digital computer, which is used to adjust ignition timing, air-fuel ratio, emission control, speed control, A/C compressor and idle speed etc. The Engine Control Module (ECM) enables the program to suit ever-changing operation conditions.


Removal


- 1. Turn off all electrical equipment and ignition switch.
- 2. Disconnect negative battery cable.
- 3. Remove front wiper arm assembly (See page 49-23).
- 4. Remove front windshield lower garnish assembly (See page 62-39).
- 5. Remove Engine Control Module (ECM).
 - a. Remove ECM connector protection cover bolts.






b. For MT model, disconnect 2 ECM connectors (1).
For CVT model, disconnect 2 ECM connector (1) and TCU connector (2).






c. Remove ECM bracket fixing nuts (arrow).(Tightening torque: 7 ± 1 N⋅m)



d. Remove the Engine Control Module (ECM) from bracket.



Installation

Installation is in the reverse order of removal.

06

© CAUTION

- Pay attention to static electricity protection when installing.
- Take care to protect connector pins.
- To prevent water droplets from accumulating on connector joint, face it down.

