

AT-2

Automatic Transaxle System

General Information

SPECIFICATION

Type		A5SR2	
Driving system		2WD/ 4WD	
T/CON	Type	3 elements, 1 stage, 2 phase	
	Identification inscription [Nominal diameter (mm)]	8 (Φ250)	
	Stall torque ratio	1.76	
Transmission	Manipulating system		Remote control flow transmission (Cable method)
	Shift position	P	Fix output axle (Engine start allowed)
		R	Reverse
		N	Neutral (Engine start allowed)
		D	1↔2↔3↔4↔5
	Gear ratio	1st	3.827
		2nd	2.368
		3rd	1.52
		4th	1
		5th	0.834
		Reverse	2.613
		Final gear ratio	3.333
	Control method		Electronic control
	Function	Lock-up control	Equipped
		Operating fluid pressure control	Equipped
		Real time feedback transmission control	Equipped
		Transmission pattern auto change control	Equipped
		Self-diagnosis control	Equipped
		Fail-safe function	Equipped
		Sports mode function	Equipped
	Speedometer gear teeth (drive/driven)		6/14
	Oil pump	Type	Trochoid oil pump
		Driving system	Engine drive
ATF oil	The recommended	APOLLOIL ATF RED-1	
	Quantity	10l(10.57 US qt, 8.8 Imp.qt)	

Automatic Transaxle System

AT-3

Automatic Transaxle System

DESCRIPTION

We have employed A5SR2, the 5th speed automatic transmission with full range electronic control and sports mode that provides smooth driving with lesser transmission shock as well as pleasant driving from manual transmission.

A/T electronic control system is the system where an optimized transmission has been realized from taking a grasp of driving status, A/T internal status at A/T control unit that has integrated with control valve assembly.

This paper describes apparatus cross-sectional view, major controls and control circuit diagram, major components and their functions, and etc.

A5SR2

Item	Contents
Improved transmission feel	- Integrated control over engine and A/T (CAN communication control) system employed - Turbine sensor 1.2 employed - Real time feedback control at all phases applied
Improved driving	- Sports mode function employed - Snow mode function employed (2WD applied) - Gear ratio extension
Improved fuel consumption	- Slip lock-up employed - Full range lock-up employed (Larger lock-up zone) - E-flow torque converter employed (Improved driving efficiency) - Small transmission power train employed
Improved safety	- Transmission lock apparatus (P range maintenance apparatus affixed) employed
Improved maintenance	- Electronic system diagnosis tester (hi-scan) counterpart


MAJOR COMPONENTS AND THEIR FUNCTIONS

Part name	Acronyms	Function
Front brake	F/B	Fastens the front sun gear
Input clutch	I/ C	Engages the input shaft, with the middle annulus gear and the front annulus gear
Direct clutch	D/C	Engages the rear planetary carrier with a rear sun gear
High & low reverse clutch	H & L R/C	Engages the middle sun gear with the rear sun gear
Reverse brake	R/B	Fastens the rear planetary carrier
Forward brake	FWD/B	Fastens the middle sun gear
Low cost brake	LC/B	Fastens the middle sun gear
1st one-way clutch	1st OWC	Allows the rear sun gear to turn freely forward relative to the mid sun gear but fastens it for reverse rotation
Forward one-way clutch	FWD OWC	Allows the mid sun gear to turn freely in the forward direction but fastens it for reverse rotation
3rd one-way clutch	3rd OWC	Allows the front sun gear to turn freely in the forward direction but fastens it for reverse rotation

AT-4

Automatic Transaxle System

COMPONENTS




LLAE001A

Automatic Transaxle System

AT-5

OPERATION



Shift Position	I/C	H&L R/C	D/C	Rev/B	Fr/B	LC/B	Fwd/B	Ratio1 OWC	Forward OWC	Ratio 2 OWC	Remarks
P		△			△						Parking position
R		0		0	0			⊙		⊙	Reverse position
N		△			△	△'''					Neutral position
D	1st	△"			△		0	⊙	⊙	⊙	Automatic shift 1↔2↔3 ↔4↔5
	2nd		0		△		0		⊙	⊙	
	3rd		0	0		0	△	◇		⊙	
	4th		0	0			△	◇			
	5th		0			0	△	◇		◇	
5M	5th		0		0		△	◇		◇	Fix to the 5th speed
4M	4th		0	0			△	◇			Fix to the 4th speed
3M	3rd		0	0		0	△	◇		⊙	Fix to the 3rd speed
2M	2nd			0		0	0		⊙	⊙	Fix to the 2nd speed
1M	1st				0	0	0	⊙	⊙	⊙	Fix to the 1st speed

- 0 : Operates.
 - ⊙ : Operates during progressive acceleration.
 - ◇ : Operates and effects power transmission while coasting.
 - △ : Line pressure is applied but does not affect power transmission.
 - △" : Operates under conditions shown in the high & low reverse clutch operating condition.
 - △''' : Operates under conditions shown in the LC/B operating condition.
- Note) Delay control is applied during D(4,3,2,1) ⇒ N shift.


LLAE001B

Automatic Transaxle System

AT-7

4. D, M3, M4, M5 range ratio 2nd

- Fasten the front brake.
- The front brake and the forward one-way clutch regulate reverse rotation of the mid sun gear.
- The 3rd one-way clutch regulates reverse rotation of the front sun gear.



The direct clutch is coupled and the rear carrier and the rear sun gear are connected.

* POWER FLOW


Input shaft ⇒ Front internal gear ⇒ Front carrier ⇒ Rear internal gear ⇒ Rear carrier ⇒ Rear carrier ⇒ Middle internal gear ⇒ Middle carrier ⇒ Output shaft

LLAE002B

AT-8

Automatic Transaxle System

- 5. D, M3, M4, M5 range 3rd speed
 - Fastens the front brake.
 - The 3rd one-way clutch regulates reverse rotation of the front sun gear.



- The high & low reverse clutch is coupled and the middle and rear sun gears are connected.

*** POWER FLOW**

Input shaft ⇒ Front internal gear ⇒ Front carrier ⇒ Rear internal gear ⇒ Rear carrier ⇒ Rear carrier ⇒ Middle internal gear ⇒ Middle carrier ⇒ Output shaft


LLAE002C

AT-10

Automatic Transaxle System

7. D, M5 range 5th speed

- The front brake fastens the front sun gear.
- The direct clutch is released and the rear carrier and rear sun gear are disconnected.



*** POWER FLOW** (مسئولیت خودروه) شرکت دیجیتال خودرو
 Input shaft ⇒ Front internal ⇒ Front carrier ⇒ Rear internal input shaft ⇒ Middle internal ⇒ Rear carrier ⇒ Rear sun gear ⇒ Middle sun carrier ⇒ Middle carrier ⇒ Output shaft
 اولین سامانه


LLAE002E

Automatic Transaxle System

AT-11

8. R range

- The front brake fastens the front sun gear.
- The high & low reverse clutch is coupled and the middle and rear sun gears are connected.
- The reverse brake fastens the rear carrier.



شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

LLAE002F


* POWER FLOW

Input shaft ⇒ Front internal ⇒ Front carrier ⇒ Rear internal ⇒ Rear sun gear ⇒ Middle sun gear ⇒ Middle carrier ⇒ Output shaft

AT-12

Automatic Transaxle System

CONTROL SYSTEM DIAGRAM



LLAE002G

Automatic Transaxle System

AT-13


MAIN COMMUNICATION SIGNAL

Input to ECM(CAN)	Output to ECM(CAN)	Input from external sys.	Output to external sys.
-	-	A/T driving mode SW	Self-diagnosis indicator
Engine torque signal	Output revolution signal	Sports mode SW	Range signal (P, R, N, D)
Engine revolution signal	Turbine sensor signal	Up SW	Range signal
-	Torque reduction request signal	Down SW	Reverse lamp signal
Accelerator opening signal		Stop lamp SW	N position signal
Power		4 x 4 Low signal	

LINE PRESSURE CONTROL

- If the engine control unit sends the input torque signal equivalent to the engine driving force to the A/T control unit (TCM), the A/T control unit (TCM) controls line pressure solenoid.
- This line pressure solenoid controls the pressure regulator valve as the signal pressure and adjusts the pressure of the operating oil discharged from the oil pump to the line pressure most appropriate to the driving plate.

LINE PRESSURE SYSTEM DIAGRAM



LLAE002H


AT-14

Automatic Transaxle System

Line pressure control based on line pressure characteristic pattern of A/T control unit (TCM)


- A/T control unit (TCM) has stored in memory a number of patterns for the optimum line pressure characteristics according to driving conditions.
- In order to obtain the most appropriate line pressure characteristic to meet the current driving state, the TCM controls the line pressure solenoid current valve and thus controls the line pressure.
 - Normal line pressure control.
Each clutch is adjusted to the necessary pressure to match the engine drive force.

Normal time line pressure characteristic



- Back-up control (Engine brake)
Line pressure according to speed is set during shift down by select operation while driving.

Line pressure characteristic for backup control




Shift control

- The clutch pressure control solenoid is controlled by the signals from the switches and sensors. Thus the clutch pressure is adjusted to be appropriate to the engine load state and vehicle driving state. It becomes possible to finely control the clutch hydraulic pressure with high precision and a smoother shift change characteristic is attained.

SHIFT CONTROL SYSTEM DIAGRAM


- During shift change
Set to line pressure that is necessary for shift change. Therefore, line pressure characteristic is set according to input torque and shift types.

Line pressure characteristic during shift




- At low fluid temperature
When the A/T fluid temperature drops below the prescribed temperature, in order to speed up the action of each friction element, the line pressure is set higher than the normal line pressure characteristic.

Line pressure character during low temperature



Automatic Transaxle System

AT-15



LLAE002M

Shift description

Controls clutches with optimum timing and fluid pressure in response to engine speed, engine torque information, and e-ct.

Lock-up control

Lock-up control is to enhance delivery efficiency by preventing the torque converter from slipping, engaging the lock-up piston into the torque converter.

It operates lock-up solenoid control in response to a signal from A/T control unit (TCM) and lock-up control valve behavior control, engages or releases the lock up piston of the torque converter.

LOCK-UP OPERATING CONDITION TABLE

Select lever	D range			Sports mode	
Gear position	5	4	3	5	4
Lock-up	○	○	-	○	○
Slip lock-up	○	○	-	-	-

LLAE002N


Lock-up control valve control

- In the lock-up control valve, there is operating fluid pressure circuit linked into the lock-up piston and lock-up solenoid operates valve shift in response to a signal from the A/T control unit.
- Operating fluid pressure circuit that is applied to the lock-up piston chamber is controlled with the release or apply sides.

Automatic Transaxle System

AT-17

ENGINE BRAKE CONTROL SYSTEM DIAGRAM



LLAE002P

- The operation of the low coast brake solenoid switches the low coast brake switch valve and controls the coupling and releasing of the low coast brake. The low coast brake reducing valve controls the low coast brake coupling force.

CONTROL VALVE

Control valve functions

Valve name	Function
Torque converter regulator valve	Regulates line pressure to the optimum pressure (torque converter operating pressure) to prevent pressure applied to the torque converter from being excessive.
Pressure regulator valve Pressure regulator plug Pressure regulator sleeve	Regulates oil pump discharge pressure to the optimum pressure (line pressure) in response to the driving conditions.
Front brake control valve	Regulates line pressure to the optimum pressure (front brake pressure) to be applied to the front brake during the front brake apply.
Accumulator control valve	Regulates pressure applied to the accumulator piston, and the low coast reducing valve (accumulator control pressure) in response to the driving conditions (regulates clutch pressure at 1st, 2nd, 3rd, 5th gears).
Pilot valve A	Regulates line pressure to the regular pressure required by line pressure control, shift control, and lock-up control (pilot pressure).
Pilot valve B	Regulates line pressure to the regular pressure required by shift control (pilot pressure).

AT-18

Automatic Transaxle System

Valve name	Function
Low coast brake switching valve	Provides the low coast brake reducing valve with line pressure during engine brake operation.
Low coast brake reducing valve	Regulates line pressure to the optimum pressure to be applied to the low coast brake when the low coast brake is coupled.
N-R accumulator	Produces the stabilizing pressure for when N-R is selected.
Direct clutch piston switching valve	Operates in 4th gear and switches the direct clutch coupling capacity.
High & low reverse clutch control valve	Regulates line pressure to the optimum pressure (high & low reverse clutch pressure) to be applied to the high & low reverse clutch when the high & low reverse clutch is coupled (regulates clutch pressure in 1st, 3rd, 4th, 5th gears).
Input clutch control valve	Regulates line pressure to the optimum pressure (input clutch pressure) to be applied to the input clutch when the input clutch is coupled (regulates clutch pressure in 4th, 5th gears).
Direct clutch control valve	Regulates line pressure to the optimum pressure (direct clutch pressure) to be applied to the direct clutch when the direct clutch is coupled (regulates clutch pressure in 2nd, 3rd, 4th gears).
Lock-up control valve Lock-up control plug Lock-up control sleeve	Switches lock-up to operating or released. Also, by performing the lock-up operation transiently, lock-up smoothly.
Torque converter lubrication valve	Operates to switch torque converter, cooling, and oil path of lubrication system during lock-up.
Cool bypass valve	Allows excess oil to by pass cooler circuit without being fed into it.
Line pressure relief valve	Discharges excess oil from line pressure circuit.
N-D accumulator	Produces the stabilizing pressure for when N-D is selected.
Manual valve	Delivers line pressure to each circuit in response to each select position. Circuit to which line pressure is not sent drain.

FUNCTION OF PRESSURE SWITCH


Name	Function
Fluid pressure switch 1 (FR/B)	Detects abnormal fluid pressure of the front brake. When it detects any malfunction, it puts the system into fail-safe mode.
Fluid pressure switch 2(LC/B)	Detects abnormal fluid pressure of the low coast brake. When it detects any malfunction, it puts the system into fail-safe mode.
Fluid pressure switch 3(I/C)	Detects abnormal fluid pressure of the input clutch. When it detects any malfunction, it puts the system into fail-safe mode.
Fluid pressure switch 5(D/C)	Detects abnormal fluid pressure of the direct clutch. When it detects any malfunction, it puts the system into fail-safe mode.
Fluid pressure switch 6 (H & LR/C)	Detects abnormal fluid pressure of the high & low reverse clutch. When it detects any malfunction, it puts the system into fail-safe mode.

Automatic Transaxle System


AT-19

SUB ROM unit

1. Installing location: The valve body upper part
2. Function: To obtain A/T fluid pressure stability by compensating for solenoid & valve body unit fluid pressure differential.
3. Principle: Install additional ROM onto valve body of automatic transmission and input fluid pressure differential of solenoid & valve body so that TCM reads the input data to perform fluid pressure compensation.



LLAE117A



LLAE117B

4. Maintenance

- 1) When replacing with a new TCM in the vehicle
 - TCM automatically reads SUB ROM DATA during I.G ON. At this time, shift range valve is off for about 2.5 second.
- 2) When replacing A/T (regardless of new or old ones) in the vehicle
 - Must erase SUB ROM DATA stored in TCM.
 - Erase SUB ROM DATA in SCAN TOOL delete mode during shift stage in R-range + accelerator opening angle maintains 50% + I.G ON.
 - TCM reads SUB ROM DATA from a new A/T upon I.G ON again after I.G OFF.


3) Moving TCM from vehicle A to another vehicle B

- Perform the same way as in 2) above.

VALVE BODY fluid pressure circuit diagram (D Range)

AT-20

Automatic Transaxle System




LLAE006A

* Refer to body valves for L(number) valve name.

1st gear

Automatic Transaxle System

AT-21




LLAE006B

AT-22

Automatic Transaxle System

2nd gear




LLAE006C

3rd gear

Automatic Transaxle System

AT-23




LLAE006D

AT-24

Automatic Transaxle System

4th gear




LLAE006E

Automatic Transaxle System

AT-25

5th gear (lock-up)




LLAE006F

AT-28

Automatic Transaxle System

R range



LLAE0061

Automatic Transaxle System

AT-29

BASIC INSPECTION ADJUSTMENT

TRANSAXLE FLUID LEVEL

INSPECTION

1. Drive the vehicle until the fluid reaches normal operating temperature [70~80°C(158~176°F)].
2. Place the vehicle on a level surface.
3. Move the gear selector lever through all gear positions. This will fill the torque converter with trans fluid. Set the selector lever to the "N" (Neutral) position.
4. Before removing the oil level gauge, wipe all contaminants from around the oil level gauge. Then take out the oil level gauge and check the condition of the fluid.

NOTICE

If the fluid smells as if it is burning, it means that the fluid has been contaminated by fine particles from the bushes and friction materials, a transmission overhaul may be necessary.

5. Check that the fluid level is in the "HOT" mark on the oil level gauge. If fluid level is low, add automatic transaxle fluid until the level reaches the "HOT" mark.

Automatic transaxle fluid :

APOLLOIL ATF RED-1

ATF capacity: 10ℓ(10.57 US qt, 8.8 Imp.qt)

NOTICE

Low fluid level can cause a variety of abnormal conditions because it allows the pump to take in air along with fluid. Air trapped in the hydraulic system forms bubbles, which are compressible. Therefore, pressures will be erratic, causing delayed shifting, slipping clutches and brakes, etc. Improper filling can also raise fluid level too high. When the transaxle has too much fluid, gears churn up foam and cause the same conditions which occur with low fluid level, resulting in accelerated deterioration of automatic transaxle fluid. In either case, air bubbles can cause overheating, and fluid oxidation, which can interfere with normal valve, clutch, and brake operation. Foaming can also result in fluid escaping from the transaxle vent where it may be mistaken for a leak.

6. Insert the oil level gauge securely.

NOTICE

When new, automatic transmission fluid should be red, The red dye is added so the assembly plant can identify it as transmission fluid and distinguish it from engine oil or antifreeze. The red dye, which is not an indicator of fluid quality, is not permanent. As the vehicle is driven the transmission fluid will begin to look darker. The color may eventually appear light brown.

REPLACEMENT

If you have a fluid changer, use this changer to replace the fluid. If you do not have a fluid replace the fluid by the following procedure.


1. Disconnect the hose, which connects the transmission and the oil cooler (inside the radiator).
2. Start the engine and let the fluid drain out.

Running conditions : "N" range with engine idling

CAUTION

The engine should be stopped within one minute after it is started. If the fluid has all drained out before then, the engine should be stopped at that point.

3. Remove the drain plug(A) from the bottom of the transmission case to drain the fluid.



SBLAT6030L

AT-30

Automatic Transaxle System

4. Install the drain plug via the gasket, and tighten it the specified torque.

TORQUE:

58.83~63.74Nm (6~6.5kgf.m, 43.39~47.01lb-ft)

5. Pour the new fluid in through the oil filler tube.

CAUTION

Stop pouring if the full volume of fluid cannot be poured in.

6. Repeat the procedure in step (2).

NOTICE

Check the old fluid for contamination. If it has been contaminated, repeat the steps (5) and (6).

7. Pour the new fluid in through the oil filler tube.
8. Reconnect the hose, which was disconnected in step (1) above, and firmly replace the oil level gauge.
(In case of this "replace", this means after wiping off any dirt around the oil level gauge, insert it into the filler tube.)
9. Start the engine and run it at idle for 1~2 minutes.
10. Move the select lever through all positions, and then move it to the "N" or "P" position.
11. Drive the vehicle until the fluid temperature rises to the normal temperature (70~80°C(158~176°F)), and then check the fluid level again. The fluid level must be at the HOT mark.
12. Firmly insert the oil level gauge into the oil filler tube.

TROUBLESHOOTING

DIAGNOSTIC TROUBLE CODES (INSPECTION PROCEDURE)

Check the Diagnostic Trouble Codes

1. Turn the ignition switch to OFF.
2. Connect the Hi-scan tool to the DLC connector for diagnosis.
3. Turn the ignition switch to ON.
4. Check the diagnostic trouble codes using the Hi-scan tool.
5. Read the output diagnostic trouble codes. Then follow the remedy procedures according to the "DIAGNOSTIC TROUBLE CODE DESCRIPTION" on the following pages.

NOTICE

- A maximum of 10 diagnostic trouble codes (in the sequence of occurrence) can be stored in the Random Access Memory (RAM) incorporated within the control module.
- The same diagnostic trouble code can be stored one time only.
- If the number of stored diagnostic trouble codes or diagnostic trouble patterns exceeds 10, already stored diagnostic trouble codes will be erased in sequence, beginning with the oldest.
- Do not disconnect the battery until all diagnostic trouble codes or diagnostic trouble patterns have been read out, because all stored diagnostic trouble codes or diagnostic trouble patterns will be cancelled when the battery is disconnected.
- All diagnostic trouble codes are deleted from memory the 200th time the ATF temperature reaches 50°C(122°F) after memorization of the most recent diagnostic code.

6. Delete the diagnostic trouble code.
7. Disconnect the Hi-scan tool.

NOTICE

DTC cleaning should only be done with the scan tool.

Diagnostic trouble code table

No.	Code	Item	MIL	Remark
1	P0705	TRANSMISSION RANGE SENSOR CIRCUIT MALFUNCTION (PRND Input)	X	
2	P0711	TRANSMISSION FLUID TEMPERATURE SENSOR A RATIONALITY	●	
3	P0712	TRANSMISSION FLUID TEMPERATURE SENSOR A STUCK OFF(HIGH INPUT)	●	
4	P0713	TRANSMISSION FLUID TEMPERATURE SENSOR A STUCK ON(LOW INPUT)	●	

Automatic Transaxle System

AT-31


5	P0716	A/T INPUT SPEED SENSOR CIRCUIT - OPEN or SHORT(GND)	●	
6	P0721	A/T OUTPUT SPEED SENSOR CIRCUIT - OPEN or SHORT(GND)	●	
7	P0741	TORQUE CONVERTER CLUTCH STUCK OFF	●	
8	P0743	TCC CONTROL SOLENOID VALVE CIRCUIT - OPEN or SHORT(GND)	●	
9	P0748	PRESSURE CONTROL SOLENOID VALVE-A CIRCUIT - OPEN or SHORT(GND)	●	
10	P0751	SHIFT SOLENOID "A(I/C SOLENOID)" PERPOMANCE OR STUCK OFF	●	
11	P0752	SHIFT SOLENOID "A(I/C SOLENOID)" PERPOMANCE OR STUCK ON	●	
12	P0753	SHIFT SOLENOID "A(I/C SOLENOID)" CIRCUIT - OPEN or SHORT(GND)	●	
13	P0756	SHIFT SOLENOID "B(Fr/B SOLENOID)" PERPOMANCE OR STUCK OFF	●	
14	P0757	SHIFT SOLENOID "B(Fr/B SOLENOID)" PERPOMANCE OR STUCK ON	●	
15	P0758	SHIFT SOLENOID "B(Fr/B SOLENOID)" CIRCUIT - OPEN or SHORT(GND)	X	
16	P0761	SHIFT SOLENOID "C(D/C SOLENOID)" PERPOMANCE OR STUCK OFF	X	
17	P0762	SHIFT SOLENOID "C(D/C SOLENOID)" PERPOMANCE OR STUCK ON	X	
18	P0763	SHIFT SOLENOID "C(D/C SOLENOID)" CIRCUIT - OPEN or SHORT(GND)	X	
19	P0766	SHIFT SOLENOID "D(H & LR/C SOLENOID)" PERPOMANCE OR STUCK OFF	X	
20	P0767	SHIFT SOLENOID "D(H & LR/C SOLENOID)" PERPOMANCE OR STUCK ON	●	
21	P0768	SHIFT SOLENOID "D(H & LR/C SOLENOID)" CIRCUIT - OPEN or SHORT(GND)	●	
22	P0772	SHIFT SOLENOID "E(LC/B SOLENOID)" PERPOMANCE OR STUCK OFF	●	
23	P0773	SHIFT SOLENOID "E(LC/B SOLENOID)" CIRCUIT - OPEN or SHORT(GND)	●	
24	P0863	CAN COMMUNICATION BUS OFF	●	
25	P0893	MULTIPLE GEARS ENGAGED	●	

AT-32

Automatic Transaxle System

P0601

COMPONENT LOCATION



SBLAT6200L

DTC DESCRIPTION

The TCU set this code when the ROM I.D is changed by external force or input non-available data.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	• Check sum fault	• Faulty TCM
Enable Conditions	• IG "on"	
Threshold value	• Checksum fault or TCU internal Failure	
Diagnostic Time	• More than 1sec	
Fail Safe	• Locked in 3rd gear	

Monitor Scantool Data

1. Connect scantool to data link connector(DLC).
2. Ignition "ON".
3. Confirm the "ROM I.D".
4. Perform the "ROM UP-DATE".
5. Perform the Re-diagnosis
6. Is "DTC" disappeared?

YES

► Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO


► Replace PCM/TCM as necessary and then go to "Verification of Vehicle Repair" procedure.

Automatic Transaxle System

AT-33

P0641

COMPONENT LOCATION



SBLAT6200L

GENERAL DESCRIPTION

The TCM monitors voltage that supplied to solenoid valve.

DTC DESCRIPTION

The TCM sets this code when supplying voltage to TCM is lower or higher than specification.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	• Check voltage range	• Faulty TCM
Enable Conditions	• Battery voltage > 11.7V	
Threshold value	• 10.4V < Sensor supply voltage > 16V	
Diagnostic Time	• More than 0.2sec	
Fail Safe	• Damper clutch "OFF" • Prevention of pressure adaptation	

AT-34

Automatic Transaxle System

Monitor Scantool Data

1. Connect scantool to data link connector(DLC).
2. Ignition "ON" & Engine "OFF".
3. Monitor the "BATTERY VOLTAGE and A/T MAIN RELAY VOLTAGE" parameter on the scantool.

Specification : approx. 12V

1.11 CURRENT DATA		03/34
✖	BATTERY VOLTAGE	13.8 V
✖	A/T MAIN RELAY VOLTAGE	13.8 V
	ENGINE TORQUE	
	DRIVING PATTERN	
	CALEFF	
	LU CAL.MAP NUMBER	
	LU CAL.GAIN	
	LU CAL.OFFSET	

FIX PART FULL HELP GRPH RCRD

SBLAT6201L

4. Does "BATTERY VOLTAGE and A/T MAIN RELAY VOLTAGE" follow the reference data?

YES

▶ Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

▶ Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

▶ Repair as necessary and go to "Verification of vehicle Repair" procedure.

NO


▶ Go to "Power supply circuit inspection" procedure.

AT-36

Automatic Transaxle System

P0705

COMPONENT LOCATION



SBLAT6100L

GENERAL DESCRIPTION

The TRANSMISSION Range Switch sends the shift lever position information to the TCM using a 5V signal. Deciding each TCM range depend on 4 s/w signal. Standard patterns are fixed and these patterns are on the Specification table as listed below. For example, when s/w 1,2,4 are 'ON(0V)' and s/w 3 is 'OFF(5V)', TCM recognizes 'D Range'.When the shift lever is in the D (Drive) position the output signal of Tansaxle Range Switch is 12V and in all other positions the voltage is 0V. The TCM judges the shift lever position by reading all signals, for the TRANSMISSION Range Switch, simultaneously.

DTC DESCRIPTION

The TCM sets this code when patterns are without Specification of the table shown below. The TRANSMISSION Range Switch has no output signal for an extended period of time.

DTC DETECTING CONDITION

[DSL 2.5]

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Range decision by switch pattern 	<ul style="list-style-type: none"> OPEN OR SHORT IN CIRCUIT Faulty TRANSMISSION RANGE SWITCH Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed $\geq 10\text{km/h}$[6.2MPH] Throttle opening $\geq 12.5\%$ 	
Threshold value	<ul style="list-style-type: none"> Detect irregular range pattern (REFER TO SPECCIFICATION) 	
Diagnostic Time	<ul style="list-style-type: none"> More than 2sec 	
Fail Safe	<ul style="list-style-type: none"> SELECT POSITION IS REGARDED AS "D" INDICATOR DECISION "OFF" START RERAY SIGNAL "OFF" REVERSE LAMP SIGNAL "OFF" 	

Automatic Transaxle System

AT-37

[GSL 3.3/3.8]

Item	Detecting Condition	Possible cause
DTC Strategy	• Range decision by switch pattern	<ul style="list-style-type: none"> • OPEN OR SHORT IN CIRCUIT • Faulty TRANSMISSION RANGE SWITCH • Faulty TCM
Enable Conditions	• Always	
Threshold value	• "INHIBITOR SWITCH" pattern check.	
Diagnostic Time	• More than 10sec	
Fail Safe	<ul style="list-style-type: none"> • SELECT POSITION IS REGARDED AS "D" • INDICATOR DECISION "OFF" • REVERSE LAMP SIGNAL "OFF" 	

SPECIFICATION

A/T RANGE PATTERN

A/T range switch				Range swsitch	Remarks
SW1	SW2	SW3	SW4		
OFF	OFF	OFF	OFF	Pst	P start
OFF	OFF	ON	OFF	P	P
OFF	OFF	ON	ON	P-R	Intermediate
ON	OFF	ON	ON	R	R
ON	OFF	ON	OFF	N-R	Intermediate
ON	OFF	OFF	OFF	Nst	N start
ON	OFF	OFF	ON	N-D	Intermediate
ON	ON	OFF	ON	D	D
OFF	ON	OFF	ON	3	3
OFF	ON	ON	ON	2	2
OFF	ON	ON	OFF	1	1
Irregular Pattern				Other	

[OFF= 5V, ON = 0V]

Monitor Scantool Data

1. Connect scantool to data link connector(DLC).
2. Ignition "ON" & Engine "OFF".
3. Monitor the "TRANSMISSION RANGE SWITCH" parameter on the scantool.
4. Move selector lever from "P" range to "D" range.

AT-38

Automatic Transaxle System

1.3 CURRENT DATA		34/76
* SELECTED LEVER RANGE	P, N	
* SPORTS MODE SELECT	OFF	
* INHIBITOR SW.- 4	OFF	
* INHIBITOR SW.- 3	OFF	
* INHIBITOR SW.- 2	OFF	
* INHIBITOR SW.- 1	OFF	
FLUID PRESSURE SW.- 6		
FLUID PRESSURE SW.- 5		

FIG.1)

1.3 CURRENT DATA		34/76
* SELECTED LEVER RANGE	R	
* SPORTS MODE SELECT	OFF	
* INHIBITOR SW.- 4	ON	
* INHIBITOR SW.- 3	ON	
* INHIBITOR SW.- 2	OFF	
* INHIBITOR SW.- 1	ON	
FLUID PRESSURE SW.- 6		
FLUID PRESSURE SW.- 5		

FIG.2)

1.3 CURRENT DATA		34/76
* SELECTED LEVER RANGE	P, N	
* SPORTS MODE SELECT	OFF	
* INHIBITOR SW.- 4	OFF	
* INHIBITOR SW.- 3	OFF	
* INHIBITOR SW.- 2	OFF	
* INHIBITOR SW.- 1	ON	
FLUID PRESSURE SW.- 6		
FLUID PRESSURE SW.- 5		

FIG.3)

1.3 CURRENT DATA		34/76
* SELECTED LEVER RANGE	D	
* SPORTS MODE SELECT	OFF	
* INHIBITOR SW.- 4	ON	
* INHIBITOR SW.- 3	OFF	
* INHIBITOR SW.- 2	ON	
* INHIBITOR SW.- 1	ON	
FLUID PRESSURE SW.- 6		
FLUID PRESSURE SW.- 5		

FIG.4)

1.3 CURRENT DATA		34/76
* SELECTED LEVER RANGE	SPORTS	
* SPORTS MODE SELECT	ON	
* INHIBITOR SW.- 4	ON	
* INHIBITOR SW.- 3	OFF	
* INHIBITOR SW.- 2	ON	
* INHIBITOR SW.- 1	ON	
FLUID PRESSURE SW.- 6		
FLUID PRESSURE SW.- 5		

FIG.5)

- FIG.1) P RANGE
- FIG.2) R RANGE
- FIG.3) N RANGE
- FIG.4) D RANGE
- FIG.5) SPORTS MODE

5. Does "TRANSMISSION RANGE SWITCH" follow the reference data?

YES

▶ Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

▶ Go to "Terminal & connector inspection"

procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

▶ Repair as necessary and go to "Verification of vehicle Repair" procedure.

SBLAT6101L

Automatic Transaxle System

AT-39


NO

► Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-3/C106-3" connector.
2. Ignition "ON" & Engine "OFF".
3. Measure voltage between each terminal "1,2,3,4" of the TCM side harness connector and chassis ground.

Specification : approx. 5V



1. TRANSMISSION RANGE SWITCH SW1
2. TRANSMISSION RANGE SWITCH SW2
3. TRANSMISSION RANGE SWITCH SW3
4. TRANSMISSION RANGE SWITCH SW4
6. TURBINE SENSOR 1
7. TURBINE SENSOR 2

SBLAT6102L

4. Is voltage within specifications?

YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good PCM/TCM and check for proper operation. If the problem is corrected, replace PCM/TCM as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION

1. Ignition "OFF".
2. Disconnect "C06-3/C106-3" connector.
3. Measure the resistance between each terminal of the sensor.

Specification :



AT-40


Automatic Transaxle System

PIN No.	GND	1(S1)	2(S2)	3(S3)	4(S4)	IND
P-ST	●					P
P-R(middle)	●				●	-
R	●	●		●	●	R
N-R(middle)	●	●	●		●	-
N-ST	●	●				N
N-D(middle)	●	●	●	●		-
D	●	●	●		●	D

● : SWITCH IS ON(GND LEVER)

- : RANGE INDICATER LAMP "OFF" AND MAINTAIN PREVIOUS RANGE

[RANGE SWITCH continuity check table]



- 1. TRANSMISSION RANGE SWITCH SW1
- 2. TRANSMISSION RANGE SWITCH SW2
- 3. TRANSMISSION RANGE SWITCH SW3
- 4. TRANSMISSION RANGE SWITCH SW4
- 6. TURBINE SENSOR 1
- 7. TURBINE SENSOR 2

SBLAT6103L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good "TRANSMISSION RANGE SWITCH" and check for proper operation. If the problem is corrected, replace "TRANSMISSION RANGE SWITCH" as necessary and go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

Automatic Transaxle System

AT-41

P0711

COMPONENT LOCATION



SBLAT6110L

GENERAL DESCRIPTION

The automatic transmission fluid(ATF) temperature sensor A is installed in the INHIBITOR SWITCH and fluid(ATF) temperature sensor B is installed in the valve body. Sensor "B" is measure the oil temperature that inflowed in from Torque convertor. This sensors use a thermistor whose resistance changes according to the temperature changes. The TCM supplies a 5V reference voltage to the sensor, and the output voltage of the sensor changes when the ATF temperature varies. The automatic transmission fluid(ATF) temperature provides very important data for the TCM's control of the Torque Converter Clutch, and is also used for many other purposes.

DTC DESCRIPTION

This DTC is for checking sensor failure. This code is set if the temperature data from Oil Temperature sensor is fixed between -4°F and 32°F or 32°F and 68°F for 10min. after driving a vehicle.

DTC DETECTING CONDITION

[DSL 2.5]

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Fluctuation of A/T fluid temperature 	※ ATF T/S : Automatic Transmission Fluid Temperature Sensor • OPEN OR SHORT IN CIRCUIT • Faulty ATF T/S 1 • Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> A/T range switch is D range Vehicle speed ≥ 6.2MPH(10km/h) Throttle opening ≥ 12.5% Engine speed ≥ 305rpm 	
Threshold value	<ul style="list-style-type: none"> -4°F ≤ A/T fluid temperature < 32°F for cumulative total of 10 minutes or 32°F ≤ A/T fluid temperature < 68°F for cumulative total of 10 minutes(refer fig.2 Diagnostic logic for ATF temp. sensor) 	
Diagnostic Time	<ul style="list-style-type: none"> 10minutes accumulative total 	
Fail Safe	<ul style="list-style-type: none"> S-MODE is Inhibited 5th gear is Inhibite 	

AT-42

Automatic Transaxle System

[GSL 3.3/3.8]

Item	Detecting Condition	Possible cause
DTC Strategy	• Rationality	※ ATF T/S : Automatic Transmission Fluid Temperature Sensor • OPEN OR SHORT IN CIRCUIT • Faulty ATF T/S 1 • Faulty TCM
Enable Conditions	• Always	
Threshold value	• Oil temp. at IG "ON" - Coolant temp. at IG "ON" > 10°C	
Diagnostic Time	• More than 2 sec	
Fail Safe	• Fluid temperature is regarded as 80°C	

SPECIFICATION

	PIN No	TEMPERATURE (°F)	RESISTANCE (KΩ)	VOLTAGE (V)
ATF 1	C06-1/C106-1 : 9 ~ Earth	32	Approx. 15	Approx. 3.3
		68	Approx. 6.5	Approx. 2.7
		176	Approx. 0.9	Approx. 0.9
ATF 2	C06-2/C106-2 : 1 ~ Earth	32	Approx. 10.5	Approx. 3.3
		68	Approx. 4.3	Approx. 2.5
		176	Approx. 0.5	Approx. 0.7

Monitor Scantool Data

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "TRANSAXLE FLUID TEMPERATURE SENSOR "1" parameter on the scantool.

Specification : Increasing Gradually

Automatic Transaxle System

AT-43




FIG.1)




FIG.2)




FIG.3)

FIG.1) Normal

FIG.2) Signal harness open

FIG.3) Signal harness ground short

4. Does "TRANSMISSION FLUID TEMPERATURE SENSOR" follow the reference data?

YES

▶ Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

▶ Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor

connection, bending, corrosion, contamination, deterioration, or damage.

3. Has a problem been found?

YES

▶ Repair as necessary and go to "Verification of vehicle Repair" procedure.

NO

▶ Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION


1. Ignition "ON" & Engine "OFF".
2. Disconnect the "ATF 1[C06-1/C106-1] and ATF 2[C06-2/C106-2]" connector.
3. Measure the voltage between terminal "9" of the "ATF 1 [C06-1/C106-1]" harness connector and chassis ground.

Specification : Approx. 5 V

SBLAT6111L

AT-44

Automatic Transaxle System



C06-1 [DSL 2.5]
C106-1 [GSL 3.3/3.8]

- 1.VIGN-OUT 1
- 2.DATA BIT 1
- 3.PSB 2
- 4.PSC 2
- 5.SEL 1
- 6.SEL 2
- 7.SEL 3
- 8.GND
- 9.ATF 1**
- 10.VSP 1

SBLAT6112L

4. Is voltage within specifications?

YES

▶ Go to "Component Inspection" procedure.

NO

▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Go to "CHECK TCM" of the "Component Inspection" procedure.

COMPONENT INSPECTION

1. CHECK "TRANSMISSION FLUID TEMPERATURE SENSOR"

- 1) Ignition "OFF".
- 2) Disconnect the "ATF 1 [C06-1/C106-1] and ATF 2 [C06-2/C106-2]" connector.
- 3) Measure the resistance between terminal "9" of the "ATF 1 [C06-1/C106-1]" harness connector and chassis ground.


Specification : Refer to " Reference data"

[Reference data]

	PIN No	TEMPERATURE (°F)	RESISTANCE (KΩ)	VOLTAGE (V)
ATF 1	C06-1/C106-1 : 9 ~ Earth	32	Approx. 15	Approx. 3.3
		68	Approx. 6.5	Approx. 2.7
		176	Approx. 0.9	Approx. 0.9
ATF 2	C06-2/C106-2 : 1 ~ Earth	32	Approx. 10.5	Approx. 3.3
		68	Approx. 4.3	Approx. 2.5
		176	Approx. 0.5	Approx. 0.7

Automatic Transaxle System

AT-45



C06-1 [DSL 2.5]
C106-1 [GSL 3.3/3.8]
Component side

- 1.VIGN-OUT 1
- 2.DATA BIT 1
- 3.PSB 2
- 4.PSC 2
- 5.SEL 1
- 6.SEL 2
- 7.SEL 3
- 8.GND
- 9.ATF 1
- 10.VSP 1

SBLAT6113L

4) Is resistance within specifications?

YES

► Go to "CHECK PCM/TCM" as below.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

Replace "TRANSMISSION FLUID TEMPERATURE SENSOR 1" as necessary and Go to "Verification of Vehicle Repair" procedure.

2. CHECK TCM

- 1) Ignition "ON" & Engine "OFF".
- 2) Disconnect the "ATF 1 [C06-1/C106-1]" connector.
- 3) Install scantool and select a SIMU-SCAN.
- 4) Simulate voltage (0→5V) to "TRANSMISSION FLUID TEMPERATURE SENSOR 1, 2" signal circuit.




FIG.1)




FIG.2)

FIG.1) INPUT 1.02V → 63°C

FIG.2) INPUT 2.00V → 33°C

※The values are subject to change according to vehicle model or conditions.

AT-46

Automatic Transaxle System

SBLAT6114L

5) Is FLUID TEMP. SENSOR signal value changed according to simulation voltage?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

▶ Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO

▶ System performing to specification at this time.




Automatic Transaxle System

AT-47

P0712

COMPONENT LOCATION



SBLAT6110L

GENERAL DESCRIPTION

The automatic transmission fluid(ATF) temperature sensor A is installed in the INHIBITOR SWITCH and fluid(ATF) temperature sensor B is installed in the valve body. Sensor "B" is measure the oil temperature that inflowed in from Torque convertor. This sensors use a thermistor whose resistance changes according to the temperature changes. The TCM supplies a 5V reference voltage to the sensor, and the output voltage of the sensor changes when the ATF temperature varies. The automatic transmission fluid(ATF) temperature provides very important data for the TCM's control of the Torque Converter Clutch, and is also used for many other purposes.

DTC DESCRIPTION

This DTC is for checking sensor failure. This code is set if the temperature data from Oil Temperature sensor is fixed between -4°F and 32°F or 32°F and 68°F for 10min. after driving a vehicle.

DTC DETECTING CONDITION

[DSL 2.5]

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Fluctuation of A/T fluid temperature 	※ ATF T/S :Automatic Transmissi-on Fluid Temperature Sensor • OPEN IN CIRCUIT • Faulty ATF T/S 1 • Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> A/T range switch is D range Vehicle speed ≥ 6.2MPH(10km/h) Throttle opening ≥ 12.5% Engine speed ≥ 305rpm 	
Threshold value	<ul style="list-style-type: none"> A/T fluid is below then -4°F for 10 minutes (refer fig. 2 Diagnostic logic for ATF temp. sensor) 	
Diagnostic Time	<ul style="list-style-type: none"> 10minutes accumulative total 	
Fail Safe	<ul style="list-style-type: none"> S-MODE is Inhibited 5th gear is Inhibite 	

AT-48

Automatic Transaxle System

[GSL 3.3/3.8]

Item	Detecting Condition	Possible cause
DTC Strategy	• Check the voltage range	※ ATF T/S : Automatic Transmission Fluid Temperature Sensor • OPEN IN CIRCUIT • Faulty ATF T/S 1
Enable Conditions	• Battery voltage > 10V	
Threshold value	• Input voltage < 0.05V	
Diagnostic Time	• More than 2 sec	
Fail Safe	• Fluid temperature is regarded as 80°C	

SPECIFICATION

	PIN No	TEMPERATURE (°F)	RESISTANCE (KΩ)	VOLTAGE (V)
ATF 1	C06-1/C106-1 : 9 ~ Earth	32	Approx. 15	Approx. 3.3
		68	Approx. 6.5	Approx. 2.7
		176	Approx. 0.9	Approx. 0.9
ATF 2	C06-2/C106-2 : 1 ~ Earth	32	Approx. 10.5	Approx. 3.3
		68	Approx. 4.3	Approx. 2.5
		176	Approx. 0.5	Approx. 0.7

Monitor Scantool Data

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "TRANSAXLE FLUID TEMPERATURE SENSOR "1" parameter on the scantool.

Specification : Increasing Gradually



Automatic Transaxle System

AT-49




FIG.1)




FIG.2)




FIG.3)

FIG.1) Normal

FIG.2) Signal harness open

FIG.3) Signal harness ground short

4. Does "TRANSMISSION FLUID TEMPERATURE SENSOR" follow the reference data?

YES

▶ Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

▶ Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor

connection, bending, corrosion, contamination, deterioration, or damage.

3. Has a problem been found?

YES

▶ Repair as necessary and go to "Verification of vehicle Repair" procedure.

NO

▶ Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION


1. Ignition "ON" & Engine "OFF".
2. Disconnect the "ATF 1[C06-1/C106-1] and ATF 2[C06-2/C106-2]" connector.
3. Measure the voltage between terminal "9" of the "ATF 1 [C06-1/C106-1]" harness connector and chassis ground.

Specification : Approx. 5 V

SBLAT6111L

AT-50

Automatic Transaxle System



C06-1 [DSL 2.5]
C106-1 [GSL 3.3/3.8]

- 1.VIGN-OUT 1
- 2.DATA BIT 1
- 3.PSB 2
- 4.PSC 2
- 5.SEL 1
- 6.SEL 2
- 7.SEL 3
- 8.GND
- 9.ATF 1**
- 10.VSP 1

SBLAT6112L

4. Is voltage within specifications?

YES

▶ Go to "Component Inspection" procedure.

NO

▶ Check for open in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION


1. CHECK "TRANSMISSION FLUID TEMPERATURE SENSOR"

- 1) Ignition "OFF".
- 2) Disconnect the "ATF 1 [C06-1/C106-1] and ATF 2 [C06-2/C106-2]" connector.
- 3) Measure the resistance between terminal "9" of the "ATF 1 [C06-1/C106-1]" harness connector and chassis ground.

Specification : Refer to "Reference data"

[Reference data]

	PIN No	TEMPERATURE (°F)	RESISTANCE (KΩ)	VOLTAGE (V)
ATF 1	C06-1/C106-1 : 9 ~ Earth	32	Approx. 15	Approx. 3.3
		68	Approx. 6.5	Approx. 2.7
		176	Approx. 0.9	Approx. 0.9
ATF 2	C06-2/C106-2 : 1 ~ Earth	32	Approx. 10.5	Approx. 3.3
		68	Approx. 4.3	Approx. 2.5
		176	Approx. 0.5	Approx. 0.7



C06-1 [DSL 2.5]
C106-1 [GSL 3.3/3.8]
Component side

- 1.VIGN-OUT 1
- 2.DATA BIT 1
- 3.PSB 2
- 4.PSC 2
- 5.SEL 1
- 6.SEL 2
- 7.SEL 3
- 8.GND
- 9.ATF 1**
- 10.VSP 1

Automatic Transaxle System

AT-51

SBLAT6113L

4) Is resistance within specifications?

YES

▶ Go to "CHECK PCM/TCM" as below.

NO

▶ Check for open in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

▶ Replace "TRANSMISSION FLUID TEMPERATURE SENSOR 1" as necessary and Go to "Verification of Vehicle Repair" procedure.

2. CHECK TCM

- 1) Ignition "ON" & Engine "OFF".
- 2) Disconnect the "ATF 1 [C06-1/C106-1]" connector.
- 3) Install scantool and select a SIMU-SCAN.
- 4) Simulate voltage (0→5V) to "TRANSMISSION FLUID TEMPERATURE SENSOR 1, 2" signal circuit.




FIG.1)




FIG.2)

FIG.1) INPUT 1.02V → 63°C

FIG.2) INPUT 2.00V → 33°C

※The values are subject to change according to vehicle model or conditions.

SBLAT6114L

5) Is FLUID TEMP. SENSOR signal value changed according to simulation voltage?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to

"Verification of Vehicle Repair" procedure.

NO

▶ Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.

AT-52

Automatic Transaxle System

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

- ▶ Go to the applicable troubleshooting procedure.

NO

- ▶ System performing to specification at this time.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




Automatic Transaxle System

AT-53

P0713

COMPONENT LOCATION



SBLAT6110L

GENERAL DESCRIPTION

The automatic transmission fluid(ATF) temperature sensor A is installed in the INHIBITOR SWITCH and fluid(ATF) temperature sensor B is installed in the valve body. Sensor "B" is measure the oil temperature that inflowed in from Torque convertor. This sensors use a thermistor whose resistance changes according to the temperature changes. The TCM supplies a 5V reference voltage to the sensor, and the output voltage of the sensor changes when the ATF temperature varies. The automatic transmission fluid(ATF) temperature provides very important data for the TCM's control of the Torque Converter Clutch, and is also used for many other purposes.

DTC DESCRIPTION

This DTC is for checking sensor failure. This code is set if the temperature data from Oil Temperature sensor is fixed between -4°F and 32°F or 32°F and 68°F for 10min. after driving a vehicle.

DTC DETECTING CONDITION

[DSL 2.5]

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Fluctuation of A/T fluid temperature 	※ ATF T/S :Automatic Transmissi-on Fluid Temperature Sensor • OPEN IN CIRCUIT • Faulty ATF T/S 1 • Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> A/T range switch is D range Vehicle speed ≥ 6.2MPH(10km/h) Throttle opening ≥ 12.5% Engine speed ≥ 305rpm 	
Threshold value	<ul style="list-style-type: none"> A/T fluid is over than 180degrees for 10 minutes(refer fig.2 Diagnostic logic for ATF temp. sensor) 	
Diagnostic Time	<ul style="list-style-type: none"> 10minutes accumulative total 	
Fail Safe	<ul style="list-style-type: none"> S-MODE is Inhibited 5th gear is Inhibite 	

AT-54

Automatic Transaxle System

[GSL 3.3/3.8]

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Check the voltage range 	※ ATF T/S : Automatic Transmission Fluid Temperature Sensor <ul style="list-style-type: none"> OPEN OR SHORT IN CIRCUIT Faulty ATF T/S 1 Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Oil temp. at IG "ON" ≤ -39°C Engine speed > 1000rpm Output speed ≥ 500rpm Engine coolant temp. ≥ 70°C Delay time = 160sec 	
Threshold value	<ul style="list-style-type: none"> Input voltage > 4.8V 	
Diagnostic Time	<ul style="list-style-type: none"> 10 minutes accumulative total 	
Fail Safe	<ul style="list-style-type: none"> Fluid temperature is regarded as 80°C 	

SPECIFICATION

	PIN No	TEMPERATURE (°F)	RESISTANCE (KΩ)	VOLTAGE (V)
ATF 1	C06-1/C106-1 : 9 ~ Earth	32	Approx. 15	Approx. 3.3
		68	Approx. 6.5	Approx. 2.7
		176	Approx. 0.9	Approx. 0.9
ATF 2	C06-2/C106-2 : 1 ~ Earth	32	Approx. 10.5	Approx. 3.3
		68	Approx. 4.3	Approx. 2.5
		176	Approx. 0.5	Approx. 0.7

Monitor Scantool Data

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "TRANSAXLE FLUID TEMPERATURE SENSOR "1" parameter on the scantool.

Specification : Increasing Gradually

Automatic Transaxle System

AT-55




FIG.1)




FIG.2)




FIG.3)

FIG.1) Normal

FIG.2) Signal harness open

FIG.3) Signal harness ground short

4. Does "TRANSMISSION FLUID TEMPERATURE SENSOR" follow the reference data?

YES

▶ Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

▶ Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor

connection, bending, corrosion, contamination, deterioration, or damage.

3. Has a problem been found?

YES

▶ Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

▶ Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION


1. Ignition "ON" & Engine "OFF".
2. Disconnect the "ATF 1 [C06-1/C106-1] and ATF 2 [C06-2/C106-2]" connector.
3. Measure the voltage between terminal "9" of the "ATF 1 [C06-1/C106-1]" harness connector and chassis ground.

Specification : Approx. 5 V

SBLAT6111L

AT-56

Automatic Transaxle System



C06-1 [DSL 2.5]
C106-1 [GSL 3.3/3.8]

- 1.VIGN-OUT 1
- 2.DATA BIT 1
- 3.PSB 2
- 4.PSC 2
- 5.SEL 1
- 6.SEL 2
- 7.SEL 3
- 8.GND
- 9.ATF 1
- 10.VSP 1

SBLAT6112L

4. Is voltage within specifications?

YES

► Go to "Component Inspection" procedure.

NO

► Check for short to ground in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION

1. CHECK "TRANSMISSION FLUID TEMPERATURE SENSOR"

- 1) Ignition "OFF".
- 2) Disconnect the "ATF 1 [C06-1/C106-1] and ATF 2 [C06-2/C106-2]" connector.
- 3) Measure the resistance between terminal "9" of the "ATF 1 [C06-1/C106-1]" harness connector and chassis ground.


Specification : Refer to "Reference data"

[Reference data]

	PIN No	TEMPERATURE (°F)	RESISTANCE (KΩ)	VOLTAGE (V)
ATF 1	C06-1/C106-1 : 9 ~ Earth	32	Approx. 15	Approx. 3.3
		68	Approx. 6.5	Approx. 2.7
		176	Approx. 0.9	Approx. 0.9
ATF 2	C06-2/C106-2 : 1 ~ Earth	32	Approx. 10.5	Approx. 3.3
		68	Approx. 4.3	Approx. 2.5
		176	Approx. 0.5	Approx. 0.7

Automatic Transaxle System

AT-57



C06-1 [DSL 2.5]
C106-1 [GSL 3.3/3.8]
Component side

- 1.VIGN-OUT 1
- 2.DATA BIT 1
- 3.PSB 2
- 4.PSC 2
- 5.SEL 1
- 6.SEL 2
- 7.SEL 3
- 8.GND
- 9.ATF 1
- 10.VSP 1

SBLAT6113L

4) Is resistance within specifications?

YES

▶ Go to "CHECK PCM/TCM" as below.

NO

▶ Check for short to ground in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

▶ Replace "TRANSMISSION FLUID TEMPERATURE SENSOR 1" as necessary and Go to "Verification of Vehicle Repair" procedure.

2. CHECK TCM

- 1) Ignition "ON" & Engine "OFF".
- 2) Disconnect the "ATF 1 [C06-1/C106-1]" connector.
- 3) Install scantool and select a SIMU-SCAN.
- 4) Simulate voltage (0→5V) to "TRANSMISSION FLUID TEMPERATURE SENSOR 1, 2" signal circuit.





FIG.1) INPUT 1.02V → 63°C
FIG.2) INPUT 2.00V → 33°C

*The values are subject to change according to vehicle model or conditions.

AT-58

Automatic Transaxle System

SBLAT6114L

5) Is FLUID TEMP. SENSOR signal value changed according to simulation voltage?

YES

► Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

► Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

► Go to the applicable troubleshooting procedure.

NO

► System performing to specification at this time.




Automatic Transaxle System

AT-59

P0716

COMPONENT LOCATION



SBLAT6120L

GENERAL DESCRIPTION

The Input Sensor of RXC Auto transmission is composed of S1(Sensor1) and S2(Sensor2). S1 inputs signal to TCM only at 4th gear and S2 does at 1st, 2nd, 3rd, 4th and 5th gear. Therefore, sensing pulse frequency outputted from 2 of signal, TCM calculates Inputshaft speed and compute Turbine rotation. This value is mainly used to control the optimum fluid pressure during shifting.

DTC DESCRIPTION

The TCM sets this code if an output pulse-signal is not detected, from the INPUT SPEED SENSOR 1 or 2, when the vehicle is running faster than 24.85MPH(40km/h). The Fail-Safe function will be set by the TCM if this code is detected.

DTC DETECTING CONDITION

[DSL 2.5]

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Speed rationality check 	<ul style="list-style-type: none"> Signal circuit is open or short Sensor power circuit is open Sensor ground circuit is open Faulty INPUT SPEED SENSOR 1 Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed > 24.85MPH(40km/h) Engine speed > 1500 rpm Throttle opening ≥ 12.5% A/T range switch is D range 	
Threshold value	<ul style="list-style-type: none"> Input speed < 600rpm 	
Diagnostic Time	<ul style="list-style-type: none"> more than 5sec 	
Fail Safe	<ul style="list-style-type: none"> "Nt" is regarded as 600rpm(Nt = 600rpm) S-MODE is Inhibited 5th gear is Inhibited 	

AT-60

Automatic Transaxle System

[GSL 3.3/3.8]

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Speed rationality check 	<ul style="list-style-type: none"> Signal circuit is open or short Sensor power circuit is open Sensor ground circuit is open Faulty INPUT SPEED SENSOR 1 Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Battery voltage > 10V Output speed > 200rpm Engine speed > 700 rpm State of "TRANSMISSION" is "STATIC" The time after the last shift was finished 500sec 	
Threshold value	<ul style="list-style-type: none"> Input speed1 > 50rpm 	
Diagnostic Time	<ul style="list-style-type: none"> More than 2sec 	
Fail Safe	<ul style="list-style-type: none"> "Input speed" is regarded as 600rpm(Nt = 600rpm) Shift prevention over 4th gear Prevention of manual shift Prevention of pressure adaptation 	

Signal Waveform




FIG.1)

FIG.1) 1GEAR
FIG.2) 4 GEAR




FIG.2)

Caution: TURBINE SENSOR 2 CAN BE DETECTED 5V IN FIG.1

SBLAT6121L

SPECIFICATION

NAME	PIN NO	Measurement condition	Spec
Turbine Sensor1	6	<ul style="list-style-type: none"> 1gear 12.42MPH(20km/h) Idle SW OFF 	Approx. 1.1K(Hz)
Turbine Sensor2	7	<ul style="list-style-type: none"> 4gear 31MPH(50km/h) Idle SW OFF 	

CAUTION

Scan tool data link cable is maintain to connecting condition.

Automatic Transaxle System

AT-61

Monitor Scantool Data

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "INPUT SPEED SENSOR 1" parameter on the scantool.
4. Driving at speed of over 12.42MPH(20km/h) at 1gear.

Specification : Increasing Gradually

1.3 CURRENT DATA		05/76
✖	TURBIN SPEED SENSOR	704 rpm
✖	ENGINE SPEED	736 rpm
	DAMPER CLUTCH SL.RPM	
	ACCEL. OPEN SIGNAL	
	TPS OPEN SIGNAL	
	ACCEL. FULL SW(CAL.)	
	ACCEL. IDLE SW(CAL.)	
	FLUID TEMP-1(F.FAN)	

FIG.1)

FIG.1) Low speed
FIG.2) High speed

1.3 CURRENT DATA		05/76
✖	TURBIN SPEED SENSOR	3744 rpm
✖	ENGINE SPEED	3744 rpm
	DAMPER CLUTCH SL.RPM	
	ACCEL. OPEN SIGNAL	
	TPS OPEN SIGNAL	
	ACCEL. FULL SW(CAL.)	
	ACCEL. IDLE SW(CAL.)	
	FLUID TEMP-1(F.FAN)	

FIG.2)

5. Does "INPUT SPEED SENSOR" follow the reference data?

YES

▶ Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

▶ Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination,

deterioration, or damage.

3. Has a problem been found?

YES

▶ Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

▶ Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION


1. Ignition "ON" & Engine "OFF".
2. Disconnect the "C06-3/C106-3" connector.
3. Measure voltage between terminal "6" of the C06-3/C106-3 harness connector and chassis ground.

Specification : Approx. 5 V

SBLAT6122L

AT-62

Automatic Transaxle System



1. TRANSMISSION RANGE SWITCH SW1
2. TRANSMISSION RANGE SWITCH SW2
3. TRANSMISSION RANGE SWITCH SW3
4. TRANSMISSION RANGE SWITCH SW4
- 6. TURBINE SENSOR 1**
7. TURBINE SENSOR 2

SBLAT6123L

4. Is voltage within specifications?

YES

▶ Go to "Power supply circuit inspection" procedure.

NO


▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Go to "Check TCM" of the "Component Inspection" procedure.

Power supply circuit inspection

1. Remove "OIL PAN".
2. Ignition "ON", Engine "OFF".
3. Connect the "C06-3/C106-3 and Shift CM" connector.
4. Measure resistance between terminal "4" of the TURBINE SENSOR harness connector and chassis ground.

Specification : approx. 12V



SBLAT6124L

5. Is voltage within specifications ?

YES

▶ Go to "Ground circuit inspection" procedure.

NO

▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair"

Automatic Transaxle System

AT-63

procedure.


If power circuit in harness is OK, Substitute with a known-good Shift CM and check for proper operation.

If the problem is corrected, replace Shift CM as necessary and go to "Verification of Vehicle Repair" procedure.

Ground circuit inspection

1. Remove "OIL PAN".
2. Engine "OFF".
3. Disconnect the "C06-3/C106-3 and Shift CM" connector.
4. Measure resistance between terminal "3" of the INPUT SPEED SENSOR harness connector and chassis ground.

Specification : approx. 0Ω



SBLAT6125L

5. Is resistance within specifications?

YES

- ▶ Go to "Component inspection" procedure.

NO

- ▶ Check for open in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION

1. Check "TURBINE SENSOR 2"
 - 1) Ignition "ON" & Engine "OFF".
 - 2) Connect the "C06-3/C106-3" connector.
 - 3) Measure Frequency between terminal "6" of the C06-3/C106-3 harness connector and chassis ground.

Specification :

NAME	PIN NO	Measurement condition	Spec
------	--------	-----------------------	------


AT-64

Automatic Transaxle System

Turbine Sensor1	6	<ul style="list-style-type: none"> • 1gear • 12.42MPH(20km/h) • Idle SW OFF 	Approx. 1.1K(Hz)
Turbine Sensor2	7	<ul style="list-style-type: none"> • 4gear • 31MPH(50km/h) • Idle SW OFF 	

CAUTION

Scan tool data link cable is maintain to connecting condition.



SBLAT6126L

4) Is frequency within specifications?

YES

► Go to "CHECK TCM " as below.

NO

► Replace "TURBINE SENSOR" as necessary and Go to "Verification of Vehicle Repair" procedure.

2. CHECK TCM

- 1) Ignition "ON" & Engine "OFF".
- 2) Disconnect "C06-3/C106-3" connector.
- 3) Install scantool and select a SIMU-SCAN.
- 4) Simulate frequency to TURBINE SENSOR 1 signal circuit.



Automatic Transaxle System

AT-65





FIG.1)

FIG.2)

FIG.1) INPUT 150HZ → 224rpm

FIG.2) INPUT 250HZ → 352rpm

※The values are subject to change according to vehicle model or conditions.

SBLAT6127L

5) Is "TURBINE SENSOR 1" signal value changed according to simulation frequency?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

▶ Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.

▶ System performing to specification at this time.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.


NO

AT-66

Automatic Transaxle System

P0717

COMPONENT LOCATION



SBLAT6120L

GENERAL DESCRIPTION

The Input Sensor of RXC Auto transmission is composed of S1(Sensor1) and S2(Sensor2). S1 inputs signal to TCM only at 4th gear and S2 does at 1st, 2nd, 3rd, 4th and 5th gear. Therefore, sensing pulse frequency outputted from 2 of signal, TCM calculates Inputshaft speed and compute Turbine rotation. This value is mainly used to control the optimum fluid pressure during shifting.

DTC DESCRIPTION

The TCM sets this code if an output pulse-signal is not detected, from the INPUT SPEED SENSOR 1 or 2, when the vehicle is running faster than 24.85MPH(40km/h). The Fail-Safe function will be set by the TCM if this code is detected.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Speed rationality check 	<ul style="list-style-type: none"> Signal circuit is open or short Sensor power circuit is open Sensor ground circuit is open Faulty INPUT SPEED SENSOR 1 Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Battery voltage > 10V Output speed > 1000rpm Engine speed(Only current gear is the 1st gear) > 3000 rpm Engine speed(2.3.4.5 gear) > 700 rpm Position lever = "D" 	
Threshold value	<ul style="list-style-type: none"> Input speed1 ≤ 50rpm 	
Diagnostic Time	<ul style="list-style-type: none"> More than 2sec 	
Fail Safe	<ul style="list-style-type: none"> "Input speed" is regarded as 600rpm(Nt = 600rpm) Shift prevention over 4th gear Prevention of manual shift Prevention of pressure adaptation 	

Automatic Transaxle System

AT-67

Signal Waveform




FIG.1)

FIG.1) 1GEAR
FIG.2) 4 GEAR




FIG.2)

Caution: TURBINE SENSOR 2 CAN BE DETECTED 5V IN FIG.1

SBLAT6121L

SPECIFICATION

NAME	PIN NO	Measurement condition	Spec
Turbine Sensor1	6	<ul style="list-style-type: none"> 1gear 12.42MPH(20km/h) Idle SW OFF 	Approx. 1.1K(Hz)
Turbine Sensor2	7	<ul style="list-style-type: none"> 4gear 31MPH(50km/h) Idle SW OFF 	

CAUTION

Scan tool data link cable is maintain to connecting condition.

Monitor Scantool Data

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "INPUT SPEED SENSOR 1" parameter on the scantool.
4. Driving at speed of over 12.42MPH(20km/h) at 1gear.

Specification : Increasing Gradually

AT-68

Automatic Transaxle System

1.11 CURRENT DATA 01/59	
* ENGINE SPEED	706 rpm
* INPUT SPEED(PG-A)	650.0rpm
* TURBIN SPEED SENDOR 1	0.0 rpm
* TURBIN SPEED SENDOR 2	620.0rpm
* TCC SLIP RPM	25.0 rpm
* CURRENT GEAR POSITION	P N
* SELECTED LEVER RANGE	P
INHIBITOR SWITCH 1	

FIG.1)

1.11 CURRENT DATA 01/59	
* ENGINE SPEED	661 rpm
* INPUT SPEED(PG-A)	0.0 rpm
* TURBIN SPEED SENDOR 1	0.0 rpm
* TURBIN SPEED SENDOR 2	0.0 rpm
* TCC SLIP RPM	650.0rpm
* CURRENT GEAR POSITION	REVERSE
* SELECTED LEVER RANGE	R
INHIBITOR SWITCH 1	

FIG.2)

1.11 CURRENT DATA 01/59	
* ENGINE SPEED	656 rpm
* INPUT SPEED(PG-A)	0.0 rpm
* TURBIN SPEED SENDOR 1	0.0 rpm
* TURBIN SPEED SENDOR 2	0.0 rpm
* TCC SLIP RPM	654.0rpm
* CURRENT GEAR POSITION	1 GEAR
* SELECTED LEVER RANGE	D
INHIBITOR SWITCH 1	

FIG.3)

1.11 CURRENT DATA 01/59	
* ENGINE SPEED	1927 rpm
* INPUT SPEED(PG-A)	1890. rpm
* TURBIN SPEED SENDOR 1	0.0 rpm
* TURBIN SPEED SENDOR 2	1887. rpm
* TCC SLIP RPM	14.0 rpm
* CURRENT GEAR POSITION	1 GEAR
* SELECTED LEVER RANGE	D
INHIBITOR SWITCH 1	

FIG.4)

1.11 CURRENT DATA 01/59	
* ENGINE SPEED	1885 rpm
* INPUT SPEED(PG-A)	1862. rpm
* TURBIN SPEED SENDOR 1	0.0 rpm
* TURBIN SPEED SENDOR 2	1857. rpm
* TCC SLIP RPM	26.0 rpm
* CURRENT GEAR POSITION	2 GEAR
* SELECTED LEVER RANGE	D
INHIBITOR SWITCH 1	

FIG.5)

1.11 CURRENT DATA 01/59	
* ENGINE SPEED	2140 rpm
* INPUT SPEED(PG-A)	2116. rpm
* TURBIN SPEED SENDOR 1	0.0 rpm
* TURBIN SPEED SENDOR 2	2079. rpm
* TCC SLIP RPM	32.0 rpm
* CURRENT GEAR POSITION	3 GEAR
* SELECTED LEVER RANGE	D
INHIBITOR SWITCH 1	

FIG.6)

1.11 CURRENT DATA 01/59	
* ENGINE SPEED	1987 rpm
* INPUT SPEED(PG-A)	1986. rpm
* TURBIN SPEED SENDOR 1	1030. rpm
* TURBIN SPEED SENDOR 2	3022. rpm
* TCC SLIP RPM	0.0 rpm
* CURRENT GEAR POSITION	4 GEAR
* SELECTED LEVER RANGE	D
INHIBITOR SWITCH 1	

FIG.7)

1.11 CURRENT DATA 01/59	
* ENGINE SPEED	2038 rpm
* INPUT SPEED(PG-A)	2040. rpm
* TURBIN SPEED SENDOR 1	0.0 rpm
* TURBIN SPEED SENDOR 2	2072. rpm
* TCC SLIP RPM	0.0 rpm
* CURRENT GEAR POSITION	5 GEAR
* SELECTED LEVER RANGE	D
INHIBITOR SWITCH 1	

FIG.8)

FIG.1) "P,N" range

FIG.2) "R" range

FIG.3) "D" range 1st gear, vehicle speed = 0

FIG.4) "D" range 1st gear

FIG.5) "D" range 2nd gear

FIG.6) "D" range 3rd gear

FIG.7) "D" range 4th gear

FIG.8) "D" range 5th gear

SBLAT6203L

5. Does "INPUT SPEED SENSOR" follow the reference data?

YES

► Fault is intermittent caused by poor contact in the

Automatic Transaxle System

AT-69

sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and go to "Verification of Vehicle Repair" procedure.


NO

► Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Ignition "ON" & Engine "OFF".
2. Disconnect the "C106-3" connector.
3. Measure voltage between terminal "6" of the C106-3 harness connector and chassis ground.

Specification : Approx. 5 V



1. TRANSMISSION RANGE SWITCH SW1
2. TRANSMISSION RANGE SWITCH SW2
3. TRANSMISSION RANGE SWITCH SW3
4. TRANSMISSION RANGE SWITCH SW4
- 6. TURBINE SENSOR 1**
7. TURBINE SENSOR 2

SBLAT6204L

4. Is voltage within specifications?

YES

► Go to "Power supply circuit inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

AT-70



Automatic Transaxle System

If signal circuit in harness is OK, Go to "Check TCM" of the "Component Inspection" procedure.

Power supply circuit inspection

1. Remove "OIL PAN".
2. Ignition "ON", Engine "OFF".
3. Connect the "C106-3 and Shift CM" connector.
4. Measure resistance between terminal "4" of the TURBINE SENSOR harness connector and chassis ground.

Specification : approx. 12V



5. Is voltage within specifications ?

YES

▶ Go to "Ground circuit inspection" procedure.

NO

▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If power circuit in harness is OK, Substitute with a known-good Shift CM and check for proper operation. If the problem is corrected, replace Shift CM as necessary and go to "Verification of Vehicle Repair" procedure.


Ground circuit inspection

1. Remove "OIL PAN".
2. Engine "OFF".
3. Disconnect the "C106-3 and Shift CM" connector.
4. Measure resistance between terminal "3" of the INPUT SPEED SENSOR harness connector and chassis ground.

Specification : approx. 0Ω

Automatic Transaxle System

AT-71



SBLAT6125L

5. Is resistance within specifications?

YES

▶ Go to "Component inspection" procedure.

NO

▶ Check for open in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION

1. Check "TURBINE SENSOR 2"

- 1) Ignition "ON" & Engine "OFF".
- 2) Connect the "C106-3" connector.
- 3) Measure Frequency between terminal "6" of the C106-3 harness connector and chassis ground.

Specification :


NAME	PIN NO	Measurement condition	Spec
Turbine Sensor1	6	<ul style="list-style-type: none"> • 1gear • 12.42MPH(20km/h) • Idle SW OFF 	Approx. 1.1K(Hz)
Turbine Sensor2	7	<ul style="list-style-type: none"> • 4gear • 31MPH(50km/h) • Idle SW OFF 	

CAUTION

Scan tool data link cable is maintain to connecting condition.

AT-72

Automatic Transaxle System



1. TRANSMISSION RANGE SWITCH SW1
2. TRANSMISSION RANGE SWITCH SW2
3. TRANSMISSION RANGE SWITCH SW3
4. TRANSMISSION RANGE SWITCH SW4
6. TURBINE SENSOR 1
7. TURBINE SENSOR 2

SBLAT6205L

4) Is frequency within specifications?

YES

▶ Go to "CHECK TCM " as below.

NO

▶ Replace "TURBINE SENSOR" as necessary and Go to "Verification of Vehicle Repair" procedure.

2. CHECK TCM

- 1) Ignition "ON" & Engine "OFF".
- 2) Disconnect "C106-3" connector.
- 3) Install scantool and select a SIMU-SCAN.
- 4) Simulate frequency to TURBINE SENSOR 1 signal circuit.




FIG.1) INPUT 150HZ → 224rpm

FIG.2) INPUT 250HZ → 352rpm

*The values are subject to change according to vehicle model or conditions.

SBLAT6127L

5) Is "TURBINE SENSOR 1" signal value changed according to simulation frequency?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to

Automatic Transaxle System

AT-73

"Verification of Vehicle Repair" procedure.

NO

▶ Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO

▶ System performing to specification at this time.



شرکت دیجیتال خودرو (مسئولیت محدود)


اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

AT-74

Automatic Transaxle System

P0721

COMPONENT LOCATION



SBLAT6130L

GENERAL DESCRIPTION

The OUTPUT SPEED SENSOR outputs waveform signals according to the revolutions of the output shaft of the transmission. The Output Speed Sensor is installed in front of the Parking Gear to determine the Parking Gear rpms by counting the frequency of the pulses. This value, together with the throttle position data, is mainly used to decide the optimum gear position.

DTC DESCRIPTION

The TCM sets this code if the calculated value of the signals is noticeably different from the value calculated, using the Vehicle Speed Sensor output, when the vehicle is running faster than 18.6MPH(30km/h). The TCM will initiate the fail safe function if this code is detected.

DTC DETECTING CONDITION

[DSL 2.5]

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Speed rationality check 	<ul style="list-style-type: none"> Signal circuit is open or short Sensor power circuit is open Sensor ground circuit is open Faulty OUTPUT SPEED SENSOR Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed \geq 18.6MPH(30km/h) or engine speed $>$ 3500 rpm (in case of failure at vehicle speed) A/T range switch is D range Throttle opening \geq 12.5% 	
Threshold value	<ul style="list-style-type: none"> output speed $<$ 5 pulse (Reference 18 pulses per 1 output revolution) 	
Diagnostic Time	<ul style="list-style-type: none"> more than 2sec 	
Fail Safe	<ul style="list-style-type: none"> Substitute for VSS. If Faulty in VSS, Locked into 4th gear (RETURN TO FAILSAFE: $5 <$ Vehicle speed $<$ 20 SENSOR 1,2) 	

Automatic Transaxle System

AT-75

[GSL 3.3/3.8]

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Speed rationality check 	<ul style="list-style-type: none"> Signal circuit is open or short Sensor power circuit is open Sensor ground circuit is open Faulty OUTPUT SPEED SENSOR Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Battery voltage > 10V Lever position = "D" Input speed > 1200 rpm Output speed > 3000 rpm 	
Threshold value	<ul style="list-style-type: none"> Output speed = 0 rpm 	
Diagnostic Time	<ul style="list-style-type: none"> More than 4sec 	
Fail Safe	<ul style="list-style-type: none"> Shift prevention over 4th gear Prevention of manual shift Prevention of pressure adaptation Output speed from vehicle speed 	

Signal Waveform





FIG.1)

FIG.2)

FIG.1) LOW - SPEED
FIG.2) HIGH - SPEED

SBLAT6131L

SPECIFICATION

NAME	PIN NO	Measurement condition	Spec
OUTPUT SPEED SENSOR	10	• 12.42MPH(20km/h)	Approx. 149(Hz)

AT-76

Automatic Transaxle System

Monitor Scantool Data

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "OUTPUT SPEED SENSOR" parameter on the scantool.
4. Driving at speed of over 5km/h.

Specification : Increasing Gradually

1.3 CURRENT DATA		02/76
✖ USS 1(A/T)	11 MPH	
✖ USS 2(ECU)	11 MPH	
✖ OUTPUT SPEED SNSR	448 rpm	
✖ TURBIN SPEED SENSOR	1760 rpm	
✖ ENGINE SPEED	1760 rpm	
✖ CURRENT GEAR POS.	1 GEAR	
✖ CURRENT SHIFT MODE	SPORTS	
✖ SELECTED LEVER RANGE	SPORTS	

FIG.1)

1.3 CURRENT DATA		02/76
✖ USS 1(A/T)	50 MPH	
✖ USS 2(ECU)	50 MPH	
✖ OUTPUT SPEED SNSR	2016 rpm	
✖ TURBIN SPEED SENSOR	1664 rpm	
✖ ENGINE SPEED	1728 rpm	
✖ CURRENT GEAR POS.	5 GEAR	
✖ CURRENT SHIFT MODE	SPORTS	
✖ SELECTED LEVER RANGE	D	

FIG.2)

FIG.1) Low-speed
FIG.2) High-speed

5. Does "OUTPUT SPEED SENSOR" follow the reference data?

YES

▶ Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

▶ Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination,

deterioration, or damage.

3. Has a problem been found?

YES

▶ Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

▶ Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION


1. CHECK "OUTPUT SPEED SENSOR SIGNAL CIRCUIT 1"
 - 1) Ignition "ON" & Engine "OFF".
 - 2) Disconnect the "C06-1/C106-1" connector.
 - 3) Measure voltage between terminal "10" of the C06-1/C106-1 harness connector and chassis ground.

Specification : approx. 5V

SBLAT6132L

Automatic Transaxle System

AT-77



C06-1 [DSL 2.5]
C106-1 [GSL 3.3/3.8]

- 1.VIGN-OUT 1
- 2.DATA BIT 1
- 3.PSB 2
- 4.PSC 2
- 5.SEL 1
- 6.SEL 2
- 7.SEL 3
- 8.GND
- 9.ATF 1
- 10.OUTPUT SPEED SENSOR

SBLAT6133L

4) Is voltage within specifications?

YES

► Go to "OUTPUT SPEED SENSOR SIGNAL CIRCUIT 2" as below.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.



If signal circuit in harness is OK, Go to "Component Inspection" procedure.

2. CHECK "OUTPUT SPEED SENSOR SIGNAL CIRCUIT 2"

- 1) Remove "OIL PAN".
- 2) Connect the "C06-1/C106-1" connector.
- 3) Ignition "ON" & Engine "OFF".
- 4) Disconnect the "OUTPUT SPEED SENSOR" connector.
- 5) Measure voltage between terminal "WHITE COLOR" of the OUTPUT SPEED SENSOR harness connector and chassis ground.

Specification : approx. 5V

(TRANSMISSION RANGE SWITCH SIDE)



SBLAT6134L

AT-78

Automatic Transaxle System

6) Is voltage within specifications?

YES

► Go to "Power supply circuit inspection" procedure.

NO

► Check for open or short in harness(H-02[A]~TRANSMISSION RANGE SWITCH). Repair as necessary and Go to "Verification of Vehicle Repair" procedure.



If signal circuit in harness is OK, Replace "TRANSMISSION RANGE SWITCH" as necessary and Go to "Verification of Vehicle Repair" procedure.

Power supply circuit inspection

1. Remove "OIL PAN".
2. Connect the "C06-1/C106-1" connector.
3. Ignition "ON" & Engine "OFF".
4. Disconnect the "OUTPUT SPEED SENSOR" connector.
5. Measure voltage between terminal "PINK COLOR" of the OUTPUT SPEED SENSOR harness connector and chassis ground.

Specification : approx. 12V

(TRANSMISSION RANGE SWITCH SIDE)



SBLAT6135L

6. Is voltage within specifications?

YES

► Go to "Ground circuit Inspection" procedure.

NO

► Replace "TRANSMISSION RANGE SWITCH" as necessary and Go to "Verification of Vehicle Repair"

procedure.

Ground circuit inspection

1. Ignition "OFF" & Engine "OFF".
2. Remove "OIL PAN".
3. Connect the "C06-1/C106-1" connector.
4. Disconnect the "OUTPUT SPEED SENSOR" connector.



Automatic Transaxle System

AT-79

5. Measure resistance between terminal "BLACK COLOR" of the OUTPUT SPEED SENSOR harness connector and chassis ground.

Specification : approx. 0Ω

(TRANSMISSION RANGE SWITCH SIDE)



SBLAT6136L

6. Is resistance within specifications?

YES

- ▶ Substitute with a known-good "OUTPUT SPEED SENSOR" and check for proper operation. If the problem is corrected, replace "OUTPUT SPEED SENSOR" as necessary and go to "Verification of Vehicle Repair" procedure.

NO

- ▶ Replace "TRANSMISSION RANGE SWITCH" as necessary and Go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION

CHECK TCM

1. Ignition "ON" & Engine "OFF".
2. Disconnect "C06-1/C106-1" connector.
3. Install scantool and select a SIMU-SCAN.
4. Simulate frequency to OUTPUT SPEED SENSOR signal circuit.

AT-80

Automatic Transaxle System





FIG.1)

FIG.2)

FIG.1) INPUT 150HZ → 480rpm

FIG.2) INPUT 250HZ → 800rpm

※The values are subject to change according to vehicle model or conditions.

SBLAT6137L

5. Is "OUTPUT SPEED SENSOR" signal value changed according to simulation frequency?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

▶ Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO

▶ System performing to specification at this time.




Automatic Transaxle System

AT-81

P0731

COMPONENT LOCATION



SBLAT6210L

GENERAL DESCRIPTION

The value of the input shaft speed should be equal to the value of the output shaft speed, when multiplied by the 1st gear ratio, while the transaxle is engaged in the 1st gear. For example, if the output speed is 1000 rpm and the 1st gear ratio is 3.827, then the input speed is 3827 rpm.

DTC DESCRIPTION

This code is set if the value of input shaft speed is not equal to the value of the output shaft, when multiplied by the 1st gear ratio, while the transaxle is engaged in 1st gear. This malfunction is mainly caused by mechanical troubles such as control valve sticking or solenoid valve malfunctioning rather than an electrical issue.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> 1st gear incorrect ratio 	<ul style="list-style-type: none"> Faulty input speed sensor Faulty output speed sensor Faulty inside transmission element
Enable Conditions	<ul style="list-style-type: none"> Engine speed > 600rpm 150rpm > Output speed < 6000rpm Lever Position = "D" Input speed > 600rpm A/T oil temp output $\geq -10^{\circ}\text{C}$ Throttle opening > 15% The time after the last shift was finish > 1sec 	
Threshold value	<ul style="list-style-type: none"> $\text{Input speed} - \text{output speed} \times 1\text{st gear ratio} \geq 200\text{rpm}$ 	
Diagnostic Time	<ul style="list-style-type: none"> More than 1sec 	
Fail Safe	<ul style="list-style-type: none"> 4th gear Limp-Home mode 	

AT-82

Automatic Transaxle System

SIGNAL WAVEFORM




FIG.1)

A : INPUT SPEED SENSOR
 B : OUTPUT SPEED SENSOR

SBLAT6211L

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "ENGINE SPEED, INPUT SPEED SENSOR, OUTPUT SPEED SENSOR, GEAR POSITION" parameter on the scantool.
4. Perform the "STALL TEST" with gear position "1"

Specification : 2300 ± 200 engine rpm



1.11 CURRENT DATA		01/59
×	ENGINE SPEED	2233 rpm
×	INPUT SPEED(PG-A)	0.0 rpm
×	OUTPUT SPEED(PG-B)	0.0 rpm
×	CURRENT GEAR POSITION	1 GEAR
×	SELECTED LEVER RANGE	D
	ACC ON FLAG	
	SPORTS MODE SWITCH	
	SPORTS MODE UP SW	

SBLAT6212L

Automatic Transaxle System

AT-83

OPERATING ELEMENT OF EACH SHIFTING RANGE

Shifting Position	Input clutch	High&Low Reverse Clutch	Direct clutch	Reverse Brake	Front Brake	Low Coast Brake	Forward Brake	1st OwnWayClutch	Forward OwnWayClutch	3rd OwnWayClutch
P		▲			▲					
R		●		●	●			●		●
N		▲			▲	★				
D	1st gear	★			▲		●	●	●	●
	2nd gear		●		▲		●		●	●
	3rd gear		●	●	●		▲	◆		●
	4th gear	●	●	●			▲	◆		
	5th gear	●	●			●	▲	◆		◆

● : WORKING.

◆ : PARTICIPATE IN DELIVERY TORQUE WHEN COAST DRIVING.

▲ : SUPPLING OIL PRESSURE TO ELEMENT, BUT NOT EFFECT ON OUTPUT.

★ : TEMPORARY WORKING.

SBLAT6213L

Stall test procedure in D1 and reason

Procedure

1. Warm up the engine
2. After positioning the select lever in "D", depress the foot brake pedal fully. After that, depress the accelerator pedal to the maximum

* The slippage of 1st gear operating parts can be detected by stall test in D

Reason for stall test

1. If there is no mechanical defaults in A/T, all slippage occurs in the torque converter.
2. Therefore, engine revolution is output, but input and output speed revolution must be "zero" due to wheel's lock.
3. If 1st gear operating parts have faults, input speed revolution will be out of specification.
4. If output speed revolution is output. It means that the foot brake force is not applied fully. Remeasuring is required.
5. Is "STALL TEST " within specification?

YES

▶ Go to "Signal Circuit Inspection" procedure.

NO

▶ Go to "Component inspection" procedure.

CAUTION

● Do not let anybody stand in front of or behind the vehicle while this test is being carried out.

● Check the A/T fluid level and temperature and the engine coolant temperature.

- Fluid level : At the hot mark on the oil level gauge.

- Fluid temperature : 176 °F~ 212 °F (80~100 °C).

- Engine coolant temperature : 176 °F~ 212 °F (80~100 °C).

● Chock both rear wheels(left and right).

● Pull the parking brake lever on with the brake pedal fully depressed.

● The throttle should not be left fully open for more than eight seconds.

● If carrying out the stall test two or more times, move the select lever to the "N" position and run the engine at 1,000 rpm to let the A/T fluid cool down before carrying out subsequent tests.

SIGNAL CIRCUIT INSPECTION

1. Connect Scantool.
2. Engine "ON".
3. Monitor the "INPUT & OUTPUT SPEED SENSOR" parameter on the scantool.
4. Accelerate the Engine speed until about 2000 rpm in the 1st gear.

Specification : INPUT SPEED - (OUTPUT SPEED × 1st GEAR RATIO) ≤ 200 RPM

AT-84

Automatic Transaxle System

1.11 CURRENT DATA 01/59	
* ENGINE SPEED	2044 rpm
* INPUT SPEED(PG-A)	2050. rpm
* TURBIN SPEED SENDOR 1	0.0 rpm
* TURBIN SPEED SENDOR 2	2070. rpm
* OUTPUT SPEED(PG-B)	544.0rpm
* CURRENT GEAR POSITION	1 GEAR
* SELECTED LEVER RANGE	D
INHIBITOR SWITCH 1	

FIX PART FULL HELP GRPH RCRD

SBLAT6214L

5. Does "INPUT & OUTPUT SPEED SENSOR" within specifications?

YES

▶ Go to "Component Inspection" procedure.

NO

▶ Check for electrical noise of circuit in INPUT & OUTPUT SPEED SENSOR or replace INPUT & OUTPUT SPEED SENSOR. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION

1. Connect Scantool.
2. Engine "ON".
3. Monitor the "OIL PRESSURE. S/W 1,2,3,5,6" parameter on the scantool.
4. Move select lever to "D" range and operate vehicle within 1st gear condition.

Shift position	Oil Pressure Switch					
	I/C(SW3)	H & LR/C(SW6)	H & LR/C(SW6)	FR/B(SW1)	LC/B(SW2)	
P	X	O	X	O	X	
R	X	O	X	O	X	
N	X	O	X	O	X	
D	1st gear	X	X	X	O	X
	2nd gear	X	X	O	O	X
	3rd gear	X	O	O	O	X
	4th gear	O	O	O	X	X
	5th gear	O	O	X	O	X

Automatic Transaxle System

AT-85

1.11 CURRENT DATA		33/59
×	CURRENT GEAR POSITION	1 GEAR
×	OIL PRESS.SW-2(LC/B)	ON
×	OIL PRESS.SW-5(D/C)	OFF
×	OIL PRESS.SW-3(I/C)	OFF
×	OIL PRESS.SW-1(Fr/B)	ON
×	OIL PRESS.SW-6(H&LB/C)	ON
×	SELECTED LEVER RANGE	D
	INHIBITOR SWITCH 1	

FIX PART FULL HELP GRPH RCRD

SBLAT6216L

5. Does "OIL PRESSURE. SW 1,2,3,5,6 " follow the reference data?

YES

- ▶ Repair AUTO TRANSAXLE(Clutch or Brake) as necessary and Go to "Verification of Vehicle Repair" procedure.

NO

- ▶ Replace AUTO TRANSAXLE (BODY CONTROL VALVE faulty) as necessary and go to "Verification of Vehicle Repair " procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in general information.
4. Are any DTCs present ?

YES

- ▶ Go to the applicable troubleshooting procedure.

NO

- ▶ System performing to specification at this time.




AT-86

Automatic Transaxle System

P0732

COMPONENT LOCATION



SBLAT6210L

GENERAL DESCRIPTION

The value of the input shaft speed should be equal to the value of the output shaft speed, when multiplied by the 2nd gear ratio, while the transaxle is engaged in the 2nd gear. For example, if the output speed is 1000 rpm and the 2nd gear ratio is 2.368, then the input speed is 2368 rpm.

DTC DESCRIPTION

This code is set if the value of input shaft speed is not equal to the value of the output shaft, when multiplied by the 2nd gear ratio, while the transaxle is engaged in 2nd gear. This malfunction is mainly caused by mechanical troubles such as control valve sticking or solenoid valve malfunctioning rather than an electrical issue.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> 2nd gear incorrect ratio 	<ul style="list-style-type: none"> Faulty input speed sensor Faulty output speed sensor Faulty inside transmission element
Enable Conditions	<ul style="list-style-type: none"> Engine speed > 600rpm 150rpm > Output speed < 6000rpm Lever Position = "D" Input speed > 600rpm A/T oil temp output ≥ -10°C Throttle opening > 15% The time after the last shift was finish > 1sec 	
Threshold value	<ul style="list-style-type: none"> Input speed - output speed × 2nd gear ratio ≥ 200rpm 	
Diagnostic Time	<ul style="list-style-type: none"> More than 1sec 	
Fail Safe	<ul style="list-style-type: none"> 4th gear Limp-Home mode 	

Automatic Transaxle System

AT-87

SIGNAL WAVEFORM




FIG.1)


A : INPUT SPEED SENSOR
 B : OUTPUT SPEED SENSOR

SBLAT6221L

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "ENGINE SPEED, INPUT SPEED SENSOR, OUTPUT SPEED SENSOR, GEAR POSITION" parameter on the scantool.
4. Perform the "STALL TEST" with gear position "2"

Specification : 2300 ± 200 engine rpm



SBLAT6222L

AT-88

Automatic Transaxle System

OPERATING ELEMENT OF EACH SHIFTING RANGE

Shifting Position	Input clutch	High&Low Reverse Clutch	Direct clutch	Reverse Brake	Front Brake	Low Coast Brake	Forward Brake	1st OwnWayClutch	Forward OwnWayClutch	3rd OwnWayClutch
P		▲			▲					
R		●		●	●			●		●
N		▲			▲	★				
D	1st gear	★			▲		●	●	●	●
	2nd gear		●		▲		●		●	●
	3rd gear		●	●	●		▲	◆		●
	4th gear	●	●	●			▲	◆		
	5th gear	●	●			●	▲	◆		◆

- : WORKING.
- ◆ : PARTICIPATE IN DELIVERY TORQUE WHEN COAST DRIVING.
- ▲ : SUPPLING OIL PRESSURE TO ELEMENT, BUT NOT EFFECT ON OUTPUT.
- ★ : TEMPORARY WORKING.

SBLAT6213L

Stall test procedure in D2 and reason

Procedure

1. Warm up the engine
2. After positioning the select lever in "D", depress the foot brake pedal fully. After that, depress the accelerator pedal to the maximum

* The slippage of 2nd gear operating parts can be detected by stall test in D2

Reason for stall test

1. If there is no mechanical defaults in A/T, all slippage occurs in the torque converter.
2. Therefore, engine revolution is output, but input and output speed revolution must be "zero" due to wheel's lock.
3. If 2nd gear operating parts have faults, input speed revolution will be out.
4. If output speed revolution is output. It means that the foot brake force is not applied fully. Remeasuring is required.
5. Is "STALL TEST " within specification?

YES

▶ Go to "Signal Circuit Inspection" procedure.

NO

▶ Go to "Component inspection" procedure.

CAUTION

- Do not let anybody stand in front of or behind the vehicle while this test is being carried out.
- Check the A/T fluid level and temperature and the engine coolant temperature.
 - Fluid level : At the hot mark on the oil level gauge.
 - Fluid temperature : 176 °F~ 212 °F (80~100 °C).
 - Engine coolant temperature : 176 °F~ 212 °F (80~100 °C).
- Chock both rear wheels(left and right).
- Pull the parking brake lever on with the brake pedal fully depressed.
- The throttle should not be left fully open for more than eight seconds.
- If carrying out the stall test two or more times, move the select lever to the "N" position and run the engine at 1,000 rpm to let the A/T fluid cool down before carrying out subsequent tests.

SIGNAL CIRCUIT INSPECTION

1. Connect Scantool.
2. Engine "ON".
3. Monitor the "INPUT & OUTPUT SPEED SENSOR" parameter on the scantool.
4. Accelerate the Engine speed until about 2000 rpm in the 2nd gear.

Specification : INPUT SPEED - (OUTPUT SPEED × 2nd GEAR RATIO) ≤ 200 RPM

Automatic Transaxle System

AT-89

1.11 CURRENT DATA		01/59
× ENGINE SPEED	1975 rpm	
× INPUT SPEED(PG-A)	1953.rpm	
× TURBIN SPEED SENDOR 1	0.0 rpm	
× TURBIN SPEED SENDOR 2	1939.rpm	
× OUTPUT SPEED(PG-B)	817.0rpm	
× CURRENT GEAR POSITION	2 GEAR	
× SELECTED LEVER RANGE	D	
INHIBITOR SWITCH 1		

FIX PART FULL HELP GRPH RCRD

SBLAT6224L

5. Does "INPUT & OUTPUT SPEED SENSOR" within specifications?

YES

▶ Go to "Component Inspection" procedure.

NO

▶ Check for electrical noise of circuit in INPUT & OUTPUT SPEED SENSOR or replace INPUT & OUTPUT SPEED SENSOR. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION

1. Connect Scantool.
2. Engine "ON".
3. Monitor the "OIL PRESSURE. S/W 1,2,3,5,6" parameter on the scantool.
4. Move select lever to "D" range and operate vehicle within 2nd gear condition.

Shift position	Oil Pressure Switch					
	I/C(SW3)	H & LR/C(SW6)	H & LR/C(SW6)	FR/B(SW1)	LC/B(SW2)	
P	X	O	X	O	X	
R	X	O	X	O	X	
N	X	O	X	O	X	
D	1st gear	X	X	X	O	X
	2nd gear	X	X	O	O	X
	3rd gear	X	O	O	O	X
	4th gear	O	O	O	X	X
	5th gear	O	O	X	O	X

AT-90

Automatic Transaxle System

1.11 CURRENT DATA		33/59
×	CURRENT GEAR POSITION	2 GEAR
×	OIL PRESS.SW-2(LC/B)	ON
×	OIL PRESS.SW-5(D/C)	ON
×	OIL PRESS.SW-3(I/C)	OFF
×	OIL PRESS.SW-1(Fr/B)	ON
×	OIL PRESS.SW-6(H&LB/C)	OFF
×	SELECTED LEVER RANGE	D
	INHIBITOR SWITCH 1	
	FIX	PART FULL HELP GRPH RCRD

SBLAT6226L

5. Is oil pressure value within specifications?

YES

▶ Repair AUTO TRANSAXLE(Clutch or Brake) as necessary and Go to "Verification of Vehicle Repair" procedure.

NO

▶ Replace AUTO TRANSAXLE (BODY CONTROL VALVE faulty) as necessary and go to "Verification of Vehicle Repair " procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in general information.
4. Are any DTCs present ?

YES

▶ Go to the applicable troubleshooting procedure.

NO

▶ System performing to specification at this time.




Automatic Transaxle System

AT-91

P0733

COMPONENT LOCATION



SBLAT6210L

GENERAL DESCRIPTION

The value of the input shaft speed should be equal to the value of the output shaft speed, when multiplied by the 3rd gear ratio, while the transaxle is engaged in the 3rd gear. For example, if the output speed is 1,000 rpm and the 3rd gear ratio is 1.520, then the input speed is 1520 rpm.

DTC DESCRIPTION

This code is set if the value of input shaft speed is not equal to the value of the output shaft, when multiplied by the 3rd gear ratio, while the transaxle is engaged in 3rd gear. This malfunction is mainly caused by mechanical troubles such as control valve sticking or solenoid valve malfunctioning rather than an electrical issue.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> 3rd gear incorrect ratio 	<ul style="list-style-type: none"> Faulty input speed sensor Faulty output speed sensor Faulty inside transmission element
Enable Conditions	<ul style="list-style-type: none"> Engine speed > 600rpm 150rpm > Output speed < 6000rpm Lever Position = "D" Input speed > 600rpm A/T oil temp output $\geq -10^{\circ}\text{C}$ Throttle opening > 15% The time after the last shift was finish > 1sec 	
Threshold value	<ul style="list-style-type: none"> $\text{Input speed} - \text{output speed} \times 3\text{rd gear ratio} \geq 200\text{rpm}$ 	
Diagnostic Time	<ul style="list-style-type: none"> More than 1sec 	
Fail Safe	<ul style="list-style-type: none"> 4th gear Limp-Home mode 	

AT-92

Automatic Transaxle System

SIGNAL WAVEFORM




FIG.1)

A : INPUT SPEED SENSOR
 B : OUTPUT SPEED SENSOR


SBLAT6231L

SIGNAL CIRCUIT INSPECTION

1. Connect Scantool.
2. Engine "ON".
3. Monitor the "INPUT & OUTPUT SPEED SENSOR" parameter on the scantool.

4. Accelerate the Engine speed until about 2000 rpm in the 3rd gear.

Specification : $INPUT\ SPEED - (OUTPUT\ SPEED \times 3rd\ GEAR\ RATIO) \leq 200\ RPM$



SBLAT6232L

5. Does "INPUT & OUTPUT SPEED SENSOR" within specifications?

YES

- ▶ Go to "Component Inspection" procedure.

NO

- ▶ Check for electrical noise of circuit in INPUT & OUTPUT SPEED SENSOR or replace INPUT & OUTPUT SPEED SENSOR. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

Automatic Transaxle System

AT-93

COMPONENT INSPECTION

1. Connect Scantool.
2. Engine "ON".

3. Monitor the "OIL PRESSURE. S/W 1,2,3,5,6" parameter on the scantool.
4. Move select lever to "D" range and operate vehicle within 3rd gear condition.

Shift position		Oil Pressure Switch				
		I/C(SW3)	H & LR/C(SW6)	H & LR/C(SW6)	FR/B(SW1)	LC/B(SW2)
P		X	O	X	O	X
R		X	O	X	O	X
N		X	O	X	O	X
D	1st gear	X	X	X	O	X
	2nd gear	X	X	O	O	X
	3rd gear	X	O	O	O	X
	4th gear	O	O	O	X	X
	5th gear	O	O	X	O	X



SBLAT6233L

5. Is oil pressure value within specifications?

YES

► Repair AUTO TRANSAXLE(Clutch or Brake) as necessary and Go to "Verification of Vehicle Repair" procedure.

NO

► Replace AUTO TRANSAXLE (BODY CONTROL VALVE faulty) as necessary and go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in general information.
4. Are any DTCs present ?

YES

► Go to the applicable troubleshooting procedure.

NO


► System performing to specification at this time.

AT-94

Automatic Transaxle System

P0734

COMPONENT LOCATION



SBLAT6210L

GENERAL DESCRIPTION

The value of the input shaft speed should be equal to the value of the output shaft speed, when multiplied by the 4th gear ratio, while the transaxle is engaged in the 4th gear. For example, if the output speed is 1,000 rpm and the 4th gear ratio is 1.000, then the input speed is 1000 rpm.

DTC DESCRIPTION

This code is set if the value of input shaft speed is not equal to the value of the output shaft, when multiplied by the 4th gear ratio, while the transaxle is engaged in 4th gear. This malfunction is mainly caused by mechanical troubles such as control valve sticking or solenoid valve malfunctioning rather than an electrical issue.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> 4th gear incorrect ratio 	<ul style="list-style-type: none"> Faulty input speed sensor Faulty output speed sensor Faulty inside transmission element
Enable Conditions	<ul style="list-style-type: none"> Engine speed > 600rpm 150rpm > Output speed < 6000rpm Lever Position = "D" Input speed > 600rpm A/T oil temp output ≥ -10°C Throttle opening > 15% The time after the last shift was finish > 1sec 	
Threshold value	<ul style="list-style-type: none"> Input speed - output speed × 4th gear ratio ≥ 20 0rpm 	
Diagnostic Time	<ul style="list-style-type: none"> More than 1sec 	
Fail Safe	<ul style="list-style-type: none"> 4th gear Limp-Home mode 	

Automatic Transaxle System

AT-95

SIGNAL WAVEFORM




FIG.1)

A : INPUT SPEED SENSOR
 B : OUTPUT SPEED SENSOR


SBLAT6241L

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC).
2. Engine "ON".

3. Monitor the "ENGINE SPEED, INPUT SPEED SENSOR, OUTPUT SPEED SENSOR, GEAR POSITION" parameter on the scantool.
4. Perform the "STALL TEST" with gear position "4"

Specification : 2300 ± 200 engine rpm



SBLAT6242L

AT-96

Automatic Transaxle System

OPERATING ELEMENT OF EACH SHIFTING RANGE

Shifting Position	Input clutch	High&Low Reverse Clutch	Direct clutch	Reverse Brake	Front Brake	Low Coast Brake	Forward Brake	1st OwnWayClutch	Forward OwnWayClutch	3rd OwnWayClutch
P		▲			▲					
R		●		●	●			●		●
N		▲			▲	★				
D	1st gear	★			▲		●	●	●	●
	2nd gear		●		▲		●		●	●
	3rd gear	●	●		●		▲	◆		●
	4th gear	●	●	●			▲	◆		
	5th gear	●	●			●	▲	◆		◆

● : WORKING.

◆ : PARTICIPATE IN DELIVERY TORQUE WHEN COAST DRIVING.

▲ : SUPPLING OIL PRESSURE TO ELEMENT, BUT NOT EFFECT ON OUTPUT.

★ : TEMPORARY WORKING.

SBLAT6213L

Stall test procedure in D4 and reason

Procedure

1. Warm up the engine
2. After positioning the select lever in "D" or "ON" of the HOLD SW (Operate UP SHIFT in case of "SPORTS MODE"), depress the foot brake pedal fully after that, depress the accelerator pedal to the maximum.

* The slippage of 4th gear operating parts can be detected by stall test in D4

Reason for stall test

1. If there is no mechanical defaults in A/T, all slippage occurs in the torque converter.
2. Therefore, engine revolution is output, but input and output speed revolution must be "zero" due to wheel's lock.
3. If 4th gear operating parts have faults, input speed revolution will be out.
4. If output speed revolution is output. It means that the foot brake force is not applied fully. Remeasuring is required.

5. Is "STALL TEST " within specification?

YES

- ▶ Go to "Signal Circuit Inspection" procedure.

NO

- ▶ Go to "Component inspection" procedure.

CAUTION

● Do not let anybody stand in front of or behind the vehicle while this test is being carried out.

● Check the A/T fluid level and temperature and the engine coolant temperature.

- Fluid level : At the hot mark on the oil level gauge.

- Fluid temperature : 176 °F~ 212 °F (80~100 °C).

- Engine coolant temperature : 176 °F~ 212 °F (80~100 °C).

● Chock both rear wheels(left and right).

● Pull the parking brake lever on with the brake pedal fully depressed.

● The throttle should not be left fully open for more than eight seconds.

● If carrying out the stall test two or more times, move the select lever to the "N" position and run the engine at 1,000 rpm to let the A/T fluid cool down before carrying out subsequent tests.

Automatic Transaxle System

AT-97

SIGNAL CIRCUIT INSPECTION

1. Connect Scantool.
2. Engine "ON".
3. Monitor the "INPUT & OUTPUT SPEED SENSOR" parameter on the scantool.

4. Accelerate the Engine speed until about 2000 rpm in the 4th gear.

Specification : $INPUT\ SPEED - (OUTPUT\ SPEED \times 4th\ GEAR\ RATIO) \leq 200\ RPM$

1.11 CURRENT DATA		01/59
✖	ENGINE SPEED	2006 rpm
✖	INPUT SPEED(PG-A)	2005. rpm
✖	TURBIN SPEED SENDOR 1	1045. rpm
✖	TURBIN SPEED SENDOR 2	3054. rpm
✖	OUTPUT SPEED(PG-B)	2008. rpm
✖	CURRENT GEAR POSITION	4 GEAR
✖	SELECTED LEVER RANGE	D
INHIBITOR SWITCH 1		

FIX PART FULL HELP GRPH BCRD

SBLAT6244L

5. Does "INPUT & OUTPUT SPEED SENSOR" within specifications?

YES

▶ Go to "Component Inspection" procedure.

NO

▶ Check for electrical noise of circuit in INPUT & OUTPUT SPEED SENSOR or replace INPUT & OUTPUT SPEED SENSOR. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

COMPONENT INSPECTION

1. Connect Scantool.
2. Engine "ON".
3. Monitor the "OIL PRESSURE. S/W 1,2,3,5,6" parameter on the scantool.
4. Move select lever to "D" range and operate vehicle within 4th gear condition.

Shift position	Oil Pressure Switch					
	I/C(SW3)	H & LR/C(SW6)	H & LR/C(SW6)	FR/B(SW1)	LC/B(SW2)	
P	X	O	X	O	X	
R	X	O	X	O	X	
N	X	O	X	O	X	
D	1st gear	X	X	X	O	X
	2nd gear	X	X	O	O	X
	3rd gear	X	O	O	O	X
	4th gear	O	O	O	X	X
	5th gear	O	O	X	O	X

AT-98

Automatic Transaxle System

1.11 CURRENT DATA		33/59
✖	CURRENT GEAR POSITION	4 GEAR
✖	OIL PRESS.SW-2(LC/B)	OFF
✖	OIL PRESS.SW-5(D/C)	ON
✖	OIL PRESS.SW-3(I/C)	ON
✖	OIL PRESS.SW-1(Fr/B)	OFF
✖	OIL PRESS.SW-6(H&LR/C)	ON
✖	SELECTED LEVER RANGE	D
	INHIBITOR SWITCH 1	

FIX PART FULL HELP GRPH RCRD

SBLAT6246L

5. Is oil pressure value within specifications?

YES

► Repair AUTO TRANSAXLE(Clutch or Brake) as necessary and Go to "Verification of Vehicle Repair" procedure.

NO

► Replace AUTO TRANSAXLE (BODY CONTROL VALVE faulty) as necessary and go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in general information.
4. Are any DTCs present ?

YES

► Go to the applicable troubleshooting procedure.

NO


► System performing to specification at this time.

Automatic Transaxle System

AT-99

P0735

COMPONENT LOCATION



SBLAT6210L

GENERAL DESCRIPTION

The value of the input shaft speed should be equal to the value of the output shaft speed, when multiplied by the 5th gear ratio, while the transaxle is engaged in the 5th gear. For example, if the output speed is 1,000 rpm and the 5th gear ratio is 0.834, then the input speed is 834 rpm.

DTC DESCRIPTION

This code is set if the value of input shaft speed is not equal to the value of the output shaft, when multiplied by the 5th gear ratio, while the transaxle is engaged in 5th gear. This malfunction is mainly caused by mechanical troubles such as control valve sticking or solenoid valve malfunctioning rather than an electrical issue.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> 5th gear incorrect ratio 	<ul style="list-style-type: none"> Faulty input speed sensor Faulty output speed sensor Faulty inside transmission element
Enable Conditions	<ul style="list-style-type: none"> Engine speed > 600rpm 150rpm > Output speed < 6000rpm Lever Position = "D" Input speed > 600rpm A/T oil temp output ≥ -10°C Throttle opening > 15% The time after the last shift was finish > 1sec 	
Threshold value	<ul style="list-style-type: none"> Input speed - output speed × 5th gear ratio ≥ 200rpm 	
Diagnostic Time	<ul style="list-style-type: none"> More than 1sec 	
Fail Safe	<ul style="list-style-type: none"> 4th gear Limp-Home mode 	

AT-100

Automatic Transaxle System

SIGNAL WAVEFORM




FIG.1)

A : INPUT SPEED SENSOR
 B : OUTPUT SPEED SENSOR


SBLAT6251L

SIGNAL CIRCUIT INSPECTION

1. Connect Scantool.
2. Engine "ON".
3. Monitor the "INPUT & OUTPUT SPEED SENSOR" parameter on the scantool.

4. Accelerate the Engine speed until about 2000 rpm in the 5th gear.

Specification : $INPUT\ SPEED - (OUTPUT\ SPEED \times 5th\ GEAR\ RATIO) \leq 200\ RPM$



SBLAT6252L

5. Does "INPUT & OUTPUT SPEED SENSOR" within specifications?

YES

- ▶ Go to "Component Inspection" procedure.

NO

- ▶ Check for electrical noise of circuit in INPUT & OUTPUT SPEED SENSOR or replace INPUT & OUTPUT SPEED SENSOR. Repair as necessary and go to "Verification of Vehicle Repair" procedure.

Automatic Transaxle System

AT-101

COMPONENT INSPECTION

1. Connect Scantool.
2. Engine "ON".

3. Monitor the "OIL PRESSURE. S/W 1,2,3,5,6" parameter on the scantool.
4. Move select lever to "D" range and operate vehicle within 5th gear condition.

Shift position		Oil Pressure Switch				
		I/C(SW3)	H & LR/C(SW6)	H & LR/C(SW6)	FR/B(SW1)	LC/B(SW2)
P		X	O	X	O	X
R		X	O	X	O	X
N		X	O	X	O	X
D	1st gear	X	X	X	O	X
	2nd gear	X	X	O	O	X
	3rd gear	X	O	O	O	X
	4th gear	O	O	O	X	X
	5th gear	O	O	X	O	X



5. Is oil pressure value within specifications?

YES

► Repair AUTO TRANSAXLE(Clutch or Brake) as necessary and Go to "Verification of Vehicle Repair" procedure.

NO

► Replace AUTO TRANSAXLE (BODY CONTROL VALVE faulty) as necessary and go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scan tool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in general information.
4. Are any DTCs present ?


YES

► Go to the applicable troubleshooting procedure.

NO

► System performing to specification at this time.

SBLAT6253L

AT-102**Automatic Transaxle System****P0741****COMPONENT LOCATION**

SBLAT6140L

GENERAL DESCRIPTION

The PCM/TCM controls the locking and unlocking of the Torque Converter Clutch (or Damper Clutch), to the input shaft of the transmission, by applying hydraulic pressure. The main purpose of T/C clutch control is to save fuel by decreasing the hydraulic load inside the T/C. The TCM outputs duty pulses to control the Damper Clutch Control Solenoid Valve(DCCSV) and hydraulic pressure is applied to DC according to the DCC duty ratio value.

When the duty ratio is high, high pressure is applied and the Damper Clutch is locked. The normal operating range of the Damper Clutch Control current is from 0.05A(unlocked) to 0.75A(locked).

DTC DESCRIPTION

The PCM/TCM increases the duty ratio to engage the Damper Clutch by monitoring slip rpms (difference value between engine speed and turbine speed).

To decrease the slip of the Damper Clutch, the TCM increases the duty ratio by applying more hydraulic pressure.

When slip rpm does not drop under some value with 100% duty ratio, the PCM/TCM determines that the Torque Converter Clutch is stuck OFF and sets this code.

Automatic Transaxle System

AT-103

DTC DETECTING CONDITION

[DSL 2.5]

Item		Detecting Condition	Possible cause
DTC Strategy		<ul style="list-style-type: none"> Stuck "OFF" 	※ TORQUE CONVERTER (DAMP-ER) CLUTCH : TCC <ul style="list-style-type: none"> Faulty TCC or oil pressure system Faulty TCC solenoid valve Faulty body control valve Faulty TCM
Enable C- onditions	case1	<ul style="list-style-type: none"> Vehicle speed ≥ 6.2MPH(10km/h) Engine speed > 305 rpm A/T range switch is D range $68^{\circ}\text{F} \leq \text{A/T fluid temperature} \leq 212^{\circ}\text{F}$ 	
	case2	<ul style="list-style-type: none"> Vehicle speed ≥ 6.2MPH(10km/h) Engine speed > 305 rpm A/T range switch is D range $68^{\circ}\text{F} \leq \text{A/T fluid temperature} \leq 212^{\circ}\text{F}$ 	
Threshold d Value	case1	<ul style="list-style-type: none"> Calculated slip (engine speed-input speed) $> 40\text{rpm} + \text{Vsp}/2$ at 5th gear full lock up 	
	case2	<ul style="list-style-type: none"> Calculated slip (engine speed-input speed) $\geq \text{Target slip speed} + 65\text{rpm}$ at 4th, 5th gear slip lock up 	
Diagnostic Time		<ul style="list-style-type: none"> more than 30sec 	
Fail Safe		<ul style="list-style-type: none"> Lock-up control is prohibited Slip lock-up control is prohibited 	

[GSL 3.3/3.8]

Item		Detecting Condition	Possible cause
DTC Strategy		<ul style="list-style-type: none"> Stuck "OFF" 	※ TORQUE CONVERTER(DAMP-ER) CLUTCH : TCC <ul style="list-style-type: none"> Faulty TCC or oil pressure system Faulty TCC solenoid valve Faulty body control valve Faulty TCM
Enable Conditions		<ul style="list-style-type: none"> Duty of "Damper clutch solenoid valve" = 100% Input speed > 0rpm 	
Threshold value		<ul style="list-style-type: none"> Calculated slip (engine speed-input speed) > 100rpm 	
Diagnostic Time		<ul style="list-style-type: none"> More than 5sec 	
Fail Safe		<ul style="list-style-type: none"> Damper clutch "OFF" 	

AT-104

Automatic Transaxle System

Monitor Scantool Data

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Select "D RANGE" and drive vehicle 5 gear.

4. Monitor the "TORQUE CONVERTER(DAMPER) CLUTCH" parameter on the scantool .

Specification :

[DSL 2.5]

TCC SLIP < 40RPM+ Vsp1/2(In condition that LU(TCC) SOL. current > 6.5A)

[GSL 3.3/3.8]

Calculated slip (engine speed-input speed) < 100rpm

[DSL 2.5]

1.3 CURRENT DATA		07/76
* TURBIN SPEED SENSOR	0	rpm
* ENGINE SPEED	736	rpm
* DAMPER CLUTCH SL. RPM	254	rpm
* LU SOL. OUTPUT	0.01	A
* LU SOL. MONITOR	0.00	A
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	D	
SELECTED LEVER RANGE		

FIG.1)

1.3 CURRENT DATA		07/76
* TURBIN SPEED SENSOR	2720	rpm
* ENGINE SPEED	2720	rpm
* DAMPER CLUTCH SL. RPM	0	rpm
* LU SOL. OUTPUT	0.45	A
* LU SOL. MONITOR	0.57	A
* CURRENT GEAR POS.	4	GEAR
* SHIFT RANGE INDICATOR	-	
SELECTED LEVER RANGE		

FIG.2)

FIG.1) : Non-operating Lock-up Clutch
 FIG.2) : Operating Lock-up Clutch

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

SBLAT6141L

Automatic Transaxle System

AT-105

[GSL 3.3/3.8]

1.11 CURRENT DATA		89/59
× ENGINE SPEED	721 rpm	
× INPUT SPEED(PG-A)	761.0rpm	
× TCC SLIP RPM	8.0 rpm	
× TCCSV(LU)	0.0 %	
× TCCSV CURRENT(LU)	48.0 mA	
× TCCSV PRESSURE(LU)	-43.5psi	
× CURRENT GEAR POSITION	P N	
× SELECTED LEVER RANGE	N	

FIG.1)

1.11 CURRENT DATA		89/59
× ENGINE SPEED	895 rpm	
× INPUT SPEED(PG-A)	840.0rpm	
× TCC SLIP RPM	53.0 rpm	
× TCCSV(LU)	0.0 %	
× TCCSV CURRENT(LU)	48.0 mA	
× TCCSV PRESSURE(LU)	-43.5psi	
× CURRENT GEAR POSITION	REVERSE	
× SELECTED LEVER RANGE	R	

FIG.2)

1.11 CURRENT DATA		89/59
× ENGINE SPEED	1039 rpm	
× INPUT SPEED(PG-A)	1021.0rpm	
× TCC SLIP RPM	33.0 rpm	
× TCCSV(LU)	0.0 %	
× TCCSV CURRENT(LU)	48.0 mA	
× TCCSV PRESSURE(LU)	-43.5psi	
× CURRENT GEAR POSITION	1 GEAR	
× SELECTED LEVER RANGE	D	

FIG.3)

1.11 CURRENT DATA		89/59
× ENGINE SPEED	1668 rpm	
× INPUT SPEED(PG-A)	1642.0rpm	
× TCC SLIP RPM	16.0 rpm	
× TCCSV(LU)	0.0 %	
× TCCSV CURRENT(LU)	48.0 mA	
× TCCSV PRESSURE(LU)	-43.5psi	
× CURRENT GEAR POSITION	2 GEAR	
× SELECTED LEVER RANGE	D	

FIG.4)

1.11 CURRENT DATA		89/59
× ENGINE SPEED	2335 rpm	
× INPUT SPEED(PG-A)	2325.0rpm	
× TCC SLIP RPM	20.0 rpm	
× TCCSV(LU)	0.0 %	
× TCCSV CURRENT(LU)	48.0 mA	
× TCCSV PRESSURE(LU)	-43.5psi	
× CURRENT GEAR POSITION	3 GEAR	
× SELECTED LEVER RANGE	D	

FIG.5)

1.11 CURRENT DATA		89/59
× ENGINE SPEED	2293 rpm	
× INPUT SPEED(PG-A)	2304.0rpm	
× TCC SLIP RPM	0.0 rpm	
× TCCSV(LU)	38.4 %	
× TCCSV CURRENT(LU)	388.0mA	
× TCCSV PRESSURE(LU)	5.8 psi	
× CURRENT GEAR POSITION	4 GEAR	
× SELECTED LEVER RANGE	D	

FIG.6)

1.11 CURRENT DATA		89/59
× ENGINE SPEED	2352 rpm	
× INPUT SPEED(PG-A)	2353.0rpm	
× TCC SLIP RPM	0.0 rpm	
× TCCSV(LU)	42.0 %	
× TCCSV CURRENT(LU)	400.0mA	
× TCCSV PRESSURE(LU)	10.1 psi	
× CURRENT GEAR POSITION	5 GEAR	
× SELECTED LEVER RANGE	D	

FIG.7)

- FIG.1) "P,N" range
- FIG.2) "R" range
- FIG.3) "D" range 1st gear
- FIG.4) "D" range 2nd gear
- FIG.5) "D" range 3rd gear
- FIG.6) "D" range 4th gear
- FIG.7) "D" range 5th gear

SBLAT6143L

AT-106

Automatic Transaxle System

5. Is "TCC SLIP(DAMPER CLUTCH SL.RPM)" within specifications?

YES

► Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Component Inspection" procedure.

COMPONENT INSPECTION

1. Disconnect "C06-2/C106-2" connector.
2. Ignition "OFF".
3. Measure resistance between terminal "9" of the C06-2/C106-2 harness connector and chassis ground.

Specification : approx. 3~9Ω

1	2	3	4	5
6	7	8	9	10



C06-2 [DSL 2.5]

C106-2 [GSL 3.3/3.8]

Component side

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. DIRECT CLUTCH SOLENOID VALVE
6. FRONT BRAKE SOLENOID VALVE
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

4. Is resistance within specifications?

YES

► Repair TORQUE CONVERTER CLUTCH(REPLACE Torque Converter) as necessary and Go to "Verification of Vehicle Repair" procedure.

NO

► Replace A/T assembly (possible to BODY CONTROL VALVE faulty) as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

► Go to the applicable troubleshooting procedure.

NO

► System performing to specification at this time.


SBLAT6142L

Automatic Transaxle System

AT-107

P0743

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

The PCM/TCM controls the locking and unlocking of the Torque Converter Clutch (or Damper Clutch), to the input shaft of the transmission, by applying hydraulic pressure. The main purpose of T/C clutch control is to save fuel by decreasing the hydraulic load inside the T/C. The TCM outputs duty pulses to control the Damper Clutch Control Solenoid Valve(DCCSV) and hydraulic pressure is applied to DC according to the DCC duty ratio value. When the duty ratio is high, high pressure is applied and the Damper Clutch is locked. The normal operating range of the Damper Clutch Control current is from 0.05A(unlocked) to 0.75A(locked).

DTC DESCRIPTION

The TCM checks the Damper Clutch Control Signal by monitoring the feedback signal from the solenoid valve drive circuit. If an unexpected signal is monitored, (For example, high voltage is detected when low voltage is expected, or low voltage is detected when high voltage is expected) the TCM judges that the DCCSV circuit is malfunctioning and sets this code.

DTC DETECTING CONDITION

[DSL 2.5]

Item	Detecting Condition	Possible cause
DTC Strategy	• Check voltage range	※ TORQUE CONVERTER(DAMPER) CLUTCH : TCC • Open or short in circuit • Faulty TCC SOLENOID VALVE • Faulty PCM/TCM
Enable Conditions	• CONTINUOUS	
Threshold value	• Ground short/open :Monitoring value[current] \leq 0.05A , When the driver output \geq 0.49A • B+ short : Monitoring value[current] \leq 0.4A, When the driver output \geq 0.75A	
Diagnostic Time	• More than 5sec	
Fail Safe	• Lock-up control is prohibited(L/U off)	

AT-108

Automatic Transaxle System

[GSL 3.3/3.8]

Item	Detecting Condition	Possible cause
DTC Strategy	• Check voltage range	※ TORQUE CONVERTER(DAMPER) CLUTCH : TCC • Open or short in circuit • Faulty TCC SOLENOID VALVE • Faulty PCM/TCM
Enable Conditions	• 10V < Actuator power supply voltage < 16V	
Threshold value	• Hardware "IC" check	
Diagnostic Time	• More than 0.2sec	
Fail Safe	• Lock-up control is prohibited(L/U off)	

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "TCC SOL. VALVE" parameter on the scantool.
4. Select "D RANGE" and Operate the vehicle 5 gear.
5. Check "TCC SOL. VALVE" parameter value changes while driving.




FIG.1)

FIG.1) Not engagement status of TCC




FIG.2)

FIG.2) Engagement status of TCC

SBLAT6151L

6. Does "TCC SOLENOID DUTY " follow the reference data?

YES

► Fault is intermittent caused by poor contact in the sensor's and/or TCM(PCM)'s connector or was repaired and TCM(PCM) memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of vehicle repair" procedure.

NO

► Go to "Terminal & connector inspection " procedure.

Automatic Transaxle System

AT-109

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.


NO

► Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2/C106-2" connector.
2. IGNITION "ON", ENGINE "OFF".
3. Measure voltage between terminal "9" of the C06-2/C106-2 harness connector and chassis ground.

Specification : approx. 5V



C06-2 [DSL 2.5]
C106-2 [GSL 3.3/3.8]

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. DIRECT CLUTCH SOLENOID VALVE
6. FRONT BRAKE SOLENOID VALVE
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV (LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

4. Is voltage within specifications?


YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.



AT-110


Automatic Transaxle System

COMPONENT INSPECTION

1. Disconnect "C06-2/C106-2" connector.
2. Ignition "OFF".

3. Measure resistance between terminal "9" of the C06-2/C106-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2 [DSL 2.5]
C106-2 [GSL 3.3/3.8]
Component side

- 1.ATF 2
- 2.LOW COAST BRAKE SOLENOID VALVE
- 3.HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
- 4.DIRECT CLUTCH SOLENOID VALVE
- 6.FRONT BRAKE SOLENOID VALVE
- 7.INPUT CLUTCH SOLENOID VALVE
- 8.PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
- 9.TCCSV

SBLAT6142L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "TCC SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

Automatic Transaxle System

AT-111

P0748

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

The line pressure solenoid valve regulates the oil pump discharge pressure to suit the driving condition in response to a signal sent from the TCM. The line pressure duty cycle valve is not consistent when the closed throttle position signal is "ON".

DTC DESCRIPTION

To confirm the line pressure duty cycle at low pressure, the accelerator (throttle) should be open until the closed throttle position signal is "OFF".

DTC DETECTING CONDITION

[DSL 2.5]

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Check voltage range 	※ PRESSURE CONTROL SOLENOID VALVE(LINE PRESSURE : PCSV(PL. SOL)) <ul style="list-style-type: none"> Open or short in circuit Faulty PCSV Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> CONTINUOUS 	
Threshold value	<ul style="list-style-type: none"> Ground short/open : Monitoring value[current] ≤ 0.05 A, When the driver output ≥ 0.49A B+ short : Monitoring value[current] ≤ 0.4A, When the driver output ≥ 0.75A 	
Diagnostic Time	<ul style="list-style-type: none"> More than 5sec 	
Fail Safe	<ul style="list-style-type: none"> 5 gear is prohibited.(L/U off) Sports mode is prohibited. 	

AT-112

Automatic Transaxle System

[GSL 3.3/3.8]

Item	Detecting Condition	Possible cause
DTC Strategy	• Check voltage range	※ PRESSURE CONTROL SOLENOID VALVE(LINE PRESSURE : PCSV(PL. SOL)) <ul style="list-style-type: none"> • Open or short in circuit • Faulty PCSV • Faulty TCM
Enable Conditions	• 10V < Actuator power supply voltage < 16V	
Threshold value	• Hardware "IC" check	
Diagnostic Time	• More than 0.2sec	
Fail Safe	• Lock-up control is prohibited(L/U off)	

Signal Waveform




FIG.1)




FIG.2)




FIG.3)

FIG.1) N RANGE

FIG.2) N → D (Low pressure control)

FIG.3) STALL TEST(High pressure control)

SBLAT6155L

Automatic Transaxle System

AT-113

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC)
2. Engine "ON".
3. Monitor the "PCSV" parameter on the scantool.

4. Select "D RANGE" and Operate the vehicle.
5. Check "PCSV" parameter value changes while driving.

1.3 CURRENT DATA		18/76
× PL. SOL. OUTPUT	0.44 A	
× PL. SOL. MONITOR	0.53 A	
× CURRENT GEAR POS.	1 GEAR	
× SHIFT RANGE INDICATOR	P	
SELECTED LEVER RANGE		
SPORTS MODE SELECT		
SPORTS MODE DOWN SW		
SPORTS MODE UP SW		
<div style="display: flex; justify-content: space-between;"> FIX PART FULL HELP GRPH RCRD </div>		

FIG.1)

1.3 CURRENT DATA		18/76
× PL. SOL. OUTPUT	0.54 A	
× PL. SOL. MONITOR	0.63 A	
× CURRENT GEAR POS.	1 GEAR	
× SHIFT RANGE INDICATOR	R	
SELECTED LEVER RANGE		
SPORTS MODE SELECT		
SPORTS MODE DOWN SW		
SPORTS MODE UP SW		
<div style="display: flex; justify-content: space-between;"> FIX PART FULL HELP GRPH RCRD </div>		

FIG.2)

1.3 CURRENT DATA		18/76
× PL. SOL. OUTPUT	0.45 A	
× PL. SOL. MONITOR	0.53 A	
× CURRENT GEAR POS.	1 GEAR	
× SHIFT RANGE INDICATOR	N	
SELECTED LEVER RANGE		
SPORTS MODE SELECT		
SPORTS MODE DOWN SW		
SPORTS MODE UP SW		
<div style="display: flex; justify-content: space-between;"> FIX PART FULL HELP GRPH RCRD </div>		

FIG.3)

1.3 CURRENT DATA		18/76
× PL. SOL. OUTPUT	0.45 A	
× PL. SOL. MONITOR	0.53 A	
× CURRENT GEAR POS.	1 GEAR	
× SHIFT RANGE INDICATOR	D	
SELECTED LEVER RANGE		
SPORTS MODE SELECT		
SPORTS MODE DOWN SW		
SPORTS MODE UP SW		
<div style="display: flex; justify-content: space-between;"> FIX PART FULL HELP GRPH RCRD </div>		

FIG.4)

1.3 CURRENT DATA		18/76
× PL. SOL. OUTPUT	0.29 A	
× PL. SOL. MONITOR	0.36 A	
× CURRENT GEAR POS.	2 GEAR	
× SHIFT RANGE INDICATOR	-	
SELECTED LEVER RANGE		
SPORTS MODE SELECT		
SPORTS MODE DOWN SW		
SPORTS MODE UP SW		
<div style="display: flex; justify-content: space-between;"> FIX PART FULL HELP GRPH RCRD </div>		

FIG.5)

1.3 CURRENT DATA		18/76
× PL. SOL. OUTPUT	0.43 A	
× PL. SOL. MONITOR	0.51 A	
× CURRENT GEAR POS.	3 GEAR	
× SHIFT RANGE INDICATOR	-	
SELECTED LEVER RANGE		
SPORTS MODE SELECT		
SPORTS MODE DOWN SW		
SPORTS MODE UP SW		
<div style="display: flex; justify-content: space-between;"> FIX PART FULL HELP GRPH RCRD </div>		

FIG.6)

1.3 CURRENT DATA		18/76
× PL. SOL. OUTPUT	0.48 A	
× PL. SOL. MONITOR	0.59 A	
× CURRENT GEAR POS.	4 GEAR	
× SHIFT RANGE INDICATOR	-	
SELECTED LEVER RANGE		
SPORTS MODE SELECT		
SPORTS MODE DOWN SW		
SPORTS MODE UP SW		
<div style="display: flex; justify-content: space-between;"> FIX PART FULL HELP GRPH RCRD </div>		

FIG.7)

1.3 CURRENT DATA		18/76
× PL. SOL. OUTPUT	0.48 A	
× PL. SOL. MONITOR	0.58 A	
× CURRENT GEAR POS.	5 GEAR	
× SHIFT RANGE INDICATOR	-	
SELECTED LEVER RANGE		
SPORTS MODE SELECT		
SPORTS MODE DOWN SW		
SPORTS MODE UP SW		
<div style="display: flex; justify-content: space-between;"> FIX PART FULL HELP GRPH RCRD </div>		

FIG.8)

FIG.1) "P" Range

FIG.2) "R" Shifting

FIG.3) "N" Range

FIG.4) "D" Range 1st gear

FIG.5) "D" Range 2nd gear

FIG.6) "D" Range 3rd gear

FIG.7) "D" Range 4th gear

FIG.8) "D" Range 5th gear

SBLAT6156L

AT-114

Automatic Transaxle System

6. Does "PCSV DUTY " follow the reference data?

YES

▶ Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

▶ Go to "Terminal & connector inspection " procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

▶ Repair as necessary and then go to "Verification of vehicle repair" procedure.


NO

▶ Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2/C106-2" connector.
2. IGNITION "ON", ENGINE "OFF"
3. Measure voltage between terminal "8" of the C06-2/C106-2 harness connector and chassis ground.

Specification : approx. 5V



C06-2 [DSL 2.5]
C106-2 [GSL 3.3/3.8]

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. DIRECT CLUTCH SOLENOID VALVE
6. FRONT BRAKE SOLENOID VALVE
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6157L

4. Is voltage within specifications?

YES

▶ Go to "Component inspection" procedure.

NO

▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.

Automatic Transaxle System


AT-115

COMPONENT INSPECTION

1. Disconnect "C06-2/C106-2" connector.
2. Ignition "OFF".

3. Measure resistance between terminal "8" of the C06-2/C106-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2 [DSL 2.5]
C106-2 [GSL 3.3/3.8]
Component side

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. DIRECT CLUTCH SOLENOID VALVE
6. FRONT BRAKE SOLENOID VALVE
7. INPUT CLUTCH SOLENOID VALVE
- 8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)**
9. TCCSV

SBLAT6158L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "PRESSURE CONTROL SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

AT-116

Automatic Transaxle System

P0751

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

The Automatic Transmission changes the gear position of the transmission utilizing a combination of Clutches and Brakes, which are controlled by solenoid valves. Input clutch solenoid valve is controlled by the TCM in response to signals sent from the inhibitor switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

DTC DESCRIPTION

This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Rationality check (stuck-off) 	※ INPUT CLUTCH SOLENOID VALVE : I/C SOLENOID VALVE • Open or short in circuit • Faulty I/C SOLENOID VALVE • Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed ≥ 6.2MPH(10km/h) Engine speed > 305 rpm A/T range switch is D range A/T flued temperature $\geq -40^{\circ}$F 	
Threshold value	<ul style="list-style-type: none"> Fluid pressure switch A "OFF" when the monitoring value ≤ 0.05A and When there's a difference between calculated and measured gear ratio. 	
Diagnostic Time	<ul style="list-style-type: none"> A/T flued temperature $> 14^{\circ}$F : More then 2secs A/T flued temperature $\leq 14^{\circ}$F : More then 8secs 	
Fail Safe	<ul style="list-style-type: none"> Locked in to 4th gear. 	

Automatic Transaxle System

AT-117

Signal Waveform




FIG.1)

FIG.1) N RANGE

FIG.2) 4 GEAR




FIG.2)

MONITOR SCANTOOL DATA


1. Connect scantool to data link connector(DLC)
2. Engine "ON".

3. Monitor the "I/C SOLENOID" parameter on the scantool.
4. Select "D RANGE" and Operate the vehicle.
5. Check "I/C SOLENOID" parameter value changes while driving.

SBLAT6160L

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



AT-118

Automatic Transaxle System

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.69 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	P	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH RCRD

FIG.1)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.70 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	R	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH RCRD

FIG.2)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.70 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	N	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH RCRD

FIG.3)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.70 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	D	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH RCRD

FIG.4)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.69 A	
* I/C SOL. MONITOR	0.79 A	
* CURRENT GEAR POS.	2	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH RCRD

FIG.5)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.68 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	3	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH RCRD

FIG.6)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.01 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	4	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW3(I/C)	ON	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH RCRD

FIG.7)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.01 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	5	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW3(I/C)	ON	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH RCRD

FIG.8)

- FIG.1) "P" Range
- FIG.2) "R" Shifting
- FIG.3) "N" Range
- FIG.4) "D" Range 1st gear

- FIG.5) "D" Range 2nd gear
- FIG.6) "D" Range 3rd gear
- FIG.7) "D" Range 4th gear
- FIG.8) "D" Range 5th gear

6. Does "I/C SOLENOID " follow the reference data?

YES

► Fault is intermittent caused by poor contact in the

sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage.Repair or replace as

SBLAT6161L

Automatic Transaxle System

AT-119

necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.


NO

► Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2" connector.
2. IGNITION "ON", ENGINE "OFF"
3. Measure voltage between terminal "7" of the C06-2 harness connector and chassis ground.

Specification : Output voltage repeated between 4V and 12V



C06-2

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. DIRECT CLUTCH SOLENOID VALVE
6. FRONT BRAKE SOLENOID VALVE
7. **INPUT CLUTCH SOLENOID VALVE**
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6162L

4. Is voltage within specifications?

YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.


AT-120

Automatic Transaxle System

COMPONENT INSPECTION

1. Disconnect "C06-2" connector.
2. Ignition "OFF".
3. Measure resistance between terminal "7" of the C06-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2
Component side



- 1.ATF 2
- 2.LOW COAST BRAKE SOLENOID VALVE
- 3.HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
- 4.DIRECT CLUTCH SOLENOID VALVE
- 6.FRONT BRAKE SOLENOID VALVE
- 7.INPUT CLUTCH SOLENOID VALVE**
- 8.PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
- 9.TCCSV

SBLAT6163L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "I/C SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

Automatic Transaxle System

AT-121

P0752

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

The Automatic Transmission changes the gear position of the transmission utilizing a combination of Clutches and Brakes, which are controlled by solenoid valves. Input clutch solenoid valve is controlled by the TCM in response to signals sent from the inhibitor switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

DTC DESCRIPTION

This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Rationality check (stuck-on) 	※ INPUT CLUTCH SOLENOID VALVE : I/C SOLENOID VALVE • Open or short in circuit • Faulty I/C SOLENOID VALVE • Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed ≥ 6.2MPH(10km/h) Engine speed > 305 rpm A/T range switch is D range A/T flued temperature $\geq -40^{\circ}$F 	
Threshold value	<ul style="list-style-type: none"> Fluid pressure switch A "ON" when the monitoring value ≤ 0.75A and When there's a difference between calculated and measured gear ratio. 	
Diagnostic Time	<ul style="list-style-type: none"> A/T flued temperature $> 14^{\circ}$F : More then 2secs A/T flued temperature $\leq 14^{\circ}$F : More then 8secs 	
Fail Safe	<ul style="list-style-type: none"> Locked in to 4th gear. 	

AT-122

Automatic Transaxle System

Signal Waveform




FIG.1)

FIG.1) N RANGE




FIG.2)

FIG.2) 4 GEAR

SBLAT6160L

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC)
2. Engine "ON".
3. Monitor the "I/C SOLENOID" parameter on the scantool.
4. Select "D RANGE" and Operate the vehicle.
5. Check "I/C SOLENOID" parameter value changes while driving.



Automatic Transaxle System

AT-123

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.69 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	P	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.1)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.70 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	R	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.2)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.70 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	N	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.3)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.70 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	D	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.4)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.69 A	
* I/C SOL. MONITOR	0.79 A	
* CURRENT GEAR POS.	2	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.5)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.68 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	3	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.6)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.01 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	4	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW3(I/C)	ON	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.7)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.01 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	5	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW3(I/C)	ON	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.8)

FIG.1) "P" Range

FIG.2) "R" Shifting

FIG.3) "N" Range

FIG.4) "D" Range 1st gear

FIG.5) "D" Range 2nd gear

FIG.6) "D" Range 3rd gear

FIG.7) "D" Range 4th gear

FIG.8) "D" Range 5th gear

SBLAT6161L

6. Does "I/C SOLENOID " follow the reference data?

YES

► Fault is intermittent caused by poor contact in the

sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as

AT-124

Automatic Transaxle System

necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.


NO

► Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2" connector.
2. IGNITION "ON", ENGINE "OFF"
3. Measure voltage between terminal "7" of the C06-2 harness connector and chassis ground.

Specification : Output voltage repeated between 4V and 12V



1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. DIRECT CLUTCH SOLENOID VALVE
6. FRONT BRAKE SOLENOID VALVE
7. **INPUT CLUTCH SOLENOID VALVE**
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6162L

4. Is voltage within specifications?

YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.


Automatic Transaxle System

AT-125

COMPONENT INSPECTION

1. Disconnect "C06-2" connector.
2. Ignition "OFF".
3. Measure resistance between terminal "7" of the C06-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2
Component side



- 1.ATF 2
- 2.LOW COAST BRAKE SOLENOID VALVE
- 3.HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
- 4.DIRECT CLUTCH SOLENOID VALVE
- 6.FRONT BRAKE SOLENOID VALVE
- 7.INPUT CLUTCH SOLENOID VALVE**
- 8.PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
- 9.TCCSV

SBLAT6163L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "I/C SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

AT-126

Automatic Transaxle System

P0753

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

The Automatic Transmission changes the gear position of the transmission utilizing a combination of Clutches and Brakes, which are controlled by solenoid valves. Input clutch solenoid valve is controlled by the TCM in response to signals sent from the inhibitor switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

DTC DESCRIPTION

This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

DTC DETECTING CONDITION

[DSL 2.5]

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Check voltage range 	※ INPUT CLUTCH SOLENOID VALVE : I/C SOLENOID VALVE <ul style="list-style-type: none"> Open or short in circuit Faulty I/C SOLENOID VALVE Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed \geq 6.2MPH(10km/h) 	
Threshold value	<ul style="list-style-type: none"> Ground short/open :Monitoring value[current]\leq 0.4A, When the driver output \geq 0.7A B+ short:Monitoring value[current]\leq 0.4A, When the driver output \geq 0.7A 	
Diagnostic Time	<ul style="list-style-type: none"> more than 5sec 	
Fail Safe	<ul style="list-style-type: none"> 5 gear is prohibited.(L/U off) Sports mode is prohibited. 	

Automatic Transaxle System

AT-127

[GSL 3.3/3.8]

Item	Detecting Condition	Possible cause
DTC Strategy	• Check voltage range	※ INPUT CLUTCH SOLENOID V-ALVE : I/C SOLENOID VALVE • Open or short in circuit • Faulty I/C SOLENOID VALVE • Faulty TCM
Enable Conditions	• $10V < \text{Actuator power supply voltage} < 16V$	
Threshold value	• Hardware "IC" check	
Diagnostic Time	• More than 0.2sec	
Fail Safe	• Lock-up control is prohibited(L/U off)	

Signal Waveform




FIG.1)

FIG.1) N RANGE

FIG.2) 4 GEAR




FIG.2)

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC)
2. Engine "ON".
3. Monitor the "I/C SOLENOID" parameter on the scantool.
4. Select "D RANGE" and Operate the vehicle.
5. Check "I/C SOLENOID" parameter value changes while driving.

SBLAT6160L

AT-128

Automatic Transaxle System

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.69 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	P	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.1)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.70 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	R	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.2)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.70 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	N	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.3)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.70 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	D	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.4)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.69 A	
* I/C SOL. MONITOR	0.79 A	
* CURRENT GEAR POS.	2	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.5)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.68 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	3	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW3(I/C)	OFF	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.6)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.01 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	4	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW3(I/C)	ON	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.7)

1.3 CURRENT DATA		20/76
* I/C SOL. OUTPUT	0.01 A	
* I/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	5	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW3(I/C)	ON	
SPORTS MODE UP SW		
SPORTS MODE GEAR POS.		
INHIBITOR SW. MONITOR		
FIX	PART	FULL HELP GRPH BCRD

FIG.8)

FIG.1) "P" Range

FIG.2) "R" Shifting

FIG.3) "N" Range

FIG.4) "D" Range 1st gear

FIG.5) "D" Range 2nd gear

FIG.6) "D" Range 3rd gear

FIG.7) "D" Range 4th gear

FIG.8) "D" Range 5th gear

SBLAT6161L

6. Does "I/C SOLENOID " follow the reference data?

YES

► Fault is intermittent caused by poor contact in the

sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage.Repair or replace as

Automatic Transaxle System

AT-129

necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.


NO

► Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2/C106-2" connector.
2. IGNITION "ON", ENGINE "OFF"
3. Measure voltage between terminal "7" of the C06-2/C106-2 harness connector and chassis ground.

Specification : Output voltage repeated between 4V and 12V



C06-2 [DSL 2.5]

C106-2 [GSL 3.3/3.8]

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. DIRECT CLUTCH SOLENOID VALVE
6. FRONT BRAKE SOLENOID VALVE
7. **INPUT CLUTCH SOLENOID VALVE**
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6164L

4. Is voltage within specifications?

YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.


AT-130

Automatic Transaxle System

COMPONENT INSPECTION

1. Disconnect "C06-2/C106-2" connector.
2. Ignition "OFF".
3. Measure resistance between terminal "7" of the C06-2/C106-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2 [DSL 2.5]
C106-2 [GSL 3.3/3.8]
Component side

- 1.ATF 2
- 2.LOW COAST BRAKE SOLENOID VALVE
- 3.HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
- 4.DIRECT CLUTCH SOLENOID VALVE
- 6.FRONT BRAKE SOLENOID VALVE
- 7.INPUT CLUTCH SOLENOID VALVE
- 8.PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
- 9.TCCSV

SBLAT6169L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "I/C SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

Automatic Transaxle System

AT-131

P0756

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

The Automatic Transmission changes the gear position of the transmission utilizing a combination of Clutches and Brakes, which are controlled by solenoid valves. Front brake solenoid valve is controlled by the TCM in response to signals sent from the inhibitor switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gear will then be shifted to the optimum position.

DTC DESCRIPTION

This is not only caused by electrical malfunction (circuit open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Rationality check (stuck-off) 	※ FRONT BRAKE SOLENOID VALVE : Fr/B SOLENOID VALVE • Open or short in circuit • Faulty Fr/B SOLENOID VALVE • Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed ≥ 6.2MPH(10km/h) Engine speed > 305 rpm A/T range switch is D range A/T fluid temperature $\geq -40^{\circ}$F 	
Threshold value	<ul style="list-style-type: none"> Fluid pressure switch B "OFF" when the monitoring value ≤ 0.75A and When there's a difference between calculated and measured gear ratio. 	
Diagnostic Time	<ul style="list-style-type: none"> A/T fluid temperature $> 14^{\circ}$F : More then 2secs A/T fluid temperature $\leq 14^{\circ}$F : More then 8secs 	
Fail Safe	<ul style="list-style-type: none"> Locked in to 4th gear. 	

AT-132

Automatic Transaxle System

Signal Waveform




FIG.1)

FIG.1) R RANGE




FIG.2)

FIG.2) 4 GEAR

SBLAT6165L

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "Fr/B SOLENOID" parameter on the scantool.
4. Select "R,D RANGE" and Operate the vehicle.
5. Check "Fr/B SOLENOID" parameter value changes while driving.



Automatic Transaxle System

AT-133

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.78 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	P	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.1)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.71 A	
* FR/B SOL. MONITOR	0.79 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	R	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.2)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.71 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	N	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.3)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.71 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	D	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.4)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.78 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	2 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.5)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.69 A	
* FR/B SOL. MONITOR	0.79 A	
* CURRENT GEAR POS.	3 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.6)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.81 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	4 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW1(FR/B)	OFF	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.7)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.68 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	5 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.8)

FIG.1) "P" Range

FIG.2) "R" Shifting

FIG.3) "N" Range

FIG.4) "D" Range 1st gear

FIG.5) "D" Range 2nd gear

FIG.6) "D" Range 3rd gear

FIG.7) "D" Range 4th gear

FIG.8) "D" Range 5th gear

SBLAT6166L

6. Does "Fr/B SOLENOID " follow the reference data?

YES

► Fault is intermittent caused by poor contact in the

sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as

AT-134

Automatic Transaxle System

necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.


NO

► Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2" connector.
2. IGNITION "ON", ENGINE "OFF"
3. Measure voltage between terminal "6" of the C06-2 harness connector and chassis ground.

Specification : approx. 5V



C06-2

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. DIRECT CLUTCH SOLENOID VALVE
- 6. FRONT BRAKE SOLENOID VALVE**
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6167L

4. Is voltage within specifications?

YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.


Automatic Transaxle System

AT-135

COMPONENT INSPECTION

1. Disconnect "C06-2" connector.
2. Ignition "OFF".
3. Measure resistance between terminal "6" of the C06-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2
Component side

- 1.ATF 2
- 2.LOW COAST BRAKE SOLENOID VALVE
- 3.HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
- 4.DIRECT CLUTCH SOLENOID VALVE
- 6.FRONT BRAKE SOLENOID VALVE**
- 7.INPUT CLUTCH SOLENOID VALVE
- 8.PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
- 9.TCCSV

SBLAT6168L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "Fr/B SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

AT-136

Automatic Transaxle System

P0757

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

The Automatic Transmission changes the gear position of the transmission utilizing a combination of Clutches and Brakes, which are controlled by solenoid valves. Front brake solenoid valve is controlled by the TCM in response to signals sent from the inhibitor switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gear will then be shifted to the optimum position.

DTC DESCRIPTION

This is not only caused by electrical malfunction (circuit open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Rationality check (stuck-off) 	※ FRONT BRAKE SOLENOID VALVE : Fr/B SOLENOID VALVE <ul style="list-style-type: none"> Open or short in circuit Faulty Fr/B SOLENOID VALVE Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed ≥ 6.2MPH(10km/h) Engine speed > 305 rpm A/T range switch is D range A/T flued temperature $\geq -40^{\circ}$F 	
Threshold value	<ul style="list-style-type: none"> Fluid pressure switch B "ON" when the monitoring v-alue ≤ 0.05A and When there's a difference between calculated and measured gear ratio. 	
Diagnostic Time	<ul style="list-style-type: none"> A/T flued temperature $> 14^{\circ}$F : More then 2secs A/T flued temperature $\leq 14^{\circ}$F : More then 8secs 	
Fail Safe	<ul style="list-style-type: none"> Locked in to 5th gear. 	

Automatic Transaxle System

AT-137

Signal Waveform




FIG.1)

FIG.1) R RANGE




FIG.2)

FIG.2) 4 GEAR

SBLAT6165L

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC)
2. Engine "ON".
3. Monitor the "Fr/B SOLENOID" parameter on the scantool.
4. Select "R,D RANGE" and Operate the vehicle.
5. Check "Fr/B SOLENOID" parameter value changes while driving.



AT-138

Automatic Transaxle System

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.78 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	P	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.1)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.71 A	
* FR/B SOL. MONITOR	0.79 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	R	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.2)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.71 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	N	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.3)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.71 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	D	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.4)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.78 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	2	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.5)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.69 A	
* FR/B SOL. MONITOR	0.79 A	
* CURRENT GEAR POS.	3	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.6)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.81 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	4	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW1(FR/B)	OFF	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.7)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.68 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	5	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.8)

FIG.1) "P" Range

FIG.2) "R" Shifting

FIG.3) "N" Range

FIG.4) "D" Range 1st gear

FIG.5) "D" Range 2nd gear

FIG.6) "D" Range 3rd gear

FIG.7) "D" Range 4th gear

FIG.8) "D" Range 5th gear

SBLAT6166L

6. Does "Fr/B SOLENOID " follow the reference data?

YES

► Fault is intermittent caused by poor contact in the

sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage.Repair or replace as

Automatic Transaxle System

AT-139

necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.


NO

► Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2" connector.
2. IGNITION "ON", ENGINE "OFF"
3. Measure voltage between terminal "6" of the C06-2 harness connector and chassis ground.

Specification : approx. 5V



C06-2

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. DIRECT CLUTCH SOLENOID VALVE
- 6. FRONT BRAKE SOLENOID VALVE**
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6167L

4. Is voltage within specifications?

YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.


AT-140

Automatic Transaxle System

COMPONENT INSPECTION

1. Disconnect "C06-2" connector.
2. Ignition "OFF".
3. Measure resistance between terminal "6" of the C06-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2
Component side

- 1.ATF 2
- 2.LOW COAST BRAKE SOLENOID VALVE
- 3.HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
- 4.DIRECT CLUTCH SOLENOID VALVE
- 6.FRONT BRAKE SOLENOID VALVE**
- 7.INPUT CLUTCH SOLENOID VALVE
- 8.PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
- 9.TCCSV

SBLAT6168L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "Fr/B SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

Automatic Transaxle System

AT-141

P0758

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

The Automatic Transmission changes the gear position of the transmission utilizing a combination of Clutches and Brakes, which are controlled by solenoid valves. Front brake solenoid valve is controlled by the TCM in response to signals sent from the inhibitor switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gear will then be shifted to the optimum position.

DTC DESCRIPTION

This is not only caused by electrical malfunction (circuit open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

DTC DETECTING CONDITION

[DSL 2.5]

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Check voltage range 	※ FRONT BRAKE SOLENOID VALVE : Fr/B SOLENOID VALVE <ul style="list-style-type: none"> Open or short in circuit Faulty Fr/B SOLENOID VALVE Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed \geq 6.2MPH(10km/h) 	
Threshold value	<ul style="list-style-type: none"> Ground short/open :Monitoring value[current]\leq 0.4A, When the driver output \geq 0.7A B+ short:Monitoring value[current]\leq 0.4A, When the driver output \geq 0.7A 	
Diagnostic Time	<ul style="list-style-type: none"> more than 5sec 	
Fail Safe	<ul style="list-style-type: none"> Locked into 4 or 5th gear, lock-up control is inhibited, pressure control is inhibited. 	

AT-142

Automatic Transaxle System

[GSL 3.3/3.8]

Item	Detecting Condition	Possible cause
DTC Strategy	• Check voltage range	※ FRONT BRAKE SOLENOID V-ALVE : Fr/B SOLENOID VALVE • Open or short in circuit • Faulty Fr/B SOLENOID VALVE • Faulty TCM
Enable Conditions	• $10V < \text{Actuator power supply voltage} < 16V$	
Threshold value	• Hardware "IC" check	
Diagnostic Time	• More than 0.2sec	
Fail Safe	• Lock-up control is prohibited(L/U off)	

Signal Waveform




FIG.1)

FIG.1) R RANGE

FIG.2) 4 GEAR




FIG.2)

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC)
2. Engine "ON".
3. Monitor the "Fr/B SOLENOID" parameter on the scantool.
4. Select "R,D RANGE" and Operate the vehicle.
5. Check "Fr/B SOLENOID" parameter value changes while driving.

SBLAT6165L

Automatic Transaxle System

AT-143

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.78 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	P	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.1)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.71 A	
* FR/B SOL. MONITOR	0.79 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	R	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.2)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.71 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	N	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.3)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.71 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	D	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.4)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.78 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	2 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.5)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.69 A	
* FR/B SOL. MONITOR	0.79 A	
* CURRENT GEAR POS.	3 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.6)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.81 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	4 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW1(FR/B)	OFF	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.7)

1.3 CURRENT DATA		22/76
* FR/B SOL. OUTPUT	0.68 A	
* FR/B SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	5 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW1(FR/B)	ON	
BRAKE SWITCH		
REVERSE LAMP		
STARTER RELAY MONITOR		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.8)

FIG.1) "P" Range

FIG.2) "R" Shifting

FIG.3) "N" Range

FIG.4) "D" Range 1st gear

FIG.5) "D" Range 2nd gear

FIG.6) "D" Range 3rd gear

FIG.7) "D" Range 4th gear

FIG.8) "D" Range 5th gear

SBLAT6166L

6. Does "Fr/B SOLENOID " follow the reference data?

YES

► Fault is intermittent caused by poor contact in the

sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as

AT-144

Automatic Transaxle System

necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.


NO

► Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2/C106-2" connector.
2. IGNITION "ON", ENGINE "OFF"
3. Measure voltage between terminal "6" of the C06-2/C106-2 harness connector and chassis ground.

Specification : approx. 5V



C06-2 [DSL 2.5]

C106-2 [GSL 3.3/3.8]

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. DIRECT CLUTCH SOLENOID VALVE
- 6. FRONT BRAKE SOLENOID VALVE**
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6173L

4. Is voltage within specifications?

YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.


Automatic Transaxle System

AT-145

COMPONENT INSPECTION

1. Disconnect "C06-2/C106-2" connector.
2. Ignition "OFF".
3. Measure resistance between terminal "6" of the C06-2/C106-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2 [DSL 2.5]

C106-2 [GSL 3.3/3.8]

Component side

- 1.ATF 2
- 2.LOW COAST BRAKE SOLENOID VALVE
- 3.HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
- 4.DIRECT CLUTCH SOLENOID VALVE
- 6.FRONT BRAKE SOLENOID VALVE
- 7.INPUT CLUTCH SOLENOID VALVE
- 8.PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
- 9.TCCSV



SBLAT6174L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "Fr/B SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

AT-146

Automatic Transaxle System

P0761

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

The Automatic Transmission changes the gear position of the transmission utilizing a combination of Clutches and Brakes, which are controlled by solenoid valves. Direct clutch solenoid valve is controlled by the TCM in response to signals sent from the inhibitor switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

DTC DESCRIPTION

This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Rationality check (stuck-off) 	※ DIRECT CLUTCH SOLENOID VALVE : D/C SOLENOID VALVE • Open or short in circuit • Faulty D/C SOLENOID VALVE • Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed ≥ 6.2MPH(10km/h) Engine speed > 305 rpm A/T range switch is D range A/T flued temperature $\geq -40^{\circ}$F 	
Threshold value	<ul style="list-style-type: none"> Fluid pressure switch C "OFF" when the monitoring value ≤ 0.05A and When there's a difference between calculated and measured gear ratio. 	
Diagnostic Time	<ul style="list-style-type: none"> A/T flued temperature $> 14^{\circ}$F : More then 2secs A/T flued temperature $\leq 14^{\circ}$F : More then 8secs 	
Fail Safe	<ul style="list-style-type: none"> Locked in to 4th gear. 	

Automatic Transaxle System

AT-147

Signal Waveform




FIG.1)

FIG.1) N RANGE

FIG.2) 2 GEAR




FIG.2)

SBLAT6185L

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "D/C SOLENOID" parameter on the scantool.
4. Select "D RANGE" and Operate the vehicle.
5. Check "D/C SOLENOID" parameter value changes while driving.



AT-148

Automatic Transaxle System

1.3 CURRENT DATA		24/76						
* D/C SOL. OUTPUT	0.72 A							
* D/C SOL. MONITOR	0.79 A							
* CURRENT GEAR POS.	1 GEAR							
* SHIFT RANGE INDICATOR	P							
* OIL PRESS SW5(D/C)	OFF							
OIL PRESS SW3(I/C)								
OIL PRESS SW2(LC/B)								
OIL PRESS SW1(FR/B)								
<table border="0"> <tr> <td>FIX</td> <td>PART</td> <td>FULL</td> <td>HELP</td> <td>GRPH</td> <td>RCRD</td> </tr> </table>			FIX	PART	FULL	HELP	GRPH	RCRD
FIX	PART	FULL	HELP	GRPH	RCRD			

FIG.1)

1.3 CURRENT DATA		24/76						
* D/C SOL. OUTPUT	0.72 A							
* D/C SOL. MONITOR	0.80 A							
* CURRENT GEAR POS.	1 GEAR							
* SHIFT RANGE INDICATOR	R							
* OIL PRESS SW5(D/C)	OFF							
OIL PRESS SW3(I/C)								
OIL PRESS SW2(LC/B)								
OIL PRESS SW1(FR/B)								
<table border="0"> <tr> <td>FIX</td> <td>PART</td> <td>FULL</td> <td>HELP</td> <td>GRPH</td> <td>RCRD</td> </tr> </table>			FIX	PART	FULL	HELP	GRPH	RCRD
FIX	PART	FULL	HELP	GRPH	RCRD			

FIG.2)

1.3 CURRENT DATA		24/76						
* D/C SOL. OUTPUT	0.72 A							
* D/C SOL. MONITOR	0.79 A							
* CURRENT GEAR POS.	1 GEAR							
* SHIFT RANGE INDICATOR	N							
* OIL PRESS SW5(D/C)	OFF							
OIL PRESS SW3(I/C)								
OIL PRESS SW2(LC/B)								
OIL PRESS SW1(FR/B)								
<table border="0"> <tr> <td>FIX</td> <td>PART</td> <td>FULL</td> <td>HELP</td> <td>GRPH</td> <td>RCRD</td> </tr> </table>			FIX	PART	FULL	HELP	GRPH	RCRD
FIX	PART	FULL	HELP	GRPH	RCRD			

FIG.3)

1.3 CURRENT DATA		24/76						
* D/C SOL. OUTPUT	0.72 A							
* D/C SOL. MONITOR	0.80 A							
* CURRENT GEAR POS.	1 GEAR							
* SHIFT RANGE INDICATOR	D							
* OIL PRESS SW5(D/C)	OFF							
OIL PRESS SW3(I/C)								
OIL PRESS SW2(LC/B)								
OIL PRESS SW1(FR/B)								
<table border="0"> <tr> <td>FIX</td> <td>PART</td> <td>FULL</td> <td>HELP</td> <td>GRPH</td> <td>RCRD</td> </tr> </table>			FIX	PART	FULL	HELP	GRPH	RCRD
FIX	PART	FULL	HELP	GRPH	RCRD			

FIG.4)

1.3 CURRENT DATA		24/76						
* D/C SOL. OUTPUT	0.82 A							
* D/C SOL. MONITOR	0.80 A							
* CURRENT GEAR POS.	2 GEAR							
* SHIFT RANGE INDICATOR	-							
* OIL PRESS SW5(D/C)	ON							
OIL PRESS SW3(I/C)								
OIL PRESS SW2(LC/B)								
OIL PRESS SW1(FR/B)								
<table border="0"> <tr> <td>FIX</td> <td>PART</td> <td>FULL</td> <td>HELP</td> <td>GRPH</td> <td>RCRD</td> </tr> </table>			FIX	PART	FULL	HELP	GRPH	RCRD
FIX	PART	FULL	HELP	GRPH	RCRD			

FIG.5)

1.3 CURRENT DATA		24/76						
* D/C SOL. OUTPUT	0.82 A							
* D/C SOL. MONITOR	0.80 A							
* CURRENT GEAR POS.	3 GEAR							
* SHIFT RANGE INDICATOR	-							
* OIL PRESS SW5(D/C)	ON							
OIL PRESS SW3(I/C)								
OIL PRESS SW2(LC/B)								
OIL PRESS SW1(FR/B)								
<table border="0"> <tr> <td>FIX</td> <td>PART</td> <td>FULL</td> <td>HELP</td> <td>GRPH</td> <td>RCRD</td> </tr> </table>			FIX	PART	FULL	HELP	GRPH	RCRD
FIX	PART	FULL	HELP	GRPH	RCRD			

FIG.6)

1.3 CURRENT DATA		24/76						
* D/C SOL. OUTPUT	0.82 A							
* D/C SOL. MONITOR	0.80 A							
* CURRENT GEAR POS.	4 GEAR							
* SHIFT RANGE INDICATOR	-							
* OIL PRESS SW5(D/C)	ON							
OIL PRESS SW3(I/C)								
OIL PRESS SW2(LC/B)								
OIL PRESS SW1(FR/B)								
<table border="0"> <tr> <td>FIX</td> <td>PART</td> <td>FULL</td> <td>HELP</td> <td>GRPH</td> <td>RCRD</td> </tr> </table>			FIX	PART	FULL	HELP	GRPH	RCRD
FIX	PART	FULL	HELP	GRPH	RCRD			

FIG.7)

1.3 CURRENT DATA		24/76						
* D/C SOL. OUTPUT	0.69 A							
* D/C SOL. MONITOR	0.80 A							
* CURRENT GEAR POS.	5 GEAR							
* SHIFT RANGE INDICATOR	-							
* OIL PRESS SW5(D/C)	OFF							
OIL PRESS SW3(I/C)								
OIL PRESS SW2(LC/B)								
OIL PRESS SW1(FR/B)								
<table border="0"> <tr> <td>FIX</td> <td>PART</td> <td>FULL</td> <td>HELP</td> <td>GRPH</td> <td>RCRD</td> </tr> </table>			FIX	PART	FULL	HELP	GRPH	RCRD
FIX	PART	FULL	HELP	GRPH	RCRD			

FIG.8)

FIG.1) "P" Range

FIG.2) "R" Shifting

FIG.3) "N" Range

FIG.4) "D" Range 1st gear

FIG.5) "D" Range 2nd gear

FIG.6) "D" Range 3rd gear

FIG.7) "D" Range 4th gear

FIG.8) "D" Range 5th gear

SBLAT6170L

6. Does "D/C SOLENOID" follow the reference data?

YES

► Fault is intermittent caused by poor contact in the

sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as

Automatic Transaxle System

AT-149

necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.

NO

► Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2" connector.
2. IGNITION "ON", ENGINE "OFF"
3. Measure voltage between terminal "4" of the C06-2 harness connector and chassis ground.

Specification : approx. 5V



C06-2

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. **DIRECT CLUTCH SOLENOID VALVE**
6. FRONT BRAKE SOLENOID VALVE
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6171L

4. Is voltage within specifications?

YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.


AT-150

Automatic Transaxle System

COMPONENT INSPECTION

1. Disconnect "C06-2" connector.
2. Ignition "OFF".
3. Measure resistance between terminal "4" of the C06-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2
Component side



1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. **DIRECT CLUTCH SOLENOID VALVE**
6. FRONT BRAKE SOLENOID VALVE
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6172L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "D/C SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

Automatic Transaxle System

AT-151

P0762

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

The Automatic Transmission changes the gear position of the transmission utilizing a combination of Clutches and Brakes, which are controlled by solenoid valves. Direct clutch solenoid valve is controlled by the TCM in response to signals sent from the inhibitor switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

DTC DESCRIPTION

This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Rationality check (stuck-on) 	※ DIRECT CLUTCH SOLENOID VALVE : D/C SOLENOID VALVE <ul style="list-style-type: none"> Open or short in circuit Faulty D/C SOLENOID VALVE Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed \geq 6.2MPH(10km/h) Engine speed $>$ 305 rpm A/T range switch is D range A/T flued temperature \geq -40°F 	
Threshold value	<ul style="list-style-type: none"> Fluid pressure switch C "ON" when the monitoring v-alue \leq 0.75A and When there's a difference between calculated and measured gear ratio. 	
Diagnostic Time	<ul style="list-style-type: none"> A/T flued temperature $>$ 14°F : More then 2secs A/T flued temperature \leq 14°F : More then 8secs 	
Fail Safe	<ul style="list-style-type: none"> Locked in to 4th gear. 	

AT-152

Automatic Transaxle System

Signal Waveform




FIG.1)

FIG.1) N RANGE




FIG.2)

FIG.2) 2 GEAR

SBLAT6185L

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "D/C SOLENOID" parameter on the scantool.
4. Select "D RANGE" and Operate the vehicle.
5. Check "D/C SOLENOID" parameter value changes while driving.



Automatic Transaxle System

AT-153

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.72 A	
* D/C SOL. MONITOR	0.79 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	P	
* OIL PRESS SW5(D/C)	OFF	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		

FIG.1)

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.72 A	
* D/C SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	R	
* OIL PRESS SW5(D/C)	OFF	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		

FIG.2)

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.72 A	
* D/C SOL. MONITOR	0.79 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	N	
* OIL PRESS SW5(D/C)	OFF	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		

FIG.3)

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.72 A	
* D/C SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	D	
* OIL PRESS SW5(D/C)	OFF	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		

FIG.4)

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.82 A	
* D/C SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	2 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW5(D/C)	ON	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		

FIG.5)

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.82 A	
* D/C SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	3 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW5(D/C)	ON	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		

FIG.6)

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.82 A	
* D/C SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	4 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW5(D/C)	ON	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		

FIG.7)

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.69 A	
* D/C SOL. MONITOR	0.88 A	
* CURRENT GEAR POS.	5 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW5(D/C)	OFF	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		

FIG.8)

FIG.1) "P" Range

FIG.2) "R" Shifting

FIG.3) "N" Range

FIG.4) "D" Range 1st gear

FIG.5) "D" Range 2nd gear

FIG.6) "D" Range 3rd gear

FIG.7) "D" Range 4th gear

FIG.8) "D" Range 5th gear

SBLAT6170L

6. Does "D/C SOLENOID" follow the reference data?

YES

► Fault is intermittent caused by poor contact in the

sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as

AT-154

Automatic Transaxle System

necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.

NO

► Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2" connector.
2. IGNITION "ON", ENGINE "OFF"
3. Measure voltage between terminal "3" of the C06-2 harness connector and chassis ground.

Specification : approx. 5V



C06-2

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. **DIRECT CLUTCH SOLENOID VALVE**
6. FRONT BRAKE SOLENOID VALVE
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6171L

4. Is voltage within specifications?

YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.


Automatic Transaxle System

AT-155

COMPONENT INSPECTION

1. Disconnect "C06-2" connector.
2. Ignition "OFF".
3. Measure resistance between terminal "4" of the C06-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2
Component side



- 1.ATF 2
- 2.LOW COAST BRAKE SOLENOID VALVE
- 3.HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
- 4.DIRECT CLUTCH SOLENOID VALVE**
- 6.FRONT BRAKE SOLENOID VALVE
- 7.INPUT CLUTCH SOLENOID VALVE
- 8.PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
- 9.TCCSV

SBLAT6172L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "D/C SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

AT-156

Automatic Transaxle System

P0763

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

The Automatic Transmission changes the gear position of the transmission utilizing a combination of Clutches and Brakes, which are controlled by solenoid valves. Direct clutch solenoid valve is controlled by the TCM in response to signals sent from the inhibitor switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

DTC DESCRIPTION

This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

DTC DETECTING CONDITION

[DSL 2.5]

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Check voltage range 	※ DIRECT CLUTCH SOLENOID VALVE : D/C SOLENOID VALVE <ul style="list-style-type: none"> Open or short in circuit Faulty D/C SOLENOID VALVE Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed \geq 6.2MPH(10km/h) 	
Threshold value	<ul style="list-style-type: none"> Ground short/open :Monitoring value[current]\leq 0.4A, When the driver output \geq 0.7A B+ short:Monitoring value[current]\leq 0.4A, When the driver output \geq 0.7A 	
Diagnostic Time	<ul style="list-style-type: none"> More than 5sec 	
Fail Safe	<ul style="list-style-type: none"> Locked into 4th gear, lock-up control is inhibited, pressure control is inhibited. 	

Automatic Transaxle System

AT-157

[GSL 3.3/3.8]

Item	Detecting Condition	Possible cause
DTC Strategy	• Check voltage range	※ DIRECT CLUTCH SOLENOID VALVE : D/C SOLENOID VALVE • Open or short in circuit • Faulty D/C SOLENOID VALVE • Faulty TCM
Enable Conditions	• $10V < \text{Actuator power supply voltage} < 16V$	
Threshold value	• Hardware "IC" check	
Diagnostic Time	• More than 0.2sec	
Fail Safe	• Lock-up control is prohibited(L/U off)	

Signal Waveform




FIG.1)

FIG.1) N RANGE




FIG.2)

FIG.2) 2 GEAR

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

SBLAT6185L

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "D/C SOLENOID" parameter on the scantool.
4. Select "D RANGE" and Operate the vehicle.
5. Check "D/C SOLENOID" parameter value changes while driving.

AT-158

Automatic Transaxle System

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.72 A	
* D/C SOL. MONITOR	0.79 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	P	
* OIL PRESS SW5(D/C)	OFF	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.1)

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.72 A	
* D/C SOL. MONITOR	0.80 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	R	
* OIL PRESS SW5(D/C)	OFF	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.2)

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.72 A	
* D/C SOL. MONITOR	0.79 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	N	
* OIL PRESS SW5(D/C)	OFF	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.3)

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.72 A	
* D/C SOL. MONITOR	0.80 A	
* CURRENT GEAR POS.	1 GEAR	
* SHIFT RANGE INDICATOR	D	
* OIL PRESS SW5(D/C)	OFF	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.4)

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.82 A	
* D/C SOL. MONITOR	0.80 A	
* CURRENT GEAR POS.	2 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW5(D/C)	ON	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.5)

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.82 A	
* D/C SOL. MONITOR	0.80 A	
* CURRENT GEAR POS.	3 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW5(D/C)	ON	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.6)

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.82 A	
* D/C SOL. MONITOR	0.80 A	
* CURRENT GEAR POS.	4 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW5(D/C)	ON	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.7)

1.3 CURRENT DATA		24/76
* D/C SOL. OUTPUT	0.69 A	
* D/C SOL. MONITOR	0.80 A	
* CURRENT GEAR POS.	5 GEAR	
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW5(D/C)	OFF	
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
OIL PRESS SW1(FR/B)		
<input type="button" value="FIX"/> <input type="button" value="PART"/> <input type="button" value="FULL"/> <input type="button" value="HELP"/> <input type="button" value="GRPH"/> <input type="button" value="RCRD"/>		

FIG.8)

FIG.1) "P" Range

FIG.2) "R" Shifting

FIG.3) "N" Range

FIG.4) "D" Range 1st gear

FIG.5) "D" Range 2nd gear

FIG.6) "D" Range 3rd gear

FIG.7) "D" Range 4th gear

FIG.8) "D" Range 5th gear

SBLAT6170L

6. Does "D/C SOLENOID" follow the reference data?

YES

► Fault is intermittent caused by poor contact in the

sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as

Automatic Transaxle System

AT-159

necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.

NO

► Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2/C106-2" connector.
2. IGNITION "ON", ENGINE "OFF"
3. Measure voltage between terminal "4" of the C06-2/C106-2 harness connector and chassis ground.

Specification : approx. 5V



C06-2 [DSL 2.5]

C106-2 [GSL 3.3/3.8]

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. **DIRECT CLUTCH SOLENOID VALVE**
6. FRONT BRAKE SOLENOID VALVE
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV



SBLAT6104L

4. Is voltage within specifications?

YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.


AT-160

Automatic Transaxle System

COMPONENT INSPECTION

1. Disconnect "C06-2/C106-2" connector.
2. Ignition "OFF".
3. Measure resistance between terminal "4" of the C06-2/C106-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2 [DSL 2.5]
C106-2 [GSL 3.3/3.8]
Component side

- 1.ATF 2
- 2.LOW COAST BRAKE SOLENOID VALVE
- 3.HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
- 4.DIRECT CLUTCH SOLENOID VALVE**
- 6.FRONT BRAKE SOLENOID VALVE
- 7.INPUT CLUTCH SOLENOID VALVE
- 8.PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
- 9.TCCSV

SBLAT6105L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "D/C SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

Automatic Transaxle System

AT-161

P0766

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

The Automatic Transmission changes the gear position of the transmission utilizing a combination of Clutches and Brakes, which are controlled by solenoid valves. High & low reverse clutch solenoid valve is controlled by the TCM in response to signals sent from the inhibitor switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

DTC DESCRIPTION

This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Rationality check (stuck-off) 	※ HIGH & LOW REVERSE CLUTCH SOLENOID VALVE : H & LR/C SOLENOID <ul style="list-style-type: none"> Open or short in circuit Faulty H & LR/C SOLENOID VALVE Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed ≥ 6.2MPH(10km/h) Engine speed > 305 rpm A/T range switch is D range A/T flued temperature $\geq -40^{\circ}$F 	
Threshold value	<ul style="list-style-type: none"> Fluid pressure switch D "OFF" when the monitoring value ≤ 0.05A and When there's a difference between calculated and measured gear ratio. 	
Diagnostic Time	<ul style="list-style-type: none"> A/T flued temperature $> 14^{\circ}$F : More then 2secs A/T flued temperature $\leq 14^{\circ}$F : More then 8secs 	
Fail Safe	<ul style="list-style-type: none"> Locked in to 4th gear. 	

AT-162

Automatic Transaxle System

Signal Waveform




FIG.1)

FIG.1) 2 RANGE




FIG.2)

FIG.2) 3 GEAR

SBLAT6186L

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "H & LR/C SOLENOID" parameter on the scantool.
4. Select "D RANGE" and Operate the vehicle.
5. Check "H & LR/C SOLENOID" parameter value changes while driving.



Automatic Transaxle System

AT-163

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	P	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.1)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	R	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.2)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	N	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.3)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.66 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	D	
* OIL PRESS SW6(H&L R/C)	OFF	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.4)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.66 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	2	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW6(H&L R/C)	OFF	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.5)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	3	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.6)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	4	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.7)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	5	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.8)

FIG.1) "P" Range

FIG.2) "R" Shifting

FIG.3) "N" Range

FIG.4) "D" Range 1st gear

FIG.5) "D" Range 2nd gear

FIG.6) "D" Range 3rd gear

FIG.7) "D" Range 4th gear

FIG.8) "D" Range 5th gear

SBLAT6175L

6. Does "H & LR/C SOLENOID" follow the reference data?

YES

► Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination,

AT-164

Automatic Transaxle System

deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.


NO

► Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2" connector.
2. IGNITION "ON", ENGINE "OFF"
3. Measure voltage between terminal "3" of the C06-2 harness connector and chassis ground.

Specification : Output voltage repeated between 4V and 12V



C06-2

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. **HIGH&LOW REVERSE CLUTCH SOLENOID VALVE**
4. DIRECT CLUTCH SOLENOID VALVE
6. FRONT BRAKE SOLENOID VALVE
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6176L

4. Is voltage within specifications?

YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.


Automatic Transaxle System

AT-165

COMPONENT INSPECTION

1. Disconnect "C06-2" connector.
2. Ignition "OFF".
3. Measure resistance between terminal "3" of the C06-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2
Component side

- 1.ATF 2
- 2.LOW COAST BRAKE SOLENOID VALVE
- 3.HIGH&LOW REVERSE CLUTCH SOLENOID VALVE**
- 4.DIRECT CLUTCH SOLENOID VALVE
- 6.FRONT BRAKE SOLENOID VALVE
- 7.INPUT CLUTCH SOLENOID VALVE
- 8.PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
- 9.TCCSV

SBLAT6177L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "H & LR/C SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

AT-166

Automatic Transaxle System

P0767

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

The Automatic Transmission changes the gear position of the transmission utilizing a combination of Clutches and Brakes, which are controlled by solenoid valves. High & low reverse clutch solenoid valve is controlled by the TCM in response to signals sent from the inhibitor switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

DTC DESCRIPTION

This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Rationality check (stuck-on) 	※ HIGH & LOW REVERSE CLUTCH SOLENOID VALVE : H & LR/C SOLENOID • Open or short in circuit • Faulty H & LR/C SOLENOID VALVE • Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed ≥ 6.2MPH(10km/h) Engine speed > 305 rpm A/T range switch is D range A/T flued temperature ≥ -40°F 	
Threshold value	<ul style="list-style-type: none"> Fluid pressure switch D "ON" when the monitoring value ≤ 0.75A and When there's a difference between calculated and measured gear ratio. 	
Diagnostic Time	<ul style="list-style-type: none"> A/T flued temperature > 14°F : More then 2secs A/T flued temperature ≤ 14°F : More then 8secs 	
Fail Safe	<ul style="list-style-type: none"> Locked in to 4th gear. 	

Automatic Transaxle System

AT-167

Signal Waveform




FIG.1)

FIG.1) 2 RANGE

FIG.2) 3 GEAR




FIG.2)

SBLAT6186L

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "H & LR/C SOLENOID" parameter on the scantool.
4. Select "D RANGE" and Operate the vehicle.
5. Check "H & LR/C SOLENOID" parameter value changes while driving.



AT-168

Automatic Transaxle System

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	P	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.1)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	R	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.2)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	N	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.3)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.66 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	D	
* OIL PRESS SW6(H&L R/C)	OFF	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.4)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.66 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	2	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW6(H&L R/C)	OFF	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.5)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	3	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.6)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	4	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.7)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	5	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.8)

FIG.1) "P" Range

FIG.2) "R" Shifting

FIG.3) "N" Range

FIG.4) "D" Range 1st gear

FIG.5) "D" Range 2nd gear

FIG.6) "D" Range 3rd gear

FIG.7) "D" Range 4th gear

FIG.8) "D" Range 5th gear

SBLAT6175L

6. Does "H & LR/C SOLENOID" follow the reference data?

YES

► Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination,

Automatic Transaxle System

AT-169

deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.


NO

► Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2" connector.
2. IGNITION "ON", ENGINE "OFF"
3. Measure voltage between terminal "3" of the C06-2 harness connector and chassis ground.

Specification : Output voltage repeated between 4V and 12V



C06-2

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. **HIGH&LOW REVERSE CLUTCH SOLENOID VALVE**
4. DIRECT CLUTCH SOLENOID VALVE
6. FRONT BRAKE SOLENOID VALVE
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6176L

4. Is voltage within specifications?

YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.


AT-170

Automatic Transaxle System

COMPONENT INSPECTION

1. Disconnect "C06-2" connector.
2. Ignition "OFF".
3. Measure resistance between terminal "3" of the C06-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2
Component side

- 1.ATF 2
- 2.LOW COAST BRAKE SOLENOID VALVE
- 3.HIGH&LOW REVERSE CLUTCH SOLENOID VALVE**
- 4.DIRECT CLUTCH SOLENOID VALVE
- 6.FRONT BRAKE SOLENOID VALVE
- 7.INPUT CLUTCH SOLENOID VALVE
- 8.PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
- 9.TCCSV

SBLAT6177L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "H & LR/C SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

Automatic Transaxle System

AT-171

P0768

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

The Automatic Transmission changes the gear position of the transmission utilizing a combination of Clutches and Brakes, which are controlled by solenoid valves. High & low reverse clutch solenoid valve is controlled by the TCM in response to signals sent from the inhibitor switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

DTC DESCRIPTION

This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

DTC DETECTING CONDITION

[DSL 2.5]

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Check voltage range 	※ HIGH & LOW REVERSE CLUTCH SOLENOID VALVE: H & LR/C SOLENOID VALVE <ul style="list-style-type: none"> Open or short in circuit Faulty H & LR/C SOLENOID VALVE Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed \geq 6.2MPH(10km/h) 	
Threshold value	<ul style="list-style-type: none"> Ground short/open :Monitoring value[current]\leq 0.4A, When the driver output \geq 0.7A B+ short:Monitoring value[current]\leq 0.4A, When the driver output \geq 0.7A 	
Diagnostic Time	<ul style="list-style-type: none"> More than 5sec 	
Fail Safe	<ul style="list-style-type: none"> Locked into 4th gear, lock-up control is inhibited, pressure control is inhibited. 	

AT-172

Automatic Transaxle System

[GSL 3.3/3.8]

Item	Detecting Condition	Possible cause
DTC Strategy	• Check voltage range	※ HIGH & LOW REVERSE CLUTCH SOLENOID VALVE: H & LR/C SOLENOID VALVE • Open or short in circuit • Faulty H & LR/C SOLENOID VALVE • Faulty TCM
Enable Conditions	• $10V < \text{Actuator power supply voltage} < 16V$	
Threshold value	• Hardware "IC" check	
Diagnostic Time	• More than 0.2sec	
Fail Safe	• Lock-up control is prohibited(L/U off)	

Signal Waveform




FIG.1)

FIG.1) 2 RANGE

FIG.2) 3 GEAR




FIG.2)

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "H & LR/C SOLENOID" parameter on the scantool.
4. Select "D RANGE" and Operate the vehicle.
5. Check "H & LR/C SOLENOID" parameter value changes while driving.

SBLAT6186L

Automatic Transaxle System

AT-173

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	P	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.1)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	R	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.2)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	N	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.3)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.66 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	D	
* OIL PRESS SW6(H&L R/C)	OFF	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.4)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.66 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	2	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW6(H&L R/C)	OFF	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.5)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	3	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.6)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	4	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.7)

1.3 CURRENT DATA		26/76
* H&L R/C SOL. OUTPUT	0.01 A	
* H&L R/C SOL. MONITOR	0.00 A	
* CURRENT GEAR POS.	5	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW6(H&L R/C)	ON	
OIL PRESS SW5(D/C)		
OIL PRESS SW3(I/C)		
OIL PRESS SW2(LC/B)		
FIX	PART	FULL HELP GRPH RCRD

FIG.8)

FIG.1) "P" Range

FIG.2) "R" Shifting

FIG.3) "N" Range

FIG.4) "D" Range 1st gear

FIG.5) "D" Range 2nd gear

FIG.6) "D" Range 3rd gear

FIG.7) "D" Range 4th gear

FIG.8) "D" Range 5th gear

SBLAT6175L

6. Does "H & LR/C SOLENOID" follow the reference data?

YES

► Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination,

AT-174

Automatic Transaxle System

deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.


NO

► Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2/C106-2" connector.
2. IGNITION "ON", ENGINE "OFF"
3. Measure voltage between terminal "3" of the C06-2/C106-2 harness connector and chassis ground.

Specification : Output voltage repeated between 4V and 12V



C06-2 [DSL 2.5]
C106-2 [GSL 3.3/3.8]

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH & LOW REVERSE CLUTCH SOLENOID VALVE
4. DIRECT CLUTCH SOLENOID VALVE
6. FRONT BRAKE SOLENOID VALVE
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV (LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6178L

4. Is voltage within specifications?

YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.


Automatic Transaxle System

AT-175

COMPONENT INSPECTION

1. Disconnect "C06-2/C106-2" connector.
2. Ignition "OFF".
3. Measure resistance between terminal "3" of the C06-2/C106-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2 [DSL 2.5]
C106-2 [GSL 3.3/3.8]
Component side

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. **HIGH&LOW REVERSE CLUTCH SOLENOID VALVE**
4. DIRECT CLUTCH SOLENOID VALVE
6. FRONT BRAKE SOLENOID VALVE
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6179L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "H & LR/C SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

AT-176

Automatic Transaxle System

P0772

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

Low coast brake solenoid valve is turned "ON" or "OFF" by the TCM in response to signals sent from the inhibitor switch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

DTC DESCRIPTION

This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Rationality check (stuck-on) 	※ LOW COAST BRAKE SOLENOID VALVE: LC/B SOLENOID VALVE • Open or short in circuit • Faulty LC/B SOLENOID VALVE • Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Vehicle speed ≥ 6.2MPH(10km/h) Engine speed > 305 rpm A/T range switch is D range A/T flued temperature $\geq -40^{\circ}$F 	
Threshold value	<ul style="list-style-type: none"> Fluid pressure switch E "ON" when the monitoring value is "OFF". 	
Diagnostic Time	<ul style="list-style-type: none"> A/T flued temperature $> 14^{\circ}$F : More then 2secs A/T flued temperature $\leq 14^{\circ}$F : More then 8secs 	
Fail Safe	<ul style="list-style-type: none"> Locked into 2nd gear. 	

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "LC/B SOLENOID" parameter on the scantool.
4. Select "D RANGE" and Operate the vehicle.

5. Check "LC/B SOLENOID" parameter value changes while driving.

Automatic Transaxle System

AT-177

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	OFF	
* LC/B SOL. MONITOR	ON	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	P	
* OIL PRESS SW2(LC/B)	OFF	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.1)

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	OFF	
* LC/B SOL. MONITOR	ON	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	R	
* OIL PRESS SW2(LC/B)	OFF	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.2)

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	OFF	
* LC/B SOL. MONITOR	ON	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	N	
* OIL PRESS SW2(LC/B)	OFF	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.3)

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	OFF	
* LC/B SOL. MONITOR	ON	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	D	
* OIL PRESS SW2(LC/B)	OFF	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.4)

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	ON	
* LC/B SOL. MONITOR	OFF	
* CURRENT GEAR POS.	2	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW2(LC/B)	ON	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.5)

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	OFF	
* LC/B SOL. MONITOR	ON	
* CURRENT GEAR POS.	3	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW2(LC/B)	OFF	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.6)

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	OFF	
* LC/B SOL. MONITOR	ON	
* CURRENT GEAR POS.	4	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW2(LC/B)	OFF	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.7)

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	OFF	
* LC/B SOL. MONITOR	ON	
* CURRENT GEAR POS.	5	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW2(LC/B)	OFF	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.8)

FIG.1) "P" Range

FIG.2) "R" Shifting

FIG.3) "N" Range

FIG.4) "D" Range 1st gear

FIG.5) "D" Range 2nd gear

FIG.6) "D" Range 3rd gear

FIG.7) "D" Range 4th gear

FIG.8) "D" Range 5th gear

SBLAT6180L

6. Does "LC/B SOLENOID" follow the reference data?

YES

► Fault is intermittent caused by poor contact in the

sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as

AT-178

Automatic Transaxle System

necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.


NO

► Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2" connector.
2. IGNITION "ON", ENGINE "OFF"
3. Measure voltage between terminal "2" of the C06-2 harness connector and chassis ground.

Specification : approx. 12V



C06-2

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. DIRECT CLUTCH SOLENOID VALVE
6. FRONT BRAKE SOLENOID VALVE
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6181L

4. Is voltage within specifications?

YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.


Automatic Transaxle System

AT-179

COMPONENT INSPECTION

1. Disconnect "C06-2" connector.
2. Ignition "OFF".
3. Measure resistance between terminal "2" of the C06-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2
Component side

1. ATF 2
- 2.LOW COAST BRAKE SOLENOID VALVE**
- 3.HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
- 4.DIRECT CLUTCH SOLENOID VALVE
- 6.FRONT BRAKE SOLENOID VALVE
- 7.INPUT CLUTCH SOLENOID VALVE
- 8.PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
- 9.TCCSV

SBLAT6182L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "LC/B SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

AT-180

Automatic Transaxle System

P0773

COMPONENT LOCATION



SBLAT6150L

GENERAL DESCRIPTION

Low coast brake solenoid valve is turned "ON" or "OFF" by the TCM in response to signals sent from the inhibitor witch, vehicle speed sensor and accelerator pedal position sensor (throttle position sensor). Gears will then be shifted to the optimum position.

DTC DESCRIPTION

This is not only caused by electrical malfunction (circuits open or shorted) but also by mechanical malfunction such as control valve sticking, improper solenoid valve operation.

DTC DETECTING CONDITION

[DSL 2.5]

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> • Check voltage range 	※ LOW COAST BRAKE SOLENOID VALVE: LC/B SOLENOID VALVE <ul style="list-style-type: none"> • Open or short in circuit • Faulty LC/B SOLENOID VALVE • Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> • Vehicle speed ≥ 6.2MPH(10km/h) 	
Threshold value	<ul style="list-style-type: none"> • Ground short/open :Monitoring value[ON/OFF] "OFF" , When the driver output is "ON" • B+ short:Monitoring value[ON/OFF] "OFF", When the driver output is "ON" 	
Diagnostic Time	<ul style="list-style-type: none"> • more than 0.2sec 	
Fail Safe	<ul style="list-style-type: none"> • Locked into 2nd gear. 	

Automatic Transaxle System

AT-181

[GSL 3.3/3.8]

Item	Detecting Condition	Possible cause
DTC Strategy	• Check voltage range	※ LOW COAST BRAKE SOLENOID VALVE: LC/B SOLENOID VALVE • Open or short in circuit • Faulty LC/B SOLENOID VALVE • Faulty TCM
Enable Conditions	• 10V < Actuator power supply voltage < 16V	
Threshold value	• Hardware "IC" check	
Diagnostic Time	• More than 0.2sec	
Fail Safe	• Lock-up control is prohibited(L/U off)	

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "LC/B SOLENOID" parameter on the scantool.
4. Select "D RANGE" and Operate the vehicle.
5. Check "LC/B SOLENOID" parameter value changes while driving.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



AT-182

Automatic Transaxle System

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	OFF	
* LC/B SOL. MONITOR	ON	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	P	
* OIL PRESS SW2(LC/B)	OFF	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.1)

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	OFF	
* LC/B SOL. MONITOR	ON	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	R	
* OIL PRESS SW2(LC/B)	OFF	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.2)

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	OFF	
* LC/B SOL. MONITOR	ON	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	N	
* OIL PRESS SW2(LC/B)	OFF	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.3)

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	OFF	
* LC/B SOL. MONITOR	ON	
* CURRENT GEAR POS.	1	GEAR
* SHIFT RANGE INDICATOR	D	
* OIL PRESS SW2(LC/B)	OFF	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.4)

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	ON	
* LC/B SOL. MONITOR	OFF	
* CURRENT GEAR POS.	2	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW2(LC/B)	ON	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.5)

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	OFF	
* LC/B SOL. MONITOR	ON	
* CURRENT GEAR POS.	3	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW2(LC/B)	OFF	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.6)

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	OFF	
* LC/B SOL. MONITOR	ON	
* CURRENT GEAR POS.	4	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW2(LC/B)	OFF	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.7)

1.3 CURRENT DATA		28/76
* LC/B SOLENOID	OFF	
* LC/B SOL. MONITOR	ON	
* CURRENT GEAR POS.	5	GEAR
* SHIFT RANGE INDICATOR	-	
* OIL PRESS SW2(LC/B)	OFF	
OIL PRESS SW1(FR/B)		
BRAKE SWITCH		
REVERSE LAMP		
FIX	PART	FULL HELP GRPH RCRD

FIG.8)

FIG.1) "P" Range

FIG.2) "R" Shifting

FIG.3) "N" Range

FIG.4) "D" Range 1st gear

FIG.5) "D" Range 2nd gear

FIG.6) "D" Range 3rd gear

FIG.7) "D" Range 4th gear

FIG.8) "D" Range 5th gear

SBLAT6180L

6. Does "LC/B SOLENOID" follow the reference data?

YES

▶ Fault is intermittent caused by poor contact in the

sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as

Automatic Transaxle System

AT-183

necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.


NO

► Go to "Signal circuit Inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Disconnect "C06-2/C106-2" connector.
2. IGNITION "ON", ENGINE "OFF"
3. Measure voltage between terminal "2" of the C06-2/C106-2 harness connector and chassis ground.

Specification : approx. 12V



C06-2 [DSL 2.5]

C106-2 [GSL 3.3/3.8]

1. ATF 2
2. LOW COAST BRAKE SOLENOID VALVE
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. DIRECT CLUTCH SOLENOID VALVE
6. FRONT BRAKE SOLENOID VALVE
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6183L

4. Is voltage within specifications?

YES

► Go to "Component inspection" procedure.

NO

► Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Substitute with a known-good TCM and check for proper operation. If the problem is corrected, replace TCM as necessary and go to "Verification of Vehicle Repair" procedure.


AT-184

Automatic Transaxle System

COMPONENT INSPECTION

1. Disconnect "C06-2/C106-2" connector.
2. Ignition "OFF".
3. Measure resistance between terminal "2" of the C06-2/C106-2 harness connector and chassis ground.

Specification : approx. 3~9Ω



C06-2 [DSL 2.5]
C106-2 [GSL 3.3/3.8]
Component side

1. ATF 2
2. **LOW COAST BRAKE SOLENOID VALVE**
3. HIGH&LOW REVERSE CLUTCH SOLENOID VALVE
4. DIRECT CLUTCH SOLENOID VALVE
6. FRONT BRAKE SOLENOID VALVE
7. INPUT CLUTCH SOLENOID VALVE
8. PCSV(LINE PRESSURE CONTROL SOLENOID VALVE)
9. TCCSV

SBLAT6184L

4. Is resistance within specifications?

YES

▶ Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage. Repair or replace as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

5. ▶ Check for open or short in harness. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

If signal circuit in harness is OK, Replace "LC/B SOLENOID VALVE" as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO


▶ System performing to specification at this time.

Automatic Transaxle System

AT-185

P0819

COMPONENT LOCATION



SBLAT6260L

GENERAL DESCRIPTION

The TRANSMISSION Range Switch sends the shift lever position information to the TCM using a 5V signal. Deciding each TCM range depend on 4 s/w signal. Standard patterns are fixed and these patterns are on the Specification table as listed below. For example, when s/w 1,2,4 are 'ON(0V)' and s/w 3 is 'OFF(5V)', TCM recognizes 'D Range'.

When the shift lever is in the D (Drive) position the output signal of Tansaxle Range Switch is 12V and in all other positions the voltage is 0V. The TCM judges the shift lever position by reading all signals, for the TRANSMISSION Range Switch, simultaneously.

DTC DESCRIPTION

The TCM sets this code when patterns are without Specification of the table shown below.

The TRANSMISSION Range Switch has no output signal for an extended period of time.

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Rationality 	<ul style="list-style-type: none"> OPEN OR SHORT IN CIRCUIT Faulty TRANSMISSION RANGE SWITCH Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> Battery voltage > 10V 	
Threshold value	<ul style="list-style-type: none"> Abnormal input signal is detected. 	
Diagnostic Time	<ul style="list-style-type: none"> More than 5sec 	
Fail Safe	<ul style="list-style-type: none"> Prevention of manual shift 	

AT-186

Automatic Transaxle System

SPECIFICATION


A/T RANGE PATTERN

A/T range switch				Range swsitch	Remarks
SW1	SW2	SW3	SW4		
OFF	OFF	OFF	OFF	Pst	P start
OFF	OFF	ON	OFF	P	P
OFF	OFF	ON	ON	P-R	Intermediate
ON	OFF	ON	ON	R	R
ON	OFF	ON	OFF	N-R	Intermediate
ON	OFF	OFF	OFF	Nst	N start
ON	OFF	OFF	ON	N-D	Intermediate
ON	ON	OFF	ON	D	D
OFF	ON	OFF	ON	3	3
OFF	ON	ON	ON	2	2
OFF	ON	ON	OFF	1	1
Irregular Pattern				Other	

[OFF= 5V, ON = 0V]

Monitor Scantool Data

1. Connect scantool to data link connector(DLC).
2. Ignition "ON" & Engine "OFF".
3. Monitor the "SPORTS MODE SELECT S/W, SPORTS MODE UP S/W, SPORTS MODE DOWN S/W" parameter on the scantool.
4. Move selector lever to "SPORTS MODE".



Automatic Transaxle System

AT-187




FIG.1)




FIG.2)




FIG.3)




FIG.4)

FIG.1) "D" RANGE

FIG.2) "SPORTS MODE ON"

FIG.3) "UP S/W ON"

FIG.4) "DOWN S/W ON"

5. Does "SPORTS MODE SELECT S/W" follow the reference data?

YES

► Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.

2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.

3. Has a problem been found?

YES

► Repair as necessary and go to "Verification of vehicle Repair" procedure.

NO

► Go to "Power supply circuit inspection" procedure.

Power supply circuit inspection


1. Connect "M62" connector.
2. Ignition "ON" & Engine "OFF"
3. Measure voltage between terminal "2" of the "M62" connector and chassis ground.

Specification : approx. 12V

SBLAT6261L

AT-188

Automatic Transaxle System



1. ILLUMINATION
2. **POWER SUPPLY**
4. ILLUMINATION
6. UP SHIFT
7. SELECT SWITCH
8. DOWN SHIFT

SBLAT6262L

4. Is voltage within specifications?

YES

▶ Go to "Signal circuit inspection" procedure.


NO

▶ Check for open or short in harness and Fuse. Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

SIGNAL CIRCUIT INSPECTION

1. Connect "M62" connector.
2. Ignition "ON" & Engine "OFF".
3. Move select lever to "SPORTS MODE" and operate select lever to up and down.
4. Measure voltage between terminal "6, 7, 8" of the "M62" connector and chassis ground

Specification : approx. 12V



1. ILLUMINATION
2. POWER SUPPLY
4. ILLUMINATION
6. **UP SHIFT**
7. **SELECT SWITCH**
8. **DOWN SHIFT**

SBLAT6263L

5. Is voltage within specifications?

YES

▶ Go to "Component inspection" procedure.

NO

▶ Substitute with a known-good "SPORTS MODE SWITCH" and check for proper operation. If the problem is corrected, replace "SPORTS MODE SWITCH" and Go to "Verification Vehicle Repair" procedure.


COMPONENT INSPECTION

1. Connect "TCU" connector.
2. Ignition "ON" & Engine "OFF".
3. Move select lever to "SPORTS MODE" and operate select lever to up and down.
4. Measure voltage between terminal "16, 17, 61" of the "TCU" connector(C120) and chassis ground.

Specification : approx. 12V

Automatic Transaxle System

AT-189



16. UP shift
17. DOWN shift
61. MODE SELECT switch

SBLAT6264L

5. Is voltage within specifications?

YES

▶ Substitute with a known-good "TCU" and check for proper operation. If the problem is corrected, replace "TCU" and Go to "Verification of Vehicle Repair" procedure.

NO

▶ Check for open or short between "M62" and "C120" harness . Repair as necessary and Go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?


YES

▶ Go to the applicable troubleshooting procedure.

NO

▶ System performing to specification at this time.



AT-190**Automatic Transaxle System****P0863****COMPONENT LOCATION**

SBLAT6190L

GENERAL DESCRIPTION

The TCM can either receive data from the Engine Control Module or ABS control module, or it can send data to the ECM and ABSCM by using CAN communication. The CAN communication is one of the vehicle communications method, which is now widely used to transfer the vehicle data.

DTC DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability. Many electronic control units are equipped on a vehicle, and each control units shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring. Each control unit transmits/receives data but selectively reads required data only.


DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	• Check voltage range	<ul style="list-style-type: none"> • Open or Short in CAN communication harness • Faulty ECM • Faulty TCM
Enable Conditions	• CONTINUOUS	
Threshold value	• No signal transmitted at CAN module	
Diagnostic Time	• More then 2sec	
Fail Safe	• CAN COMMUNICATION IS INHIBITED.	

Automatic Transaxle System

AT-191

Signal Waveform



SBLAT6191L

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "CAN COMMUNICATION SERVICE DATA (ENGINE RPM, VEHICLE SPEED SENSOR, THROTTLE P. SENSOR)" parameters on the scantool.

1.3 CURRENT DATA		02/76
* USS 1(A/T)	0	km/h
* USS 2(ECU)	0	km/h
* ENGINE SPEED	736	rpm
* TPS OPEN SIGNAL	0.0	
* ACCEL.FULL SW(CAL.)	OFF	
* ACCEL.IDLE SW(CAL.)	ON	
* CAN FLAG(ECU-TCU)	OK	
* CAN FLAG(TX)	OK	

1.3 CURRENT DATA		02/76
* USS 1(A/T)	164	km/h
* USS 2(ECU)	158	km/h
* ENGINE SPEED	3392	rpm
* TPS OPEN SIGNAL	2.2	
* ACCEL.FULL SW(CAL.)	OFF	
* ACCEL.IDLE SW(CAL.)	OFF	
* CAN FLAG(ECU-TCU)	OK	
* CAN FLAG(TX)	OK	

FIG.1)

FIG.2)

FIG.1) LOW - SPEED
FIG.2) HIGH - SPEED

SBLAT6192L

4. Does "CAN BUS LINE DATA" follow the reference data?

YES

► Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. And go to Verification of Vehicle Repair procedure.

NO

► Go to "Terminal & connector inspection" procedure.

AT-192

Automatic Transaxle System

TERMINAL & CONNECTOR INSPECTION


1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and then go to "Verification of vehicle repair" procedure.

NO

► Go to "Signal circuit Inspection" procedure.



4. Is measured resistance within specifications?

YES

► Substitute with a known-good PCM/TCM and check for proper operation. If the problem is corrected, replace PCM/TCM as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

► Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage of ECM and then Repair or replace Resistance for CAN communication as necessary and go to "Verification of Vehicle Repair" procedure.

SIGNAL CIRCUIT INSPECTION

1. Ignition "OFF".
2. Disconnect the "TCM" connector.
3. Measure resistance between terminal "6" and "7" of the "TCM" harness connector.

Specification : approx. 120 Ω

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

► Go to the applicable troubleshooting procedure.

NO


► System performing to specification at this time.

Automatic Transaxle System

AT-193

P0893

COMPONENT LOCATION



SBLAT6195L

GENERAL DESCRIPTION

While monitoring clutch engagement using Oil pressure switch of clutch pressure circuit, if abnormal Inter-lock engagement pattern is detected, 'Fail safe' mode is activated.

DTC DESCRIPTION

In case of abnormal shift pattern, the DTC-code is set(Refer to Specification as below).

DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Check voltage range 	<ul style="list-style-type: none"> Open or short in circuit Faulty FLUID PRESSURE SWITCH E(H & LR/C) Faulty SHIFT C/U
Enable Conditions	<ul style="list-style-type: none"> Time after gear shifting 	
Threshold value	<ul style="list-style-type: none"> Each fluid pressure switch agree with the patterns in fig.3 interlock 	
Diagnostic Time	<ul style="list-style-type: none"> More then 2sec 	
Fail Safe	<ul style="list-style-type: none"> Locked into 2nd or 4th or 5th gear. 	

AT-194

Automatic Transaxle System

Specification

※ DETECTING PATTERN AND FAIL SAFE

■ : Don't care

④ Oil pressure ON/OFF

	RANGE	GEAR POSITION	PRESSURE SWITCH					Fail safe	
			I/C	H&LR/C	D/C	Fr/B	LC/B		
INTER LOCK PATTERNN	① D,4,3,2,1,M	1	●	○	■	○	○	Fixed at 4th gear	
	②	1	■	○	●	■	○	Fixed at 4th gear	
	③	2	■	●	○	■	○	Fixed at 4th gear	
	④		●	■	○	○	■	Fixed at 4th gear	
	⑤	D,4,3,M	3	■	○	○	■	Fixed at 2nd gear	
	⑥		●	■	○	○	■	Fixed at 4th gear	
	⑦	D,4,M	4	■	○	○	■	Fixed at 2nd gear	
	⑧			○	■	○	●	■	Fixed at 5th gear
	⑨	D,M	5	○	○	■	○	●	Fixed at 2nd gear
	⑩			○	■	●	○	■	Fixed at 4th gear

SBLAT6196L

MONITOR SCANTOOL DATA

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "FLUID PRESSURE SWITCH" parameter on the scantool.
4. Select "D RANGE or SPORTS MODE" and Operate the vehicle.
5. Check "FLUID PRESSURE SWITCH" parameter value changes while driving.



اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

Automatic Transaxle System

AT-195

1.3 CURRENT DATA 34/76		1.3 CURRENT DATA 34/76	
* CURRENT GEAR POS. 1 GEAR		* CURRENT GEAR POS. 1 GEAR	
* SELECTED LEVER RANGE P, N		* SELECTED LEVER RANGE R	
* FLUID PRESSURE SW.- 6 ON		* FLUID PRESSURE SW.- 6 ON	
* FLUID PRESSURE SW.- 5 OFF		* FLUID PRESSURE SW.- 5 OFF	
* FLUID PRESSURE SW.- 3 OFF		* FLUID PRESSURE SW.- 3 OFF	
* FLUID PRESSURE SW.- 2 OFF		* FLUID PRESSURE SW.- 2 OFF	
* FLUID PRESSURE SW.- 1 ON		* FLUID PRESSURE SW.- 1 ON	
INHIBITOR SW.- 2		BRAKE SWITCH	
FIX PART FULL HELP GRPH RCRD		FIX PART FULL HELP GRPH RCRD	

FIG.1)

FIG.2)

1.3 CURRENT DATA 34/76		1.3 CURRENT DATA 30/76	
* CURRENT GEAR POS. 1 GEAR		* CURRENT GEAR POS. 1 GEAR	
* SELECTED LEVER RANGE D		* SELECTED LEVER RANGE SPORTS	
* FLUID PRESSURE SW.- 6 OFF		* FLUID PRESSURE SW.- 6 ON	
* FLUID PRESSURE SW.- 5 OFF		* FLUID PRESSURE SW.- 5 OFF	
* FLUID PRESSURE SW.- 3 OFF		* FLUID PRESSURE SW.- 3 OFF	
* FLUID PRESSURE SW.- 2 OFF		* FLUID PRESSURE SW.- 2 ON	
* FLUID PRESSURE SW.- 1 ON		* FLUID PRESSURE SW.- 1 ON	
INHIBITOR SW.- 2		BRAKE SWITCH	
FIX PART FULL HELP GRPH RCRD		FIX PART FULL HELP GRPH RCRD	

FIG.3)

FIG.4)

1.3 CURRENT DATA 30/76		1.3 CURRENT DATA 30/76	
* CURRENT GEAR POS. 2 GEAR		* CURRENT GEAR POS. 3 GEAR	
* SELECTED LEVER RANGE SPORTS		* SELECTED LEVER RANGE SPORTS	
* FLUID PRESSURE SW.- 6 OFF		* FLUID PRESSURE SW.- 6 ON	
* FLUID PRESSURE SW.- 5 ON		* FLUID PRESSURE SW.- 5 ON	
* FLUID PRESSURE SW.- 3 OFF		* FLUID PRESSURE SW.- 3 OFF	
* FLUID PRESSURE SW.- 2 ON		* FLUID PRESSURE SW.- 2 OFF	
* FLUID PRESSURE SW.- 1 ON		* FLUID PRESSURE SW.- 1 ON	
BRAKE SWITCH		BRAKE SWITCH	
FIX PART FULL HELP GRPH RCRD		FIX PART FULL HELP GRPH RCRD	

FIG.5)

FIG.6)

1.3 CURRENT DATA 30/76		1.3 CURRENT DATA 30/76	
* CURRENT GEAR POS. 4 GEAR		* CURRENT GEAR POS. 5 GEAR	
* SELECTED LEVER RANGE SPORTS		* SELECTED LEVER RANGE D	
* FLUID PRESSURE SW.- 6 ON		* FLUID PRESSURE SW.- 6 ON	
* FLUID PRESSURE SW.- 5 ON		* FLUID PRESSURE SW.- 5 OFF	
* FLUID PRESSURE SW.- 3 ON		* FLUID PRESSURE SW.- 3 ON	
* FLUID PRESSURE SW.- 2 OFF		* FLUID PRESSURE SW.- 2 OFF	
* FLUID PRESSURE SW.- 1 OFF		* FLUID PRESSURE SW.- 1 ON	
BRAKE SWITCH		BRAKE SWITCH	
FIX PART FULL HELP GRPH RCRD		FIX PART FULL HELP GRPH RCRD	

FIG.7)

FIG.8)

FIG.1) P/N RANGE

FIG.2) R RANGE

FIG.3) 1 GEAR(D RANGE)

FIG.4) 1 GEAR(S- MODE)

FIG.5) 2 GEAR(S- MODE)

FIG.6) 3 GEAR(S- MODE)

FIG.7) 4 GEAR(S- MODE)

FIG.8) 5 GEAR(D RANGE)

SBLAT6197L

AT-196

Automatic Transaxle System

6. Does "FLUID PRESSURE SWITCH" follow the reference data?

YES

▶ Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

▶ Substitute with a known-good "TRANSMISSION" and check for proper operation. If the problem is corrected, replace "TRANSMISSION" as necessary and go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

▶ Go to the applicable troubleshooting procedure.

NO

▶ System performing to specification at this time.

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




Automatic Transaxle System

AT-197

U0001

COMPONENT LOCATION



SBLAT6200L

GENERAL DESCRIPTION

The TCM can either receive data from the Engine Control Module or ABS control module, or it can send data to the ECM and ABSCM by using CAN communication. The CAN communication is one of the vehicle communications method, which is now widely used to transfer the vehicle data.

DTC DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability.

Many electronic control units are equipped on a vehicle, and each control units shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring.

Each control unit transmits/receives data but selectively reads required data only.


DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Check voltage range 	<ul style="list-style-type: none"> Open or Short in CAN communication harness Faulty ECM Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> IG "ON" Battery voltage > 10V Input speed > 300rpm 	
Threshold value	<ul style="list-style-type: none"> BUS OFF 	
Diagnostic Time	<ul style="list-style-type: none"> More than 2sec 	
Fail Safe	<ul style="list-style-type: none"> Default value 	

AT-198

Automatic Transaxle System

Signal Waveform



SBLAT6271L

Monitor Scantool Data

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "CAN COMMUNICATION SERVICE DATA (ENGINE RPM, VEHICLE SPEED SENSOR, THROTTLE P. SENSOR)" parameters on the scantool.





FIG.1)

FIG.2)

FIG.1) Low-speed

FIG.2) High-speed

SBLAT6272L

4. Does "CAN BUS LINE DATA" follow the reference data?

YES

► Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor

connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

Automatic Transaxle System

AT-199

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

► Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Ignition "OFF".
2. Disconnect the "TCM" connector.
3. Measure resistance between terminal "65" and "87" of the "TCM" harness connector.

Specification : Approx. 120Ω



65. CAN-LOW
87. CAN-HIGH



SBLAT6273L


4. Is measured resistance within specifications?

YES

► Substitute with a known-good PCM/TCM and check for proper operation. If the problem is corrected, replace PCM/TCM as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

► Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage of ECM and then Repair or replace Resistance for CAN communication as necessary and go to "Verification of Vehicle Repair" procedure.

AT-200**Automatic Transaxle System****U0100****COMPONENT LOCATION**

SBLAT6200L

GENERAL DESCRIPTION

The TCM can either receive data from the Engine Control Module or ABS control module, or it can send data to the ECM and ABSCM by using CAN communication. The CAN communication is one of the vehicle communications method, which is now widely used to transfer the vehicle data.

DTC DESCRIPTION

CAN (Controller Area Network) is a serial communication line for real time application. It is an on-vehicle multiplex communication line with high data communication speed and excellent malfunction detection ability.

Many electronic control units are equipped on a vehicle, and each control units shares information and links with other control units during operation (not independent). In CAN communication, control units are connected with 2 communication lines (CAN H line, CAN L line) allowing a high rate of information transmission with less wiring.

Each control unit transmits/receives data but selectively reads required data only.


DTC DETECTING CONDITION

Item	Detecting Condition	Possible cause
DTC Strategy	<ul style="list-style-type: none"> Check voltage range 	<ul style="list-style-type: none"> Open or Short in CAN communication harness Faulty ECM Faulty TCM
Enable Conditions	<ul style="list-style-type: none"> IG "ON" Battery voltage > 10V Input speed > 300rpm 	
Threshold value	<ul style="list-style-type: none"> Lost communication 	
Diagnostic Time	<ul style="list-style-type: none"> More than 2sec 	
Fail Safe	<ul style="list-style-type: none"> Default value 	

Automatic Transaxle System

AT-201

Signal Waveform



SBLAT6271L

Monitor Scantool Data

1. Connect scantool to data link connector(DLC).
2. Engine "ON".
3. Monitor the "CAN COMMUNICATION SERVICE DATA (ENGINE RPM, VEHICLE SPEED SENSOR, THROTTLE P. SENSOR)" parameters on the scantool.





FIG.1)

FIG.2)

FIG.1) Low-speed

FIG.2) High-speed

SBLAT6272L

4. Does "CAN BUS LINE DATA" follow the reference data?

YES

► Fault is intermittent caused by poor contact in the sensor's and/or PCM/TCM's connector or was repaired and PCM/TCM memory was not cleared. Thoroughly check connectors for looseness, poor

connection, bending, corrosion, contamination, deterioration or damage. Repair or replace as necessary and go to "Verification of Vehicle Repair" procedure.

NO

► Go to "Terminal & connector inspection" procedure.

AT-202

Automatic Transaxle System

TERMINAL & CONNECTOR INSPECTION

1. Many malfunctions in the electrical system are caused by poor harness and terminals. Faults can also be caused by interference from other electrical systems, and mechanical or chemical damage.
2. Thoroughly check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration, or damage.
3. Has a problem been found?

YES

- ▶ Repair as necessary and go to "Verification of Vehicle Repair" procedure.

NO

- ▶ Go to "Signal circuit inspection" procedure.

SIGNAL CIRCUIT INSPECTION

1. Ignition "OFF".
2. Disconnect the "TCM" connector.
3. Measure resistance between terminal "65" and "87" of the "TCM" harness connector.

Specification : Approx. 120Ω



65. CAN-LOW
87. CAN-HIGH

SBLAT6273L

4. Is measured resistance within specifications?

YES

- ▶ Substitute with a known-good PCM/TCM and check for proper operation. If the problem is corrected, replace PCM/TCM as necessary and then go to "Verification of Vehicle Repair" procedure.

NO

- ▶ Check connectors for looseness, poor connection, bending, corrosion, contamination, deterioration or damage of ECM and then Repair or replace Resistance for CAN communication as necessary and go to "Verification of Vehicle Repair" procedure.

VERIFICATION OF VEHICLE REPAIR

After a repair, it is essential to verify that the fault has been corrected.

1. Connect scantool and select "Diagnostic Trouble Codes(DTCs)" mode.
2. Using a scantool, Clear DTC.
3. Operate the vehicle within DTC Enable conditions in General information.
4. Are any DTCs present?

YES

- ▶ Go to the applicable troubleshooting procedure.


NO

- ▶ System performing to specification at this time.

Automatic Transaxle System

AT-203

Automatic Transaxle COMPONENTS



- | | | |
|---------------------------------|-------------------------------------|---|
| 1. Adapter case (4WD) | 15. Oil pump housing | 29. Input clutch drum |
| 2. Parking gear | 16. Stator | 30. Input shaft |
| 3. Output shaft | 17. Impeller assembly | 31. Front annulus gear |
| 4. Control valve upper body | 18. Turbine & lockup assembly | 32. Direct clutch return spring |
| 5. Control valve lower body | 19. Torque converter cover assembly | 33. Direct clutch piston |
| 6. Separator plate assembly | 20. Front pinion gear | 34. Reverse brake hub |
| 7. Rear sun gear | 21. Front planetary carrier | 35. Direct clutch assembly |
| 8. Rear sun plate | 22. Front sun gear | 36. High & low reverse clutch return spring |
| 9. Middle sun gear assembly | 23. Front brake drum | 37. High & low reverse clutch piston |
| 10. Rear annulus gear assembly | 24. Rear pinion gear | 38. High & low reverses clutch assembly |
| 11. Rear annulus cell | 25. Rear planetary carrier plate | 39. Low coast brake clutch assembly |
| 12. Automatic transmission case | 26. Middle annulus gear | 40. Forward one-way clutch |
| 13. Converter housing | 27. Middle pinion gear | 41. Forward brake clutch assembly |
| 14. Oil pump cover | 28. Middle planetary carrier | 42. Low coast brake hub |


AT-204

Automatic Transaxle System

SBLAT6305L


Removal

1. Remove the battery and battery tray (A).



AKAF051A

2. Drain the automatic transmission fluid after removing the drain plug (A).



AKAF051B


3. Disconnect the control cable.
4. Remove the under cover.
5. Disconnect the ATF oil cooler hose.
6. Remove the transmission oil level gage pipe.

7. Remove the rear propeller shaft (A).

Tightening torque :


49.1 ~ 58.9 N.m (5.0 ~ 6.0 kgf.m, 36.2 ~ 43.4lb-ft)

[Front side]



SBLAT6300L

[Rear side]



SBLAT6301L

Automatic Transaxle System

AT-205


8. Remove the front propeller shaft (A).

Tightening torque :

Part time 4WD: 25.5 ~ 29.4 N.m (2.6 ~ 3.0 kgf.m, 18.8 ~ 21.7 lb-ft)

Full time 4WD: 49.1 ~ 58.9 N.m (5.0 ~ 6.0 kgf.m, 36.2 ~ 43.4lb-ft)

[Front side]



SBLAT6302L

[Rear side]




SBLAT6303L

9. Remove the front muffler (A).


Tightening torque :

42.2 ~ 60.8 N.m (4.3 ~ 6.2 kgf.m, 31.1 ~ 44.9 lb-ft)



AKAF051E

10. Disconnect the transfer case connector (4WD).





AKAF051F

AT-206

Automatic Transaxle System

11. Disconnect the transmission connector (3ea).




SBLAT6304L

12. Remove the starter motor.

Tightening torque :

26.5 ~ 33.4 N.m (2.7 ~ 3.4 kgf.m, 19.5 ~ 24.6 lb-ft)



AKAF051H


13. Remove the bellhousing cover.

Tightening torque :

9.8 ~ 11.8 N.m (1.0 ~ 1.2 kgf.m, 7.2 ~ 8.7 lb-ft)


14. Remove the drive plate (A) and the torque converter mounting bolt (6ea).

15. Remove the mounting bolt after rotating the crankshaft pulley.



AKAF051I

16. Remove the transmission housing mounting bolt.




AKAF051J

Automatic Transaxle System

AT-207

17. Remove the transmission mounting (A) and the cross member (B) with a jack.




AKAF051K

Tightening torque :

Bolt (C): 39.2 ~ 49.1 N.m (4.0 ~ 5.0 kgf.m, 28.9 ~ 36.2 lb-ft)

Bolt (D): 19.6 ~ 28.4 N.m (2.0 ~ 2.9 kgf.m, 14.5 ~ 21.0 lb-ft)



AKAF051L

18. Remove the transmission.

Installation

1. Installation is the reverse of removal.

⚠ CAUTION

After replacement or reinstallation procedure of the automatic transaxle assembly, must perform procedures below.

- Power steering fluid replacement and air bleeding (Refer to "General information" in ST group.)
- Adding automatic transaxle fluid. (Refer to "automatic transaxle assembly" in this group.)