


ABS Power Supply, Grounding, Data Line



Harness connector	Description	Pages
CA01	To instrument harness connector 1	29
CA02	To instrument harness connector 2	29
CA13	Harness connector of ABS control module	28
IP36	To engine compartment harness connector 2	40
IP37	To engine compartment harness connector 3	40
CA22	To engine harness connector	28
EM36	To harness connector of engine compartment fuse box (2)	34
EM01	Engine control module	35
G5	Engine compartment grounding	67
G6A	Engine compartment grounding	67


دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران



ABS Sensor



Harness connector	Description	Pages
CA02	To instrument harness connector 2	29
IP37	To engine compartment harness connector 3	40
CA07	Harness connector of FL wheel speed sensor	28
CA08	To body harness connector	29
CA13	Harness connector of ABS control module	28
CA16	Harness connector of FR wheel speed sensor	28
SO14	To engine compartment harness connector	50
SO25	Harness connector of RR wheel speed	50
SO28	Harness sensor of RL wheel speed sensor	50

دیجیتال خودرو

شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

