GENERAL INFORMATION	66-3	Front Body Assembly Clearances	66-15
Description	66-3	Rear Body Assembly Clearances	66-25
Body Frame Dimensions	66-4		









GENERAL INFORMATION

Description


- All measurements should be made from bare metal. Remove trim and bumper covers as necessary.
- Repair badly damaged areas before taking measurements for underbody alignment.
- Monitor upper body structure for excessive stress or movement while making any corrections to underbody structure.
- Remove all necessary glasses to prevent breakage.
- · All dimensions are shown in millimeters (mm).






Body Frame Dimensions

Dimensions of Engine Compartment and Windshield Frame




Dimension Number	Standard Value	Measuring Area
А	1144.8 ± 2 mm	Distance between installation centers of front suspension
В	1520.3 ± 1.5 mm	Diagonal distance of wing fixing bolts
С	230.4 ± 2 mm	Distance between installation center of front suspension and wing
D	876.5 ± 2 mm	Distance between center of front baffle plate and wing fixing bolt
E	796 ± 2 mm	Front windshield opening




Dimension Number	Standard Value	Measuring Area
A1, A2	A1 = A2	Diagonal distance of windshield outer frame
B1, B2	B1 = B2	Diagonal distance of engine compartment
С	872.7 mm	Distance between center of wing installation hole and upper part of front windshield lower crossmember
D	291.9 mm	Distance between center of wing installation hole and center of front shock absorber seat positioning hole

Luggage Compartment Opening Dimensions




Dimension Number	Standard Value	Measuring Area
А	1016.3 ± 2 mm	Luggage compartment opening
В	1132 ± 2 mm	Lateral distance of luggage compartment




Dimension Number Standard Value Measuring Area

A1, A2 A1 = A2 Diagonal distance of luggage compartment outer frame




Dimension Number	Standard Value	Measuring Area
A	1558.8 ± 2 mm	Y-direction distance between B-pillar lock pillar installation positions
В	1406.5 ± 2 mm	Distance between seat belt holders



	Dimension Number	Standard Value	Measuring Area
	С	1127.8 ± 2 mm	Y-direction distance between rear suspension
d	ە (مسئولىت محد	بتال خودرو سامانه	installation center positions


Dimension of distance between A-pillar hinges

Dimension Number	Standard Value	Measuring Area
A	364 ± 0.3 mm	Distance between A-pillar hinges




Dimension of distance between B-pillar hinges


Dimension Number	Standard Value	Measuring Area
A	468 ± 0.3 mm	Distance between B-pillar hinges



Dimensions of front and rear doors opening



Dimension Number	Standard Value	Measuring Area
А	917 ± 1 mm	Distance between B-pillar and rear door lock pillar installation position
В	947 ± 1 mm	Distance between A-pillar and B-pillar lock pillar installation positions
С	987 ± 1.5 mm	Front door opening
D	1393 ± 1.5 mm	Front door opening
E	1098 ± 1.5 mm	Rear door opening
F	1245 ± 1.5 mm	Rear door opening



Dimension Number	Standard Value	Measuring Area
1	960 ± 1 mm	Distance between A and a
2	1488 ± 1.5 mm	Distance between A and b
3	869 ± 1 mm	Distance between B and b
4	1175 ± 1 mm	Distance between A and B
5	1226 ± 1.5 mm	Distance between B and C
6	1599.5 ± 2 mm	Distance between B and c
7	1215 ± 1.5 mm	Distance between C and c
8	1055.5 ± 1.5 mm	Distance between C and D
9	1492 ± 1.5 mm	Distance between C and d
10	915 ± 1.5 mm	Distance between D and d
11	2030.9 mm	Distance between E and e
12	2173.4 mm	Distance between F and e
13	960.2 mm	Distance between F and E




شرکت دیجیتال خودرو سامانه (مسئولیت محدود)

اولین سامانه دیجیتال تعمیرکاران خودرو در ایران




Roof Dimensions



Dimension Number	Standard Value	Measuring Area
А	2135 mm	Diagonal distance of roof
В	2135 mm	Diagonal distance of roof

Distance Between Centers of Sub Frame Installation Holes



Dimension Number

Standard Value

Measuring Area

Diagonal distance between centers of sub frame installation holes

B

624.0 mm

Distance between centers of sub frame installation holes


C

913 mm


Distance between centers of sub frame installation holes

Front Body Assembly Clearances


- 1. Clearance is indicated by the standard distance measurement symbol |-----|.
- 2. Flush measurement method and instructional symbol description:
 - a. Reference surface is indicated by \blacktriangle .
 - b. Reference surface is indicated by \rightarrow .
 - c. If level is higher than reference surface, number is positive, whereas negative.
 - d. All measurements are shown in millimeters (mm).




Standard clearance between hood and wing: 02C02



Standard clearance between wing and A-pillar: 03A



Standard clearance between quarter outer panel and outside rear view mirror: 04D



Standard clearance between roof and front windshield: 12A


ROOF 4.0±1.0//1.0

FRONT WINDSHIELD


RT15650040

ن سامانه دیجیتال تعمیرکاران خودرو در ایرار


Standard clearance between front windshield and quarter outer panel: 12B




Standard clearance between roof and sunroof: 17A01



Standard clearance between front part and rear part of sunroof: 17A03




Standard clearance between roof and roof molding: 17B



Standard clearance between sunroof and roof: 17A02


يجيتاك خودرو

، دیجیتال خودرو سامانه (مسئولیت محدود




ر سامانه دیجیتال تعمیرکاران خودرو در ایران


Standard clearance between roof molding and quarter and roof: 08C




Standard clearance between quarter outer panel and front door upper window frame: 04B



Standard clearance between rear door front window frame and front door rear window frame: 05C01




Standard clearance between cover plate and door handle: 14A




Standard clearance between rear door window frame and rear triangular block: 05G

66


ن دیجیتال خودرو سامانه (مسئولیت محدود




Standard clearance between rear side window glass assembly and quarter outer panel: 08B02




Standard clearance between door handle and front door outer panel: 14B



Standard clearance between front door outer panel and rear door outer panel: 05C02




Standard clearance between wing and outside rear view mirror: 04E



Standard clearance between outside rear view mirror and front door outer panel: 04F


بجيتالـ خودرو

، دیجیتال خودرو سامانه (مسئولیت محدود




ن سامانه دیجیتال تعمیرکاران خودرو در ایرار


Standard clearance between wing and front door outer panel: 03B




Standard clearance between front door outer panel and front door trim panel: 04G



Standard clearance between wing and front wheel arch trim panel: 03D01



Standard clearance between wing and front wheel arch trim panel: 03D02



Standard clearance between front door trim panel and front wheel arch trim panel: 04H

66

دیجیتال خودرو سامانه (مسئولیت محدود

0±1.0//1.0 FRONT DOOR TRIM

FRT WHEEL ARCH MOULDING

5.5±1.5//1.5

RT15650240

Standard clearance between hood and headlight: 01B


HOOD

4.047,017,017,0


HEAD LAMP

RT15650250


Standard clearance between wing and front bumper: 03C



Standard clearance between front bumper and front wheel arch trim panel: 06H01




Standard clearance between front bumper and front wheel arch trim panel: 06H02



Standard clearance between front bumper and headlight: 01A01


يجيتاك خودرو

، دیجیتال خودرو سامانه (مسئولیت محدود)




ن سامانه دیجیتال تعمیرکاران خودر و در ایرار


Standard clearance between headlight and radiator grille strip: 01D




Standard clearance between front fog light and front fog light cover: 06F



Standard clearance between front bumper lower trim board and front bumper: 06G




Standard clearance between front bumper and front fog light cover: 06E




Standard clearance between radiator grille strip and front bumper: 06A03




، دیجیتال خودرو سامانه (مسئولیت محدود




Standard clearance between radiator grille strip and front bumper: 06A02




Standard clearance between front bumper and headlight: 01A02



Standard clearance between front LOGO base and radiator grille strip: 061




Standard clearance between front towing hook cover and front bumper: 06D




Standard clearance between front bumper and grille: 06A01




، دیجیتال خودرو سامانه (مسئولیت محدود




Standard clearance between hood and front bumper: 02A




Standard clearance between headlight and front bumper: 01A03



Standard clearance between headlight and wing: 01C



Standard clearance between front windshield lower trim board and front windshield and wing: 12C




Standard clearance between hood and wing: 02C01

66


ه دیجیتال خودرو سامانه (مسئولیت محدود

ن سامانه دیجیتال تعمیرکاران خودرو در ایران




Rear Body Assembly Clearances


Rear View




Standard clearance between spoiler assembly and roof




Standard clearance between D-pillar trim board and luggage compartment door outer panel: 11C



Standard clearance between rear windshield and D-pillar trim board: 13B




Standard clearance between spoiler assembly and D-pillar trim board: 18E01




Standard clearance between D-pillar trim board and spoiler assembly: 18E02




، دیجیتال خودرو سامانه (مسئولیت محدود




Standard clearance between quarter outer panel and spoiler assembly: 18C




Standard clearance between D-pillar trim board and quarter outer panel: 08A02



Standard clearance between quarter outer panel and rear side window glass assembly: 08B01




Standard clearance between quarter outer panel and rear door upper window frame: 05B



Standard clearance between rear door window frame and rear side window glass assembly: 05D01


الحوره

، دیجیتال خودرو سامانه (مسئولیت محدود




ن سامانه دیجیتال تعمیرکاران خودرو در ایرار


Standard clearance between quarter outer panel and luggage compartment door outer panel: 08A01




Standard clearance between rear door glass outer weather bar and rear side window glass assembly: 05D02



Standard clearance between quarter outer panel and taillight: 09C03




Standard clearance between quarter outer panel and taillight: 09C02



Standard clearance between quarter outer panel and rear door outer panel: 05B02




ن در حريقال خود رو ساماند




Standard clearance between front door glass outer weather


Standard clearance between front door glass outer weather bar and rear door glass outer weather bar: 05C03




Standard clearance between front door outer panel and side turn signal light: 14C



Standard clearance between quarter outer panel and fuel filler door outer panel: 16A




Standard clearance between rear door trim panel and rear wheel arch trim panel: 05F



Standard clearance between rear door outer panel and rear door trim panel: 05E02


يجيتاك خودرو

، دیجیتال خودرو سامانه (مسئولیت محدود




ن سامانه دیجیتال تعمیرکاران خودرو در ایرار


Standard clearance between front door trim panel and side skirt outer panel: 041




Standard clearance between front door trim panel and rear door trim panel: 05C04



Standard clearance between rear door outer panel and rear door trim panel: 05E01




Standard clearance between quarter outer panel and rear wheel arch trim panel: 08D




Standard clearance between quarter outer panel and taillight: 09C01

66


ن در حیتال خود رو سامانه (




Standard clearance between quarter outer panel and rear bumper: 07A




Standard clearance between right of rear bumper and rear wheel arch trim panel: 07E01



Standard clearance between rear bumper and rear wheel arch trim panel: 07E02




Standard clearance between right of rear bumper and rear bumper: 07F



Standard clearance between taillight and rear bumper: 09B


يجيتالـخودرو

، دیجیتال خودرو سامانه (مسئولیت محدود




رسامانه دیجیتال تعمیرکاران خودرو در ایرار


Standard clearance between rear bumper and rear fog light: 07B




Standard clearance between rear bumper towing hook cover and rear bumper: 07C



Standard clearance between luggage compartment door outer panel and rear bumper: 11A02




Standard clearance between taillight and taillight: 09A




Standard clearance between taillight and luggage compartment door outer panel: 10A02




ب دیجیتال خودرو سامانه (مسئولیت محدود




Standard clearance between rear bumper and rear bumper lower trim board: 07G




Standard clearance between luggage compartment door outer panel and rear bumper: 11A01



Standard clearance between luggage compartment door outer panel and taillight: 10A01




Standard clearance between rear windshield and luggage compartment door outer panel: 13C



Standard clearance between luggage compartment door outer panel and taillight: 11B




دیجیتال خودرو سامانه (مسئولیت محدود




ن سامانه دیجیتال تعمیرکاران خودرو در ایرار


Standard clearance between spoiler assembly and rear windshield: 18B



Standard clearance between spoiler assembly and high mounted stop light: 18D



Standard clearance between high mounted stop light and rear windshield: 13D





اولین سامانه دیجیتال تعمیرکاران خودرو در ایران

